

₹

Hitachi VFD Quick Troubleshooting Guide

000819

WWW.mgitech.com

MGI **Technologies** Inc. 275 West 4th Ave, Vancouver, BC Canada

7

Important Application Notes

In general, proper installation and software programming can solve majority of the VFD problems. Before you assume that you have a faulty or bad VFD, please check the following mechanical and electrical conditions:

- Make sure that all electrical connections are tight. They may get loose during shipment or during operation, due to vibration. They can cause poor electrical connection and may cause "Hot Spot" result in failures after power up.
- Make sure that VFD and all the electrical connections are free of debris.
- Make sure that the VFD rated output current is greater than the motor FLA. VFDs are current rated device, not a horsepower rated. Some older motor may have higher than typical FLA that may exceed VFD rating.
- Make sure that supply voltage, VFD rated voltage and motor voltage match.
- Make sure that no power factor correction capacitors are installed between the VFD and the motor. It will damage the VFD if not removed.
- Make sure that no power factor correction capacitors are installed within 100m (300ft) of input to the VFD without a line reactor. They may cause nuisance overvoltage trips.
- Make sure that VFD is installed with ambient temperature no greater than 40°C (104°F). VFD must be de-rated. There must be at least 10cm (4in) of free space around the VFD for cooling. If the VFD is installed in a cabinet, there must be ample amount of space surrounding to ensure proper cooling.
- Make sure that VFD is installed with humidity level within 10~90% non-condensing.
- Make sure that the motor and the load rotate freely. Check for bad bearings, correct belt tension, belt alignment, and/or shaft alignment.
- For 46OVac or 575Vac installations, make sure that the motor specification for the cable length and carrier frequency limitations are okay. A load reactor or a output filter can be installed if necessary.

HITACHI VARIABLE FREQUENCY DRIVE COMMON PROBLEMS

PROBLEM: The VFD keypad display does not light up

SOLUTION

- . Check the input voltage at L1, L2, and L3 terminals. It should be within the VFD nameplate information.
- Check the DC bus voltage at P and N terminals. It should be approximately 1.4 times the input voltage.

208Vac = 294Vdc 46OVac = 65OVdc 575Vdc = 800Vdc

If there is no voltage, input rectifier is damaged and the unit must be repaired.

. Check the connection between the keypad, the control board and the power supply beard.

PROBLEM: The VFD does not run the motor (no output)

Software parameters	J100)300	L100 & SJ100	L300P & SJ300
Frequency set	F2	F2	F01	F001
Freq. Reference Source	F9	F9	A01	A001
Run Command Source	F9	F9	A02	A002

The VFD must have a Frequency Reference set from the keypad, via terminal (0-10Vdc or 4-20mA), potentiometer (if equipped), or preset speeds.

The VFD must have a Run Command from its keypad (RUN key) or via terminal.

SOLUTIONS

- . Make sure that the VFD is not tripped on an error. If it is, press "Stop/Reset" key once to clear the trip. It is recommended to investigate the cause of error prior to running the VFD.
- Check what the Frequency Reference Source is set to. Unless the VFD is a stand-alone unit, it should be set to 'Terminal".
- Check what the Run Command Source is set to. Unless the VFD is a stand-alone unit, it should be set to "Terminal".
- In some application, FRS (Free-Run-Stop, Coast-to-Stop) is set to one of the input terminal of the VFD. Clear the condition that enables FRS.

- . Some VFD systems have interlocks that have to be cleared. Check your system diagram for details.
- Some VFD systems have time delay to commence running. Check your system diagram or system operation guide for details.

PROBLEM: The VFD does not reach the maximum speed (60Hz)

Software parameters	J100	J300	L100 & SJ100	L300P & SJ300
Maximum speed limit	A05	A05	A61	A061
0 end	na	na	Al2	A012
OI end	na	na	Al2	Al02

SOLUTION

- . Check the maximum speed limit is set to 60Hz or 0Hz (Hitachi factory default).
- . Check the 0 end and OI end are set to 60Hz or 0Hz (Hitachi factory default). <if applicable>
- . Check to sure that the motor is not overloaded. If it is, the VFD may be operating in current limit condition.
- Check if the VFD is receiving full-speed reference of 10Vdc or 20mA. If not, see solutions for noise problems.
- . Check if the motor nameplate voltage is within the VFD nameplate. If the motor is a **dual**-voltage motor, make sure that it is wired to correct voltage.
- . Check if the wiring is okay. It may be operating in a single-phase condition. Make sure that wires are not **knicked** or cut during installation. Even the motor is checked and is running fine in bypass mode (across-the-line); the VFD may see a ground fault or over-current condition.

PROBLEM: The VFD trips during Acceleration

Sofhvare parameters	J100	<u> </u>	L100 & SJ100	L300P & SJ300
Acceleration time	F6	F6	F02	F002
Motor receiving voltage	F11	F11	A82	A082
Electronic overload level	A23	A23	b12	b012
Manual torque boost	F8	F8	A42	A042
DC brake enable	na	*	na	A051
DC brake power (start)	na	*	na	A057
DC brake time (start)	na	*	na	A058

^{*} requires DOP, DRW, HOP or HRW high performance keypads or DOP Plus software

Error codes	J100	J300	L100 & SJ100	L300P_&_SJ300_
CC during acceleration	E3	E03 & E33	E03	E03 & E30
Overload	E5	E05	E05	E05

If a large inertia load is accelerate in short period of time, the motor may require more current than what the VFD can supply. In this condition, the VFD trips on either overcurrent or overload depending on severity. In some cases, the VFD may have problems starting with spinning motor.

SOLUTION

- Increase the Acceleration time. Longer acceleration lowers the load on the VFD and the motor; which reduces heat generation. Also, it &ends the life of bells if equipped.
- Check if the motor and the load can be rotated freely. Bad bearings, tight and misaligned belts will cause excessive resistance. Foreign object may impede the operation. These can cause overcurrent condition and must be rectified immediately.
- Make sure that the motor nameplate voltage matches the VFD. Incorrect voltage can cause overcurrent condition and must be rectified immediately.
- Make sure that the Motor Receiving Voltage setting matches the motor nameplate voltage.
 Setting this parameter lower than the nameplate may cause the motor to stall. For 208V motor, choose 215V setting.
 - Check if the thermal overload level is set correctly. If it is, increase the acceleration time,, and/or check the motor load.
- Check the Manual torque boost setting. You may have to increase or decrease depending on the situation. If the motor does not turn over 10Hz, increase the setting. If the motor turns, decrease the setting.
- If the motor and the load are spinning and the VFD is having a problem starting, wait until slow down or DC injection braking at start (not available on 3100, L100 and \$J100 series) may be introduced to slow it down.

PROBLEM: The VFD trips during Deceleration

Software parameters Deceleration time	<u>J100</u> F7	<u>J300</u> F7	L100 & SJ100 F03	L300P & SJ300 F003
Error codes	J100	J300	L100 & SJ100	L300P & SJ300
Overvoltage	E7	E07	E07	E07
Dynamic brake overload	E6	E06	E06*	E06
OC during deceleration	E2	E02 & E32	E02	E02 & E30

If a large inertia load is decelerated in short time, it will regenerate energy and acts as a generator. This will increase the DC bus voltage of the VFD and may cause DC bus overvoltage trip.

SOLUTION

- . Increase the Deceleration time. Longer deceleration lowers the load on the VFD and can increase the life of its components.
- If rapid deceleration is required, a dynamic braking unit may be used. Contact your supplier for details.

NOTE: "Dynamic Brake Overload" error may appear if the DC bus voltage level is lower than "Overvoltage" trip level and the condition lasts for extended period of time. This voltage level is only slightly lower than the overvoltage trip level and must be rectified to eliminate nuisance trips.

PROBLEM: VFD current readout does not match the clamp on meter values

Software parameters	J100	J300	L100 & SJ100	L300P & SJ300
Output current	F1	d 02	d02	d002
Output voltage	na	na	na	d013

Due to non-sinusoidal (PWM) output waveform and the harmonic content, many Fluke, Amprobe or other digital meter display erratic values. To obtain accurate readings, a True RMS or analog meter can be used. The VFD readings display an average of all three phases and are fairly accurate.

NOTE: Due to the current measurement and the calculation method used within the VFD processor, L100 and SJ100 series VFD may show higher current than normal under SO% full load of the VFD.

PROBLEM: Return Fan VFD trips on Overvoltaae under constant speed

Under certain control scenarios, the supply fan demands more airflow from the return fan can supply at, certain speed. This can cause the return fan to spin faster than what the VFD outputting to fun and causes regeneration of energy back to the VFD. Extended operation in this condition will cause the DC bus voltage to increase and will trip on overvoltage.

SOLUTION

- . In general, the supply and the return fans should be operating within 20Hz of each other.
- . Start both fans at same time and at same acceleration and deceleration time.
- . Install Dynamic Brake Unit if fan operating speeds cannot be within 20Hz

PROBLEM: The frequency reference signal gets "pulled down"

A frequency reference signal (0-10Vdc or 4-20mA) can get noise induced. This may 'pull down" the signal to give erratic speed reference.

Solutions

ق

- Install shielded cable for all analog signal lines. Shield of the wire must be ground at the common at one side only. Try both ends once at a time because depending on installation, grounding the shield at the source or receiving end may show different results.
- . Keep analog signal lines away from 120Vac and power (208, 230, 460 or 575Vac) lines. They can induce noise to analog signal lines. Keep at least 10cm (4in) away if installed parallel to those lines. If lines must be crossed, keep a right angle as much as possible. In some installation, can induce more than 200Vac on the signal line if two lines are installed parallel to each other.
- . Install a **0.1**uF capacitor between the positive and negative of the signal terminals. Depending on installation, it may yield best result if installed at the source, at the receiving end or at both ends.
- . Install small inductor in line with analog signal lines. Depending on installation, it may yield batter result if installed in positive line, in common line or in both lines.

NOTE: Installation of both a capacitor and an inductor may cause to resonate and may worsen the condition.

PROBLEM: Others

There many other problems you may experience. In ordered to assist you better, please record all the error codes, values, time of error occurred or any other information that may cause the problem.



MGI Technologies Inc. Integrated VFD System Commissioning Manual < Hitachi >

- 1) Integrated VFD system diagrams
- 2) Commissioning manual
- 3) MGI standard system operation and troubleshooting manual
- 4) MGI system with bypass option operation and troubleshooting manual
- 5) MGI system routine maintenance guide
- 6) MGI system product manuals
- 7) Hitachi 5300 series manual
- 8) Hitachi L100 series manual
- 9) Hitachi L300 Plus series manual
- 10) Hitachi VFD software parameter list






MGI rechnologies Inc.


MGI Integrated VFD System Diagrams

000525

WWW.mgitech.com

MGI Technologies Inc. 275 West 4th Ave, Vancouver, BC Canada









Commissioning Manual

000525

WWW.mgitech.com

MGI Technologies Inc. 275 West 4th Ave, Vancouver, BC Canada

MGI - Hitachi VFD System Commissioning Manual

To properly **commission** the MGI – Hitachi VFD System, you will require following items:

- · Quality tools
- Digital multimeter capable to measure up to 1000Vac and dc
- Clamp-on ammeter
- Megger
- 0- 1 0Vdc and 4-20mA signal generator

Following items are optional:

- DOP or DRW keypad with adapter for L100 and L300Plus
- DOP Plus PC software

Please use the MGI - Hitachi VFD System Commissioning Report sheet. To provide better service and fof warranty purpose, please complete and return the sheet for each VFD unit commissioned to the MGI Service Department.

PRE-POWER-UP CHECKS

Record the nameplate information. Be sure that the VFD full load current capacity is greater than the **motor** rating.

Contact information

- Your **company** name and the service technician who commissioned the VFD.
- Customer's name
- Project site information

Nameplate information

- VFD system nameplate data, tag name, location, application, etc
- VFD nameplate data
- Motor nameplate data

Following installation conditions must be met unless the system is designed for such conditions:

Environment

- Ambient temperature is within -10° C $\sim 40^{\circ}$ C $(14^{\circ}$ F $\sim 104^{\circ}$ F).
- Humidity is within 20% ~ 90%, non-condensing.
- Adequate ventilation, no corrosive or dusty environment.
- Protection against water source. (i.e. sprinkler, pipes, vent holes)
- Tidiness of the unit, no loose wire, metal or any foreign objects inside.

Power supply, Wirine & Motor

- . A line reactor is required if:
 - 9 The **kVA** rating of the supply transformer is greater than 10 times the **kVA** rating of the VFD.
 - 9 Supply transformer is greater than 500kVA.
 - 9 The supply voltage is 575Vac.
- Completion of **field** wiring. Check for their size, termination and installation method.
- . Check electrical connections, mounting bolts, nuts and screws. They may become loose during shipping.
- . Check for the proper grounding.
- The motor should be meggered.
- . Determine the application of the motor, constant torque or variable torque.
- . A load reactor and/or filter is required if:
 - 9 575Vac application.
 - 9 460Vac application with cable longer than **50ft**.
 - 9 Load reactor may not be necessary if inverter duty motor is used. Check with motor specification.

POWERED CHECKS

Power Supply

Without applying the power to the VFD, measure the line voltages:

- L1-L2
- . L1-L3
- L2-L3

They should be within 3% of each other and 10% of the VFD nameplate rating.

If the line voltage is within the VFD rating, apply the power to the VFD. Measure the line voltages again and record the readings. Measure the DC bus voltage across P(+) and N(-) terminals.

Software Programming

Check and program all necessary software parameters such as acceleration & deceleration time, application (constant & variable torque), carrier frequency, motor voltage, and thermal overload level. Incorrect software programming may result in equipment malfunction or damage. Record any changes to the software for future reference.

Motor Rotation

Check if the system can be operated at full speed. In some systems, full speed operations require special procedures, otherwise damages to other equipment may occur.

Check the direction of motor rotation in both the VFD and the BYPASS mode. Record the Free Run Stop (Coast-to-stop) time. If the rotation is incorrect follow the procedure below:

	Rotation is fine in the VFD	Rotation is reverse in the
	mode	VFD mode
Rotation is fine in the	No wiring changes required	Swap two phases at both
Bypass mode		input and output of the unit.
Rotation is reverse in	Swap two phases at the	Swap two phases at the
the Bypass mode	input of the unit.	output of the unit.

Motor Current

Check the motor current in both the VFD and the BYPASS operation. Depending on the digital clamp on ammeter, readings may not be accurate in the VFD operation due to frequency content of the output waveform. Use the VFD current monitor display. Other than the inrush current, the motor should not draw more than its FLA rating.

Input and Output Signals

ė

Check both the input and the output signals for correct and accurate operation,

- Check the accuracy of **0-10Vdc** or 4-20mA speed reference input.
- Run command.
- Customer interlock.
- Preset speed, if required.
- Check the accuracy of **0-10Vdc** or 4-20mA feedback.
- RUN status feedback.
- AT SPEED status feedback.
- FAULT status feedback.
- VFD mode status feedback.
- BYPASS mode status feedback.

Operator switches and Indicator lights

Check all operator switches and indicator lights for correct operation,

Commissioning Wrap-up

To complete the commissioning of the VFD system, check the following:

- . Software parameter setting is recorded.
- VFD manual in the enclosure pocket.
- VFD system wiring diagram in the system.
- Instruction manuals for other devices are in the enclosure pocket.
- Record any other changes made to the system.
- Complete the MGI VFD System Commissioning Report.

You must send the MGI VFD System Commissioning Report and the VFD parameter sheet to MGI to register the warranty extension.







MGI Standard VFD System Operation and Troubleshooting Manual

000525

WWW.mgitech.com

MGI Technologies Inc. 275 West 4th Ave, Vancouver, BC Canada

Integrated VFD System with Hand-Off-Auto Option Operation Manual

Thank you for purchasing MGI Integrated VFD System with Hand-Off-Auto Option. This operation manual guides you through basic operation of this package.

- Note - MGI Integrated VFD Systems are custom built for your specific needs. Your unit may have additional features not mentioned in this manual.

Modes of operation

This unit is equipped with Hand-Off-Auto selector switch. This switch enables you to select the source of operation commands such as RUN and FREQUENCY commands.

Operation of the VFD in "HAND" mode

The "HAND" mode is sometime referred to as "LOCAL" mode. In this mode, both the "Run Command" and the "Frequency Reference" are provided the controls on the VFD package. It is commonly used if your building management system is not functioning but you would like to operate the equipment manually. The "Run Command" is initiated as soon as you select the "HAND-OFF-AUTO" operator to "HAND" position and the Speed Pot can be used to set the desired speed.

Operation of the VFD in "OFF" mode

In this mode, the VFD will be powered but no operation will be performed. This mode is used when software programming of the VFD is required.

Operation of the VFD in "AUTO" mode

The "AUTO" mode is sometime referred to as "REMOTE" mode. In this mode, both the "Run Command" and the "Frequency Reference" is provided by the building management system. Normally, this is the setting you would select and the building management system will take care the rest for you.

ŝ

Integrated VFD System with HOA Option Troubleshooting Guide


This section guides you to troubleshoot the MGI Integrated VFD System with HOA Option.

To troubleshoot the VFD unit itself, please refer to the VFD troubleshooting manuals for each VFD model types.


!! WARNING !!

Some troubleshooting procedures require the system to be powered and its door to be opened to perform the test. There are multiple circuits that may be powered at any given time. Follow standard safety procedures to prevent any damage to the equipment or personal injuries.

1. When the motor does not operate



~








MGI VFD System with Bypass Option Operation and Troubleshooting Manual





000525

WWW.mgitech.com

MGI Technologies Inc. 275 West 4th Ave, Vancouver, BC Canada

Integrated VFD System with Bypass Option Oneration Manual

Thank you for purchasing MGI Integrated VFD System with Bypass Option. This operation manual guides you through basic operations of this package.

- **Note** - MGI Integrated VFD Systems are custom built for your specific needs. Your unit may have additional features not mentioned in this manual.

SELECTOR SWITCHES

VFD – OFF – BYPASS selector switch

This switch enables you to select one of following operations:

I. VFD position: Enables variable speed operation of the motor using the VFD. Normally,

this is the mode you would select to operate this unit.

2. OFF position: No motor operation in this position. This mode used when you want to

power down the motor.

3. BYPASS position: Across-the-line (full speed) operation for the motor and no variable speed

regulation. This mode is used when the VFD is not functioning but you

would like to operate the motor.

HAND - OFF- AUTO selector switch

This switch enables you to select the source of operation commands such as RUN and FREQUENCY commands. This switch enables you to select one following operations:

1. HAND position: Sometime referred as LOCAL mode. The motor operations are

performed manually.

2. OFF position: No operation in this position,

3. AUTO position: Sometime referred as REMOTE mode. The motor operations are

performed using remote controller such as PLC or building management

system.

OPERATION IN VARIOUS MODES

Operation of the VFD in "HAND" mode

In this mode, both the "Run Command" and the "Frequency Reference" are provided by the controls on the VFD package. This mode is commonly used if your building management system is not functioning but you would like to operate the equipment manually. The "Run Command" is initiated as soon as you select the "HAND-OFF-AUTO" operator to "HAND" position. In the VFD mode, the Speed Pot can be used to set the desired speed.

Operation of the VFD in "OFF" mode

In this mode, the VFD will be powered but no operation will be performed. This mode is used when software programming of the VFD is required.

Operation of the VFD in "AUTO" mode

In this mode, both the "Run Command" and the "Frequency Reference" is provided by the building management system. Normally, this is the setting you would select and the building management system will take care the rest for you.

Operation of the BYPASS in "HAND" mode

In this mode, switching "H-O-A" switch from "OFF" to "HAND" enables the BYPASS operation.

Operation of the BYPASS in "OFF" mode

No operation of the motor will be performed.

Operation of the BYPASS in "AUTO" mode

In this mode, the BYPASS operation is controlled by the building management system.

In case of VFD errors

•

VFD will trip to protect itself or the load (motor) if abnormal condition occurs. When it trips, the VFD will lock itself out and require a manual reset by pressing the "STOP/RESET" button. Before you reset the VFD, please log the error message and other error data. Error information is important to correct the problem from happening again. Please use supplied log sheet.

VFD Error Log Sheet (EXAMPLE)

Equipmen	t J300-075HFU Bypass Package	Serial Number ME-12345-2	
Tag	AHU-2		

Date Page Pa	Time of Section acknowledgeme	Trip cause	Frequency	Currenti Currenti	Yoltage (Run time)	Notes
An example for the	e standard operator	кеураб.					, , , , , , , , , , , , , , , , , , ,
January 1, 2000	8:00 AM	E05	54.3Hz	18A	78U	na	Happened between 6:00am to 7:30am
	<u> </u>						
An example for the	B DOP, HOP and S	C-OPE operator key	pad.			·	·
January 1, 2000	8:00 AM	Over V	34.5Hz	12.3A	852.4V	1Y 234D	Happened during Generator test

Repeated fault condition will stress the unit and may lead to the VFD failure. If same type of faults appear frequently, contact your local service representative and have the cause of the problem corrected immediately.

In case of VFD failure

If the fault condition is severe enough, the VFD may be permanently damaged. Also, water, dust, or metal objects entering the package may damage the unit. If these conditions occur, contact your local service representative for an inspection and a repair.

Integrated WD System with Bypass Option Troubleshooting Manual

This manual guides you to troubleshoot the MGI Integrated VFD System with Bypass Option. This section is divided into two:

- 1. When the motor does not operate in the "VFD mode".
- 2. When the motor does not operate in the "BYPASS mode".

To troubleshoot the VFD unit itself, please refer to the VFD troubleshooting manuals for each VFD model types.


WARNING!!


Some troubleshooting procedures require the package to be powered and its door to be opened to perform the test. There are multiple circuits that may be powered at any given time. Follow standard safety procedures to prevent any damage to the equipment or personal injuries.

1. When the motor does not operate in the "VFD mode".

چَ


:1,






2. When the motor does not operate in the "BYPASS mode",

 \mathfrak{S}



₫

Ê







HITACHI



MGI VFD System Routine Maintenance Manual

000525

WWW.mgitech.com

MGI Technologies Inc. 275 West 4th Ave, Vancouver, BC Canada

Integrated VFD System Routine Maintenance Guide

To maintain reliable operation, the equipment must be routinely checked. Following is the maintenance procedure under normal condition. If the installation environment is severe, such as dusty condition or vibrating mounting fixture, more frequent maintenance is required.

Every six (6) months if continuous operation, every three (3) months if operated less than 24 hours a day

- Check power wire connections at following locations. Tighten if necessary.
 - 9 VFD terminal
 - 9 Line and **load** reactors, if equipped
 - 9 Contactors, if equipped
 - 9 Output filter, if equipped
 - 9 Disconnect, if equipped
 - **9** Thermal overload, if equipped
 - 9 Input and output terminal, if equipped
- Check ventilation filter if equipped. Clean and replace it if necessary.
- Check for the cleanness of the VFD heatsink. In dusty environment, the **heatsink** may be clogged and may cause overheating problem.
- Check the indicator lights if they are the incandescent-type bulbs. **Replace** if necessary.

If the equipment is operated less than 24 hours a day, heating and cooling of equipment cause expansion and contraction of components. This increases the possibility of connections getting loose.

Every twelve (12) months

- Check the VFD cooling and package cooling fans if equipped. If it is making too much noise (i.e. squeaking, grinding, etc), replace it.
- Check electrolytic capacitors (i.e. DC bus capacitors, power supply capacitors) for leakage or bulging. Replace if necessary.




HOA MODULE

SA-HOA-MOD-A

Operator's Manual

HIDGOM VOI



000819

WWW.mgitech.com


MGI Technologies Inc. 275 West 4th Ave, Vancouver, BC Canada

Hand-Off-Auto Module: Model SA-HOA-MOD-A

Introduction

MGI's Hand-Off-Auto module, SA-HOA-MOD-A, is designed to operate with Hitachi VFDs. It is designed to mount on to the front door of the enclosure with all operators and indicator lights clearly marked. The rocker style selector switch and the potentiometer provide solid and easy operation; seven high brightness LED indicator lights monitor the system status. All connections to the Hand-Off-Auto Module are made with quick connectors for fast and reliable installation.

Figure 1 Front view of the Hand-Off-Auto Module.



Features

Ę.


Operator Controls			
Control	<u>Function</u>		
HAND-OFF-AUTO selector	Sets system to HAND, OFF or AUTO mode		
SPEED POT potentiometer	Sets FD frequency when HAND mode is selected		

Diagnostic Indicator Lights				
	l iaht	I ON Status		
VFD ON		When VFD is powered		
CONTROL TYPE	HAND	When in "HAND" mode		
	AUTO	When in "AUTO" mode		
VFD RUN		When VFD is running		
	AT SET SPEED	Whe VFD reaches Set Speed		
	FAULT	When VFD experiences a Fault Condition		
	EXT. FAULT	When external fault condition is received (e.g. Freeze		
		status, Smoke status). VFD will not operate motor until		
		fault, clears		


	Drv Contact Outputs	,		
Contact Designation)	Туре	Rating	
RSO- RS1	Closes when VFD is running	N/O	30Vdc 2A	
FAO-FA1	Closes when VFD reaches Set Sp	eed	N/O	30Vdc 2A
RRA – RRS	Closes when VFD receives 'RUN"	command	N/O	30Vdc 2A
EXO –EX1	Closes when system re ives 'Ex input	ternal Fault"	N/C	30Vdc 2A
EX2 – EX3	Opens when system receives 'Ext input (used for internal wiring of th not available for external connecti	e package,	N/0 3	0Vdc 2A
FRO – FR1 – FR2	Contacts change state when VFD Condition occurs FRO, FR1 – closes in faultconditio FRO, FR2 -opens in fault conditio	N/O & N/C	30Vdc 2A	
HRO -HR1	Closes when system is in "HAND"	mode	N/O	30Vdc 2A

Dip Switch setting

The DIP switch, **DP1**, must be set correctly depending on the VFD model and the type of frequency reference signal Follow the chart below for settings.



Circuit diaaram for SA-HOA-MOD-A Hand-Off-Alto Module



٤




BYPASS MODULE

SA-BPMO-B

Operator's Manual





000604

WWW.mgitech.com

MGI Technologies Inc. 275 West 4th Ave, Vancouver, BC Canada

C

BYPASS MODULE: Model SA-BPMO-B

1. INTRODUCTION

MGI's Bypass Module, the SA-BPMO-B, is designed to operate with 2 or 3 contactor bypass system using Hitachi VFD. It is designed to mount on to the front door of the bypass enclosure with all operators and indicators clearly marked. Four rocker switches and one potentiometer provide solid and easy operation; twelve high brightness LED indicator lights monitor the system status, All connections to the Bypass Module are made with plug-in quick connectors, for fast and reliable installation. Other features such as "VFD TEST MODE", "BYPASS AUTO START" and adjustable time delay for the VFD run command are built into the Bypass Module.




Figure 1

Front view of the Bypass Module

FEATURES

: 2.1 OPERATOR SWITCHES AND SPEED-POT

Control	Function
VFD-OFF-BYPASS selector	Sets system to VFD, OFF or BYPASS mode
HAND-OFF-AUTO selector	Sets system to HAND, OFF or AUTO mode
VFD TEST MODE-OFF-NORMAL OPERATION selector	Sets system to VFD TEST MODE, OFF or NORMAL OPERATION mode. While in VFD TEST MODE, the motor can be run in BYPASS mode.
BYPASS AUTO START - NORMAL OPERATION selector	Sets system to BYPASS AUTO START or NORMAL mode. If AUTO START is selected, the system will switch to Bypass mode in an event of VFD faults automatically.
SPEED POT potentiometer	Sets VFD frequency when VFD and HAND modes are

٤

‡

indicat	or Light	ON Status
POWER ON		When control power is applied to the Bypass Module
EXT. FAULT		When external fault signal is received (e.g. Freeze status, Smoke
		status). Motor cannot run until fault clears.
CONTROL TYPE	- HAND	When in "HAND" mode
	- AUTO	When in 'AUTO" mode
VFD	-ON	When VFD is powered
	- RUN	When VFD receives a Run command
	-AT SET SPEED	When VFD reaches Set Speed
	FALULT	When VFD experiences a Fault Condition
	-TEST MODE	When VFD TEST MODE is selected
BYPASS	-ON	When System is in BYPASS mode
	- O/L FAULT	When thermal Overload Relay is in Fault Condition
	- AUTO START	When BYPASS AUTO START mooe is selected

Note: The "RUN" and "At SET SPEED" indicators are available if the MG-PSRM-A is used with the Bypass Module.

2.3 BYPASS SYSTEM STATUS -DRY CONTACT OUTPUTS

Contacts	Contact Function	Type	Rating
RRA - RRB	Closes when VFD receives "RUN" command	N/O	30Vdc 2A
EXO-EX1	Closes when system receives "External Fault" input	NIC	30Vdc 2A
FRO – FR1– FR2	Contacts change state when VFD fault condition occurs	NIO & NIC	30Vdc 2A
HRO-HR1	Closes when system is in "HAND" mode	N/O	30Vdc 2A
BP0 - BP1	Closes when system is in "BYPASS" mode	N/O	30Vdc 2A

NOTE: Do **not use these dry contact outputs for voltages higher then 30Vdc.** For a **120Vac** system, install a relay rated for **120Vac**.

3. OPERATION OF THE BYPASS SYSTEM

,3.1 VFD OPERATION

- . "VFD TEST MODE-NORMAL OPERATION" switch in the "NORMAL OPERATION" position.
- · "VFD-OFF-BYPASS" switch in the "OFF" position
 - Contactors 1 M, 2M and 3M will open. The motor will not operate in both the VFD and the Bypass mode.
- · "VFD-OFF-BYPASS" switch in 'VFD" position
 - Contactors 1M and 2M will close and contactor 3M will open. Connects the power to the VFD input and connects the VFD output to the motor.
 - The VFD "ON" indicator light and the digital operator will light up.
- . "HAND-OFF-AUTO" switch in the "OFF" position
 - The Run command cannot be initiated. VFD is in the stand-by-mode.
 - The Frequency can be set via the speed potentiometer.
 - Motor will not run or will decelerate to stop.

.

ن

2,

- "HAND-OFF-AUTO" switch in the "HAND" position
 - "HAND" indicator light will light up.
 - The Run command is closed and the VFD accelerates to the frequency set by the speed pot.
 - "RUN' and "AT SET SPEED" indicator lights will light up when the Bypass Module is used with the MG-PSRM-A Power Supply/Relay Module. (Exception: When used with Hitachi J100 series VFD, only one of the signals can be displayed)
- "HAND-OFF-AUTO" switch in "AUTO" position.
 - "AUTO" indicator light will light up.
 - The Frequency setting command is received from an external 0-IOVDC or 4-20mA analog signal connected to terminals, Land VFS or L and CFS respectively.
 - The Run command is applied by externally controlled, N/O dry contact connected to terminals 7 and 8.

NOTE:

The "VFD FAULT" indicator light will light up when the VFD is in the fault mode.

The "VFD TEST MODE-OFF-NORMAL OPERATION" switch must be in the "NORMAL

OPERATION" position for the motor to run in the VFD mode.

3.2 BYPASS OPERATION

- · "VFD-OFF-BYPASS" switch in the "BYPASS" position
 - "BYPASS ON" indicator light will light up.
- . "HAND-OFF-AUTO" switch in the 'OFF" position
 - Contactors 1M, 2M and 3M will open. No operation of the motor
- . "HAND-OFF-BYPASS" switch in "HAND " position
 - "HAND" indicator light will light up.
 - Contactor 3M will close and will operate the motor under full speed
 - Contactors **1M** and **3M** will remain open.
- . "HAND-OFF-AUTO" switch in the "AUTO" position
 - "AUTO" indicator light will light up.
 - Contactor 3M will close when an external run command is initiated and will operate the motor under full speed.
 - Contactors 2M and 3M will remain open.

3.3 VFD TEST MODE

- "VFD TEST MODE-OFF-Normal Operation" switch in the "VFD TEST MODE" position
 - Contactor **1M** will close and apply power to the VFD.
- . "VFD-OFF-BYPASS" switch in the VFD or OFF position
 - No motor operation.
- . "VFD-OFF-BYPASS" switch in the "BYPASS" position.
 - Contactor 3 M will close and operate the motor under full speed.

NOTE:

In order to run the motor in the 'VFD" mode after the "VFD Test Mode", the run command must to be removed by switching the "HAND-OFF-AUTO" switch to the "OFF" position. Once the VFD output frequency has decelerated to 0Hz, the system is ready to operate in the "VFD" mode.

3.3 AUTO BYPASS START OPERATION

€*

- "BYPASS AUTO START-NORMAL OPERATION" switch in the "BYPASS AUTO START" position
 - "BYPASS AUTO START" indicator light will light up.
 - In an event of VFD faults, contactors 1M and 2M will open and contactor 3M will close automatically, switching the system operation from VFD mode to BYPASS mode.

3.5 FRS (Free Run Stop) OPERATION


- FRS (coast-to-stop) operation can be enabled by selecting the Switch 8 of DS1DIP switch to the "ON" position.
- When the Run command is opened, the motor will free-run to stop.

3.6 TIME DELAY FOR RUN COMMAND


 Power interruption may cause occasional VFD trips. Trips are caused by the run command being applied to the VFD before the DC Bus and internal power supply output is stabilized. There is a time delay function for the run command built into the Bypass Module to reduce trips. The time range (approximately O-12 seconds) can be set via the R4 trim potentiometer. The delay time is factory set and should not require any field adjustment.

4. DIP SWITCH SETTING

The DIP switch, DP1, must be set correctly depending on the VFD model and the type of frequency reference signal. Follow the chart below for settings.



3. ELECTRICAL DIAGRAM of the SA-BPMO-B, BYPASS MODULE







Power Supply - Relay Module

PSRM - A

POWER SUPPLY - RELAY MODULE

Operator's Manual

000004

WWW.mgitech.com

MGI Technologies Inc. 275 West 4th Ave, Vancouver, BC Canada

gr. .

Power Supply Relay Module: ME-PSRM-A

INTRODUCTION

This module is design to operate with any collector (solid state) type output rated at 24VDC of the inverter. It can provide sets of normally open dry contacts and output for 24VDC pilot lights for two separate inputs.

Also, there is 24VDC power (up to 100mA) available for additional relays, SC-OPE unit or transducers as required.




Figure 1. Typical interconnection of the Power Supply Relay Module with Hitachi 5300 series inverter.

I/O TERMINALS DESCRIPTION

L1 & L2 120VAC power input. +24 & COM 24VDC *output*.

RUN, FA, & COM 24VDC outputs for "RUN" and "FA" (Frequency Arrival) pilot lights.

* Power to the "RUN" is available when VFD is operating the motor.*

*Power to the "FA" (Frequency Arrival) is available when VFD is operating at

the set speed.*

111, 121, & CM2 Inputs, "11", "12", and "CM2", from the inverter.

RSO, RSI "RUN" status dry contact output. Closes when the VFD is operating the motor. FAO, FAI "FA" (Frequency Arrival) status dry contact output. Closes when the VFD is

operating at the set frequency.

SPECIFICATIONS:

Input voltage: 120VAC (also available with 240VAC)

Relay contact ratings: 0.5A at 125VAC

2A at 30VDC

Minimum load 10uA, 10mVDC

DC Power Supply: 24VDC, maximum load 100mA including indicator lights "RUN" and "FA".

NOTE LED type indicator lamp is recommended to minimize the load on the power supply



SINE WAVE FILTER

MG-SWFI-A Series

SAFENE FILER

Instruction Manual and Operation Guide

000604

WWW.mgitech.com

MGI Technologies Inc. 275 West 4th Ave, Vancouver, BC Canada

MG-SWFI-A Series LRC Sine Wave Filter

Introduction

In **IGBT** VFD applications with long motor cables, a phenomenon called voltage amplification occurs. This phenomenon causes the motor terminal voltage to increase as high as three times the DC bus voltage of the VFD. This high voltage can lead to motor winding insulation breakdowns. The severity of this condition varies with the system voltage, cable length, motor surge impedance, cable surge impedance, and voltage rise time.




Fig. 1: Typical LRC Sine Wave Filter connection

The MG-SWFI-A series LRC sine wave filter includes a RC component combined with a 5% impedance reactor. It is designed to operate with VFDs at high carrier frequencies for whisper-quiet operation of the motor. See Table 1 for recommended carrier frequency setting.


Advantages of using the MG-SWFI-A LRC Sine Wave Filter

- . produces sinusoidal current and voltage waveforms
- . protects motor insulation breakdown due to voltage stress
- . motor runs cooler and quieter
- extends the life of the motor
- reduces losses in the motor
- reduces shaft current
- · reduces harmonic leakage current in the cable
- eliminates cable length restrictions caused by voltage amplification

The MG-SWFI-A LRC Sine Wave Filter eliminates all the headaches with <code>dv/dt</code> and peak voltage by converting the PWM output waveform into a near sinusoidal voltage waveform. The peak motor terminal voltage with the <code>MG-SWFI-ALRC</code> Sine Wave Filter is equal to the DC bus voltage of the VFD, which equals to the line voltage. See Fig. 2, 3 and 4 for the differences in performance.

Vp da 600 A/C class motor terminal voltage

- . Fig. 2 with no reactor and no LRC filter, 150 ft of motor cable
- Fig. 3 with load reactor only and 250 ft of motor cable
- Fig. 4 with the MG-SWFI-A LRC Sine Wave Filter and 250 ft of motor cable



20 Citi: 549 Vol. 5 ds

Fig. 3

Fig. 4


Table 1: MG-SWFI-A Series LRC Sine Wave Filter Selection and Carrier Frequency Setting Chart

Motor	Нр	LRC Sine Wave Filter	Reactor	RC Component	Minimum carrier	Recommended
575V	460V	P/N	P/N	P/N	frequency	Carrier frequency
1	1	MG-SWFI-002-3-A	RL-00203	MG-RCFI-055-A	8 kHz	14-16 kHz
2	2	MG-SWFI-004-4-A	RL-00404	MG-RCFI-055-A	6 kHz	14-16 kHz
3	NA	MG-SWFI-004-3-A	RL-00403	MG-RCFI-055-A	6 kHz	14-16 kHz
5	3	MG-SWFI-008-4-A	RL-00804	мG-RCFI-055-A	6 kHz	14-16 kHz
7.5	5	MG-SWFI-008-3-A	RL-00803	MG-RCFI-055-A	6 kHz	14-16 kHz
10	7.5	MG-SWFI-012-3-A	RL-01203	MG-RCFI-110-A	12 kHz	14-16 kHz
15	10	MG-SWFI-018-3-A	RL-01803	MG-RCFI-110-A	12 kHz	14-16 kHz
20/25	15	MG-SWFI-025-3-A	RL-02503	MG-RCFI-220-A	14 kHz	14-16 kHz
30	20/25	MG-SWFI-035-3-A	RL-03503	MG-RCFI-220-A	14 kHz	14-16 kHz
40	30	MG-SWFI-045-3-A	RL-04503	MG-RCFI-300-A	12 kHz	12-16 kHz
50	40	MG-SWFI-055-3-A	RL-05503	MG-RCFI-300-A	12 kHz	12-16 kHz
60/75	50/60	MG-SWFI-080-3-A	RL-08003	MG-RCFI-450-A	10 kHz	12-16 kHz


Notes:

- 1) MG-SWFI-A LRC Sine Wave Filters are supplied with a reactor and a RC component.
- MG-SWFI-A LRC Sine Wave Filters operate more efficiently at higher carrier frequency. It is recommended to set the carrier frequency higher than the specified minimum setting.

<u>Dimensions for Open-Type MG-SWFI-080-3-A LRC Sine Wave Filter</u>




<u>Dimensions for Open-Type LRC Sine Wave Filter up to MG-SWFI-055-3-A</u>



LRC Sine Wave		Dimensions (mm/in)				
Filter P/N	L	L1 or 2L1	W	W1	H	
MG-SWFI-002-3-A	270/10.7	230/9.0	165/6.5	145/5.7	122/5.7	
MG-SWFI-004-4-A	270/10.7	230/9.0	165/6.5	145/5.7	122/5.7	
MG-SWFI-004-3-A	270/10.7	230/9.0	165/6.5	145/5.7	122/5.7	
MG-SWFI-008-4-A	270/10.7	230/9.0	165/6.5	145/5.7	145/5.7	
MG-SWFI-008-3-A	270/10.7	230/9.0	165/6.5	145/5.7	145/5.7	
MG-SWFI-012-3-A	310/12.2	270/9.0	165/6.5	145/5.7	145/5.7	
MG-SWFI-018-3-A	310/12.2	270/9.0	165/6.5	145/5.7	165/6.5	
MG-SWFI-025-3-A	380/15.0	165/6.5	180/7.0	165/6.5	165/6.5	
MG-SWFI-035-3-A	380/15.0	165/6.5	180/7.0	165/6.5	204/8.0	
ME-SWFI-045-3-A	380/15.0	165/6.5	180/7.0	165/6.5	234/9.0	
MG-SWFI-055-3-A	380/15.0	165/6.5	180/7.0	165/6.5	230/9.0	
MG-SWFI-080-3-A	508/20.0	230/9.0	410/16.2	380/15.0	285/11.2	

Dimensions for Enclosed-Type LRC Sine Wave Filter

'n



LRC Sine	•	Dimensions (mm/in)				
Wave Filter P/N	W	W1	Н	H1	D	
ME-SWFI-002-3-A	260/10.2	1240/9.5	310/12.2	280/11.0	180/7.0	
ME-SWFI-004-4-A	260/10.2	1240/9.5	310/12.2	280/11.0	180/7.0	
ME-SWFI-004-3-A	260/10.2	1240/9.5	310/12.2	280/11.0	180/7.0	
ME-SWFI-008-4-A	260/10.2	1240/9.5	310/12.2	280/11.0	180/7.0	
ME-SWFI-008-3-A	260/10.2	1240/9.5	310/12.2	280/11.0	180/7.0	
ME-SWFI-012-3-A	260/10.2	1240/9.5	310/12.2	280/11.0	180/7.0	
ME-SWFI-018-3-A	260/10.2	1240/9.5	310/12.2	280/11.0	180/7.0	
ME-SWFI-025-3-A	310/12.2	340/14.2	360/13.4	310/12.2	230/9.0	
ME-SWFI-035-3-A	310/12.2	340/14.2	360/13.4	310/12.2	230/9.0	
ME-SWFI-045-3-A	310/12.2	340/14.2	360/13.4	310/12.2	230/9.0	
ME-SWFI-055-3-A	310/12.2	340/14.2	360/13.4	310/12.2	230/9.0	
ME-SWFI-080-3-A	590/23.2	560/22.0	510/20.0	460/18.0	305/12.0	

HITACHI INVERTER

J300 SERIES

INSTRUCTION MANUAL

Three phase input 200/400V class

J300 U: USA version

After reading this manual, keep it at hand for future reference.

NB506XC

Hitachi, Ltd.

Tokyo Japan

SAFETY

For the Best Results with J300 Series inverter, read this manual and all of the warning sign attached to the inverter carefully before installing and operating it, and follow the instructions exactly. Keep this manual handy for your quick reference.

Definitions and Symbols

A safety instruction (message) is given with a hazard alert symbol and a signal word; WARNING or CAUTION. Each signal word has the following meaning throughout this manual.



This symbol means hazardous high voltage. It used to call your attention to items or operations that could be dangerous to your and other persons operating this equipment.

Read these message and follow these instructions carefully.



This is the "Safety Alert Symbol." This symbol is used to call your attention to items or operations that could be dangerous to your or other persons operating this equipment. Read these messages and follow these instructions carefully.



WARNING

WARNING

Indicates a potentially hazardous situation which, if not avoided, can result in serious injury or death.



CAUTION

CAUTION

Indicates a potentially hazardous situation which, if not avoided, can result in minor to moderate injury, or serious damage of product.

The matters described under **CAUTION** may, if not avoided, lead to serious results depending on the situation. Important matters are described in CAUTION (as well as WARNING), so be sure to observe them.

NOTE

NOTE: Notes indicate an area or subject of special merit, emphasizing either the product's capabilities or common errors in operation or maintenance.



HAZARDOUS HIGH VOLTAGE


Motor control equipment and electronic controllers are connected to hazardous line voltages. When servicing drives and electronic controllers, there might be exposed components with cases or protrusions at or above line potential. Extreme care should be taken to protect against shock.


Stand on an insulating pad and make it a habit to use only one hand when checking components. Always work with another person in case an emergency occurs. Disconnect power before checking controllers or performing maintenance. Be sure equipment is properly grounded. Wear safety glasses whenever working on an electronic controllers or rotating electrical equipment.







PRECAUTIONS







- MARNING: HAZARD OF ELECTRICAL SHOCK. DISCONNECT INCOMING POWER BEFORE WORKING ON THIS CONTROL.
- **AVERTISSEMENT**: RISQUE DE CHOC ELECTRIQUECOUPER L'ALIMENTATION AVANT LE DEPANNAGE DE CETTE COMMANDE.



CAUTION: Proper grounds, disconnecting devices and other safety devices and their location are the responsibility of the user and are not provided by Hitachi, Ltd.

CAUTION: Be sure to connect a motor thermal switch or overload device to the J300 series controller to assure that the inverter will shut down in the event of an overload or an overheated motor.

A CAUTION: DANGEROUS VOLTAGE EXISTS UNTIL CHARGE LIGHT IS OFF.

ATTENTION: PRESENCE DE TENSIONS DANGEREUSES TANT QUE LE VOYANT N'EST PAS ETEINT.

CAUTION: Rotating shafts and above ground electrical potentials can be hazardous. Therefore, it is strongly recommended that all electrical work conform to the National Electrical Codes and local regulations. Installation, alignment and maintenance should be performed only by qualified personnel. Factory recommended test procedures, included in the instruction manual. should he followed. Always disconnect electrical power before working on the unit.

NOTE: POLLUTION DEGREE 2

The inverter must be used in environment of the degree 2.

Typical constructions that reduce the possibility of conductive pollution are;

- 1) The use of an on-ventilated enclosure
- 2) The use of a filtered ventilated enclosure when the ventilation is fan forced that is, ventilation is accomplished by **one or** more blowers within the enclosure that provide a positive intake and exhaust.

NOTE: ENCLOSURE SIZE FOR 75 kW TO 110 kW

The inverter, 75kW to 110kW must be installed into an enclosure with dimmensions no less than 183cm (72 in) by 183cm (72 in) by 60cm (24 in).

NOTE: ENCLOSURE SIZE FOR 132 kW AND BIGGER

The inverters, 132kW and bigger, are complied as recognized components. Therse devices are intended for use in an overall ecclosure with an internal ambient of 40 degree C for variable torque rating or 50 degree C for constant torque rating maximum. End product temperature testing should be conducted to verify sufficient forced air ventilation

End product temperature testing should be conducted to verify sufficient forced air ventilation is provided to maintain this ambient in room ambient of 10-40 degree C.

Based upon component level testing, end product temperature testing may be conducted at any convenient room ambient in the **rangeof 20-40 dwgree** C, unless the room ambient in the intended application exceeds 40degree C, in which case testing should be conducted at the elevated ambient.

Enclosure internal ambient temperature should be measured above the drive on to the upper left or right side. Temperature measurments on the drive itself should not be necessary.

NOTE: SET OF MOTOR CAPACITY AND POLES (Al, A2)

When data does not match a capacity of connected motor, it may cause unstaible motor operation. Set proper motor capacity (kW) and motor poles even under V/F control mode.

Revision History Table

No.	Revision Contents	The Date of Issue	Operation Manual No
I	Page iii: Pollution degree Page 2-1: Description of inverter model Page 4-2: Change of note Page 5-8, 5-9: Addition of 750 to 1100H Page 5-10: Terminal description	Aug. 1997	NB506XA
2	Page 11-1,11-2,11-3: addition of 750 to 1100H Page iii: Enclosure size Page 4-1: Enclosure size, page 7-5; note 3, Page 7-11: F8 boost value in VP1 to 3 Page 7-15: A0 note for boost value Page 12-13: additio of note I Page A25-A3 1: addition of line for set value	Feb. 1998	NB506XB
3	Page A-33: deletion of A-93 on clause Page iii: note for 132 kW to 220 kW is added Page 2-1: added 132 to 220kW Page 4-1; note for 132 kW to 220 kW is added page 4-2: note,note1 corrected 110kW->260kW page 5-8: added 1320 to 2200H in table Page 5-10: terminal layout corrected Page7-5: corrected monitor d3 39 to 99 Page7-18: A10, addition of 1320 to 2200H Page 11-1,2,3: added 1320 to 2200H	Feb. 1999	NB506XC

TABLE OF CONTENTS

		Page
I.	SAFETY PRECAUTIONS	1-1
2.	INSPECTION UPON UNPACKING	2-l
3.	APPEARANCE AND NAMES OF PARTS.	3-1
4.	INSTALLATION	4-1
5.	WIRING	5-1
6.	OPERATION	6-I
7.	OPERATION OF THE DIGITAL OPERATOR	7-1
8.	PROTECTION FUNCTIONS	8-l
9.	TROUBLESHOOTING	9-l
IO.	MAINTENANCE AND INSPECTION.	IO-I
I1.	STANDARD SPECIFICATIONS	1 l-l
12.	FUNCTIONS WHEN USING THE OPTIONAL REMOTE OPERATOR	12-l
13.	SERVICE	13-1
APP	ENDIX 1	- I
APPI	NDIX 2A	-15
APPI	NDIX 3A	-19
APPI	NDIX 4	-2b
APPI	NDIX 5	-21
APPI	ENDIX 6	-24
APPI	NDIX 7	-25
APPI	NDIX 8 A	-32

1. SAFETY PRECAUTIONS

1. Installation

<u>(CAUTION</u>	
• Be sure to install the unit on flame resistant material such as metal. Otherwise, there is a danger of tire.	p. 4-1
Be sure not to place anything inflammable in the vicinity. Otherwise, there is a danger of fire.	p. 4-1
 ★ Be sure not to let the foreign matter enter such as cut wire refuse, spatter from welding, iron refuse, wire, dust, etc. Otherwise, there is a danger of fire. 	p. 4-1
 Be sure to install it in a place which can bear the weight according to the specifications in the text (4. Installation). Otherwise, it may fall and there is a danger of injury. 	p. 4-1
 ★ Be sure to install the unit on a perpendicular wall which is not subject to vibration. Otherwise, it may fall and there is a danger of injury. 	p. 4-1
 Be sure not to install and operate an inverter which is damaged or parts of which are missing. Otherwise, there is a danger of injury. 	p. 4-1
Be sure to install it in a room which is not exposed to direct sunlight and is well ventilated. Avoid environments which tend to be high in temperature. high in humidity or to have dew condensation, as well as places with dust, corrosive gas, explosive gas, inflammable gas, grinding-fluid mist, salt damage, etc. Otherwise, there is a danger of fire.	p. 4-1
Be sure that the wall surface is a nonflammable material, such as steel plate.	p. 4-2

2. Wiring

∕ WARNING	
Be sure to ground the unit. Otherwise, there is a danger of electric shock and/or fire.	p. 5-l
 Wiring work shall be carried out by electrical experts. Otherwise, there is a danger of electric shock and/or fire. 	p. 5-1
 Implement wiring after checking that the power supply is off. It might incur electric shock and/or fire. 	p. 5-1
 After installing the main body, carry out wiring: Otherwise, there is a danger of electric shock and/or injury. 	p. 5-1
 Wait until DC bus voltage is discharged after power supply is turned off. 	p. 5-10
Otherwise. there is a danger of electric shock.	

/\ CAUTION

 Make sure that the input voltage is: Three phase 200 to 220 V/50 Hz, 200 to 230 V/60 Hz
 Three phase 380 to 415 V/50 Hz, 400 to 460 V/60 Hz

... p. 5-2

p. 5-2

* Be sure not to input a single phase to a 3 phase type. Otherwise, there is a danger of fire.

- ... p. 3-2
- * Be sure not to connect AC power supply to the output terminals [U(T1), V(T2), W(T3)].
- p. 5-2

Otherwise, there is a danger of injury and/or fire.

INPUT	OUTPUT
Note) (L1) (L2) (L3) (T1) (T2) (T3) R S T U V W	
Power supply	

- * Fasten the screws with the specified fastening torque. Check so that there is no loosening of screws.

 Otherwise, there is a danger of fire.
- p. 5-2

- Pagura to install an earth leakage bra
- Be sure to install an earth leakage breaker.

- p. 5-2
- The ground fault protection is designed to detect current flowing to the ground upon power on. This function is to protect the inverter. not people. Install the earth leakage breaker to protect against the ground fault on wires between the inverter and the motor. (Use a breaker that is very sensitive to high frequency current so as not to cause malfunction.)
- Be sure to set the fuse(s) (the same phase as the main power supply) in the operation circuit.
- p. 5-2

- Otherwise, there is a danger of fire.
- * As for motor leads, earth leakage breakers and electromagnetic contactors, be sure to use the equivalent ones with the specified capacity (rated).

p. 5-2

- Otherwise, there is a danger of fire.
- Connection to wiring terminal must be reliabily fixed with two means of support.
- p. 5-2

€.

ું

CAUTION

External or remote over load protection required, if multiple motors to 'p. 5-4 be connected.

For models J300-450LFU and -550LFU only, connect to branch circuit protected at maximum 300% of output current rating.

Suitable for use on a circuit capable of delivering not more than 10,000 rms symmetrical amperes,*** volts maximum,

(where *** = input voltage)


Alarm connection may contain harzordous live voltage even when inverter is disconnected. In case of removing front cover for maintenance or inspection, confirm that incoming power for alarm connection is surely disconnected.

. p. 5-11

A CAUTION

Input phase failure protection

- (1) J300-U version inverter are provided with the phase failure protection on the power supply.
- (2) When a buzzer, lamp, noise filter or transformer is connected between the input power 'terminals (L1, L2, L3) and input power fuses, input phase failure cannot be protected.





3. Control and operation

A. WARNING	
* Be sure to turn on the input power supply after mounting the surface cover. While being energized, be sure not to remove the cover. Otherwise, there is a danger of electric shock.	p. 6-1
• Be sure not to operate the switches with wet hands. Otherwise, there is a danger of electric shock.	p. 6-l
 While the inverter is energized, be sure not to touch the inverter terminals even during stoppage. Otherwise, there is a danger of electric shock. 	p. 6-1
• If the re-try mode is selected, it may suddenlyrestart during the trip stop. Be sure not to approach the machine. (Be sure to design the machine so that personnel safety will be secured even if it restarts.) Otherwise, there is a danger of injury.	p. 6-l
• Even if the power supply is cut for a short period of time, it may restart operation after the power supply is recovered if the operation command is given. If it may incur danger to personnel, be sure to make a circuit so that it will not restart after power recovery. Otherwise,, there is a danger of injury.	p. 6-1
*The Stop Key is effective only when the function is set. Be sure to prepare the Key separately from the emergency stop. Otherwise, there is a danger of injury.	p. 6-1
• After the operation command is given, if the alarm reset is conducted, it will restart suddenly. Be sure to set the alarm reset after checking the operation command is off. Otherwise, there is a danger of injury.	p. 6-1
 Be sure not to touch the inside of the energized inverter or to put a bar into it. Otherwise, there is a danger of electric shock an∨ fire. 	p. 6-1
* The STOP/RESET key works only when a function is set. Prepare an emergency switch separately. The use of the STOP/RESET key as an emergency switch may cause an injury.	p. 7-1

	<u>(</u> CAUTION	
*	Radiating fin and discharging resistor will have high temperature. Be sure not to touch them. Otherwise, there is a danger of getting burned.	p. 6-2
*	Low to high speed operation of the inverter can be easily set. Be sure to operate it after checking the tolerance of the motor and machine. Otherwise, there is a danger of injury.	p. 6-2
*	If a motor is operated at a frequency higher than 60Hz, be sure to check the speeds of the motor and the machine with each manufacturer, and after getting their consent, operate them. Otherwise, there is a danger of machine breakage.	p. 6-2
*	Check the following before and during the test run. Otherwise, there is a danger of machine breakage.	p. 6-3
	 Was the short-cut bar between +l and + connected? Was the direction of the motor correct? Was the inverter tripped during acceleration or deceleration? Were the rpm and frequency meter correct? Were there any abnormal motor vibrations or noise? 	
	• When overcurrent tripping or overvoltage tripping occurs during the test run, increase the acceleration time or deceleration time.	

4. Maintenance, inspection and part replacement

WARNING	
 Be sure to turn off the power supply during maintenance and inspection. 	p. 10-1
After the power supply has been turned off, you must always wait IO minutes so that DC bus capacitors can discharge then start maintenance and inspection after the CHARGE lamp on the printed-circuit board has gone out. (Immediately after the lamp has gone out, there will be a residual voltage of about 50 V DC in the DC bus intermediate circuit.) Perform the work after the CHARGE lamp has stopped flickering.	p. 10-1
 Make sure that only qualified persons will perform maintenance, inspection and part replacement. (Before starting the work, remove metallic objects from your person (wristwatch, bracelet, etc.) (Be sure to use tools protected with insulation.) Otherwise, there is a danger of electric shock and/or injury. 	p. 10-1



CAUTION

When removing connectors, never pull the wires. (Wires for cooling fan and thermal relay)
 Otherwise, there is a danger of fire due to wire breakage and/or injury.

5. Appendix

WARNING

- ★ When the inverter stops due to a trip with retry mode selected, the motor restarts suddenly. Stand clear of the machine. Otherwise, you may be injured. (Design the machine in such a way that persons are protected against a restart of the machine.)


NWARNING

Never modify the unit.
 Otherwise, there is a danger of electric shock and/or injury.


 Withstand voltage tests and insulation resistance tests (megger test-s) are executed before the units are shipped, so that there is no need to conduct these tests before operation.

When conducting megger tests as a part of daily inspection, be sure that these tests are only executed between the main circuit and the ground. Do not execute megger tests on the control circuit.

...




- Do not attach or remove wiring or connectors (including Digital operator and Remote operator) when power is applied. Also, do not check signals during operation. Otherwise, a trip may occur or a failure may be caused. To stop the operation, be sure to use an operation instruction (FW,REV.) Do not turn power off within three minutes after it is turned on, or vice versa.
- Do not stop operation by switching off the electromagnetic(Mgo) contactors on the primary or secondary sides of the inverter. To stop the operation, be sure to use an operation instruction (FW,REV.) Do not turn power off within three minutes after it is turned on, or vice versa. (Bad example)



When there has been an instantaneous power failure, and if an operation instruction has been given; then the unit may restart operation after the power failure has ended. If there is a possibility that such an occurrence may harm humans, then install an electromagnetic contactor (Mgo) on the power supply side, so that the circuit does not allow automatic restarting after the power supply recovers. If the optional remote operator is used and the retry function has been selected, this will also cause automatic restarting when an operation instruction has been input, so please be careful.



• Do not insert leading power factor capacitors or surge absorbers between the output terminals of the inverter and the motor.



- Be sure to ground the grounding terminal, $(\underline{\underline{}})$
- When inspecting the unit, after turning the power supply off be sure to wait unit! the CHARGE lamp beside the control terminal is off before opening the cover.

(If the lamp is lit or still flickering, then the internal capacitor's residual voltage is still dangerous.)

* MOTOR TERMINAL SURGE VOLTAGE SUPPRESSION FILTER (FOR THE 400 V CLASS)

In a system using an inverter of the voltage control PWM system, a surge voltage caused by the cable constants such as the cable length (especially when the distance between the motor and inverter is 10 m or more) and cabling method may occur at the motor terminal.

A dedicated filter of the 400 V class for suppressing this surge voltage is available, Please order one.

PROTECTION AGAINST NOISE INTERFERENCE FROM INVERTER

The inverteruses many semiconductor switching elements such as transistors and **IGBTs.** Thus, a radio set or measuring instrument located near the inverter is susceptible to noise interference.


To protect the instruments from erroneous operation due to noise interference, they should be installed well apart from the inverter. It is also effective to shield the whole inverter structure.

Addition of an **EMI** filter on the input side of the inverter also reduces the effect of noise **from** commercial power line **on external** devices.

Note that **external** dispersion of noise from the power line can be minimized by connecting an **EMI filter** on the primary side of inverter.



CAUTION



EFFECTS OF DISTRIBUTOR LINES ON INVERTERS

In the cases below involving a general-purpose inverter, a large peak current flows on the power supply side, sometimes destroying the converter module. Where such situations are foreseen, or the paired equipment must be highly reliable, install an AC reactor between the power supply and the inverter.

- (A) The unbalance factor of the power supply is 3% or higher.
- (B) The power supply capacity is at least IO times greater than the inverter capacity (and the power supply capacity, 500 kVA or more).
- (C) Abrupt power supply changes are expected.

Examples:

- (1) Several inverters are interconnected with a short bus.
- (2) A thyristor converter and an inverter are interconnected with a short bus.
- (3)' An installed phase advance capacitor opens and closes.

In cases (A), (B) or (C), we recommend installing an AC reactor of 3% (in a voltage drop at rated current) with respect to the supply voltage on the power supply side.

- * When occurring an EEPROM error ([]), be sure to confirm the setting value again.
- When setting b contact to the reverse command ([REV] terminal), the inverter state automatically. Do not set to b contact.

GENERAL CAUTION


In all the illustrations in this manual, covers and safety devices are occasionally removed to describe the details. When the product is operated, make sure that the covers and safety devices are placed as they were specified originally and operate it according to the instruction manual.

Ĩ,

3


Before installation and wiring, be sure to check the following:

- Make sure that there was no damage during transportation the unit.
- After unpacking the unit, make sure that the package contains one inverter and one operation manual
- Make sure that the product is the one you ordered by checking the specifications label on the front of the cover.




Contents of Specifications Label

If you discover any problems, contact your sales agent immediately.



3. APPEARANCE AND NAMES OF PARTS

3.1 Names of Parts



4. INSTALLATION

A CAUTION

- * Be sure to install the unit on flame resistant material such as metal. Otherwise, there is a danger of fire.
- * Be sure not to place anything inflammable in the vicinity. Otherwise, there is a danger of fire.
- Be sure not to let the foreign matter enter such as cut wire refuse, spatter from welding, iron refuse, wire, dust, etc.
 Otherwise, there is a danger of tire.
- * Be sure to install it in a place which can bear the weight according to the specifications in the text (4. Installation).
 - Otherwise, it may fall and there is a danger of injury.
- ★ Be sure to install the unit on a perpendicular wall which is not subject to vibration. Otherwise, it may fall and there is a danger of injury.
- Be sure not to install and operate an inverter which is damaged or parts of which are missing.
 - Otherwise, there is a danger of injury.
- Be sure to install it in a room which is not exposed to direct sunlight and is well ventilated. Avoid environments which tend to be high in temperature, high in humidity or to have dew condensation, as well as places with dust, corrosive gas, explosive gas, inflammable gas, grinding-fluid mist, salt damage, etc.
 Otherwise, there is a danger of fire.

NOTE: ENCLOSURE SIZE FOR 75 kW to 110kW

The inverters, 75kW to 110kW must be installed into an enclosure with dimmensions no less than 183cm (72 in) by 183cm (72 in) by 60cm (24 in).

NOTE: ENCLOSURE SIZE FOR 132 kW AND BIGGER


The inverters, 132kW and bigger, are complied as recognized components.

Therse devices are intended for use in an overall ecclosure with an internal ambient of 40 degree C for variable torque rating or 50 degree C for constant torque rating maximum. End product temperature testing should be conducted to verify sufficient forced air ventilation is provided to maintain this ambient in room, ambient of 10-40 degree C.

Based upon component level testing, end product temperature testing may be conducted at any convenient room ambient in the range of 20-40 dwgree C, unless the room ambient in the intended application exceeds 40degree C, in which case testing should be conducted at the elevated ambient.

Enclosure internal ambient temperature should be measured above the drive on to the upper left or right side. Temperature measurments on the drive itself should not be necessary.

For cooling purposes, be sure that the inverter is installed vertically. In addition, be sure that it is separated from other components and walls. If foreign matter is introduced into the interior of the inverter, this may cause malfunctions, so make sure that no foreign matter can enter it.




Place of installation	Load characteristics	Ambient temperature	Applicable model
Within the enclosure	Constant torque	-10 to 50°C	All models
(NOTE I)	Variable torque	-10 to 40°C	(NOTE 2)

NOTE 1: The inverter should be installed in a locked enclosure that meets the requirements in IP4X.

The higher the ambient temperature inside the inverter, the shorter its life will be. If a heat generating unit is used near the inverter, try to keep it as far away as possible. Also, when <code>installing the</code> invener in a box, be sure to carefully consider ventilation and the dimensions.

NOTE 2: Each of inverters 22 kW to 260 kW must be installed in a locked enclosure.



5. WIRING

 ${\mathfrak F}_{r}$

/ WARNING

- * Be sure to ground the unit.

 Otherwise, there is a danger of electric shock and/or fire.
- * Wiring work shall be carried out by electrical experts.

 Otherwise, there is a danger of electric shock and/or fire.
- * Implement wiring after checking that the power supply is off. It might incur electric shock and/or fire.
- * After installing the main body, carry out wiring. Otherwise, there is a danger of electric shock and/or injury.


CAUTION

- * Make sure that the input voltage is:
 - Three phase 200 to 220 V/50 Hz, 200 to 230 V/60 Hz

Three phase 380 to 41.5 V/50 Hz, 400 to 460 V/60 Hz

- * Be sure not to input a single phase to a 3 phase type. Otherwise, there is a danger of fire.
- * Be sure not to connect AC power supply to the output terminals [U (T1), V (T2), W (T3)].

Otherwise, there is a danger of injury and/or fire.



Power supply

- * Fasten the screws with the specified fastening torque. Check so that there is no loosening of screws.
 - Otherwise, there is a danger of fire.

Be sure to install an earth leakage breaker.

- * The ground fault protection is designed to detect current flowing to the ground upon power on. This function is to protect the **inverter**,**not** people. Install the earth leakage breaker to protect against the ground fault on wires between the **inverter** and the motor. (Use a breaker that is very sensitive to high frequency current so as not to cause malfunction.)
- * Be sure to set the fuse(s) (the same phase as the main power supply) in the operation circuit.


Otherwise, there is a danger of fire.

As for motor leads, earth leakage breakers and electromagnetic **contactors**, be sure to use the equivalent ones with the specified capacity (rated).

Otherwise, there is a danger of fire.


The terminal board will be exposed when the front cover or terminal cover (450L/HF, 550L/HF) is removed. Wire the inverter in this state.

5.1 Wiring the Power Supply and Motor



- The inverter will be damaged if the power supply is connected to the motor terminals U(T1), V(T2) and W(T3), so be sure not to make any mistakes.
- If multiple motors are to be connected, be sure to attach a thermal relay to each motor.

NOTE 1: When changing the power supply of the motor between the **inverter** and commercial power, be sure to install mechanically interlocked switches Mgl and Mg2.




NOTE 2: Install an earth leakage breaker at the input of the inverter. (Select an earth leakage breaker whose sensitive current level is raised in high frequency range.)

When the cable length between the inverter and motor is long (more than IO m), the thermal relay may malfunction due to higher harmonics. Therefore, install an AC reactor on the output side of the inverter or use a cm-rent sensor in place of the thermal relay.

NOTE 3: Be sure that the specified grounding is carried out. Be sure to separate the unit's grounding pole from those of other heavy electric machinery, and avoid using common grounding poles.

If multiple inverters are used, make sure that the grounding connections do not create a loop.



A CAUTION


External or remote over load protection required, if multiple motors to be connected.


For models **J300-450LFU** and **-550LFU** only , connect to branch circuit protected at maximum 300% of output current rating.

Suitable for use on a circuit capable of delivering not more than 10,000 rms symmetrical amperes,*** volts maximum,

(where *** = input voltage)


5.2 Wiring of Control Circuit Terminals






NOTE 1: When an output intelligent terminal is used, be sure to install a surge absorbing diode in parallel with the relay (RY). Otherwise, the surge voltage created when the relay (RY) goes ON or OFF may damage the output intelligent terminal circuit.

NOTE 2: Use a twisted and shielded wire for the signal line, and cut the shielded covering as shown in the diagram below. Make sure that the length of the signal line is 20 meters or less.



- NOTE 3: When the frequency setting signal is turned on and off with a contact. use a relay which will not cause contact malfunctions, even with the extremely weak currents and voltages, such as crossbar twin contacts, etc.
- NOTE 4: Use relays which do not have contact defects at 24 V DC, 3 mA for the other terminals.
- NOTE 5: Separate the main circuit wiring from the relay control circuit wiring. If they must cross, be sure that they cross at a right angle.




- NOTE 6: Do not short between the terminals H and Land between the terminals P24 and CM1 of the control circuit.
- NOTE 7: Insulate the common terminal L for frequency analog command input and the common terminal (COMMON) of the peripheral equipment such as the sequencer before starting use.

5.3 Connection to the Programmable Controller

(I) When the internal interface power **source** is used ① This is an example when the sink type transistor **output** (open collector output) module of the sequencer is connected

Note: Make sure of the **short-circuit** bar or wire between the terminals PLC and P24.




(by Hitachi)(2) When the external interface power source is used

① This is an example when the sink type transistor output (open collector output) module of the sequencer is connected

Note: Remove the short-circuit bar or wire between the terminals CM1 and PLC or P24 and PLC.


This is an example when the **source** type transistor output (open collector output) module of the **sequencer** is connected

Note: Make sure **of the** short-circuit bar **or** wire between the terminals CMI and PLC.



② This is an example when the source type transistor output (open collector output) module of the sequencer is connected

Note: Remove the short-circuit bar or wire between the terminals CMI and PLC or P24 and PLC.




Note: Be sure to turn the inverter on after the controller and external power source are turned on. (Otherwise, the data in the inverter may be changed.)

5.4 Wiring Equipment, Options (EMI filter, etc.)

Standard equipment	(200V clas	s)								
1				Wiring	g (AWG or	Kcmil)		-	Applicable eq	uipment
Danie a superior	Inverter	Cons	tant torqe	Variable torqe		Power.	Signal	Signal	Earth leakage	
Powersupply I	model	Motor output (kW)	Power lines R,S,T,U,V W,P,N	Motor output (kW)	Power lines R,S,T,U,V W,P,N	lines External resistor RB1,2,3, P,RB	lines FM.CMI.PCL FW.8.7.6.3.43 2.1.H.O.OL.L CM2.12.11	lines P24ALOAL AL2	breaker (ELB)	magnetic contactor
494	J300-055LF	5.5	AWG 8 or more	7.5	AWG 8 or more	10 or more	AWG IS Shielded	AWG 16 or more	EX50C(30A)	H20
∂ ∂ ∫ ELB	J300-075LF	7.5	AWG 6 or more	11	AWG 6 or more	10 or more	wire	0	EX50C(30A)	H20
	J300-110LF	11	AWG 4 or more	15	AWG 4 or more		When the		EX50C(50A)	H25
	J300-150LF	15	AWG 3 or more	22	AWG 3 or more		number of shielded wires to be		EX60B(60A)	H35
999 Magnetic	J300-220LF	22	AWG I/O or more	30	AWG 1/0 or more		used is 11 or more, the section		RX100(75A)	H50
of of contactor ◆	J300-300LF	30	AWG 3/0 or more	37	AWG 3/0 or more		of each shielded wire		RX100(100A)	H65
	J300-370LF	37	AWG 4/0 or more	45	AWG 4/0 or more		should be AWG 20		RX100(100A)	H80
	J300-450LF	45	300 or more	55	300 or more		·		RX225(150A)	H100
	J300-550LF	55	350 or more	75	350 or more		ļ		RX225(175A)	H125

(400V class)

				Wiring				Applicable ec	uipmen
Inverter	Con	stant torqe					Signal lines	Earth leakage breaker (ELB)	
model	Motor output (kW)	Power lines R.S.T.U.V W.P.N	Motor output (kW)	1	External resistor		P21ALOALI	oreaker (ELB)	contacto
J300-055HF	5.5	AWG 8	7.5	AWG 8 or more	10 or more	AWG 18 Shielded	AWG 16 or more	EX50C(30A)	H20
J300-075HF	7.5`	AWG 8 or more	11	AWG 8	10 or more	wire	o. more	EX50C(30A)	H20
J300-110HF	11	AWG 8 or more	15	AWG 8		When the		EX50C(50A)	H25
J300-150HF	15	AWG 6 or more	22	AWG 6		number of shielded wires to be		EX60B(60A)	H35
J300-220HF	22	AWG 4 or more	30	AWG 4 or more		used is 11 or more, the section		RX100(75A)	H50
J300-300HF	30	AWG 4 or more	37	AWG 4 or more		of each shielded		RX100(100A)	H65
J300-370HF	37	AWG 2 or more	45	AWG 2 or more		should be AWG 20.		RX100(100A)	H80
J300-450HF	45	AWG I or more	55	AWG I or more		1	Ī	RX225(150A)	H100
J300-550HF	55	AWG 3/0 or more	75	AWG 3/0 or more				RX225(175A)	H125
J300-750HF	75	300 or more	90	300 or more				RX225(225A)	H150
1300-900HF	90	300 or more	110	300 or more		ļ	Ī	RX225(250A)	H220
J300-1100HF	110	350 or more	132	350 or more			Ī	RX400(350A)	H250
300-1320HF	132	AWG 4 / 0 parallel	160	AWG 4 / 0 parailel				RX400(400A)	H400
300-1600HF	160	300 paraliei	220	300 parallel	•			RX600(600A)	H600
1300-2200HF	220	350 parallel ,	260	350 parallei		}		RX600(600A)	H600



NOTE 1: The applicable equipment is for Hitachi standard four pole squirrel-cage motor

NOTE 2: Be sure to consider the capacity of the circuit breaker to be used.

NOTE 3: Be sure to use bigger wires for power lines if the distance exceeds 20m.

NOTE 4: Be sure to use an grounding wire same size of power line 'or similar.

(*) Use AWG 16 wire for the alarm signal wire.
Classify the detective current of the earth leakage breaker depending on the total distance—between the inverter and the motor.


length	Detective current (mA)
100 m and less	30
300 m and less	100
600 m and less	200

NOTE 5: When using CV wire and metal tube, the leakage current is around 30 mA/km.

NOTE 6: The leakage current becomes eight times because IV wires have a high dielectric constant. Therefore. "se an one class larger earth leakage breaker according to the left table.

5.5 Terminal

(I) Main circuit terminal



Terminal layout	Туре	Screw diamete t	Width (mm)
$ \begin{array}{ c c c c c c c c c c c c c c c c c c c$	055, 075LF 055,075HF	M5	13
$ \begin{array}{ c c c c c c c c c c c c c c c c c c c$	011,150LF 211,150HF 220 to 370I 450,550LF	1410	17.5 23 35
Internal short circuit bar	220 to 370HF	M6	17.5
$ \begin{array}{ c c c c c c c c c c c c c c c c c c c$	450, 550HF 1	и s	23
Internal short circuit bar	750, 900HF	міо	35
G R S T PD P N U V W G (PE) (L1) (L2) (L3) (+1) (+) (D) (T1) (T1) (T1) (PE)	1100HF	М10	40
	1320 to 2200HF	M16	51

Main circuit

Terminal symbol	Terminal description	Function	88 8 5 T PD P N U V W GG
R, S, T	Main power	Connect the power supply	Braking od od DCL Braking Units
U, V, W (T1),(T2),(T3)	Inverter output	Connect the motor	O O ELB Power supply
P, RB (+),(RB)	External braking resistor	* Only the 055LF/HF and 075LF/HF are equipped RB terminals.	Internal short circuit bar
P. N (+),(-)	Dynamic braking unit	Connect a dynamic braking unit (option)	(+1) (+)
) (PE)	Ground	Ground (connect grounding to avoid electric shock)	DCL is connected. WARNING Wait until DC bus voltage is discharged after power
PD (+1)	External choke coil	Connect a choke coil (DCL) for harmonics current reduction	Supply is turned off. Otherwise, there is a danger of electric shock.
(±)	Ground at case	Ground (connect grounding to avoid electric shock)	

(2) Control circuit terminal

The intelligent I/O terminals 1 to 8 and 11 and 12 are initialized as shown below at factory before shipment.

FM	СМІ	PLC	P24	FW	RÉV	CFI	USP	СНІ	FRS	1G	AT	RS	н	0	OI	Ļ	СМ2	RUN	FAI	AL2	ALI	AL0
					î	1	1	1	Ť	î	1							1	1			
FM	CMi	PLC	P24	FW	: 8	7	6	5	4	3	2	I	Н	0	ОІ	L	СМ2	12	11	AL2	ALI	AL0

Control circuit

	Terminal symbol	Terminal description and function		Standard setting of ntelligent terminal	Remarks	
	FM	Frequency monitor			Dry contact	
	CM1	Common for monitor	1		Close: ON (run) Open: OFF (stop)	
	PLC	Common terminal for the external power source of the sequencer (PLC)			Min. ON time: 20 ms or more	
	P24	Internal power source for the frequency monitor and intelligent input terminal			20 ms of more	
nput nonitor	FW	Forward operation]			
ignal	8	Intelligent input terminal 8	REV	Reverse operation		
	7	Intelligent input terminal 7	CFI	Multistage speed (First stage)		
	6	Intelligent input terminal 6	USP	Prevention function of restart upon power on.		
	5	Intelligent input terminal 5	CHI	2 stage acc./dec.]	
	4	Intelligent input terminal 4	FRS	Free run input signal	Note: If the power is turned on when the input terminals 1 to 5 are	
٠	3	Intelligent input terminal 3	JG	Jogging	kept on, all the data stored in the inverter is initialized.	
	2	Intelligent input terminal 2	AT	Current input selection	Therefore, never turn the power on in such a state.	
	1	Intelligent input terminal 1	RS	Reset (NOTE 1)) state.	
requency	Н	Power supply for frequency command			10 VDC	
ommand iput	0	Voltage frequency command			0-5 VDC (nominal), 0-10 VD (nominal)(Input impedance 30 kΩ	
.p=.	OI	Current frequency command			DC 4-20 mA (nominal) Input impedance 250Ω	
	L	Common for frequency command			,	
utput	CM2	Common for intelligent output terminal				
gnal	12	Intelligent output signal 12	RUN	Run signal	27 VDC	
	11	Intelligent output signal 11	FAI	Frequency arrival signal	50 mA max	
ault alarm	AL0	Normal: AL0-AL1 close	e Co	ntact rating		
1tput	ALI	Abnormal. Power off:	250	VAC 2.5 A (Resistor I		
	AL2	AL2 AL1 AL0 AL0-AL1 open	30	0.2 A (cos;=0.4 0 VDC 3.0 A (Resistor I 0.7 A (cos;=0.4	oad) 5 VDC	
		Alarm connection may contain hazard in case of removing flont cover for m for alarm connection is surely disconn	aintenar			

NOTE1: Terminal RS can use only contact a (normally open). It cannot use contact b (normally closed).

5.6 Control Circuit Terminals


Term	Terminal symbol Terminal name		пе	Description					
l ——	FM	Monitor terminal		Analog: Output frequency, current, torque					
				Digital: Output frequency x frequency convened value					
				(Set in the remote operator monitor mode), max. pulse: 3.6 kHz					
	CMI	Common terminal I		Common terminal for the monitor terminal					
	PLC Internalnterfaceommon			Common terminal for the external power source of the sequencer					
	P24	Inpusignabowersource		Internal power source for the contact input terminal and frequency					
		1 -4 6 4		monitor terminal. 24 VDC.					
				Common for the FW terminal and intelligent input terminals					
				OUTPUT frequency					
	FW	Forwardun/stoperminal							
				Forward					
				Reverse CMIPLC P24 FW 8 1					
	REV	Reverse run/stop		SWF ON SWR					
l		1		SWR. ON SWF					
				Frequency					
	CFI		SWI	(Hz) Fourth (FS) (Source type)					
	. .		""	speed .					
			ļ —	Third speed :					
			Ì	Second CMPLC P2 FW 8 7 6					
	CF2	CF2 Multistage speed	SW2	First speed					
		i		Switch Time swi swi swi					
	050	j i		SWI ON ON ON When setting frequency, connect P24 and 6 or 7					
	CF3		SW3	and set with digital					
	(NOTE 1)			ON operator ▲ or ▼.					
	JG	Jogging		Jogging run					
	DB	External DC braking		DC braking input signal					
	STN	Initialization		Initialization (shipment status at factory) input					
	SET	2nd function		The output frequency setting, base and maximum frequencies,					
			i	control method, motor constant, acceleration or deceleration time,					
∞ _				manual torque boost setting, and electronic thermal setting are					
₽	СНІ	70	· · · · · · · · · · · · · · · · · · ·	changed in batch.					
	CHI	Two-stage accelerati	on	The acceleration or deceleration time or selection of two-stage					
	FRS	or deceleration		accration or deceleration is changed by turning the contact ON.					
	LK2	Free run stop		The inverter stops and the motor stops free run					
	EXT	External trip		FRS functions when the contact is opened. (European version) External trip input signal (The contact is open.)					
	USP	Power-ON restart		Restart prevention when the power is turned on in the RUN					
	55.	prevention		state (The contact is open.)					
	CS CS	Commercial power so	nurce	Switch signal from the commercial power source to inverter					
	'	switching		drive (Note: When the terminal is used, a trip is also conceled.)					
	SFT	Terminal software lo	ck	The data of all functions except for output frequency setting is					
				locked. See 12-9 [F-25].					
	AT	Analog input comma	nd	Analog input voltage-current switching (When the contact is ON,					
]	Ç F		current input signal to OI-L is acrive.)					
	RS	Reset		Trip or alarm signal is reset.					
	UP	Remote control funct	ion,	When the contact is turned ON, the operation is accelerated.					
		acceleration	1	(Available only when the frequency command is sent					
			[to the operator.)					
	DWN	Remote control funct	ion,	When the contact is turned ON, the operation is decelerated.					
l		deceleration	l	(Available the frequency command is sent to the operator.)					
ı —	ı — — — — — — — — — — — — — — — — — — —								

Гегт	inal symbol	Terminal name	Description					
	Н	Frequency command power terminal	Initialization of a voltage signal by an external command is between 0 and 10 VDC. (Switching from 0 to 5V is executed by A48.) When inputting 4 - 20 mA, turn the input terminal at ON.					
	OI .	Frequency command terminal (voltage command) Frequency command	THOOLE THOOLE STORY					
		terminal (current command)	VRO DC0 to 10 V DC4 to 20 mV (500 Ω to 2 kΩ) DC0 to 5V Input impedance 250 kΩ					
	L	Frequency command common terminal	Input impedance 20 kΩ Input impedance 20 kΩ When a current is inputted from between OI and Land the value is 4 m/ the output frequency may 0.6 Hr. If this occurs, set a value more than the frequency which is outputted by [A 4] start frequency setting. (NOTE 2)					
	CM2	Common terminal 2	Common terminal for intelligent output terminal					
	FAI	Frequency arrival signal	When each operator is used, and arrival signal can be					
]		outputted at an optional frequency.					
7	RUN	Signal during run	The transistor output is turned ON during running.					
			(Outputted even during DC injection braking)					
	OTQ	Over-torque signal	The transistor output is turned ON when the torque is more					
			than the set value.					
			The set value can \mathfrak{be} changed by the remote operator.					
			Use this function only under the sensor less vector control.					
	AL0		Normal: AL0-AL1 close Abnormal, Power off:					
AL1		Fault alarm terminal	ALO-AL1 open Contact rating					
			250 VAC 2.5 A (Resistor load) Min100Vac 0.2 A(Cosø=0.4) 10 mA 30 VDC 3.0 A (Resistor load) 5 VDC 0.7 A(cosø=0.4) 100 mA					

NOTE 1: To set four or more multispeeds, use the CM terminal.

When an inconvernience occurs in the above characteristics, adjust it using [ABD] and [ABD]. The sum of both analog input signals is outputted When selecting one of analog input current and voltage, make sure that the other is not inputted.

5.7 Terminal Connection Diagram



NOTE 2: The regenerative resistor has a temperature sensor. When it works, turn off power supply to the inverter o set the deceleration time longer.

and the main circuit power is turned ON, and direct start results and a trip occurs.

NOTE 4: Do not input the operation command simultaneously when the main circuit is turned on.

6. OPERATION

6.1 Before Starting Operation

Prior to the test run, check the following.

/ WARNING

- ★ Be sure to turn on the input power supply after mounting the surface cover. While being energized, be sure not to remove the cover. Otherwise, there is a danger of electric shock.
- ▶ Be sure not to operate the switches with wet hands.
 Otherwise, there is a danger of electric shock.
- . While the inverter is energized, be sure not to touch the inverter terminals even during stoppage.
 - Otherwise, there is a danger of electric shock.
- If the re-try mode is selected, it may suddenly restart during the trip stop. Be sure not to approach the machine. (Be sure to design the machine so that personnel safety will be secured even if it restarts.)
 - Otherwise, there is a danger of injury.
- Even if the power supply is cut for a short period of time, it may restart operation after the power supply is recovered if the operation command is given. If it may incur danger to personnel, be sure to make a circuit so that it will not restart after power recovery.
 - Otherwise, there is a danger of injury.
- The Stop Key is effective only when the function is set. Be sure to prepare the Key separately from the emergency stop.
 - Otherwise, there is a danger of injury.
- * After the operation command is given, if the alarm reset is conducted, it will restart suddenly. Be sure to set the alarm reset after checking the operation command is off. Otherwise, there is a danger of injury.
- * Be sure not to touch the inside of the energized inverter or to put a bar into it. Otherwise, there is a danger of electric shock and/or fire.

! CAUTION

- Radiating fin and discharging resistor will have high temperature. Be sure not to touch them.
 - Otherwise, there is a danger of getting burned.
- * Low to high speed operation of the inverter can be easily set. Be sure to operate it after checking the tolerance of the motor and machine.

 Otherwise, there is a danger of injury.
- If a motor is operated at a frequency higher than **60Hz**, be sure to check the speeds of the motor and the machine with each manufacturer, and after getting their consent, operate them.
 - Otherwise, there is a danger of machine breakage.

Note:

- (I) Make sure that the power lines (input power supply R(L1), S(L2) and T(L3), and output terminals, U(T1), V(T2) and W(T3) are connected correctly.
- (2) Make sure that there are no mistakes in the signal line connections.
- (3) Make sure that the inverter case $(\stackrel{\frown}{=})$ is grounded.
- (4) Make **sure** that terminals other than those specified are not grounded.
- (5) Make sure that the inverter is installed vertically on a wall, and a nonflammable material such as a steel plate is used as a mounting surface.
- (6) Make sure that them are no short-circuits caused by stray pieces of wire, solderless terminals or other objects left from wiring work. Also, make sure that no tools have been left behind.
- (7) Make sure that the output wires are not short-circuited or grounded.
- (8) Make sure that there are no loose screws or terminals.
- (9) Make sure that the maximum frequency setting matches the machine specifications,

Be sure to refer to page 10-2 when conducting insulation resistance and withstand voltage tests. Never test terminals other than those which are indicated.

Ţ.

$\overline{\mathbb{A}}$

CAUTION

Check the following before and during the test run Otherwise, there is a danger of machine breakage.

- Was the direction of the motor correct?
- Was the inverter tripped during acceleration or deceleration?
- Were the SPEED (rpm) and frequency meter correct?
- Were there any abnormal motor vibrations or noise?

When **overcurrent** tripping or overvoltage tripping occurs during the test run, increase the acceleration time or deceleration time.

Factory settings

Maximum frequency: 60 Hz Forward operation

An example of a general connection diagram is shown below,


Operating with digital operator:

When setting frequency, run and stop with digital operator.

(The same way as remote operator (DOP) or copy with (DRW).)

Running from external command:

When setting frequency, run and stop from external command (FW,RV Terminal.) The following shows run from the operation box (OPE-4MJ2,OPE-8MJ2)



*: For sink type wiring.


Operating with digital operator:

Runnign from external command:

Prod	cedure	I	
(1)	Turn on ELB to supply power to the inverter. operator turns ON.	Make	sure that the POWER LED on the digital
(2)	Press the Func key once to display [].		
(3)	Press of the digital operator four times to	display	F 9.
(4)	Press the Func key and then press the key to set DD. Press the Func key to establish the data.	(4)	Press the Func key and then press the key to set 7. Press the Func key to establish the data.
(5)	Press the key four times to display	(5)	Press the key four times to display
(6)	Press \square of the digital operatort five times to dispaly $ \square $.	(6)	Short the terminals FW and P24 (CM I *) of the control terminal block.
(7)	Press the Func key and then the key so as to increase to frequency or the key so as to decrease the frequency. (When the func key and then the key key is pressed con-	(7)	Apply a voltage between the terminals 0 and L to start running. Open the terminals FW and P24 (CM I *)
	tinuously, the frequency is changed continuously.)		of the control terminal block to stop deceleration.
	When the) key is pressed, F 2 is displayed.	*: S ₂	ymbols are indicated for Sink type wiring. Refer to page S-5.
(8)	Check the output frequency and rotation direction. When the for key is pressed to display fy and then the rotation direction can be checked. Fy indicates forward		
	rotation and r indicates reverse rotation. When the rotation direction is		
	checked, press the Func key. When the rotation direction cannot be found, operate the equipment at a low frequency to check the rotation direction.	Γ	
(9)	Presst the RUN key. The equipment starts running.		
•	Press the STOP/RESET key. The equipment decelerates and stops.		

- The failure alarm signal is generated from the terminal ALO and ALI when a failure happens. At this time the contents of the failure are displayed on the digital operator.
- Whether the alarm terminal output is to be, turned on or off during normal run can be selected by the extension function $[L] \supseteq I$.

The alarm output terminals at initial setting are as follows (1).



• Contact specification

Maximum	Minimum
250 VAC 2.5 A (Resistor load) 0.2 A (cos¿=0.4)	100 VAC 10 mA
30 VDC 3.0 A (Resistor load) 0.7 A(cos¿=0.4)	SVDC 100 mA


Working voltage: Max. 50 V

Saving the alarm signal


When an alarm signal is outputted, the alarm signal data is stored even if the input power is turned off and the contents can be checked by turning the power on once again. However, when the input power is turned off, the inverter control power is also turned off. As a result, when the power is turned on next, the alarm contact output is reset (deleted). Therefore, when saving the alarm contact output, let the external sequence receive and save it and then turn off the inverter input power.

When the alarm contact output is set ON during normal run, a time delay occurs until the contact is closed when the power is turned on. Therefore, when using the alarm contact output, set a time delay of about 2 seconds when the power is turned on.

Resetting (Any one of A, B and C is possible)



When **the** internal interface power source **P24-CM** 1 is used (Source type wiring)



When the internal interface power source P24-CM1 is used (Sink type wiring)

- A) Turn control terminal 1 on. (In the initialization at factory before shipment, intelligent input terminal 1 is allocated to the reset RS terminal.)
- B) Press STOP/RESET on the digital operator. (This is effective only when an alarm occurs.)
- C) Open the power receiving breaker of the inverter, and make sure that the Charge lamp on the control board goes out. (See page 3-I.) Then, close the power receiving breaker.

NOTE: When the control circuit terminal RS is used, never short-circuit RS-P24(CM1*) for four seconds or more. Otherwise, a communication error R-ERROR COMM<2> may occur (Although the digital operator display is _____, the inverter is normal). When the above error occurs, open the RS terminal and press the operator key.,

*: For sink type wiring


How to return to the initialization (state before shipment)

When returning the equipment to the initial state set at factory before shipment for some reason, see page 7-14.

7. OPERATION OF THE DIGITAL OPERATOR

Ąť,

The standard type digital operator is modified so as to be used easily by minimizing key operations. Data can be set simply.



7.2 **Operation Procedure** (Example that the frequency is set and the equipment starts running) Display after Press the FUN Press the 🛕 power is turned Press the key once key once. key five times. and set the frequency by using and keys. Start run The frequency which is (Frequency FUNC When selecting the monitor Press the Press RUN monitor) set by the FUNC key is mode, press and 🔻 key once. stored. to display


7-1


7.3 Key Description

Data display Code display UP/DOWN key	The key are used to select the code and change the data. When the key is pressed once, the monitor mode is displayed first and then in the first and the first a
FUNC [Function key] Th	When this key is pressed once in the state of [7], [7], the data state is set. When the key is pressed once in the state of [7], [7], the the extension function code selection state is set.
58.1 FUNC V (A FUN F 2	FUNC
□ □ F / / screen transi	tion \[\begin{align*} \begin{align*} \begin{align*} F & 1 & 4 \\ 1 & 4 \end{align*} \] screen transition
, , , , , , , , , , , , , , , , , , , ,	key starts the run. e set value of F4 determines a forward run or a reverse run.
STOP/RESET [STOP/RES	ET key] This key stops the run. When a trip occurs, this key becomes the reset key.

7.4 Explanation of Screen Display

- When the inverter is turned on, the latest display appears. However, when the display unit for data of the commands F2 to F14 is turned off, the commands (F2 to F14) are displayed. (d10 and d11 excluded)
- Data during running in any function mode or extension function mode can be displayed. Even if data cannot be changed during running, data can be monitored.
- In each of the function modes \(F \) \(\frac{1}{2} \), \(F \) \(F \) \(\frac{1}{2} \), \(F \) \





7.5 Transition of Each Code

	_			
<monitor mode=""></monitor>	То	extension function code setting Extension function		
output frequency monitor Motor revolution	R D	Control method setting	<u> 1958</u>	Reduced voltage soft start setting
speed monitor	R /	Motor capacity setting	859	Running mode selection
Output current monitor	8 2	Motor poles setting	851	Jogging frequency setting
Frequency converted value monitor	8 3	Speed control response constant setting	852	Base frequency setting
Trip monitor	A Y	Start frequency adjustment	853	Maximum frequency setting Maximum frequency
	<i>A</i> 5	Maximum frequency limiter setting	854	selection
T&history monitor	<u> 8 5</u>	Minimum frequency limiter setting	BBD	Frequencycommand output frequency adjust (c-t. terminal) Frequency command/
<function mode=""></function>	<i>R</i> 7	Jump frequency setting 1	881	Frequency command/ output frequency adjust (OI-L terminal)
Output frequency setting	<u>B</u> B	Jump frequency setting 2		Selection of reset terminal performance P gain setting of PID
Running direction	<u>P</u> 9	Jump frequency setting 3	HHH	funciton I gain setting of PID
Setting	<u>R 10</u>	Carrier frequency setting Frequency command sampling		function D gain setting of PID
Acceleration time setting	811	frequency setting Multispeed first	892	funciton Selection of PID
Deceleration time setting	<u>A 12</u>	speed setting Multispeed second	<u> </u>	function Setting method of PID
Manual torque boost setting	813	speed setting		reference value Setting of PID
Setting Pun command	RIY	Multispeed third speed setting	895	reference value
F 9 Run command, frequency command	823	Electronic thermal level adjustment	897	Auto tuning setting
FIII Analog meter adjustment	R 24	Electronic thermal characteristic selection	N N N	Motor data selection
Matan massining	<u> </u>	Motor pole number setting for motor speed monitor	HAA	Ro-To option selection
voltage	825	External frequency setting start		Input terminal setting I
Extension function setting	827	External frequency setting end		Input terminal setting 2
	834	Instantaneous restart selection Dynamic braking usage		Input terminal setting 3
When the FUNC key is pressed once	<u> </u>	ratio		Input termiani setting 4
to set the extension function, the screen is changed to the extension	$H \rightarrow A$	Optional arrival frequency for acceleration Optional arrival frequency		Input terminal setting 5
function code selection screen. When a code is selected from the	HUU	for deceleration		Input terminal setting 6
codes [A] to [A] and the	844	Monitor signal selection		Input terminal setting 7
FUNC key is pressed. the screen is	RY	Frequency convened value setting		Input terminal setting 8
changed to the relevant extension function settig screen.	HAA	Analog input selection		Output terminal setting I I
ranoution overag sercon.	HHHH	Frequency arrival signal output method		Output terminal setting I2 Input terminal a and b
	<u>17154</u>	Restarting after FRS signal selection		contact setting Output terminal a and b contact setting

7.6 Digital Operator Initialization List

- (1) Monitor mode, function mode
 - The standard set value of each code number is displayed.
 - The extension functions shown on page 7-6 can be set by the <u>FI 4</u> extension function setting function.

			Screen display			- Initial	Settable	Set
Display order	Function name	Туре	Code display	Settable during running	Monitor/set value	value	for 2nd function	value
1	Output frequency monitor	Monitor	d 0	_	0.00-9.99/10.0-99.9/100-400		-	
2	Motor revolution speed monitor	Monitor	d I		0.00-9.99/10.0-99.9/100-600		-	
3	Output current monitor	Monitor	d 2	_	0.0-999		•	
4	Frequency converted value monitor	Monitor	d3	_	0.00-9.99/10.0-99.9/100999. 100-999/୮10-୮99	-	-	
5	Trip Monitor	Monitor	410	_	-		_	
6	Trip history monitor	Monitor	dll			_	_	
7	Output frequency setting	Set value	F 2	√	0.00-9.99/10.0-99.9/100-400	0.00	√	
8	Running direction setting	Set value	F 4	Not possible	F/r (forward run/reverse run)	F	_	
9	Acceleration time setting 1	Set value	F6	√	0.01-9.99/10.0-99.9/100-999	30.0	√	
10	Deceleration time setting I	Set value	F7	√	0.01-9.99/10.0-99.9/100-999	30.0	√	
11	Manual torque boost setting	Set value	F 8	√	00-99 NOTE 3	11	√	
12	Runn command, frequency command setting	Set value	F9	Not possible	00-15 NOTE 1	03	_	
13	Analog meter adjustment	Set value	F10	√	00-250	172	_	
14	Motor receiving voltage	Set value	FII	Not possible	200-2301380-480 _{NOTE 2}	230/460	·	
15	Extension function setting	Set value	F14	Not possible	A 0-A99/C 0-C21	A 0		

NOTE 1: In the standard configuration, four values from 0 to 3 can be selected. When an optional PC board is mounted, 16 values from 0 to 15 can be selected. Refer to F-9.

NOTE 2: For the 200 V class, one of **200**, **215**, **220**, and 230 can be selected. For the 400 V class, one of **380**, 400, 415, 440, 460 and 480 can be selected.

NOTE 3: Set torque boost in 70 to 90 when using VP1, VP2 or VP3 in V/F control mode

(2) Extension function mode

- Each function name and **settable** range to the extension function mode are shown below.
- Set the extension function code to be changed by \boxed{FIY} .


Display			T		Farmer #1:1		1	1	1
2 Motor capacity setting		Externsion function name		during		Initial value	for 2ml	Remarks	Set value
3 More poles setting		Control method setting	A0	Ñ	0-5	0	1		
4 Seed control response constant setting A 3 Ñ 000.999/100.999/100 2.00 / V 5 Start frequency adjustment A 4 Ñ 0.100.999 0.530 N V 6 Masimum frequency interies setting A 5 Ñ 0.120 (400) 0 N V 7 Minimum frequency interies setting A 6 Ñ 0.120 (400) 0 N V 7 Minimum frequency interies setting A 7 Ñ 0.400 0 N N 8 Jump frequency setting 1 A 7 N 0.400 0 N N 9 Jump frequency setting 2 A 8 N 0.400 0 N N 9 Jump frequency setting 3 A 9 N 0.400 0 N N 11 Carrier frequency setting 3 A 9 N 0.400 0 N N 12 Frequency setting 3 A 9 N 0.400 0 N N 13 Multiprend second speed setting A 10 N 2.0140 (16,0) N N S e 7.18 14 Multiprend frest speed setting A 11 N 1 8 N N 0.400 0 N N 15 Multiprend frest speed setting A 11 N N 0.400 0 N N 16 Multiprend frest speed setting A 11 N N 0.400 0 N N 17 Multiprend frest speed setting A 11 N N 0.400 0 N N 18 Multiprend frest speed setting A 11 N N 0.400 0 N N 18 Multiprend frest speed setting A 11 N N 0.400 0 N N 19 Multiprend frest speed setting A 11 N N 0.400 0 N N 19 Multiprend frest speed setting A 12 N 0.400 (400) N N 19 Multiprend frest speed setting A 11 N N 0.400 (400) N N 19 Multiprend frest speed setting A 11 N N 0.400 (400) N N 19 Multiprend frequency setting state selection A 12 N 0.400 (400) N N 19 Multiprend frequency setting setting for motor speed menitor A 22 N 0.210 (400) N N 19 Multiprend frequency setting setting for motor speed menitor A 22 N 0.400 (400) N N 19 Multiprend frequency setting setting for motor speed menitor A 24 N 0.400 N N N N N N N N N N N N N N N N N N	2	Motor capacity setting	AI	Ň	3.7 to 160		√	NOTE I	
5. Starf frequency adjustment	3	Motor poles setting	A2	Ň	2/4/6/8	4	1		
6 Maximum frequency limiter setting A	4	Speed control response constant setting	A3	Ñ	0.00-9.99/10.0-99.9/100	2.00	1		
7 Minimum frequency setting A6 N 0-120 (400) 0 N	5	Start frequency adjustment	A 4	Ň	0.10-9.99	0.50	Ň		
8 Jump frequency setting 1	6		A 5	Ň	0-120 (400)	0	Ñ		
9 Jump frequency setting 2	7	Minimum frequency limiter setting	A 6	Ñ	0-120 (400)	0	Ñ		
9 Jump frequency setting 2	8	Jump frequency setting !	A 7	Ñ	0-400	0	Ń	· · · ·	
10 Jump frequency setting 3	9		A 8	Ŕ	0-400	0	Ň		
11 Carrier frequency setting	10		A 9	Ñ	0-400	0	Ń		
Tenguency command sampling frequency	11		AIO	Ń	2.0-16.0	(16.0)	Ñ	Sec 7-18	
13 Multispeed first speed setting	12		-	Ñ			Ż		
Multispeed second speed setting	13		•	Ń		0	Ň		
15 Multispeed third speed setting	14	1		Ń		0	Ň	 	
	15			Ñ		0	Ň		
17 Electronic thermal characteristic selection	16		+			100	_		
18			1						
Description Section Section A26 N									
External frequency setting end			} 						
Instantaneous restant selection			•						-
22 Dynamic braking usage ratio				_					-
23 Optional arrival frequency for acceleration A39 N			_					See 7-21	
24 Optional arrival frequency for deceleration								5.0	
Monitor signal selection			+					-	
26 Frequency converted value setting			+	_					
27 Analog input selection	 +		\leftarrow			1.0			
28 Frequency arrival signal output method			-						
Restarting after FRS signal selection			 			0			
30 Reduced voltage soft start setting			_						
Running mode selection			: 	_					
32 Jogging frequency setting	-			_				•	
33 Base frequency setting	-					1.00	$\overline{}$	Frequencies below the start frequency	
Maximum frequency setting									
Maximum frequency selection			<u>-</u>						
36 Frequency command/output frequency adjust (O-L terminal) A80 N 0-255 N N NOTE 2	\rightarrow								
37 Frequency command/output frequency adjust (OI-L terminal) A81 N 0-255 N N NOTE 2	_			-					
38 Selection of reset terminal performance A86 N	$\overline{}$								
P gain setting of PID function			\longrightarrow					NOTE 2	
40 I gain setting of PID function			\rightarrow						
1 Digain setting of PID function A92 N 0.0-100 0.0 N 42 Selection of PID function A94 N 0-4 0 N 43 Setting method of PID reference value A95 N 0.1 0 N 44 Setting of PID reference value A96 N 0.00-200 0.00 N 45 Auto tuning setting A97 N 0-2 0 N 46 Motor data selection A98 N 0-2 0 N 47 Ro-To option selection A98 N 0-1 0 N 48 Input terminal setting C0 N 0-3.5-9, 11-16, 18-28 18 N 49 Input terminal setting 2 C1 N 0-3.5-9, 11-16, 18-28 16 N 50 Input terminal setting 3 C2 N 0-3.5-9, 11-16, 18-28 5 N 51 Input terminal setting 4 C3 N 0-3.5-9, 11-16, 18-28 11 N 52 Input terminal setting 5 C4 N 0-3.5-9, 11-16, 18-28 13 N 53 Input terminal setting 6 C5 N 0-3.5-9, 11-16, 18-28 13 N 54 Input terminal setting 7 C6 N 0-3.5-9, 11-16, 18-28 1 N 55 Input terminal setting 8 C7 N 0-3.5-9, 11-16, 18-28 1 N 56 Output terminal setting 10 C10 N 0-2 0 N 57 Output terminal setting 12 C11 N 0-2 1 N 58 Input terminal a and b contact setting C20 N 00-FF 00 N			\vdash				—-		
Selection of PID function A94 N 0-4 0 N			-						
A95 N			 				\rightarrow		
44 Setting of PID reference value A96 Ñ 0.00-200 0,00 Ñ 45 Auto tuning setting A97 Ñ 0-2 0 Ñ 46 Motor data selection A98 Ñ 0-2 0 √ 47 Ro-To option selection A99 Ñ 0-1 0 Ñ 48 Input terminal setting I C0 Ñ 0-3,5-9,11-16,18-28 18 Ñ 49 Input terminal setting 2 C1 Ñ 0-3,5-9,11-16,18-28 16 Ñ 50 Input terminal setting 3 C2 Ñ 0-3,5-9,11-16,18-28 5 Ñ 51 Input terminal setting 4 C3 Ñ 0-3,5-9,11-16,18-28 11 Ñ 52 Input terminal setting 5 C4 Ñ 0-3,5-9,11-16,18-28 11 Ñ 53 Input terminal setting 6 C5 Ñ 0-3,5-9,11-16,18-28 13 Ñ 54 Input terminal setting 8 C7 Ñ 0-3,5-9,11-16,18-28	_		_	ightarrow			-		
Auto tuning setting	_			+		-			
46 Motor data selection A98 Ñ 0-2 0 V 47 Ro-To option selection A99 Ñ 0-1 0 Ñ 48 Input terminal setting I C0 Ñ 0-3,5-9,11-16,18-28 18 Ñ 49 Input terminal setting 2 C1 Ñ 0-3,5-9,11-16,18-28 16 Ñ 50 Input terminal setting 3 C2 Ñ 0-3,5-9,11-16,18-28 5 Ñ 51 Input terminal setting 4 C3 Ñ 0-3,5-9,11-16,18-28 11 Ñ 52 Input terminal setting 5 C4 Ñ 0-3,5-9,11-16,18-28 9 Ñ 53 Input terminal setting 6 C5 Ñ 0-3,5-9,11-16,18-28 13 Ñ 54 Input terminal setting 7 C6 Ñ 0-3,5-9,11-16,18-28 1 Ñ 55 Input terminal setting 8 C7 Ñ 0-3,5-9,11-16,18-28 0 Ñ 56 Output terminal setting 11 C10 Ñ 0			$\overline{}$				$\overline{}$		
47 Ro-To option selection A99 N 0-1 0 N 48 Input terminal setting C0 N 0-3, 5-9, 11-16, 18-28 18 N 49 Input terminal setting 2 C1 N 0-3, 5-9, 11-16, 18-28 16 N 50 Input terminal setting 3 C2 N 0-3, 5-9, 11-16, 18-28 5 N 51 Input terminal setting 4 C3 N 0-3, 5-9, 11-16, 18-28 11 N 52 Input terminal setting 5 C4 N 0-3, 5-9, 11-16, 18-28 11 N 53 Input terminal setting 6 C5 N 0-3, 5-9, 11-16, 18-28 13 N 54 Input terminal setting 7 C6 N 0-3, 5-9, 11-16, 18-28 1 N 55 Input terminal setting 8 C7 N 0-3, 5-9, 11-16, 18-28 0 N 56 Output terminal setting 11 C10 N 0-2 0 N 57 Output terminal setting 12 C11 N 0-2 1 N 58 Input terminal a and b contact setting C20 N 00-FF 00 N						+			
A8 Input terminal setting C N O-3, 5-9, 11-16, 18-28 18 N	$\overline{}$					- +			
Input terminal setting 2		· · · · · · · · · · · · · · · · · · ·		ightarrow					
So Input terminal setting 3				-					
Single terminal setting 4 C3 N O-3, 5-9, 11-16, 18-28 11 N									
52 Input terminal setting 5 C 4 Ñ 0-3, 5-9, 11-16, 18-28 9 Ñ 53 Input terminal setting 6 C 5 Ñ 0-3, 5-9, 11-16, 18-28 13 Ñ 54 Input terminal setting 7 C 6 Ñ 0-3, 5-9, 11-16, 18-28 1 Ñ 55 Input terminal setting 8 C 7 Ñ 0-3, 5-9, 11-16, 18-28 0 Ñ 56 Output terminal setting 11 C 10 Ñ 0-2 0 Ñ 57 Output terminal setting 12 C 11 Ñ 0-2 1 Ñ 58 Input terminal a and b contact setting C 20 Ñ 00-FF 00 Ñ	\rightarrow						ightarrow		
53 Input terminal setting 6 C 5 N 0-3, 5-9, 11-16, 18-28 13 N 54 Input terminal setting 7 C 6 N 0-3, 5-9, 11-16, 18-28 1 N 55 Input terminal setting 8 C 7 N 0-3, 5-9, 11-16, 18-28 0 N 56 Output terminal setting 11 C 10 N 0-2 0 N 57 Output terminal setting 12 C 11 N 0-2 1 N 58 Input terminal a and b contact setting C 20 N 00-FF 00 N			\rightarrow				-		
54 Input terminal setting 7 C 6 N 0-3,5-9,11-16,18-28 1 N 55 Input terminal setting 8 C 7 N 0-3,5-9,11-16,18-28 0 N 56 Output terminal setting 11 C10 N 0-2 0 N 57 Output terminal setting 12 C11 N 0-2 1 N 58 Input terminal a and b contact setting C20 N 00-FF 00 N	_		\rightarrow				-		
55 Input terminal setting 8 C 7 Ñ 0-3, 5-9, 11-16, 18-28 0 Ñ 56 Output terminal setting 11 C10 Ñ 0-2 0 Ñ 57 Output terminal setting 12 C11 Ñ 0-2 1 Ñ 58 Input terminal a and b contact setting C20 Ñ 00-FF 00 Ñ			_						
56 Output terminal setting 11 C10 Ñ 0-2 0 Ñ 57 Output terminal setting 12 C31 Ñ 0-2 1 Ñ 58 Input terminal a and b contact setting C20 Ñ 00-FF 00 Ñ			-	 +			-		
57 Output terminal setting 12 C11 Ñ 0-2 1 Ñ 58 Input terminal a and b contact setting C20 Ñ 00-FF 00 Ñ	$\overline{}$						-		
58 Input terminal a and b contact setting C20 N 00-FF 00 N	$\overline{}$		\rightarrow				+		
			+				-		
59 Output terminal a and b contact setting C21 N 00-07 04 N		Input terminal a and b contact setting		-		+			
<u>, la </u>	59	Output terminal a and b contact setting	C21	Ň	00-07	어	Ň		


NOTE 1: The most applicable motor capacity of the inverter is set.

NOTE 2: The initial setting of each inverter is adjusted when shipping from the works.

7.1 Explanation of Modes

(1) whomior mode contents







(2) Function mode

(2) Functi	on mode					
Monitor mode contents	Contents and display					
Output frequency setting	Methods for setting the output frequency are as follows: I. Digital operator					
	(I) Setting from the digital operator A frequency between 0.01 Hz and 9.99 Hz is set in units of 0.01 Hz.					
	A frequency between 10.0 Hz and 99.9 Hz is set in units of 0.1 Hz.					
	A frequency the twee en 100 Hz and 400 Hz is set in units of 1 Hz.					
	When the for key is pressed continuously. the value is changed continuously.					
	(2) Setting from the control circuit terminal (multispeed setting)					
	The output frequency at the multispeed can be se, as specified below. When the running mode is the process stepping mode, switch it to the multistage speed mode by the remote operator.					
	① Connect the multispeed terminal for setting the frequency to CMI.					
	(The relationship between multispeeds I to 7 and the control circuit terminals is as shown below.)					
	Multispeed Control circuit terminal 1					
	② Set an optional output frequency using the 🛕 or 🔲 key.					
	③ Press the FUNC key once to store the se, output frequency. NOTE 2: F c is displayed.					
	Press the key once. (Check whether the output frequency, which is se,. is displayed.)					
	Susping (1) to (4). the output frequency in the multispeed mode can be se,.					
	NOTE 3: Whenever any data is changed, be sure to press the FUNC key before starting					
	the next setting. Note that when the FUNC key is not pressed, the data will					
	not be se,. NOTE 4: When setting to over 120 Hz, the changing over maximum frequency is necessary.					
	Remote operator or copyunit must be used.					
	(When the value is switched to 400 by F-30. an output frequency of up to 400 Hz					
	can be se,.)					

Monitor mode contents	Contents and display				
Ī IJ	Set the motor direction. Set the motor direction when running by pressing the key. NOTE: The setting during run is impossible.				
tunning lirection	FUNC Initial set value Forward run Switching can be done by pressing				



Monitor mode contents	Contents and display						
Fg	Switching the run command and frequency command setting modes Set the run command and frequency command sending destinations. The standard specification selection range is from 00 to 03.						
Run		Set value	Run command to	Frequency command to			
command- ing		00	Digital operator	Digital operator			
method			Digital operator	Terminal block			
Frequency		02	Terminal block	Digital operator			
ng	Initial value	03	Terminal block	Terminal block			
nethod		04	Digital operator	Option 1			
		05	Option 1	Digital operator			
		06	Option 1	Option 1			
		7 7	Digital operator	Option 2			
		08	Option 2	Digital operator			
		09	Option 2	Option 2			
			Terminal block	Option 1			
			Option 1	Terminal block			
		[]2	Terminal block	Option 2			
		13	Option 2	Terminal block			
		14	Option 1	Option 2			
		15	Option 2	Option 1			
Setting method FUNC Initial value FUNC FUNC Initial value FUNC NOTE1: The run command and frequency command sending destinations can be set to							
	of the terminal, operator. option I, and option 2. Select the relevant set value.						
	NOTE2: When option I or option 2 is selected for "Run command to" and "Frequency command to," the digital operator and terminal block cannot issue commands. Set option I or option 2 (set values 194 - 15) only for operation or frequency commands from the optional PC board.						



Returning to the initialization (State set at factory before shipment)

When returning the equipment to the initial state set at factory before shipment for some reason, follow the following procedure.

1) Allocate STN (set value 7) to one of the input intelligent terminals. (Use 7) to 7 in the extension function mode to set the intelligent terminals.)

(However, 7) cannot be used since resetting RS is initially set.)

. .

- 2) Short-circuit the STN terminal and P24 (CM1*), then turn power off and on. (When the power is turned off, do not turn it on again until the CHARGE lamp of the logic PCB goes off.)
- 3) Keep the STN terminal open for more than 6 seconds. (When keying, resetting, or turning power off is performed within 6 seconds, the equipment may not be initialized.)
- 4) **Turn** the power off after more than 6 seconds. (When the power is turned off within 6 seconds, the equipment may not be initialized.)

How to Delete Trip History Data (| / / / , and | / / / /)

To delete trip history data for some reason, follow the instructions shown below using the remote operator (DOP or HOP) or copy unit (DRW or HRW).

- 1. Using the remote operator (DOP-OA) or copy unit (DRW-OA)
 - (1) Display INIT TCNT (trip history count clear) or the function mode initial setting F-38 INIT.
 - (2) Move the cursor to beneath the initial set values. Select CLR and store it.
 - I) Turn the power off once and then turn it on. or close the reset terminal RS-P24 (CM 1*) for approx. a second. By this, trip history data is deleted.
 - 2) When trip history is deleted, data of [F-38] is set to [CNT]. Trip counting restarts.
- 2. Using high-performance remote operator (HOP-OJ) or high-performance copy unit (HRW-OJ)
 - (1) Display [TCNT 0: CNT] (trip history count clear) or the function mode initial setting [2-1 INIT].
 - (2) Enter a count clearing value [0: CLR] from the 10-key pad.
 - I) Turn the power off once and then turn it on. or close the reset terminal RS-P24 (CM I*) for approx. a second. By this, trip history data is deleted.
 - 2) When trip history is deleted, data of [2-1 INIT] is set to [CNT]. Trip counting restarts.


NOTE: Symbols * are indicated for Sink type wiring.


(3) Extension function mode contents

ī


Extension function code	Contents and display
80	Set the control method. Select one of the following control codes.
Control nethod setting	FUNC Initial value V/f control (VC) Constant torque characteristics of f
	V/f control (VP1) Reduced torque characteristics, I.5 power NOTE: set torque boost in 70 to 90. V/f control (VP2)
	Reduced torque characteristics, I.7 power NOTE: set torque boost in 70 to 90 V/f control (VP3)
	Reduced torque characteristics, 2.0 power NOTE: set torque boos! in 70 to 90 Sensorless vector control (SLV)
	Vector control with sensor (V2) NOTE: Vector control INV only (Feedback board is nesessary)
B I	Set the motor capacity and "umber of motor poles according to the motor to be used. The maximum rating of the applicable d-pole motor for each inverter is set initially. NOTE:
1otor apacity, notor poles etting	Motor capacity No. of motor poles When the data does not match that of the mootor, satisfactory characteristics may not be obtained during the sensorless vector running. The full performances may not be demonstrated if the rating of a motor used is tow or
	7-15


_	
Extension function code	Contents and display
Speed control response constant setting	Set the response speed (ASR system gain) between the inverter and motor. When increasing or decreasing the current motor response speed. adjust the ASR system gain. When the set value is decreased, the response speed is increased. When the set value is increased, the response speed is decreased. A constant between 0.01 and 9.99 is set in units of 0.01 FUNC Initial value A constant between 10.0 and 99.9 is set in units of 0.1. FUNC A constant between 10.0 and 99.9 is set in units of 0.1.
start requency idjustment	Set the frequency for starting output of the inverter. Set a frequency between 0. I Hz and 9.99 Hz in units of 0.01 Hz Output voltage FUNC Initial value FUNC When the start frequency is increased. the acceleration or deceleration time is decreased.








100
















Extension function code	Contents and display
code	Setting method Setting method FUNC FUNC
1aximum requency election	Select 120 Hz or 400 Hz as the upper limit that can be set in the maximum frequency setting (A63). FIET INTERIOR INITIAL VALUE FUNC FUN
requency ommand otput equency djust O-L, 01-L)	Adjust the relationship between the external frequency command and the inverter output frequency. Recommand (O-L) Current command (01-L) This function is factory-set to the appropriate polition. If this setting is changed unnecessarily, the correct relationship between the external frequency command and output frequency is no longer maintained. This will result in poor control performance. Adjust the setting of this function only when the output frequency does not conform to the external command. Adjustment method Voltage command: Put voltage command (10V of 5V) to O-L terminal. and adjust Recommand Requency comes to maximum. Current command: Put current command (4-20mH) to OI-L terminal, and adjust Recommand Requency comes to maximum.






Extension Contents and display function code A terminal function is allocated to each of the input intelligent terminals I to 8. When using a function other than the standard set functions or changing the terminal order, set the function for each terminal. The minimum input signal acceptance time of the input intelligent terminals is about 20 ms. to PCB terminal array Arrary of codes and intelligent terminals FM Terminal CMI Initial setting Code Function name rating plate **PLC** C_0 Input terminal setting 1 18 1 P24 nput FW Input terminal setting 2 2 16 C1erminal C 2 Input terminal setting 3 3 5 etting to 8 C 3 Input terminal setting 4 4 11 6 5 Input intelligent C 4 Input terminal setting 5 5 9 4 terminal section C 5 Input terminal setting 6 6 13 3 C 6 Input terminal setting 7 7 ì 2 Input terminal setting 8 Н Setting method Press the FUNCkey once for the terminal code to be set. The set values of the terminals which are set at present are displayed. Display the set value of the terminal to be used from the function list indicated below by pressing the key and c♥ and then press the FUNC key. The display is returned to the code display and the terminal function is changed; Enter the set value of the terminal name to be used bypressing the ke 🛕 and 👽 FUNC Setting example: The RS (reset) function the SFT (treminal software lock) function. Input terminal function list Set value Abbrevia-Sci value Abbrevia-Function name Function name REV Reverse 11 **FRS** Free run 0 CFI Multispeed 1 1 12 **EXT** External trip 2 CF2 Multispeed 2 USP USP function 13 CS 3 CF3 Multispeed 3 14 Commercial power source switching 5 JG Jogging 15 SFT Terminal software lock AT 6 DB External DC braking Analog input voltage/current switching 16 RS STN Initialization 18 Reset 8 SET 2nd function 27 UP Remote operation function, acceleration 9 CHI 2-stage acceleration and deceleration 28 DWN Remote operation function, deceleration Precautions for terminal setting Same terminals cannot be set between [\square and \square When moving a terminal name to another terminal, set another terminal which is not to be ued at the setting source before inputting the set value to the setting destination and then select the terminal name which is to be set at the setting destination.

71

Extension function			Conte	ents an	d display
		er than the standard			eput intelligent terminals I I and I 2. When using changing the terminal order. set the function for
	Arrary of con	des and intelligent to	erminals		PCB terminal array
V	Code F	unction name	Terminal rating plate	Initial setting	
Output	C10 Output	t terminal setting 11		0	CM2
Output terminal	C11 Output	t terminal setting 12	12	1	12
setting	Input termina	al function list			
II and 12	Set value Abbrevia-	Function n	ame		AL2
	0 FAI	Frequency arrival:	signal		ALO
	1 RUN	Signal during runn	ing		The setting method is the same
	2 OTQ	Overtorque signal	(Note)		as that of the input terminals
					<u>A 18</u> to <u>A 25</u>].
	NOTE: T	he torque of the ove	rtorque sig	nal car	be set by the remote operator. The initial
		·-			are 100% torque. The overtorque signal can be
		used only under the	_		- 1 -
	Setting meth	od			
	Press tl	he FUNC key once fo	or the termi	nal cod	de to be set.
					at present are displayed. Display the set value
		•			ist indicated below by pressing the key
	and ▼	and then press th	FUNC: ke	ey.	
	The dis	play is returned to the	ne code dis	splay aı	nd the terminal function is changed
		F 1 '	Enter the set was to be used by		the terminal name the keys and . FUNC
	<u>C 10</u>	→ 1]	····	→ [10]
	Precautions	for terminal setting			<u> </u>
		erminals cannot be s			
					minal. set another terminal which is not tobe set value to the setting destination and then
					the setting destination.

Extension function Contents and display code The input intelligent terminals 4 to I can be changed individually to the a contact or b contact specification. Select the set value by pressing the keys and \ by combining the contacts a and b with reference to the table indicated below. Example: When the set value is A: — Contact a: Input terminals 3. I Contact b: Input terminals 4, 2 Input terminal Setting method a and b contact **FUNC** setting Press the | A key 10 times. Select the contact specification with reference to the table indicated below. Initial setting Set value F Initial value Е d 7 6 5 b 3 2 0 a: Contact a specificati (Shorted when power is turned ON) 4 b ь ь ь Ъ b b ь a a a a a a a a Input terminal b: Contact b specificati 3 (Opened when power is turned ON) b b b b a a a a b b Ь b a a a а 2 b b a b ь b b b a а b a a а а a Set the high b b a b a b a b b a ь order to 0. Input terminal a and b contacts function list The output ingent terminal II and 12 and alarm output terminal can be changed idividually to the a contact orb contact specification. Select the set value by pressing the keys and combining the contacts a and b with reference to the table indicated below. Example: When the set value is - Alarm output: Contact b Output Terminals I I and I 2: Contact b 1 tierminal a and b Setting method contact setting **FUNC FUNC** Press the A key 3 times. Initial setting Initial value Output terminals 11 and 12 -Set value 6 5 4 3 2 0



8. PROTECTION FUNCTIONS

The J300 series inverters are equipped with protection functions against overcurrent, overvoltage, and undervoltage which protect the inverter. If the protection functions are engaged, the output is shut down, motor runs free and holds that condition until it is reset.

Description	Contents		Display	
Over current protection	71 Carriette ado to the attendanty carront of between the penci medale	Constant speed	<u>EIO 1</u>	
	flows through the invener and causes a fault. Therefore, when an abnormal current is detected by the alternating current CT and it exceeds	Dec.	E02	
	a specified value, the output is cut off. (An abnormal current is also detected in the power module. Refer to [F] [[] 2], [[] 3], and [[] 4].)	Acc.	E03	
Overload protection (NOTE I)	When a motor overload is detected by the electronic thermal function, the o of the invener is cut off.	output	E05	
Braking resistor overload	When the braking time exceeds the Satting by A3B braking duly factor. an overvoltage the output of the invener is Cut off.		E06	
Overvoltage protection	When the convener voltage exceeds a certain level due to regenerative ener the motor, this protection function engages, and the output of inverter is cut		E07	
EEPROM error (NOTE 2)				
Undervoltage protection	COULTO CITCUIT, It also deperates motor heat and causes low torque. Output is cut offi			
CT error	Abnormality on built-in CT and the output of the inverter is cut off.			
CPU error	Malfunction or abnormality on built-in CPU and the output of the invener is cut off.			
External trip	An abnormality signal from external equipment cuts off the output of the in .(When external trip function is selected)	nverter.	E 12	
USP error	It indicates an error when power is turned on while the invener is being rur (When USP function is selected)	n.	E 13	
Ground fault protection	g g g			
Input overvoltage	When the input voltage is higher than the specified value, it is detected 100 seconds after power is turned on and the output is cut off. However, when a voltage higher than approx. 250 to 270 V (200V class), 500 to 530 V (400 V class) is inputted, it is higher than the rated value of the pan in use. So that the pan may nor be protected and damaged.			
Instantaneous power failure for more than IS ms occurs, the output is cut off. When the instantaneous power failure time is long, the fault signal is released. Note that when restart is selected, the equipment restarts when the running command remains.				



Description	Contents	Display
		r

i

Description	Contents		Display		
Optional	An error occurs in the optional connection (connector, etc.).	Option 1	E 17		
connection error		Option 2	EIB		
Optional	An error message outputted from the optional PCB NOTE 5	Option 1	E 15		
PCB error	CCB error				
Phase failure protection error	When a phase failure is detected on the receiving side {R(L1), S(L of the inverter, the output is cut off. (NOTE 3)	2), T(L3)}	E24		
Power module	the determinant to deliver in the power models operates.				
protection	When the output side of the inverter is shorted or the motor is restricted, a large current flows through the inverter and causes a	Deceleration	E 32		
	fault. Therefore, when a current in the power module or an abnormal temperature of the main device is detected and it	Acceleration	E 33		
	exceeds a specified value, the output is cut off.	Stop	EBY		

NOTE 1: If a trip occurs, press the RESET key or short the reset terminal RS-CM I assigned as a control circuit terminal after a delay of 10 seconds.

NOTE 2: A trip can be cleared by pressing the RESET key or shorting the reset terminal RS-CM I assigned as a control circuit terminal. Resetting the power supply cannot clear a trip. (To reset the power supply is to turn power off and turn it on again after the CHARGE lamp at the upper right corner of the control PC board goes off.) Check again whether the set data is correct.

NOTE 3: Power OFF during motor deceleration may cause an input phase failure error.

NOTE 4: The instantaneous ride-thru period of 15ms may be shortend depending on the power supply voltage or load.

NOTE 5: When the J-FB is installed, an error is displayed for each factor as shown below.

Encoder line break: E 6 0

Overspeed: E 6 1

Positioning error: E 6 2

Thermistor line break: E 6 4

Motor overheat: E 6 5

Malfunction or banormality on built-in CPU of the option: [E|E]

Other display

Display	Contents
	It is displayed when the reset signal is kept supplied or an error occurs between the digital operator and inverter. When one of the keys , , and FUNC ipressed, it is recovered. When it is not recovered, turn power on once again.
	It is displayed when a data set value more than 3 digits in length (for example. দাতের 1000) is set,
	It is displayed when power is turned off.
	There is no trip history available.
000	This is not an abnormal operation because the instantaneous stop restart function is being performed. (When I to 3 is selected by the extension function [A]34.)
0	The autotuning operation terminates normally.
	The autotuning operation terminates abnormally.
<u> </u>	Waiting due to insufficient voltage. 'After recovery. the original display appears.



9. TROUBLESHOOTING

9.1 Error Messages and Diagnosis

When the inverter goes wrong, it operates as indicated below. Find the cause and take, contermeasures.

Error Messages and Diagnosis

					Error Messages	Diagnosis		
			Symptom .					
Circuit breaker (MCB)	Electromagnetic contactor (Mg)	Thermal relay (THRY)	Display on the digital operator (display on the LCD of the remote operator)	Failure alarm relay	Cause (explanation of message)	How to reset (NOTE 1)	Check	Countermeasure
			E01 (OC. Drive)	0	Overcurrent detected by the AC CT while	Α	Check whether a load was changed rapidly.	Do not change loads rapidly.
					the motor was running at a constant speed (overcurrent during operation)		Check whether there is a shoned output or ground fault.	Check whether the output lines or motor is shorted.
			E02 (OC. Decel)	0	Overcurrent detected by the AC CT during	Α	Check whether the speed was decreased rapidly.	Set a longer deceleration time.
					motor deceleration (overcurrent during deceleration)		Check whether there is a shoned output or ground fault.	Check whether the output lines or motor is shorted.
			E 0 3 (OC. Accel)	0	Overcurrent detected by the AC CT during motor acceleration	Α	Check whether a load was changed rapidly.	Do not change loads rapidly.
					(overcurrent during acceleration)		Check whether there is a shorted output or ground fault.	Check whether the output lines or motor is shorted.
							Check whether the start frequency is too high.	Lower the start frequency.
							Check whether the torque boost is too high.	Lower the torque boost.
							Check whether the motor is locked.	Check the motor or loads.
			E 0 5	0 C	verloaded inverter	Α	Check for an overload.	Lower the load ratio.
			(Over. L)		(operation under an overload)		Check whether the electronic thermal level is correct. (Check whether the level has been changed.)	Set an appropriate level.

IOTE 1: How to reset

- A: Stop the inverter. Then, connect the <RS> and <CM I > control terminals or press the STOP/RESET key on the operator.
- B: Operate the circuit breaker and electromagnetic contactor (turn the power on again)
- C: Stop the inverter. Then, reset the thermal relay.



			Symptom		I	1		
Circuit breaker (MCB)	Electromagnetic contactor (Mg)	Thermal relay (THRY)	Display on the digital operator (display on the LCD of the remote operator)	Failure alarm relay	Cause (explanation of message)	How to reset	Check	Countermeasure
			E06 (OL. BRD)	0 Т	he regenerative braking time is longer by the value set by BRD%ED.	Α	Check the braking resistor use ratio set in [A]38].	Set a longer deceleration time. Set a larger operation duty cycle. Set A[38] to [0.0].
			E07 (Over. V)	0	Overvoltage in the DC smoothing circuit	Α	Check whether the speed was decreased rapidly.	Set a longer deceleration time.
							Check whether the motor was run from the load side.	Do not use consecutive regenerative loads.
							Check whether there is a ground fault.	Check whether the output lines or motor is shorted.
			E08 (EEPROM)	0 E	EPROM error	'A	Check whether there is a large-noise source near the inverter.	Move the noise source away.
							Check whether the ambient temperature is too high.	Replace the cooling fan.
			E09 (Under. V)	01	Defective power supply (insufficient voltage)	Α	Check whether the voltage is lowered.	Check the power supply.
					voltage)		Check whether the MCB or Mg has a poor contact.	Replace the MCB or Mg.
							Check whether 10 or more instantaneous power outages within 100 ms occurred in 10 minutes.	Check the power supply.
			E10 (CT)	0 с	l-error	Α	Check whether the CT is defective.	Repair the Cf.
			E11 (CPU)	0	СРИ епог	Α	Check whether there is a large-noise source near the invener.	Move die noise source away.
							Check whether the invener is defective.	Repair the inverter.
			EI2 (EXTERNAL)	0 E:	kternal trip	Α	Check whether there was a defective external unit when rhe external trip function war selected.	Eliminate the error from the external unit.
			E13 (USP)	0	USP error	A	Check whether power was turned on while the inverter was running when rhe USP function was selected.	Eliminate the error from the external unit.

í



			Symptom					
Circuit breaker (MCR)	Flortromagnetic contactor (Ma)	Thermal relay (THRY)	Display on the digital operator (display on the LCD of the remote operator)	Failure alarm relay	Cause (explanation of message)	How to reset	Check	Countermeasure
			EI4 (GND. Fit)	0	Ground fault on the output side of the inverter	А	Checkthewiringbetweenthe inverter and motor and also check the motor for a ground fault. (Use a megger.)	Correct the portions having a ground fault.
			EI5 (OV. SRC)	0	Excessive received voltage	А	Check whether an excessive voltage was received during an operation other than deceleration.	Lower the voltage to be received. Reduces fluctuations of the received voltage. Install an AC reactor on the input side.
			E 6	0	Defective power supply(instantaneous	Α	Check whether the voltage is lowered.	Restore the power supply to normal.
			,		power outage)		Check whether the MCB or Mg has a poor contact.	Replace the MCB or Mg.
	_		E 17 (NG. OPI)	0	Incorrectly connected option-1 PC board	Α	Check the connectors and other connections for abnormal conditions.	Repair the defective connections.
			E 18 (NG. OP2)	0	Incorrectly connected option-2 PC board	Α	Check the connectors and other connections for abnormal conditions.	Repair the defective connections.
			E 9 (OP1)	0	Defective option-1 PC board	A	Refer to the instruction manual.	
			E20 (OP2)	0	Defective option-2 PC board	A	Refer to the instruction manual.	
			E24 (PH. Fail)	O	Defective power supply (missing phase)	A	Check the power supply connections for abnormal conditions.	Repair the abnormal ponions.
							Check whether the MCB or Mg has a poor contact.	Replace the MCB or Mg.
	_		E31 PM. Drive)	0	(NOTE 1) Failure detected by a detector in the power module while the motor	А	Check whether a load was changed rapidly.	Doπot change loads rapidly.
					was running at a constant speed, or excessive tem- perature rise in the inverter		Check whether there is a shorted output or ground fault.	Check whether the output lines or motor is shorted.
			E32 PM. Decel)	0	(NOTE 1) Failure detected by a detector in the power module during motor	Α	Check whether the speed was decreased rapidly.	Set a longer deceleration time.
					deceleration, or excessive temperature rise in the inverter		Check whether there is a shorted output or ground fault.	Check whether the output lines or motor is shorted.

NOTE I: The failures detectable in the power module are overcurrents, excessively hot main devices. and insufficient voltages from the gate circuit power supply.

9-3

		/mptom					
CITCUIT Dreaker (MCB)	писппантенау (ТНКҮ)	Display on the digital operator (display an the LCD of the remote operator	ראוווורי אוארח וייואע	Cause (explanation of message)	How to reset	Check	Countermeasure
		E33 PM. Accel	1 1	VOTE I) ailure detected by a etector in the power	Α	Check whether the speed was increased rapidly.	Set a longer acceleration time.
				iodule during motor iceleration, or icessive temperature		Check whether a load was chawed rapidly.	Do nor change loads rapidly.
				se in the invener		Check whether there is a shorted output or ground fault.	check whether the output lines or motor is shorted.
						Check whether the start frequency is too high.	Lower the start frequency.
						C'heck whether the torque boost is too high.	Lower the torque boost.
						Check whether the motor is !crked.	Check the motor or loads.
;		E34 PM. ERR))	iOTE I) iilure detected by a tector in the power odule while the motor	A	Check whether the installation is vertical and the wall is a nonflammable wall such as an iron plate.	Check the installation.
				as stopping. or cessive temperature ie in the inverter		Check whether the cooling fan is running and the ambient temperature is too hieh.	Replace the coaling fan.
				:		Clheck the internal power supply.	Repair the internal power supply.
						Check the main devices.	Repair main devices.
		E60 (OP1 0) 60 E67 (OP1 7))	efective J-FB PC ard	Α	Refer to the manual supplied with the J-FB PC board.	
		E70 (OP2 0) to E77 (OP27))	fective J-FB PC ard	A	:fer to the manual supplied with the I-FB PC board.	

NOTE I: The failures detectable in the power module are overcurrents, excessively hot main devices. and insufficient voltages from the gate circuit power supply.

			Symptom					
Circuit breaker (MCB)	Electromagnetic contactor (Mg)	Thermal relay (THRY)	Display on the digital operator (display on the LCD of the remote operator)		Cause (explanation of message)	How to reset	Check	Countermeasure
		0	_	_	_	С	'Check for an overload.	Lower the load ratio.
				ļ			Check whether the thermal relay is set to an appropriate value.	Set the thermal relay to an appropriatevalue.
0			_		_	В	Check whether there is a sihon or ground fault in the power supply.	Remove the short or ground fault.
		:	i				Check whether the MCB capacity is sufficient.	Increase the MCB capacity.
							Check whether the inverter module or converter module is defective.	Repair the inverter module o converter module.
	0			Ŀ	'ower outage	В	'heck for a power outage.	Flestore the power supply to normal.
		1					heck whether the MCB or 1g has a poor contact.	Fleplace the MCB or Mg.

9.2 Trouble shooting

Symptom		Probable cause	Countermeasure					
The notor vill not	The inverter outputs U(T1), V(T2)	Is power being supplied to terminals R(L1), S(L2) and T(L3)? If it is, the POWER lamp should be on.	. Check terminals R(L1), S(L2), T(L3), U(T1) V(T2), and W(T3) Turn on the power supply.					
un.	and W(T3) are not supplying voltage.	• Is the display E • ?	Press and check the content. Then press the reset key.					
		 Is the operation instruction RUN ON? Is terminal FW (or REV) connected to terminal CMI? 	. Set to ON. *Connect terminal CM1 to terminal FW (or REV) on the printed-circuit board. (When the terminal mode is selected.)					
		 Has the frequency setter been turned on by pushing FUNC key and then © key. Are the printed-circuit board terminals H, 0 and L connected to the potentiometer? Are the terminals connected to the external and internal interface power source the terminal mode is selected? 	Push down keys and set. When terminal mode is selected, connect the potentiometer to H, 0, and L. and then set. In the case of the internal interface power source, short the terminals P24 and PLC or CM I and PLC. In the case of the external interface power source, turn the PLC terminal on.					
		. Has RS/FRS been left ON?	. Release reset Contact FRS.					
		• Is the mode key $\boxed{\textit{F}}$ setting correct?	Read the explanation of the function mode once again. (Page 7-12) F9 frequency/run commanding method					
	Inverter outputs U(T1), V(T2) and W(T3) are supplyi voltage.		Release seizure or lighten the load. *Test the motor independently.					
	The optional remote operator is used. (copy unit)	 Are the remote operator and equipment body switched coorrectly? Is the setting of the DIP switch on the back of the remote operator correct? 	Check the operation of the optional remote operator. (copy unit) ON OFF 1: OFF 2: ON (Same as VWA, J100)					
he irection f the lotor is eversed.		 Are the connections of output terminals U(T1), V(T2) and W(T3) correct? Is the phase sequence of the motor forward or reverse in respect to U(T1), V(T2) and W(T3)? 	• Make the connections according to the phase sequence of the motor. (In general, forward should be in the sequence: U(T1), V(T2) and W(T3).)					
		Are the terminals on the printed-circuit board correct?	Short the FW terminal for forward rotation of the intelligent input terminal 8 (the intelliger input terminal 8 is allocated to run command REV by initialization at factory before shipment) for reverse rotation to the CMI terminal (Sink type).					

Sym	nptom	Probable cause	Countermeasure				
he rpm f the notor /ill not		After checking the wiring of the frequency setter. the rpm still does not increase when the setter is turned.	Replace the frequency setter.				
icrease.		Are terminals 7 and CM1, terminal 6 and CMI ON (Sink type)?	Turn off terminal 7 and 6. (When the frequency and multistage speed are fixed at a given frequency, the speed potentiometer Will be invalid.)				
		Is the load too great?	Decrease the load. When the load is too great, the limiting function will be activated, so that the rotational speed will be lower than the setting.				
he rpm f the notor oes not natch the nverter.		Is the maximum frequency setting correct? Are the number of motor poles, the gear ratio. and pulley ratio correct?	Check the speed-change ratio.				
he data	The data is returned to the initial setting.	The STN terminal is turned ON and the power is turned on. The input terminals I to 5 are turned ON and then power is turned on.	Turn the STN terminal OFF. Input the data again. Replace the logic PCB.				
	The data has not changed.	Was the power turned off without pushing the FUNC key after the data was changed with keys.	Input the data and push the FUNC key onc				
		The data is memorized upon power off. Is the time from power OFF to ON less than six seconds?	Take six seconds or more when turning power OFF and ON after changing the data.				
	Data copied by the copy unit is not input.	Is the power turned off for five seconds or more after the display changed from REMT to INV. (HRW-OJ)	Copy again and turn the power off five seconds or more after copying.				
he data l not nanged. r	Frequency setting can not be changed. Run and stop can not be done.	The change of the terminal mode and digital operator mode were correct?	Confirm the change in $\boxed{F} \boxed{g}$ setting mode.				
	The data can not be changed.	Is the input terminal SFT ON? Is the software lock mode set at MD2 or MD3?	Turn the SFT terminal OFF. Turn the switch OFF.				
		Note: If software lock is ON because of use with an explosion proof motor. do not release the software locks.					
		use with an explosion proof motor.					

Symptom	Probable cause	Countermeasure
Overload (Electronic thermal trip) (Low Frequency zone)	Is the F B torque boost too high? Do the electronic thermal characteristics match the set characteristics of the motor?	Decrease the torque boost. Reset the electronic thermal characteristics and level.
The input voltage trips.	Is the input voltage high? Is the equipment stopped with the inverter DC voltage increased after sudden deceleration?	Lower the input voltage. Set a deceleration time which is a little longer. Increase the AVR set value above the current input voltage and lower the V gain by the ratio.

10. MAINTENANCE AND INSPECTION

10.1 Maintenance and Inspection Precautions

WARNING

- * Be sure to turn off the power supply during maintenance and inspection.
- * After the power supply has been turned off, you must always wait 10 minutes so that DC bus capacitors can discharge then start maintenance and inspection after the CHARGE lamp on the printed-circuit board has gone out. (Immediately after the lamp has gone out, there will be a residual voltage of about 50 V DC in the DC bus intermediatecircuit.)

Perform the work after the CHARGE lamp has stopped flickering.

* Make sure that only qualified persons will perform maintenance, inspection and part replacement. (Before starting the work, remove metallic objects from your person (wristwatch, bracelet, etc.)

(Be sure to use tools protected with insulation.)

Otherwise, there is a danger of electric shock and/or injury.

/ CAUTION

- * When removing connectors, never pull the wires. (Wires for cooling fan and thermal relay)
 - Otherwise, there is a danger of fire due to wire breakage and/or injury.
 - General precautions

Always keep the unit clean so that dust or other foreign matter does not enter the inverter. Take special care in regard to breaking lines and connection mistakes. Firmly connect terminals and connectors. Keep electronic equipment away from moisture and oil. Dust, steel filings and other foreign matter can damage insulation. causing unexpected accidents, so take special care.


10.2 Inspection Items

- (1) Daily inspection
- (2) Periodic inspection (Approximately once a year)
- (3) Insulation resistance tests, withstand voltage tests

See 10-3.

Conduct these tests by short-circuiting the terminals as shown below, and by following the conditions described.

- In regard to insulation resistance tests, measure the terminals below and the grounding at 500 VDC, and make sure that 5 Megohms or greater is indicated.
- Do not perform the withstand voltage test. When it should be done, in regard to withstand voltage tests, supply the terminals below and the grounding with 1500 VAC (200 V class), 2000 VAC (400 V class) for one minute, and make sure that there are no abnormalities.
- Do not conduct insulation resistance tests and withstand voltage tests for terminals other than those indicated below.
- Increase or decrease the applied voltage for the withstand voltage test slowly and turn the equipment 0 V again.



- NOTE 1: If the inverter is used under high temperature and heavy load conditions, its operating life will be significantly reduced.
- NOTE 2: If the inverter has been stored for three years or more, apply the following conditions.
 - 1) Apply 80% of the rated voltage of the capacitor for I hour at normal temperature.
 - 2) Increase the voltage to 90% and apply it for I hour.
 - 3) Apply the rated voltage for 5 hours.
- NOTE 3: Precautions in handling printed-circuit boards.

 When maintenance and inspection of printed-circuit boards is necessary, be sure to follow the precautions below.
 - Prevent damage caused by static electricity. The IGBT of the inverter module, the MCUs and ICs on a printed-circuit board can be destroyed by static electricity, so be sure to ground work benches, soldering irons, and yourself before working on a printed-circuit board.

Daily Inspection and Periodic Inspection (1/3)

nspection	Inspection item	Inspection item Inspection content		ction cycle	Inspection method	Criteria	tandard	Instruments	
ocation			Daily	eriodic		2	eriod		
Overall	Ambient invironment	Checkambienttemperature, humidity. dust, corrosive gases. oil mist. etc.	~			Ambient temperature between -10 to +50°C; no icing.	_	Thermometer	
						Ambient humidity 20 to 90%; no dew condensation			
	Devices overall	Check for abnormal vibrations and noise.	V		Visual and aural inspection.			Hygrometer	
	ower supply oltage	Check the input line voltage.	V		Measure the voltage between inverter terminals R(L1), S(L2) and T(L3).	No abnormalities. 200 to 220 V. 50 Hz 200 to 230 V. 60 Hz 380 to 415 V. 50 Hz 400 to 460 V, 60 Hz		T'ester	
Aain ircuit	Overall	(1) Insulation resistance test (between main circuit terminals and grounding terminal)		V	(1) Increase righting Making a check on the tcrque is needed for the increase tighten-	No abnormalities in (I) and (2). Tightening torque (kgf.cm) . M3: 8 IO		500 v class Mcgohmmeter	
		(2) Check installation for looseness.		~	ing of the module! such as a power module. diode	• M4: 12 - 15 . M5: 20 - 25 . M6: 25 - 30			
		(3) Check for evidence of overheating in the various components.		~	module. Do not execute increse tightening with	• M8: 100 - 135 • M10: 150 - 200			
		(4) Clean		V	no torque gauge prepared.	Tightening torque for IPM and Diode modules (kgf.cm)			
					2) Tighten. 3) Visual	. M4: IO-15 . M5: 15-20 • M6: 20-25			
					inspection.				

Daily Inspection and Periodic Inspection (2/3)

nspection ocation	Inspection item	Inspection content	Inspection		Inspection method	Criteria	Standard replacement	Instruments
		1	Regularly -	Periodic	<u>-</u>		period	
/lain ircuit	Terminal board	No damage.		~	Visual inspection	No abnormalities.		
	Smoothing capacitor	(1) Check for leaking (2) Check for swelling	V V	No (2).	Visual inspection of (1) and (2).	No abnormalities in (I) and	5 yæars (Nate 1) 1)
	Relays	(I) Check for stuttering noise when operating		~	(I) Aural inspec- tion.	(I) No abnormalities	5 years	
	Resistors	(1) Check for large cracks or changes in color		~	(1) Visual inspection	(I) No abnormalities.		
	Cooling fan	(I) Check for abnormal vibrations and noise	~		(I) Rotate manually with power off and increase tightening	(I) Smooth rotation	2 - 3 years	_
		(2) Check for dust	~		(2) Visual inspection	(2) No abnormality		
							;	

Daily Inspection and Periodic Inspection (3/3)

Inspection	Inspection item		Inspection content	Inspection	on cycle'	Inspection method	Criteria	Standard replacement	Instrument	
location	·		•	Regularly Periodic		•		period		
Control circuit	Operation check		Operation check (I) Check the balance of the output voltage of individual phases when operating the invener independently.			(I) Measure the voltage between the phases of inverter output terminals U, V, and W.	(I) Within 2% voltage difference between phases.		_	
			(2) Conduct a sequence protection operation test, and make sure that there are no errors in the protec tion and display circuits.			(2) Simulate operation of the inverter protection circuit.	(2) Operate without any abnormalities.			
	Compo- nent check, including printed- circuit	Overall	(I) No abnormal odor or changes in color.(2) No significant corrosion.		V	Visual inspection	No abnormalities	-		
	boards	Capacitor	No fluid leakage or deformation.	~		Visual inspection	No abnormalities	5 years (Note 1)	<u>. — </u>	
Ďisplay	Digital operation panel		(I) No illegible display	V		Visual inspection	Normal operation	7 years		
			(2) No lack of character	V			Display can be read out.			
			(3) No blown out LEDs	V						

Note I. The life of the capacitor is affected by the ambient temperature. Refer to the ambient temperature - capacitor life curve shown in Appendix 5.

Note 2. The invener must be cleaned periodically. If dust accumulates on the fan and heat sink, it can cause overheating of the invener.

10.3 Measurement Method for I/O Voltage, Current, and Power

General measuring instruments for **I/O** voltage, current, and power are indicated below. The voltage to be measured is the fundamental wave effective voltage and the power to be measured is the total effective value.





Table 3 Parts to be measured

Measurement item	Pans to be measured	Me	easuringinstrument	Remarks	Reference value				
Supply voltage E ₁	Between Rand S, S and T. T and R (ER)(Es)(ET)	★	Moving-iron type voltmeter or rectifier type voltmeter	Fundamental wave effective value					
Supply current I	R, S, T (IR)(İS)(İT)	\$	Moving-iron type ammeter	Total effective value					
Supply power W _I	Between R and S, S and T (W11)(W12)		Electrodynamic type wattmeter	Total effective value					
Supply power factor Pf	Calculate the supply power supply current I_1 and supp $Pf_1 = \frac{W_1}{\sqrt{3} E_1 I_1} \times 100 (9)$	ly power		voltage. E,,					
Output voltage E ₀	Between U and V. V and W. Wand U (EU)(EV)(EW)	→	Rectifier type voltmeter	Total effective value					
Output current	U, v. w (IU)(IV)(Iw)	\$	Moving-iron type ammeter	Total effective value					
Output power W ₀	Between U and V. V and W (W01)(W02)		Electronic type wattmeter	Total effective value					
Output power factor	power Calculate the output power factor from the output voltage E, output current i, and output power W.								

- **NOTE 1:** Use a meter indicating a fundamental wave effective value for voltage, and meters indicating total effective values for current and power.
- **NOTE** 2: The inverter output waveform is a distorted wave, and low frequencys may cause errors. However, the measuring instruments and methods indicated above provide comparatively accurate values.
- **NOTE 3:** A tester (general purpose) may not be suited often to measurement of a distorted wave. 10-6



11. STANDARD SPECIFICATIONS

11.1 Common Standarsd Specifications

	İten	Description																	
Inpu v	oltage				20	. 00	V cl	las	S				-	4	100 V	√ cla	tSS		
Model	Name (Type)	055 075 110 LF LF LF	LF			00 37 F L		150 55 LF L	F	055 075 11 HF HF H	FHF	220 300 HF HF	370 4 HF 1	50 550 HF HF	750 HF	900 10 HF HI	0 1320 HF	1600 220 HF HF
Enclose	ure (NOTE	1)	Semiencio type (IP2		0)per	ı typ	pe ((IP00)	Semiencl type (IP				Oį	pen t	ype (IP00)	·
Rated A	AC input pov	wer supply (V)	Three-phas 200 to 230										hase (3 60 V±						
Rated output voltage (V) (NOTE 2)			Three-phas (Correspor						oltage	,	Tì (C	ree-p orres	ohase, spondir	380 ng to	to 46 the	60 V inpi	/ ut vo	ltage)
Output	frequency ra	ange (NOTE 3)									0.1 to	400 I	-Iz						
Freque	ncy accuracy	/	Digital c					01	% an	ıd a	inalog c	omm	and ±0).1%	for	the	maxi	mun	1
Freque	ncy setting r	esolution	Digital s	ettir	ıg:	0.0)1 F	lz/	60 H	Īz,	Analog	settir	ıg: Ma	xìm	um f	requ	ency	/100	0
Voltage	e/frequency	characteristics	V/f varia				star	rt t	orqu	c, :	standard	start	ing tor	que	(con	stan	it tor	que,	_
Accele	ration/decele	ration time	0.01 to 3	000	se	cor	ıds,	, ac	cele	rat	ion and	decel	eration	n inc	livid	ually	y set		
Starting	g torque (NC)TE 4)	150% or more (1 Hz)																
Brak- ing torque	Dynamic b (NOTE 5) Feedback t	About 20%	A	\bc	out	10	to	20%		About 20% About 10 to 15%									
•	Dynamic b external re (BRD)	Braking resistor optional for 055 and 075L, use braking unit (BRD) for 220 to 250L. Braking resistor optional for 05 075H, use braking unit (BRD) 220 to 2200H.																	
	DC injection	on braking	Operated at the DC braking frequency or by external input																
Input tienals	Frequency selling	Digital operator	Set by and and																
	Jeanny Jeanny	External signals	2 W 500 Ω to 2 $k\Omega$ potentiometer. 0 to 5 VDC (nominal), 0 to 10 VDC (nominal) (input impedance 30 $k\Omega$), 4 to 20 m (input impedance 250 Ω)						1A (nomi	nal)								
	Forward/ reverse	Digital operator	RUN/STOP (10) forward run or reverse run. the function mode should be switched.)																
	run, stop	External signals	lls FW (forward run command)/stop																
	Intelligent	REV (reverse run command), FRS (free run stop command), CFI to CF3 (multistage speed setting). USP (USP function). JG (jogging command), CHI (2-stage acceleration and deceleration). DB (external DB command). RS(reset input). STN (initialization). SF? (software lock). AT (current input selection), CS (commercial power source switching). SET (2nd setting selection), EXT (external trip), UP (remote control, acceleration). DOWN (remote control. deceleration)																	
Output	Intelligent	output terminal	FAI (speed arrival signal). RUN (signal during run). OTQ (overtorque signal)																
signals	Frequency	Analog of frequency monitor																	

	F*		1 4 50	
1. Z51. v	-)	1.1		. 4

Item												Des	crip	tior	1											\Box
Input vo	Itage	200 v class											400	٧	clas	ss										
Model N	lame (Type)					220 LF		370 LF				5 075 F HF														
Fault al	arm contact (AL0-AL1)	0	FF v	vhe	n ar	ı inv	ert	er a	larn	n oc	cu	ırs														
Other ch	aracteristics	ac	AVR function. data batch setting. V/F characteristic switching. curve acceleration and deceleration. upper and lower limiters, S-stage speed, start frequency fine adjustment, trip history monitor (up to three times stored), fuzzeleration and deceleration. autotuning, etc.						speed,																	
Protection	n functions	Overcurrent, overvol temperature. ground					ltaç dinç	je. u	ınde Ten	erv t,o	olta veri	ge, o	elec I res	etro stric	nic ctio	the	erm etc.	al.	ab	no	rma	ıl				
	Vibrations (NOTE 6)	5. 2.	9 m 0 m	/S² √S²	(0. (0.	6G) 2G)	10 10	- 55 - 55	Hz Hz	for	0:	550 20 เต	to ()751 OL	L /F and	i 1 22	0 1	o I	100	ЭН						
General specifi-cations	Operation location	AI	titud	de d	of l (000	m o	r le:	ss,	indo	or	s (fr	ee (of c	orre	osiv	e g	as	an	d d	lus	t)				
Cations	Paint color		gel oun				(M	unse	ell 9	. I Y	7.7.	.4/0.	.6 s	emi	glo	ss,	00	olin	ıg f	an	of	alu	mii	านท	n	
Options		Remote operator. copy unit, cable for digital operator. braking resistor. re for improving power factor, noise filter for inverter, fitting for conduit to connection, fitting for removing cooling fins								r																
Estimate	d mass (kg)	7.5	7.5	13	13	21	37	37	51	51	7.	7.	13	13	21	36	36	464	167	07	08	301	30 <i>°</i>	130)13	,

NOTE 1: Protective structure is based upon JEM1030- 1977.

NOTE 2: The output voltage will decrease if input voltage decreases

NOTE 3: Confirm with the motor manufacturer the motors maximum rpm when using a motor running at frequency higher than 50/60 Hz.

NOTE 4: When using the standard four-pole motor, select the high start torque (SLV) at the rated voltage (200 V class: 200, 220, 230 V; 400 V calss: 400, 415, 440. 460 V). (For details, contact the dealer you purchased the product.)

NOTE 5: Torque will be reduced when the base frequency exceeds 50/60 Hz. The dynamic braking torque is about 70% for 055LF or about 60% for 075LF when one of the 200 V class RB I to RB3 (17 Ω or more) is used at the shorttime rating or about 60% for 055HF or about 50% for 075HF when the 400 V class RB2 x 2 series (70 Ω or more) is used.

NOTE 6: According to the test method shown is JIS C 09 I I (I 984).

11.2 Individual Specification (USA version (J300- LFU, HFU))

	Item											I	Des	crip	tio	n										
nput voltage			1				200) v	clas	ss		•							40	0 V	′ cl	ass				
Model Name	(Type)		055 LF	075 LF	IIO LF		220 LF	300 LF	370 LF		550 LF		075 HF			220 HF	300 HF	370 HF	450 HF	550 HF	750 HF	900 HF	1100 HF	1320 HF	1600 HF	2200 HF
Applicable notor rating	Constant t	orque	5.5! 7.5	7.5/ 10	l .	15/ 20	22/ 30	30/ 40	37/ 50	45/ 60	55/ 75	5.5/ 7.5	7.5 [/] 10	11/ 15	15! 20	22 [/] 30								132/ 200		220 [;] 300
(4P, max. <w hp)<br="">NOTE I)</w>	Variablet (NOTE 2		7.5 ⁷	11/ 15		22/ 30	30 [.] 40		45/ 60	5 5/ 75	75/ 100	7.5/ 10	11/ 15	15° 20	22/ 30	30 [,] 40	37. 50	45/ 60	55° 75	75/ 100	90/ 120	110/ 150	132/ 200	160 [,] 250	220/ 300	260/ 350
·Continuous		200 V	8.3	11	16	22	33	42	50	63	76					1			_	_			_			
(kVA)	}	230 V	10	13	18	25	38	48	58	73	88		1							-						
	Constant torque	380 V										8.6	10.5	15	21	32	38	49	59	72	89	103	137	158	207	250
		400 V										9.0	11	16	22	33	40	52	62	76	94	108	144	166	218	263
		460 V										10.4	12.7	18	25	38	46	60	72	88	108	124	166	191	251	303
		200 V	9	12	18	25	37	47	56	71	86												ļ			
		230 V	П	14	21	29	43	54	65	82	99			- e		r -	-									
	Variable torque	380 V										9.6	1,	17	24	36	43	55	66	82	103	118	158	199	250	286
		400 V						1	-			10.1	12.5	18	25	37	45	58	70	86	108	118	166	209	263	301
		460 V							1			11.6	14.3	21	29	43	52	67	80	99	124	143	191	241	303	347
tated output urrent (A)	Constant to	orque	24	32	46	64	95	121	145	182	220	13	16	23	32	48	58	75	90	110	135	156	208	240	315	380
,	Variable to (NOTE 3)	rque	27	36	52	72	107	136	163	205	248	14.6	18	26	36	54	65	84	101	124	156	180	240	302	380	435
larrier requency	Constant to	rque		16))		12	10	0	6	6		1	6		12	IC)	6	3		3			2	
Hz)	Variable to (NOTE 3)	rque		16	<u>,</u>		12	1	0	6	6		1	6		12	1	0	6	3		2			2	
iverload arrent	Constant to	rque									15	50%	, fo	or I	mi	nute	Э									
apacity	Variable to NOTE 3)	rque									12	25%	, f	or	l r	nin	ute	Э								
Jeneral pecifications	Ambient (NOTE 4)										-	10 t	o S	O d	egr	ee C)									
	1)	T NOTE 5)									•	IO t)									
	Humidity											20) to	909	% R	RH										

NOTE 1: The applicable motor is a Hitachi standard four-pole motor. When using another motor, make sure that the rated motor current does not exceed the rated inverter current.

NOTE 2: Applicable motor raring at variable torque is valid with the condition that output current

does not exceed the rating at variable torque.

NOTE 3: When a V/F pattern (VP1, VP2, or VP3) for variable torque is selected (| D| | D| for the digital operator or F04 for the remote operator). the setting data are automatically changed by the inverter.


NOTE 4: CT: Constant torque.

NOTE 5: VT: Variable torque.

12. FUNCTIONS WHEN USING THE OPTIONAL REMOTE OPERATOR

12.1 Connecting the remote operator

Be sure to turn the power supply off when connecting the connector.



- (I) Insert the connector straight into the remote operator and inverter unit printed-circuit board.
- (2) Turn on the power supply.
- (3) Make sure that the liquid crystal display of the remote operator is lit


When the power supply of the inverter is turned on, FS000.0..... of the monitoring mode will be displayed. If, however, any of the following is displayed when the inverter is turned off, they will be displayed when power is turned on again.

Frequency setting, multi-speed setting or other frequency displays, motor rotational speed display, frequency conversion display, or output current display.

NOTE: When conflicting data is set, a warning WARN..... will be displayed. For 6 seconds thereafter. do not perform the key operation, reset operation, running operation, power-OFF operation. (Otherwise, a communication error may occur in the operator.)

NOTE: See the operation manual of the remote operator for instructions.

In addition, see the following pages for details on its various functions. Set the dip-switches mounted **on** the backside of the remote operator and copy unit as below.



12.2 Monitor mode

Monitor mode list when the remote operator (DOP) and copy unit (DRW) are used

- Monitor mode initial values and display contents
 Initial display contents. initialization. and change ranges are displayed in the table indicated below.
- Y: Setting can be changed during operation
- N: Setting can not be changed during operation Display only

)isplay equence	Monitor name	Display content	Initial value	Settin g range	Setting and change are possible?	Remarks
I	Frequency setting and output frequency	FS0000.0 0.0Hz	0.0 Hz	0 to 120 (400)	Y	(I) displays the setting (2) displays the output
	rrequericy	TM 0.0 0.0Hz	0.0 Hz			when run instruction is ON.
	Multistage-speed	Isoooo.o ::: 0.0Hz	0.0 Hz			R: Reverse run
	setting and out-	2s0000.0 □ 0.0Hz				
	l (3SOO00.0 □ 0.0Hz				
	Jogging frequency setting	[JG0000.0 [] 0.0Hz	I .O Hz	0 to 9.9	Y	A trip occurs easily at 5 Hz or more.
	Expansion multistage speed	4S0000.0 □ 0.0Hz 7S0000.0 □ 0.0Hz	0.0 Hz	0 to 120 (400)	Y	 Valid when the multistage speed terminal 3 is selected. The multistage speed are displayed when the input terminal is connected. For terminal setting, refer to F-34 "Input terminal setting".
2	Acceleration time setting	ACC1 0030.00S	30.0S	0.01 to 3000.00	Y	
3	Deceleration time setting	DEC1 0030.00S	30.0\$	0.01 to 3000.00	Y	
4	Frequency setting command	F-SET-SELECT REM	TRM	TRM/REM OP1/OP2	N	REM: Setting from the remote operator
5	Operation command	F/R-SELECT REM	TRM	TRM/REM OP1/OP2	N	TRM: Setting from the inverter terminal
6	Motor pole count setting and revolu- tion speed monitor	RPM 4P 0RPM	4P	2 to 48	Y	Synchronized speed display
7	Frequency converted value setting and converted value monitor	/Hz01.0 0.00	1.0	0 to 99.9	Y	The arithmetic value by the frequency converted value is displayed. (NOTE 1)
8	Current monitor	Im 0.0 A 0.0%		_	!	The(I) section depends on the INV rated current. The (2) section displays the rate to the rated output current.
9	Torque monitor	[Torque 0 %	-			
Ю	Manual torque boost adjustment	V-Boost code <i 1=""></i>	П	0 to 99	Υ	

NOTE1: The terminal output when the digital output frequency monitor is set at the FM terminal of the control circuit is the "output frequency x frequency convened value". The upper limit of output is 3.6 kHz.

Display sequence	Monitor name	Display content	Initial value	Setting range	Setting and change are possible?	Remarks
11	Manual torque boost frequency adjustment	V-Boost F 10.0%	10.0%	0 to 50.0	Y	
12	Output voltage gain adjustment	V-Gain 100%	100%	20 to 100	Y	
13	Jogging frequency adjustment	Jogging 1.00 Hz	1.0 Hz	0 to 9.99	Y	A trip occurs easily at 5 Hz or more.
14	Analog meter adjustment	ADJ 172	172	0 to 250	Y	at 3 112 of more.
15	Terminal input status monitor	TERM LLLLLLLL Terminal FW 7 5 3 1		When the ter- minal is ON: H When the ter- minal is OFF: L		

				
Display sequence	Monitor name	Display content	Trip cause, contents	Remarks
16	Warning monitor	WARN # WARN Flw>Fs	Normal state Frequency setting error	When the equipment is normal, # is displayed. When a value which is larger than the upper or smaller than the lower limit is set, a warning is displayed.
17	Alarm display	ERR1 #		Not occurred
	Trip monitor	ERRI OVER. V	<trip 1="" cause=""> Trip cause</trip>	The message is displayed on a priority
		ERR1 31.0 Hz	Output frequency when tripped	basis when an alarm occurs.
		ERR1 12.5 A	Output current when tripped	Trip cause Overvoltage trip
		ERR1 787.0 Vdc	Voltage between P and N when tripped	Gvervoitage trip
		ERRI RUN 0Y 10D	Cumulative years and months when tripped	
18	Total alarm count	ERROR COUNT 0		Not occurred
		ERROR COUNT 25	Total trip count	
19	Trip history monitor	ERR2 #		Not occurred
	Last trip contents	ERR2 OC.Accel	<trip 2="" cause=""> Trip cause</trip>	Trip cause
		ERR2 5.0 Hz	Output frequency when tripped	Overcurrent trip for, acceleration
		ERR2 20.1 A	Output current when tripped	,
ļ		ERR2 580.0 Vdc ,	Voltage between P and N when tripped	
<u> </u>		ERR2 R U N 0Y 7D	Cumulative years and months when tripped	
	Contents of last trip but one	ERR3 #		Not occurred
	,	ERR3 EXTERNAL	<trip 3="" cause=""> Trip cause</trip>	Trip cause External trip
		ERR3 0.0 Hz	Output frequency when tripped	External trip
		ERR3 0.0 A	Output current when tripped	
	, ·		Voltage between P and N when tripped	
		ERR3 RUN O Y ID	Cumulative years and months when tripped	

12.3 Function mode

Function mode list when the remote operator is used

• Function mode initial values and display contents
Initial display contents, initialization, and change ranges are displayed in the table indicated below.

1_	(Function	on mode 1,	(Function	mode 2)		Savina abance	
isplay quence	Function No.	Function name	Initializatio conten	• •	Initialization	Setting, change contents	Setting contents
i	F-00	Base frequency setting	F-BASE	0060 Hz	60 Hz	30 to 120 (400)	When 120 Hz is switched to 400 Hz by F-30. a frequency more than I 20 Hz can be set.
2	F-01	Maximum frequency selling	F-MAX	0060 Hz	60 Hz	30 to 120 (400)	
3	F-02	Start frequency adjustment	Fmin	0.50 Hz	0.5 Hz	0.1 to 9.9	The equipment starts running at this set value.
4	F-03 Input voltage	Motor input voltage setting	AVR AC	460 V	230/460	200,215,220,230 /380,400,415 440.460.480	The motor input voltage is set.
		AVR function for decelera- lion	AVRDEC	OFF	OFF	ON/OFF	ON or OFF of the AVR function for deceleration is set. When dynamic braking torque is necessary for deceleration. OFF is XI.
5	F-04	Control method setting	CONTROL	V C	VC	₩€, VP1, VP2, VP3, SLV, V2	. VC, VP1, VP2, VP3: V/F characteristics SLV:Sensorless vector contro V2:Sensor vector control
6	F-05 constant (NOTE I)	Autotuning Motor	AUX AUTO setting	NOR	NOR	NOR/AUT/NRT	At the first running after AUT/NRT is set, the autotuning measurement operation is executed.
	 	Motor data selection	AUX DATA	NOR	NOR	NOR: Old Hitachi general purpose TMO: New Hitachi general purpose AUT: Auto- tuning data	The autotuning motor data before starting autotuning measurement is data equivalent to NOR.
		capacity	AUX K (005.50 kW	Ratedcapacity of each inverter	3.7 to 160	Set a capacity smaller than the rated capacity as capacity data.
		Motor pole CO"", selling	AUX P	4p 	4P	2.4.6.8	The number of poles of the motor to be used is set.
		Motor constant R1 setting	AUX RI	1.004	Ratedcapacity of each invener	0 to 65.535	
		Motor constant R2 setting	AUX R2	'0.776	Ratedcapacity ofeachinverter	0 to 65.535	
		Motor constant L setting	AUX L 13.	.16 mH	Ratedcapacity of each inverter	0 to 655.35	

NOTE 1: The motor constants R1, R2, L, M, J, Kp, Ti, and CPP vary with the capacity.

Display		on mode 1)		n mode 2)	↓ .	Setting, change	
sequence	Function	Function	1	on display	Initialization	contents	Setting contents
6	F-05 Motor constant	Motor M setting constant	AUX M	123.60 mH	Ratedcapacity ofeachinverter	0 to 655.35	Primary self inductance pe phase.
		Motor J setting constant	AUX J	0.44 kgm²	Ratedcapacity of each inverter	0 to 655.35	Motor and machine inertia
		Motor constant Kp setting	AUX Kp	002.00	2.0	0 to 100.00	Smaller: High response Larger: Low response
		Motor constant Ti setting	AUX Ti	00100 ms	100 ms	0 to 10000	 Set this item after the feedback option PCB is installed.
	! !	Motor constant KPP setting	AUX KPP	001.00	1.0	0 to 100.00	Set this item after the feedback option PCB is installed.
7	F-06 Accelera- tion time	Accelera- tion time setting	ACC I	0030.00 s	30.00 s	0.01 to 3000	When the fuzzy most suitable acceleration and deceleration (F-10) are set, the time displayed here is invalid. though it can be set.
		2-stage acceleration time setting	ACC 2	0015.00 s	15.00 s	0.01 to 3000	The acceleration time can be used when the input terminal CH I is shorted. For input terminal selection, refer to F-34 input terminal.
		Curve pattern selection for acceleration	ACC LINE	L	L	L (Linear). S (S curve,, u (U curve). RU (reverse u curve)	The curve pattern is set for acceleration and deceleration respectively.
		Accelera- don and deceleration curve constant selection	ACC GAIN	02	2 (common to acceleration and deceleration)	I to 10	When the constant is set for one of acceleration and deceleration, it is common to both acceleration and deceleration. See appendix 4.
8	F-07 Decelera- tion lime	-	DEC I	0030.00 s	30.00 s	0.01 to 3000S	. When the fuzzy most suitable accelerationand deceleration (F-10) are set, the time displayed here is invalid, though it can be set.
		2-stage deceleration time setting	DEC 2	0015.00 s	15.00 \$	0.01 to 3000s	The deceleration lime can be used when the input terminal CH I is shorted. For input terminal selection. refer to F-34 input terminal.
		Curve pattern selection for	DECLINE	L	L	L (Linear). S (S curve), u (U curve), RU (reverse	The curve pattern is set for acceleration and decelera- tion respectively.
		Accelera- tion and deceleration curve constant selection	DEC GAIN	02	2 (common to acceleration and decelera- lion)	u curve,	. When the constant is set for one of acceleration and deceleration, it is common toboth acceleration and deceleration See appendix 4.

isplay		on mode I)	•	on mode 2)		Setting, change	
quence	Function No.	Function name		ition display ents	Initialization	contents	Setting contents
9		Accelera- don stop frequency setting	Fsp F	0000.0 Hz	0 Hz	0 to 400.0	The frequency at which the acceleration operation is stopped temporarily is set.
		Accelera- tion stop time setting	Fsp TIN	1E 00.0 s	0 s	0 to 60.0	The time that the acceleration is stopped temporarily at a certain frequency during acceleration is set.
10	F-09	Pattern command- ing method selection	PARAM	REM	REM	REM/ OP1/OP2 (Option connected)	The parameter setting commanding source is selected. REM (each operator), OPI (option I), OP2 (option 2)
11	F-IO Running mode						
		Running mode selection	RUN MOD	DE NOR	NOR	NOR/OEN/ GOD	NOR: Normal running OEN: Energy conservation running COD: Fuzzy most suitable acceleration and deceleration running
		Restarting after FRS signal selection	RUNFRS	ZST	ZST	fST/ZST	fST: Restart after frequency maching ZST: 0 Hz start
12	F-1 Multistage speed	Multistage speed Ispeed setting	SPD I	0000.00 Hz	0 Hz	0 to 120.0 (400)	The input terminal CFI is set andused.
		Multistage speed 2-speed setting	SPD 2	0000.00 Hz	0 Hz	0 to 120.0 (400)	• The input terminal CF2 is set and used.
		Multistage speed 3-speed setting	SPD 3	0000.00 Hz	0 Hz	0 το Ε20.0 (400)	The input terminals CFI and CF2 are set and used.
	ļ	Multistage speed d-speed setting	SPD 4	0000.00 Hz	0 Hz	0 το 120.0 (400)	• The input terminals CF1 and CF3 are se, and used.
	S	Multistage speed S-speed etting	SPD 5	0000.00 Hz	0 Hz	0 to 120.0 (400)	The input terminals CF2 and CF3 are set and used.
		Multistage speed 6-speed setting	SPD 6	0000.00 Hz	0 Hz	0 to 120.0 (400)	• The input terminals CF1, CF2, and CF3 are set and used.
		Multistage speed 7-speed setting	SPD 7	0000.00 Hz	0 Hz	0 to 120.0 (400)	The input terminal CF3 is set andused.

Nom	(Fun,:t	ion mode 1)	(Function n	node 2)		Satting above	
>isp	unction	Function	Initialization	display	Initializatio	Setting, change	Setting contents
xque	NO.	name	contents			contents	
13	F-20 DC njection	DC braking selection	DCB SW	OFF	OFF	ON/OFF	DC braking ON: DC braking available OFF: DC braking unavailable
	braking	DC brakin type selection	DCB KIND	LVL	LVL	LVL/EDG	DC braking method selection LVL: Level operation EDG: Edge operation
		DC brakin frequency selection	DCB F (X	000. 5 Hz	0.5 Hz	0 to 400.0 Hz	• The frequency at which the DC braking starts is set.
		DC brakin force selec tion (at start)	DCB V-STA	00	0	0 to 20	• The DC braking force at start is set.
		DC braking force selec- tion (at stop)	DCB V-STP	00	0	0 to 20	The DC braking force at stop is set.
		DC braking time selec- tion (at start)	DCB T-STA	000.0 s	0 s	0 to 6W.0	The DC braking time at start is set.
		DC braking time selec- tion (at stop)	DCB T-STP	000.0 s	0 s	0 to 600.0	• The DC braking time at stop ISset.
		IDC braking output cut- off time	DCB STOP-T adjustment	0.00 s	0 s	0 to 5.00	The output frequency is lowered to the DC braking frequency and the free run rime during execution of DC broking is sale.
14	F-21	Dynamic traking setting	BRD-%ED	001.5%	1.5%	0 to 100.0	braking is set. The allowable usage ratio of the braking resistor for 100 seconds is set. (NOTE 1)
15	F-22 he lowable sage	Allowable instantaneous powerfailure time setting	IPS TIME	1.0 s	1.0 s	0.3 to 25 s	When an instantaneous power failure occurs, the allowable time until the power failure is recovered is set.
	itio of e aking sistor or 100	Reclosing standbyafter instantaneous powerfailure recovered	IPS WAIT	001.0 s	s 0.1	0.3 to 100.0 s	The waiting time until the rerunning starts after an instantaneous power failure occurs and is recovered is set.
	conds set.	Instantaneous powerfailure restart selection	IPS POWR	ALM	ALM	ALM/FTP/ RST/ZST	ALM: Alarm output ZST: 0 Hz start retry FTP: Retry after frequency matching is stopped RST: Rerunning start retry
		Tripselection during stop atunder voltage	IPS TRIP	OFF	OFF	ON/OFF	When an instantaneous power failure occurs: ON: Trip OFF: Non-trip
16	ctronic	Electronic thermal characteristic selection	E-THM CHAR	SUB	SUB	CRT/SUB/FRE	Electronic thermal characteristic setting CRT: Constant torque characteristic SUB: Reduced torque characteristic FRE: Free characteristic
		E lectronic th ermallevel scetting	E-THM LEVE	L 100%	100%	20 to 120%	

NOTE 1: Initial setting of usage ratio 1.5%—055-075L/HF 0% I IO-550UHF

3		

Contents Contents	g contents
NO. name contents contents F-23 Electronic thermal characteristic free setting current (1) Electronic thermal characteristic free setting current (1) Electronic thermal characteristic free setting characteristic free setting characteristic free setting frequency(1) Electronic thermal characteristic free setting frequency(1) Electronic thermal E-THM A2 8.5A Rated capacity of each invener 0 to 400 Hz Electronic thermal E-THM A2 8.5A Rated capacity of each invener 0 to 600.0 A Electronic thermal E-THM A2 8.5A Rated capacity of each invener 0 to 600.0 A	
lectronic thermal characteristic free setting current (1) Electronic thermal characteristic free setting frequency(1) Electronic thermal characteristic free setting frequency(1) Electronic thermal characteristic free setting frequency(1) Electronic thermal E-THM A2	
lectronic thermal characteristic free setting current (1) Electronic thermal characteristic free setting current (1) Electronic thermal characteristic free setting frequency(1) Electronic thermal characteristic free setting frequency(1) Electronic thermal E-THM A2 8.5A Rated capacity of each invener 0 to 600.0 A Electronic thermal E-THM A2 8.5A Rated capacity of each invener 0 to 600.0 A	
IOTE 2) free setting current (1) Electronic thermal characteristic free setting frequency(1) Electronic thermal characteristic free setting frequency(1) Electronic thermal E-THM A2 8.5A Rated capacity of each invener	
current (1) Electronic thermal characteristic free setting frequency(1) Electronic thermal characteristic free setting frequency(1) Electronic thermal E-THM A2 8.5A Rated capacity of each invener	
Electronic thermal characteristic free setting frequency(I) Electronic thermal characteristic free setting frequency(I) Electronic thermal E-THM A2 8.5A Rated capacity of each invener thermal	
thermal characteristic free setting frequency(I) Electronic thermal E-THM A2 8.5A Rated capacity of each invener	
characteristic free settling frequency(I) Electronic thermal E-THM A2 8.5A Rated capacity of each invener	
free setting frequency(1) Electronic thermal E-THM A2 8.5A Rated capacity of each invener	
frequency(1) Electronic thermal E-THM A2 8.5A Rated capacity of each invener 0 to 600.0 A	
Electronic E-THM A2 8.5A Rated capacity of thermal each invener	
thermal cach invener	
1 1 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2	
freesetting	
current (2)	
Electronic E-THM F2 5 Hz Rated capacity of 0 to 400 Hz	
thermal each invener ,	
characteristic	
free setting	
frequency(2) Electronic E-THM A3 13.0 A Rated capacity of 0 to 600.0 A	
Electronic E-THM A3 13.0 A Rated capacity of 0 to 600.0 A	
characteristic	
freesetting	
current (3)	
Electronic E-THM F3 73 Hz Rated capacity of 0 to 400 Hz	
thermal leach invener	
characteristic	
freesetting	
frequency(3)	
17 F - 2 4 Overload OLOAD LEVEL 125% 125% 50 to 150% Inder the sens	sorless vector
	erload is detected
restriction levelsetting rom both the c	overload restric-
ion and torque	limiter.
Overload OLOAD CONSTOLC I.o 0.3 to 31.0 Khe" the setting	ng is 31.0 in SLV
restriction restriction restriction	node. the
constant verloadrestric	ction has no
setting ffect.	
Valid GLOAD ACC ON ON ON: Valid for ven if the fun	
	load restriction is
for overload Keep the "valid only for	
	hen the forward
acceleration for operation. Indeed and acceleration acceleration.	command is
1 · 1 · 1 · 1 · 1 · 1 · 1 · 1 · 1 · 1 ·	
1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	erminal software
lock	oftware look
NOTE I)	JII WALL IOUR
- - NOTE 1)	

NOTE I: When MD0 is set and the input terminal SFT is turned ON, the data of all functions is locked. When MD2 is set (stored), the data of all the functions is locked, During locking, no data can be changed. MD1, MD3 can set only the output frequency.

NOTE 2: Electronic thermal characteristic free setting current and frequency depends on the inverter rating.

Display		ion mode 1)		on mode 2)	Industry of	Setting, change	
sequence	Function No.	Function name		ition display tents	Initialization	contents	Setting contents
19	F-26 Frequency limiter	Frequency	LIMIT L	· 0000.0 Hz	0 Hz	0 to 120.0 (400) Hz	The lower limit of the frequency to be set is set. When the low limit is 0, the setting is invalid
		Frequency upper limiter setting	LIMIT H	0000.0 Hz	0 Hz	0 to 120.0 (400) Hz	The upper limit of the frequento be set is set. When the upp limit is 0, the setting is invalid
20	F-27 Jump frequency	Jump frequency setting (1)	JUMP FI	0000.0 Hz	0 Hz	0 to 400 Hz	 The section where frequenciare to be jumped is set. Up to three locations can be set. When the number of location is 0, the setting is invalid.
		Jump frequency setting (2)	JUMP F2	0000.0 Hz	0 Hz	0 to 400 Hz	
		Jump frequency setting (3)	JUMP F3	0000.0 Hz	0 Hz	0 to 400 Hz	
		Jump frequency width setting		0.5 Hz	0.5 Hz	0 to 9.9 Hz	The frequency width where frequencies are jumped is set
21	F-28	STOP key validity selection during terminal running	STOP-S	W ON	ON	ON: STOP key valid OFF: STOP key invalid	Whether or not to make the STOP key valid during termin running is selected. In the Remote mode, the STOP key i always valid.
22	F-29	Running direction selection	F/R SW	FRE	FRE	FWD/REV/ FRE	FWD: Only forward run REV: Only reverse run FRE: Both forward run and reverse run valid
İ		Reverse run prevention selection	F/R PREV	OFF	OFF	ON/OFF	Reverse run prevention ON: OFF:
		Reduced voltage soft start setting	F/R RVS	6	6	0 to 6	
23	F-30	Maximum frequency selection	F-MAX-L	120 Hz	120 Hz	120/400 Hz	Maximum frequency switching 120: 120 Hz 400: 400 Hz
24	F-31 External analog	Analog input voltage selection	IN ANA	10 V	10 V	10/5	Input voltage maximum level 10: Max. 10 V 5: Max. 5 V
	frequency command	External frequency start setting	IN EXS	0000.0 Hz	0 Hz	0 to 120.0 (400)	Frequency at which the external input starts
		External frequency end setting	IN EXE	0000.0 Hz	0 Hz	0 to 120.0 (400)	Frequency at which the external input is maximized
		External frequency start setting rate	IN EX%S	000%	0%	0 to 100	• Input start level
	F	External frequency end selling rate	IN EX%E	100%	100%	0 to 100	Input maximum level
		External command start pint selection	IN LEVEL	0 Hz	0 Hz	0 Hz/ExS	EXS: Start at EX%S setting rate or less

isplay		on mode l)	(Function mode 2)			Setting,change		
quence	Function NO.	Function name	Initialization content		Initialization	contents	Setting contents	
		Frequency command sampling frequency setting	IN F-SAMP		8	l to 8	:	
25	F-32 Frequency arrival output signal	Arrival	ARV PTN	CST	CST	CST/PAT/ANY	CST: Output a, constant frequency arrival PAT: Output of more than set frequency ANY: Output of only se, frequency	
		Arrival frequency rate setting for acceleration	ARV ACC	0.0 Hz	0 Hz	0 to 400.0		
		Arrival frequency ratesetting for deceleration	ARV DEC	0.0 Hz	0 Hz	0 to 400.0		
26	F-33 Over- torque signal (NOTE I)	Overtorque signal rate setting (for power	OV-TRQ V	100%	100%	0 to 250	During control of SLV and V2: Power running overlorque level During control of VC and VPI to VP3: Warning level for power running regenerative overload When 0 is set: Any signal is not output.	
		Overtorque signal rate setting (for regen- eration)	OV-TRQ R	100%	100%	0 to 250	During control of SLV and V2: Regenerative overtorque level During control of VC and VP1 to VP3: No effect When 0 is set; Any signal is not output.	
27	terminal	Input terminal I setting	IN-TM I	RS	RS reset terminal	RS and 17 other terminals	·	
	input terminal setting	Input terminal 2 setting	IN-TM 2	AT	AT current input selection terminal	AT and 17 other terminals		
		Input terminal 3 setting	IN-TM 3	JG	JG jogging terminal	JG and 17 other terminals		
		Input terminal 4 setting	IN-TM 4	FRS	FRS free run terminal	FRS and I7 other terminals		
		Input terminal 5 setting	IN TM 5	CHI	CHI 2-stage acceleration and deceleration terminal	CHI and 17 otherterminals		

NOTE I: When setting 20% or less, the error will increase (± 20% or more). Therefore, set 20% or more.

Display		on mode l)	(Function mode 2)			Setting change	0
olsplay cquan	Function No.	Function name	Initializatio content		Initializat	i o n contents	Settingcontents
	F-34 Intelligent terminal input	Input terminal 6 setting	IN-TM 6	USP	USP Power-ON restart prevention	USP and 17 other terminals	
	termina setting	I Input terminal 7 setting	IN-TM 7	CFI)	CFI Multi-stage input terminal	CFI and 17 other terminals	
		Input terminal 8 setting	IN-TM 8	REV	REV reverse run command input terminal	REV and 17 other terminals	
		Input terminal I NO/NC setting	IN-TMOIC-I	NO	NO	NO/NC	. Input terminal setting NO: ON when short- circuited NC: ON when opened
		Input terminal 2 NO/NC setting	IN-TM OF	(-2 NO	NO	NO/NC	Input terminal setting NO: ON when short- circuited NC: ON when opened
		Input terminal 3 NO/NC setting	IN-TM O		NO	NO/NC	Input terminal setting NO: ON when short- circuited NC: ON when opened
		Input terminal 4 NO/NC setting	IN-TM O	/C-4 N O	NO	NO/NC	 Input terminal seuing NO: ON when short-circuited NC: ON when opened
28	F-35 Intelligent terminal output	Output terminal I I setting	OUT-TM 1	FAI	FAI	FAI/RUN/OTQ	Output terminal seuing FAI: Frequency arrival signal RUN: Signal during run OTQ: Overtorque signal
	terminal selling	Output terminal 12 setting	OUT-TM 2	RUN	RUN	FAI/RUN/OTQ	Output terminal setting FA1: Frequency arrival signal RUN: Signal during run OTQ: Overtorque signal
		Alarm output NO/NC setting	ОИТ-ТМ О	K-A NC	NC	NC/NO	. Alarm output terminal contacts a and b setting NC: b contact NO: a contact
		Output 1 NO/NC setting	OUT-TM terminal	O/C-I NO	NO	NO/NC	Output terminal Contacts a and b seuing NO: b contact NC: a contact Refer to C 21
		Output terminal 12 NO/NC	ОИТ-ТМ С)/C-2 NO	NO	NO/NC	Output terminal 12 contacts a and b setting Short- NO: a contact NC: b contact
29	F-36	Carrier frequency setting	CARRIER	16.0 kHz	16.0 kHz	2.0 to 16.0 Hz Selectable in 0.1 saps	The IPM carrier frequency is set. The setting value varies with the capacity.

Dienlau	(Functio	on mode 1)	,	n mode 2)		Setting, change	
Display sequence	Function No.	Function name	Initializat conte	ion display nts	Initialization	contents	Setting contents
30	F-37	Monitor signal selection	MONITOR	A-F	A-F	A-F/A/T/D-F	The FM terminal monitor signal output is selected. A-F: Analog frequency T: Torque monitor A: Current monitor D-F: Digital frequency
31	F-38 Initiali- zation	Trip history count clear	INIT TENT	CNT	CNT	CNT/CLR	Trip count deletion selection CNT: Trip counting is continued. CLR: The trip Count is cleared.
		Debug mode display selection	INIT DEBG	OFF.	OFF NOTE I	ON/OFF	Debug mode setting ON or OFF OFF. The debug mode is turned off. ON: The debug mode is turned.
					10121		on.
		Digital operator rotation direction selection	INIT DOPE	FWD	FWD	FWD/REV	The digital operator running direction is set. FWD: Forward run REV: Reverse run
		Selection of reset performance	INIT RESE	r ON	ON	ON/OFF	ON: Alarm release when reset on OFF: Alarm release when reset off
32	F-39 Option setting	Encode pulse number setting	OP P	01024 pulse	1024	255 to 65535	Effective with option board (J-FB)
		Control mode selection	OP MODE	ASR	ASR	ASR/APR	
		Ro-To option selection	OP RO-TO	OFF	OFF	OFF/ON	Keep OFF. (No use)
33	F-40 Orientation setting	Stop position setting switching	OR POS	IN	IN	IN/OUT	Effective with option board (J-FB)
		Stop position setting	OR P	00000 pulse	0	0 to 4095	-)
	ľ	Speedsetting	OR FC	0005.0 Hz	5.0 Hz	0 to 400 Hz	-
		Direction setting	OR TURN	FWD	FWD	FWD/REV	
}		Completion rangesetting	OR L (00005 pulse	5	0 to 10000	
		Completion delay time setting	OR TW	0.00 s	0	0 to 9.99	

NOTE I: Keep debug mode "OFF", this is factory use only.

splay		on mode I)		n mode 2)	Teleleli et	Setting, change		
quenc	INO.	Function name	Initializat conte		Initialization	contents	Setting contents	
34	F-41 Electronic gear	Position setting switching	PO EGRP	FB	FB	FB/REF	Effective with option board (J-FB)	
	setting	Numerator of ratio	PO EGR-N	00001	1	1 to 9999		
		Denominator	PO EGR-D	00001	I	1 to 9999		
		Feed for- ward gain	PO FFWG	000.00	0	0 to 655.35		
	_	Position loop gain		000.50 rad/s	0.5 rad/s	0 to 100		
35	F-42 Torque limit setting	Torque limit setting switching	TRQ LIMIT		REM	REM/OPI/OP2	REM: Each operator PO1: Option 1 PO2: Option 2	
	(Note I)	Plus torque limit	TRQ FWD	150%	150%	20 to 150%		
	_	Minus torque limit	TRQ REV	150%	150%	20 to 150%	Regenerative mode	
36	F-43 PIDcontrol setting	PID target value input method switching selection	PID IN-SEL	, IN	IN	IN/OUT		
		PID target value setting	PID LVL	000.00%	0%	0 to 200%		
		P gain setting	PID P	1.0	1.0	0.1 to 5.0		
i		I gain setting	PID I	01.08	1.0	0 to 15.0		
1		D gain setting	PID D	000.0	0.000	0 to 100		
		Selection	PID MODE	MD0	MD0	MD0 to 4		
37	F-46 Communi cation	Transmission speed selection	COM BAU	00600 bps	600	300/600/1200/ 2400/4800/9600/ 19200	Effective with option board (J-CM)	
Í	protocol setting	Station number selection	COM NUMI	BER 01	ı	1 to 32		
		Transfer bit length selection	COM LENG	TH 8	8	8/7		
		Parity ON / OFF selection	COM PAR-S	SELI ON	ON	ON/OFF		
		Parity even / odd selection	COM PAR-S		EVN	EVN/ODD .		
		Stop bit length selection	COM STOP	BIT 2	2	2/1		

NOTE 1: Smaller levels of torque limit and overload restriction are given top priority and valid for any control method.

isplay	(Function No.	' ' Contents		-	Setting contents		
38	F-47 Option PCB erro setting	Main body operation selection for option PCB error I	OP-ERRI	STP	STP	STP/RUN	Effective with option board
		Main body operation selection for option PCB error 2	OP-ERR2	STP	STP	STP/RUN	•
39	F-48 Selection of relay	Setting for RYA terminal	RELAY RYA	RUN	RUN	CST/PAT /ANY/RUN /OTQ/NOR	I Effective with optionboard (J-RY)
	output	Setting for RYB terminal	RELAY RYB	CST	CST		CST: Arrival signal (constant speed) PAT: Arrival signal
		Setting for RYC terminal	RELAY RYC	ОТО	ото		(set frequency or more) ANY: Arrival signal

12.4 Protection function display list when the remote operator is used

There are protection functions for overcurrent, overvoltage, and undervoltage provided to protect the inverter. When one of the functions is performed, the output is cut off, and the motor is put into the free run state, and the status is kept until the inverter is forced to reset.

Name	Digital operat	Remote operator(DOP) copy unit(DRW)display ERR1 ***	
	Constant speed	E 0 1	OC.Drive
Overcurrent protection	Deceleration	E 02	OC.Decel
	Acceleration	E 0 3	OC.Accel
Overload protection		E 05	Over.L
Braking resistor overload		E 06	OL.BRD
Overvoltage protection		E 0 7	Over.V
EEPROM error		E 08	EEPROM
Undervoltage protection		E 09	Under.V
СТ ептог		E 10	СТ
CPU еттог	-	EII	CPU
External trip		E 12	EXTERNAL
USP error		E 13	USP
Ground fault protection	-	E 14	GND.Fit

Name	Digital operat	or display	Remote operator(DOP) copy unit(DRW)display ERRI ***
Input overvoltage		E 15	OV.SRC
Instantaneous power failure		E 16	Inst.P-F
Option connec-	Option 1	E 17	NG.OPI
tion error	Option 2	E 18	NG.OP2
Option PCB	Option 1	E 19	ОРІ
enor (NOTE 2)	Option 2	E 20	OP2
Phase failure protection error	(NOTE 1)	E 24	PH.Fail
	Constant speed	E 3 I	PM.Drive
Power module	Deceleration	E 32	PM.Decel
protection	Acceleration	E33	PM.Accel
	Stop	E 34	PM.ERR
Undervoltage standby		<i>U</i>	UV.WAIT

For error contents, see page 8-I.

Other displays

Display	Cause	Description
-R-ERROR COMM<*>	Communication error *=1. Protocol error =2. Time-out error	This is displayed when an error occurs between the inverter and remote operator. When the STOP key or another key is pressed, the original display appears. When the original display does not appear, turn the power off and then on once again. Check whether any connectors are loose.
R-ERROR INV.RUN	During inverter running	If one of the displays on the left occurs when the copy unit is used to read or copy, take the corresponding countermeasure.
R-ERROR INV.TRIP	Under inverter trip	INV. RUN: Stop the running. INV. TRIP: Press the STOP key to release the trip.
R-ERROR INV.TYPE	Inverter type mismatch	• INV. TYPE: The inverter type of the copy source is different from that of the copy destination. Use the same type of inverter to read or copy.
R-ERROR RD LOCK	Inverter read lock	The fourth switch of the DIP switch on the back of the remote operator is ON. When reading data, turn the switch OFF.
RESTART ***.*s	Instantaneous power	This indicates that the instantaneous power failure restart function is being performed. • RESTART: 0 start is in execution.
ADJUST ***.*s	failure restart function in operation	ADJUST: Frequency matching is in execution.
UV WAIT	Undervoltage	The supply voltage is lowered to the undervoltage level. When this display appears, turn the power on once again.
POWER OFF	Power OFF	The undervoltage after the power is turned off is displayed.
Tuning OK	Autotuning function end	This is displayed after the autotuning measurement is finished. • Tuning OK: The measurement terminates normally.
Tuning NG	display	• Tuning NG: The measurement fails,

NOTE 1: Power OFF during motor deceleration may cause an input phase failure error. **NOTE** 2: When the J-FB is installed, an error is display for each factor as shown below.


	Digital operator display	DOP. DRW
Encoder line break:	<u>E 60</u>	<u>OP1 0</u>
Overspeed:	<u>E 5 1</u>	<u>OPI 1</u>
Positioning error:	<u>E 62</u>	<u>OP1_2</u>
Thermistor line break:	E 64	<u>OP1_4</u>
Motor overheat:	E 65	<u>OP1 5</u>
Malfunction or abnormality on built-in-CPU of the option	: <u>E67</u>	<u>OP1_7</u>


12.5 Warning Error List

The following warning errors are displayed on the warning monitor in the **monitor** mode. Check the set value. When an attempt is made to set **a** value larger than the set range, the set value may be rewritten as shown below.

	Warnin	g erro	r display	Ford	ed rew	riting		Description	Alarm output	Recovery method
1	Fmax	>	Fch	Fmax	←	Fch	Fch:	Frequency for maximum frequency switching		cy.
2	Fb	>	Fmax	Fb	<u> </u>	Fmax	Fmax :	(120, 400) Maximum frequency		dnen
3	Fs	, >	Fmax	Fs	←	Fmax	Fmin:	Start frequency Base frequency		he fre
4	Fm	>	Fmax	Fm	<u> </u>	Fmax	Fs:	Set frequency Multistage speed setting		hout t
5	Flw	>	Fmax	Flw	←_	Fmax		frequency Lower limiter frequency		ed wit
6	Fup	>	Fmax	Fup	←'	Fmax	Flw: Fup:	Upper limiter frequency		perate "Forc
7	Fes	>	Fmax	Fes	<u> </u>	Fmax	Fp: Fes:	Jump frequency External set analog start	l.	nt is c
8	Fee	>	Fmax	Fee	<u> </u>	Fmax	Fee:	frequency External set analog end		ipme
9	Fs	>	Fup	Fs	←	Fup] Fj:	frequency Fj: Jogging frequency	OFF	Change the frequency to the correct value. (Note that when the equipment is operated without the frequency being corrected, he set contents are automatically rewritten to the contents for "Forced Rewriting".
10	Fm	>	Fup	Fm	←.	Fup				
11	Fmin	>	Fup	Fmin	←_	Fup]			
12	Flw	>	Fs	Flw	→	Fs	<u> </u>			
13	Flw	>	Fm	Flw	→	Fm				ilue. (
14	Fmin	>	Fs	Fmin	→·	Fs				ect va
15	Fmin	>	Fm	Fmin	\rightarrow	Fm				e con
16	Fmin	>	Fj	Fmin	\rightarrow	Fj				y to th
17	Fmin	>	Flw	Fmin	→	Flw				quency
18	Fp	>	Fs	Fp		Fs				ne frec rected
19	Fp	>	Fj	FP		Fj				nge It
20	Fp	>	Fm	Fp		Fm				Cha bein

Remote operator, copy unit





NOTE 1: The cables for the VWS3A and VWA series are different in cable shape from those for the J300. The cables for the J300 are the same as those for the J100. To change only cables, various cables are in stock.

12.7 Copy Unit Function

OI	peration example (Procedure to transfe	r the data of inve	ener A to B.C. and D inverters)				
Se- quence	Operation	Key	Operation result				
I	Set data is read out from the inverter A (It is stored into the memory.	READ	Inverter A Copy unit				
2	Turn off the power supply to inverter A and remove the cable.						
3	Connect the cable to inverter B and turn on the power.						
4	Copy data stored in the copy unit is written to inverter B.	СОРУ	Data copy				
5	Cut off the power supply to inverter B. (* 1)		Inverter B Inverter C Inverter D				
6 f	Perform the above processes from 3 to 5 sequentially for inverters C and D. That IS, the santagrocess as at o r inverter B.						

Operation example (Process to change and transfer to inverters B, C and D)						
, the remo	Change the data of the inverter	MON FUN STR	Copy unit Data change			
inverter A 2 to 6	Read out the data from (It is stored into the memory area of the copy unit). The following procedures are the same those of the operation I.	READ	Inverter A Copy unit			

12.8 Data to be copied by the copy unit

Precautions for copying

13. SERVICE

When inquiring about **inverter** trouble, please be ready to inform the distributor where you purchased your unit or the nearest service station the following.

- (1) Type
- (2) Purchased date
- (3) Production No. (MFG. No.)
- (4) Malfunction symptoms

If the contents are unclear due to an old nameplate, give only the clear items. To reduce the non-operation time, it is recommended to stock a spare inverter.

warranty

The warranty period under normal installation and handling conditions shall be one (1) year after the date of delivery. The warranty shall cover the repair of only the inverter to be delivered.

- 1. Service in the following cases, even within the warranty period, shall be charged to the purchaser.
 - (a) Malfunction or damage caused by misoperation or remodelling or improper repair
 - (b) Malfunction or damage caused by a drop after purchase and transportation
 - (c) Malfunction or damage caused by tire, earthquake, flood, thunderbolt, or other natural calamities, pollution or abnormal voltage.
- 2. When service is required for the product at your worksite, all expenses associated with field repair shall be charged to the purchaser.
- 3. Always keep it handy. Please do not loose it. We are sorry but this manual cannot re-issued.

Appendix 1 Manual for New Functions


1. Autotuning

[Outline of the function]

This is a function for automatically setting the motor circuit constant necessary for the sensorless vector.

When the autotuning function is performed by a motor which is designed according to JIS C 4210 and then the sensorless vector is controlled, even a motor (Hitachi general purpose motor) whose constant is unknown at an output frequency of 1 Hz can generate a torque of 150%.

An Hitachi general purpose motor is given a constant which is a default value. Therefore, in every case, the characteristics will be obtained without trouble. When the characteristics cannot be obtained, measure the motor circuit constant by the autotuning function.



- (1) Before executing the autotuning function, make sure the following set values.
 - 1) a) Base frequency
 - b) Motor capacity
 - c) No. of motor poles
 Set the values according to a motor which uses a, b, and c.
 - Make sure that 0 Hz is not set. (When 0 Hz is set, the autotuning function will not be performed.)
 - 3) Cancel all the DC braking settings. (DC braking is not set by initialization.)
 - Make an motor input voltage setting (F-03 AVR AC _____) according to the motorrating.
- (2) Drive the motor for about 60 to 120 seconds. (During autotuning, the motor automatically runs in the order of (1) to (4) given on the left and the motor constant is measured. Therefore, make sure before starting operation that no problems are caused to the load to be connected during the automatic running from (I) to (4).)

Example:

When the base frequency is 120 Hz, the motor runs up to 80% of the base frequency in (3), that is, 96 Hz and then decelerates and stops.


The status for using the autotuning data is set.

Running under sensorless vector control is available.

Autotuning start

[Setting method]


(I) Digital operator



Display the A 9 7 software switch and set it to the data (01) for starting autotuning setting.

When the equipment starts running after the data is set, the autotuning measurement is executed.

(2) Remote operator



F-05 motor constant setting is displayed.

Display the AUX AUTO screen and select AUT or NRT.

Autotuning

NOR: Setting OFF and autotuning end

AUT: Autotuning measurement start (Motor

rotates)

NRT: Autotuning measurement start (Motor

does not rotates)

When the equipment starts running after the data is set, the autotuning measurement is executed.

When the autotuning operation terminates, "Display at end" indicated on A-4 page is displayed. When the autotuning operation temiantes normally, see the "running method by autotuning data" indicated on A-5 page.


When the autotuning fails, set "measurement start" once again and perform rerunning.

When A 9 7 is set to D2 on the digital operator or NRT is selected on the remote operator, auto tuning is performed in a mode in which the motor does not run (only AC excitation and DC excitation are possible). Then, the value of motor constants R1, R2. and L are measured.

Precautions

- I. When the autotuning function is executed in the state that the DC braking is set. the accurate motor constant will not be **set**. Cancel the DC braking the then start measurement.
- 2. By the autotuning function, a capacity between the applicable motor capacity and motor capacity under one frame can be set.
- 3. When acceleration or speeding up is not to be performed in the operation for accelerating up to 80% of the base frequency, tower the set value of manual torque boost.
- 4. The autotuning measurement time is about 2 minutes or so. However, the measurement time may be increased depending on the load inertia. When the measurement time exceeds 5 minutes, press the STOP key so as to decrease rhe set value of manual torque boost and enter the run command once again.
- 5. Be sure if motor is in standstill before you carry out an autotuning. Autotuning data carried out when motor is still running may be not correct.
- Do not interrupt an autotuning with power off or any stop command except emergency case. It may case data lose.
 - In it is occurred, make an initialization and reprogram what you need, and carryout autotuning again.


 A-2



Display when the autotuning terminates


[Display in the normal state]

. When the autotuning terminates normally, the following is displayed. When one of the keys is pressed, the original screen is displayed.



[Display in the failure state]

• If the autotuning is executed when the motor is not connected to the inverter, the following is displayed and the measurement is stopped. As a motor constant when the measurement fails, the last value is set. When one of the keys is pressed, the original screen is displayed. When executing the measurement once again, change the autotuning measurement setting to "Start" and enter the run command in the same way.



When running the inverter using the autotuning data after the autotuning measurement terminates, make settings by the method indicated on the next page.

Running method by autotuning data

When running the inverter using the autotuning data:


- 1. A-O: The control method is set at SLV (sensorless vector control).
- : The motor data is set on the autotuning side by the software switch, Make the above two settings.

NOTE: When no torque is outputted during the sensorless vector run after the above settings are made, make the following settings. Increase the set value of R1 of each remote operator (motor constant) before starting running.


[Setting method]

ŝ

(1) Digital operator



(2) Remote operator



- 4 (sensorless vector control) by 1. Select [] control method. the l

 - 0: Constant torque characteristic I: Reduced torque characteristic (I.5 power) 2: Reduced torque characteristic (I.7 power) 3: Reduced torque characteristic (2.0 power)

 - 4: Sensorless vector control
- 2. Set the motor constant data to the data which is
 - . A 9 8 measured by the autotuning function using the software switch.

(Refer to the [A98] software switch of the operation manual.)

(When executing the second setting, change the

By the above two settings, running by the autotuning data is available.

1 Select[SLV] (sensorless vector control) by the F-04 control method.

VC: Constant torque characteristic

VPI: Reduced torque characteristic (1.5 power)

VP2: Reduced torque characteristic (I.7 power)


VP3: Reduced torque characteristic (2.0 power)

SLV: Sensorless vector control

2. Set the [AUT] autotuning data by motor data selection of the F-05 motor constant.

By the above two settings, running by the autotuning data is available.

(3) New remote operator



When the monitor mode is selected, running by the autotuning data starts.

[NOTES]

*1: If the desired characteristic cannot be obtained in a sensorless vector control operation with auto tuning measured data, adjust the motor constant according to the detected symptom shown below.

(DOP, DRW, HOP, and HRW functions of the remote operator are needed for this adjustment.)

Operation Status	Symptom	Adjustment	Adjusting Item (DOP/DRW Function No.)
Power running (status with an accelerating torque)	When low frequenc (a few Hz) torque is insufficient	Increase the motor constant RI in relation to auto tuning data step by step within 1.2 times.	[F-05 AUX R1]
	When the speed fluctuation coefficient becomes minus	Increase the motor constant R2 in relation to auto tuning data step by step within 1.2 times.	IF-05 AUX R2}
	When the speed fluctuation coefficient becomes plus	Decrease the motor constant R2 in relation to auto tuning data step by step within 0.8 times.	[F-OS AUX R2]
Regeneration (status with a decelerating	When low frequenc (a few Hz) torque is	Increase the motor constant R1 in relation to auto tuning data step by step within 1.2 times.	[F-OS AUX RI]
torque)	insumcient	Decrease the motor constant M in relation to auto tuning data step by step within 0.8 times.	[F-OS AUX MI
		I) Decrease the carrier frequency set value.	[F-36 CARRIER] (A 10) for digital operator
		Combine the methods I) to 3) above to adjust the motor constant.	


2. Energy conservation running

[Outline of the function]

This is a function for automatically setting the output voltage corresponding to the load during the V/F control running and suppressing useless power.


The function is effective for a load of reduced torque characteristics such as a fan and pump.

When the load of an induction motor is constant as shown in the drawing on the right, there is a voltage at which the current is minimized. When the current is minimized, the power is also minimized. The function automatically searches this voltage.



[Precautions]

- I. The output voltage is decreased so as to minimize the current. The search limits are the voltage of torque constant characteristic ±50%.
- 2. The function is performed under comparatively slow control. Therefore, when a sudden load change (such as an impact load) occurs, the motor may stall.




Range where the energy conservation is effective


[Setting method]


÷

(1) Digital operator



(2) Remote operator





Select 1 by A 5 9 running mode selection.

Running mode selection

- 0: Normal running
- 1: Energy conservation running
- 2: Fuzzy most suitable acceleration and deceleration running

When the running starts after the data is set, the energy conservation running is performed.

F- 10 running mode selection is displayed. Display the RUN MODE screen and select "OEN".

Running mode selection


NOR: Normal running

OEN: Energy conservation running

GOD: Fuzzy most suitable acceleration and

deceleration running

When the running starts after the data is set, the energy conservation running is performed.



3. Fuzzy most suitable acceleration and deceleration

[Outline of the function]

The fuzzy most suitable acceleration and deceleration function realizes acceleration and deceleration characteristics using the inverter capability at its maximum under fuzzy control to eliminate troublesome setting of the acceleration and deceleration time.

The acceleration time is a time for acceleration at the current specified by the overload restriction constant.

The deceleration time is a time for decelerating so that the current does not exceed 150% of the specified one or the DC voltage in the **inverter** circuit does not exceed 385V. (770 V for the 400V class.)


The function sets the acceleration and deceleration time automatically in response to a change in the load or inertia in real time.

[Precautions]

- 1. This function is not suitable for a machine which requires a constant acceleration and deceleration time. The acceleration and deceleration time varies with the magnitude of the load or inertia.
- 2. When the inertia of the machine is more than about 20 times of that of the motor shaft, a trip may occur.
- 3. The acceleration and deceleration time of the same motor always varies with a change of the current.
- 4. The fuzzy most suitable acceleration and deceleration setting function is valid only under the V/F control. In the high **start** torque running mode (under the sensorless vector control), the normal running is performed..
- 5. If the jogging running is executed when the fuzzy most suitable acceleration and deceleration setting function is selected, the jogging operation cannot be performed due to the fuzzy control.
- 6. When the load is more than the rated one, the deceleration time may be increased.
- 7. When acceleration and deceleration (the cycle is 2[s] or less) are repeated frequently, a trip may occur.
- 8. If an external braking unit is used, the motor cannot stop within the deceleration time set with a braking resistor. In such a case, do not use the fuzzy acceleration/deceleration function.


[Principle]

The acceleration and deceleration ratio or **acceleration** and deceleration are set in accordance with the fuzzy rule from the distance to the overload restriction level and the start slopes of current and **voltage**.





[Setting method]

(1) Digital operator



(2) Remote operator





Select 2 by A 5 9 running mode selection.

Running mode selection

- 0: Normal running
- 1: Energy conservation running
- 2: Fuzzy most suitable acceleration and decelerationrunning

When the running starts after the data is set, the most suitable acceleration and deceleration running is performed.

F-IO running mode selection is displayed. Display the RUN MODE screen and select "GOD".

Running mode selection

NOR: Normal running


OEN: Energy conservation running

GOD: Fuzzy most suitable acceleration and

deceleration running

When the running starts after the data is set, the most suitable acceleration and deceleration running is performed.

* When the running starts after the data is set, the acceleration and deceleration time display is as shown below. During the fuzzy most suitable acceleration and deceleration running, the acceleration and deceleration time display in the monitor mode is invalid. (The time can be set but the display is invalid. It becomes valid once again during the normal running.)



Appendix 2 Instantaneous Power Failure Restart and Commercial Power Source Switching

1. Instantaneous power failure restart

[Function Outline]

This function allows an **inverter** operation to be selected according to the subject system as follows when an instantaneous power failure occurs.

• Retry mode: When FTP/RST/ZST is set at IPS POWR

• Alarm mode: When ALM is set at IPS POWR

• f matching: The rotation speed and the phase are detected while the motor is on a free

running to restart the operation accordingly1

∕N WARNING

When the invener stops due to a trip with retry mode selected, the motor restarts suddenly. Stand clear of the machine. Otherwise, you may be injured. (Design the machine in such a way that persons are protected against a restart of the machine.)

[Setting Method]

Remote op	erator [F-22]	Digital operator	At instantaneous power failure	At low voltage	Apvercurrent/ overvoltage/ powermodulector	At oth
PS TIME	0.3 το 25.0		Set an allowable instantaneous power failure time.	_	_	_
PSWAIT	0.3 ю 100.0	_	Set a wait time after an instantaneo in the retry mode or after an error.	us power failure/power	restoration	
PS POWR	ALM	0	Tripping with an instantaneous power failure within the IPS TIME. If an operation command is issued for an instantaneous power failure detected out of the IPS TIME. restart the operation (I Hz start).	Tripping	Tripping	Trippii
	FTP	ı	The f matching stops with an instantaneous power failure detected within the IPS TIME. The invener trips with an' instantaneous power failure detected out of the PIS TIME.	The f matching slops if power is restored within 40s. The invener trips unless power is restored within 40s.	The f matching is retried.	
	RST	2	The f matching is restanted if the instantaneous power failure is within the IPS TIME. The invener trips if the instantaneous power failure is not within the IPS TIME.	The f matching is restarted if power is restored within 40s. The invener trips unless power is not restored within 40s.		
	ZST	3	The invener is restarted at 0 Hz if the instantaneous power failure is within the PIS TIME. The invener trips if the instantaneous power failure is not within the IPS TIME.	The invener is started at 0 Hz if power is restored within 40s. The invener trips unless paver is restored within 40s.		
'STRIP	OFF	-	No retry at an instantaneous powe at low voltage during the inverter st	ailure and no trip		_
	ON	_	Retry or under voltage trip is perfor invener stop or running.	med during the	_	_

WARNING

[] If the retry mode is selected, do not approach the inverter unnecessarily. It will be' restarted suddenly after it trips/stops. (Design the inverter so that the safety can be assured even in such a restart.) Otherwise, bodily injury will result.


NOTE: Since the retry mode is selected, the equipment restarts for trips of overcurrent, overvoltage, or undervoltage. For undervoltage, 16 retries (17th trip) are executed. For overcurrent or overvoltage, 3 retries (fourth trip) are executed. Do not use this function for a case **that** a fallen substance should be held by the machine brake **when** the motor is in the free-run mode.

In the following cases, the equipment may start at the lowest frequency (called 0 start).

- I) When the reclosing standby time (function mode F-22, IPS WAIT) after the instantaneous power failure is recovered is set to 3 seconds or more
- 2) When the output frequency is more than 60 Hz
- 3) When the base frequency is 60 Hz: Driven at 30 Hz or less When the base frequency is 50 Hz: Driven at 25 Hz or less
- 4) When the induced voltage of the motor attenuates earlier (for example, a pump or high-speed gear which causes the motor to decelerate for several seconds or less)

NOTE: The inverter control power holding time may be slightly different depending on the inverter rating, the load status, remote operator (copy unit) connection status, and input voltage.

<Time chart for retry mode>




to: Instantaneous power failure time

t I: Control power holding time when power is tuned OFF

t2: F-22 (IPS TIME se, value)


2. Commercial power source switching

		Data se	et for commercia	al power source	switching	
	Function code	9	Set value 03	Run command to Terminal	Frequency command to Terminal	⇒ Set the terminal mode.
tal opc	Extension function code	3	Function name Input terminal setting 3	Terminal rating plate	Set value	⇒ Select the CS terminal.
				• .		of the input terminal settings the input terminal setting 3.
operator (DOP)	Monitor mode		T-SELECT T	, => Se	t TRM (termina	al mode)
operator ınit (DR	Function mode F-34	F/R-	SELECT T	<u> </u>	ect the CS terr	ninal.
Remote of copy to				•		of the input terminal settings I the input terminal selling 3.



Connection example diagram and timing for commercial power source switching running

Appendix 3 Capacitor Life Curve




- * The ambient temperature herein means the temperature around the inverter body. If the inverter is housed in a panel, the ambient temperature corresponds to the temperature in the panel.
- * Even when the ambient temperature is within the rating, the capacitor life is shortened if ventilation is impeded due to bad installation conditions or dust.

Appendix 4 Acceleration/Deceleration Curve Constants

This function can vary the curvature when the acceleration curve pattern (or deceleration curve pattern) is selected to S curve, U curve or RU (reverse U) curve in the function mode (F-06). If the acceleration curve pattern or deceleration curve pattern is selected, the selected pattern applies to both acceleration and deceleration.

The larger number causes a greater curvature.



4)

√o,	Operation conditions	Phenomena	Improvements NOTE: The setting methods shown below apply to DOP and DRW operations,	Display, etc.
I	Trial running of motor only	The motor runs unsmoothly, and the revolution fails to increase. The motor current pulsates.	I. When V/f control or sensor-less vcctor control is selected Function mode • F-36	12.3 Function mode
2	Light load, low inertia load		CARRIER 16.0 kHz \rightarrow 8.0 kHz Decrease the initial value.	F-36 (P.12-14)
3	Acceleration and deceleration of light load or low inertia load	Revolution 0.1 sec. 0.1 sec.	When V/f control is selected Function mode F-04 CONTROL VC F-05 AUX R1 00.223 → 00.323 Increase the initial value.	12.3 Function mode F-04 (P.12-5) 12.3 Function mode F-05 (P.12-5)
		The motor revolution fails to increase smoothly	3. When sensor-less vector control is selected Function mode F-04 CONTROL SLV F-05 AUX DATA NOR a. AUX J 001.22 kgm² → 000.22 kgm² Decrease the initial value. b. AUX Kp 002.00 → 003.00 Increase the initial value. Use a and b solely or combine any of a and b to adjust the motor constant.	NOTE: Select AUT if the automatic tuning data is used.) Use the second function for switching operation of two motors.

D N

Operation conditions	Phenomena	Improvements NOTE: The setting methods shown below apply to DOP and DRW operations.	Display, etc.
Quickly varying load	The motor revolution varies when the load varies. NOTE: When sensor-less vector is constant is different from the load this case, measure the motor revolution varies when the load varies.	When sensor-less vector control is selected Function mode F-04 CONTROL SLV F-05 AUX DATA NOR a. AUX J 001.22 kgm² → 003.22 kgm² Increase the initial value. b. AUX Kp 002.00 → 001.00 Decrease the initial value. selected, driving of motor at low speed whose e factory settings may cause reverse run. notor constant using the automatic tuning mode of primary resistor (RI) of the motor.	NOTE: Select AUT if the automatic tuning data is used.)

Display, etc.	12.3 Function mode F-04 (P. 12-5) A I The sensor-less vector control is not applicable to multi-motor parallel operation.
Improvements NOTE: The setting methods shown below apply to DOP and DRW operations	1. When sensor-less vector control is selected • F-04 • F-04 CONTROL SLV → VC Reset to V/f control. Select the motor capacity which is the most approximate to the total capacity of the motors used. (For example, 7.5 kW, 5.5 kW, and 3.7 kW.) - Function mode Total capacity of the motors: 7.5 + 5.5 + 3.7 = 16.7kW • F-05 AUX K 022.00 kW → 015.00 kW Select the most approximate value to the total capacity. - F-05 AUX K 022.00 kW → 005.50 kW Select the most approximate value. Example 1: One 5.5 kW motor is used • F-05 AUX K 022.00 kW → 005.50 kW Select the most approximate value. Example 2: One 5.5 kW motor is changed into parallel operation of four 5.5 kW motors Foral capacity of the motors: 5.5 x 4 = 22.0 kW • F-04 • F-04 AUX K 005.50 kW → 022.00 kW Select the most approximate value.
Phenomena	Operation cannot be started at high torque, since the inverter does not know the load sharing of the motors.
Operation conditions	Parallel motor operation
NO.	ν

Appendix 6 Supplementaly Explanation of the Function Mode

- The explanation of the function mode is displayed on the DOP or DRW type of the remote operator.
 - As for the operating methods with other remote operators, refer to the corresponding table of the operator display.
- After data is changed, be sure to push down the STR key. No data is stored in the inverter body.
- Change data when the inverter is stopped. (except when the inverter is stopped during trip, and stopped when ON between the reset terminal RS and CM1.)
- In the function mode, the motor cannot be started running. Select the monitor mode beforehand.

Function name: Second function setting Function No. F-34 Intelligent input terminal [SET] to be set (F-00. F-O 1, F-04. F-OS) Function contents Setting contents It is possible to run two motors with one inverter by 1. Setting method 1: Digital operator switching the control circuit terminal [SET]. The in any of the input terminals L changing of the SET terminal can be executed only when the inverter is stopped. Function which can be set with the second function [Setting example] [Monitor mode] [Function mode] Set the Z-stage accel, and dcccl. function of / 1. F-00 1. Output frequency the second function. Basic frequency setting setting 2. Acceleration and **FUNC FUNC** Ą deceleration time 2. F-01 setting (NOTE) Maximum frequency setting (Function mode) 3. F-04 F-06 Control method Acceleration time Setting method 2: Remote operator settina 4. F-OS Set the settings [SET] in any of the input terminals I to Motor constant F-07 setting Deceleration time When using the high performance remote operator, setting

NOTE:

setting

3. Manual torque boost

When selecting the second function. 2-stage acceleration and deceleration time setting can not be set and used. When setting and using the Z-stage acceleration and deceleration time, select the first function (when [SET] terminal is OFF).

2. Function changing method

input [8] SET with the ten key.

After the input terminal of the setting function cod and SET arc short circuited, the second function setting can be started.

4 to

When the short cuicuit is recovered, the function returns to the original setting (the first function).

3. Setting method of each function

Set same as the normal setting. When checking the function mode. confirm it with the terminal status ON/OFF.

Initial settings

Initial settings which can be set with the second function is same as the factory settings.

Appendix 7 List for display and data read/copy with each operators

(1) Monitor mode Y: Possible

							N:	Not po	ossible	
Monitor name	Di	splay with	Dis	play with	FunctionNowithLigitabperator Data read/copy_se,					
Monitor name	H	OP, HRW	DO	P. DRW	Alterability	No.	Data	HRW	DRW	va
Frequency setting										
First setting	FS	0.00 H z			Y	F2	0.00	Υ	Υ	
Second setting	FS	0.00 Hz			z Y	F2	0.00	Υ	N	
Multistage speed setting	IS	0.00 Hz	<u> S0000.0</u>) 0.0 H	z Y	F2	0.00	Υ	N	
	7s	0.00 Hz	750000.0	0.0 Hz					l	
Analog frequency selling	TM	0.00 Hz			z Y	F2	0.00	N	N	
			(4)		1			ļ		<u> </u>
logging frequency setting	JG	1.00 Hz	JG 1.0	<u>0.0 Hz</u>	Y	F2	1.00	Υ	Υ	
Option I frequency display * 1	O1	0.00 Hz	<u>01</u> 0.0	0.0 Hz	Υ	F2	0.00	Y	N	
Option 2 frequency display	02	0.00 Hz	02 0.0 (7)	0.0 Hz	Υ	F2	0.00	Y	N	
Output frequency setting		0.00 Hz	FS0000.0	0.0 Hz (8)	Υ	d0	0.00	_	_	
Acceleration time setting			1						 .	
First setting	ACI	30.00 s	ACC I	0030.00 s	Υı	F6	30.0	Y	Υ	
Second setting	ACI	30.00	ACCI	0030.00 s	Υ	F6	30.0	Y	N	
2-step acceleration lime setting	AC2	15.00 s	ACC2	0015.00 s	Υ	F6	15.0	Υ	N	
Deceleration time selling]			
First setting	DC1	30.00 s	DEC1	0030.00 s	Y	F7	30.0	Y	Y	
Second setting	DCI	30.00 s		0030.00 s	Y	F7	30.0	Y	N	_
2-step deceleration time setting	DC2	15.00 s	DEC2	0015.00 s	Y	F7_	15.0	Y	N	
Motor pole number setting RPI	И	1:4 P	RPM 4P	<u>ORPM</u>	Y	A25	4	Y	Y	,
Motor rpm monitored		ORPM	(13)	(14)	Y	d1	0.00			
Converted frequency setting	/Hz	1.0	/Hz 01.0	0.00	Y	A47	1.00	Y	Y	
Converted frequency monitor		0.00	(15)	(16)	Y	d3	0.00	_		
Output current monitor	lm	0.0 A	<u>Im 0.0 A</u>	0.0 %	Y	d2	0.00			
Output current rate monitor		0.0 %	(17)	(18)	N		_	_	_	
orque monitor	Torque	0 %	Torque	0 %	N	-				
Aanual torque boost adjustment										
First setting	V-Boost		V-Boost		Υ	F8	II	Υ	Υ	
Second setting	V-Boost	1 1	V-Boost	code<11>	Υ	F8	II	Υ	N	
Aanual torque boost frequency										
djustment	12 B	n.			}					
First setting	V-Boost		V-Boost	F 10.0 %	N			Y	N	
	/-Boost	F 10.0 %	V-Boost	F 10.0 %	N			Y	_N	
Output voltage gain adjustment		100 %	V-Gain	100 %	N	_		<u>Y</u>	Y	
ogging frequency setting	Jogging		Jogging	1.00 Hz	Y	A61	1.00	Y	Y	_
nalog meter adjustment	ADJ	172	ADJ	172	Y	F10	172	Υ	N	
	TERM	LLLLLLLL	TERM L	LLLLLLLL	N		_			
Jarm display First setting	WARN	[# \	VARN	#	N -	-		Y	N	

^{*}I Represents an indication for commanding frequency from the optional PCB.

Monitor name	Displa	Display with		with	Fur	nctionNowithdig	ritabperator	Data	Data read/		set
Monitor name	HOP,	HRW	^^DUT	^^DUP;"DKW		Alterability No.		Data	HRW	DRW	Value
Trip cause factor i	ERRI	#	ERR1		#	Υ	d10		N	N	
Trio frequency	ERRI	0.0 Hz	ERR1	0.	0 Hz	N		<u> </u>	N	N	
Trip current I	ERRI	0.0 A	ERRI	().0 A	Υ	d10		i N	N	
Trip time P-N voltage 1	ERR1	0.0 Vdc	ERR1	0.0	Vo	c Y	d10		N	N	
Integrated count 1 of cause time running days	ERR1 R	0 Y 0 D	ERR1 R	0 Y 0	D	N -		<u> </u>	N	N	
Integrated error count	ERR COUN	T 0	ERR COU	NT 0		N	'	<u> </u>	N	N	
Trip cause 2	ERR2	#	ERR2		#	Y	d11		N	N	
Trip frequency 2	ERR2	0.0 Hz	ERR2	0.	O Hz	N	7 -	_	N	N	
Trip current 2	ERR2.	0.0 A	ERR2		.0 A	N	7 -	Ì	N	N	
Trip time P-N voltage 2	ERR2	0.0 Vdc	ERR2	0.0	Vdc	N	-		N	N	
Integrated count of error time running days	ERR2 R	OYOD	ERR2 R	OY	OD	N	 		ΙN	N	
Trip cause 3	ERR3	#	ERR3		#	Υ	d11		N	N	
Trip frequency 3	·ERR3	0.0 Hz	ERR3	0.0 H		N	<u> </u>	_	N	N	
Trip current 3	ERR3	0.0 A	ERR3	n	n a l	N		_	N	N	
Trip time P-N voltage 3	ERR3	0.0 Vdc	ERR3	0.0	Vdc	N	_		N	N	
Integrated count of error	ERR3 R	OYOD	ERR3 R	OYO	DD	N	_	_	N	N	

(2) Function mode

Y: Possible

N: Not possible

Function mode	Displa	y with HO	P, HRW	Display	with DOP. DRW	owithdigita	ithdigitabperator Data read/copy				
i dilonon mode	Layer	Data	Jisplay	No.	Datadisplay	Alterability	No.	Data	HRW	DRW	vaiu
Frequencycommand	1.	IF-SET	l:REM	Monito	r F-SET-	ΙΥ	F9	0	Y	Υ	
					SELECTRE	М	1	ŀ		<u> </u>	
Operation:ommand		2 F/R	1: REM 1	Monitor F	R-SELECT				Y	Y	ţ
	_				REM	<u> </u>				<u> </u>	
Parameteselection		3PARM	0: REM	F-09	PARAMREM	N		<u> </u>	Y	Y	
Triphistorycountclear	2-	1TCNT	0: CNT	F-38	INITTCNTCNT	N	<u> </u>	-	Y	Y	
Debugmodedisplayselection	_	2DEBG	0:OFF		INITDEBGOFF	N	-	_	N	N	
Digitaloperatorrotatingdirection		3DOPE	0:FWD		INITDOPERWD	Y	F4	F	Y	Y	
selection	_ '										
Resemperformanceselection		4RESET	0:ON		INITRESETON	Y	F86	0	Y	Y	<u> </u>
Basefrequencysetting											1 1
Firstsetting	3-1-1	IF-BASE	50 Hz	F-00	F-BASE0050Hz	Y	A62	50	Y	Y	
Secondsetting		IF-BASE	50 Hz		F-BASE0050Hz	Y	A62	50	Y	N	
Max.frequencysetting	1										
Firstsetting	_] [2F-MAX	50 Hz	F-01	F-MAX0050Hz	Y	A63	50	Y	Υ	
Secondsetting	_}	2F-MAX	50 Hz		F-MAX0050Hz	Y	A63	50	Y	N	
Startfrequencysetting		3 Fmin	0.5 Hz	F-02	Fmin 0.50 Hz	Y	A4 .	0.50) Y	N	
Motorvoltagesetting	7. í	4A-AC	0: 200 V	F-03	AVRAC200V	Y	FIL	200	Y	Y	
AVR function ON/OFF during	1 1	5A-DEC	0:ON		AVRDECON	N	_	-	· Y	Y	
deceleration						1	†	ļ	<u> </u>		

	Displa	y with HO	P, HRW	Display	with DOP, DRW	FunctionNo	withdigitab	perator		ad/copy	set
Function mode	Layer	Data		No.	Data display	Alterability	No.	Data	HRW	DRW	_
Controlmethod									1		
Firstsetting	3-1-1	6MODE	0: VC	F-04	CONTROLVC	Y	A0	0	Y	Y	
Secondsetting		6MODE	0: VC		CONTROLVC	Y	Α0	0	Y	N	
Autotuning setting	3-1-2	IAUTO	0: NOR	F-05	AUXAUTONOR	Y	A97	0	Y	N	
Motordataselection									•	1	
Firstsetting		2DATA	0: NOR		AUXDATANOR	Y	A98	0	Y	N	
Secondsetting]	2DATA	0.NOR		AUXDATANOR	Y	A98	0	Y	N	
Motorcapacityselection									1		
Firstsetting	1	3 K 6:5.50	kW		AUX K 0050kW	<u>Y</u>	ΑI	5.50	Y	Y	ļ
Secondsetting]	3 K 6:5.50	kW		AUXK0050kW	Y	Al	5.50	Y	N	<u> </u>
Motorpolenumberselection				<u> </u>							
Firstsetting	1	4P	1:4P		AUX P 4P	Y	A2	04	Y	Y	<u> </u>
Secondsetting		4P	1:4P		AUXP4P	Y	A2	04	Y	N	
Motorconstant R1 setting	ļ										
Firstsetting	_	5RI	0.251		AUX R1 0.0251	N		-	Y	Y	 -
Secondsetting	_	5RI	0.251		AUXRI 0.0251	N			Y	N	
Motor constant R2 setting											
Firstsetting	_	6R2	0.194	Į	AUX R2 0.0194	N			Y	Y	<u> </u>
Secondsetting	_	6R2	0.194]	AUX R2 0.0194	N		_=	Y	N	
Motor constant L setting									l	l .,	
Firstsetting	_	7L	3.29mH		AUX L 003.29 mH	N			Y	Y	 -
Secondsetting	_	7L	3.29mH	1	AUX L 003.29 mH	N		<u> </u>	Y	N	
Motor constant M setting		1							,	\ ,	
Firstsetting	4	8M	30.90 mH		AUX M 030.90 mH	,		-	Y	Y	
Secondsetting	4	8M	30.90 mH		AUX M 030.90 mH	N			 	N N	
Motor constant I setting			0.44	Ì	AUV 1 000 44 l2				Y	Y	
Firstsetting	-	91	0.44	}	AUX J 000.44 kgm ²	·		 -	Y	 	
Secondsetting	4	91	0.44		AUX J 000.44 kgm ²	i N		<u> </u>	1	N	
Motorconstant Kpsetting		-1/-	3.00		AUVV- 200	Y	A3	2.00	Y	Y	
Firstsetting	4	aKp	2.00		AUX Kp 2.00		· · · · ·		Y -	N	<u> </u>
Secondsetting	1	aKp	2.00	}	AUX Kp 2.00	Y	A3	2.00	 '	I IN	-
Motor constant Tisetting		bТi	100 ms		AUXTi00100ms	N	_	_	Y	Y	
Firstsetting	1			1	AUX Ti00100ms	N		<u>-</u>	Y	N	
Secondsetting	1	bTi	100 ms	{	AUA HUHUMIS	14		-	 '		
Motor constant Kpp setting First setting		cKrs	1.00		AUXKpp001.00	N		_	Y	Y	
Secondsetting	-	сКрр сКрр	1.00	1	AUXKpp001.00	N N		 _	Y	N	
	3-1-3		1.00 16.0kHz	F-36	CARRIER 16.0 kHz	 	A10	16.0	Y	Y	
Carrierfrequencysetting	3-1-3	ICARKI	10.0KHZ	1-50	CANNIER 10.0 KHZ	1	710	10.0	<u>'</u> -	 	
Accelerationtimesetting Firstsetting	3-2-1	IAI	30.00s	F-06	ACC1 0030.00s	Y	F6	30.0	Y	Y	
Secondsetting	3-2-1	1AI	30.00s	1.00	ACC1 0030.00s	Y	F6	30.0	Y	N	
2-stepaccelerationsetting	+	2A2	15.00s	1	ACC2 0015.00s	Y	F6	15.0	Y	N	
	1	3LINE	0: L	1	ACCLINE L	N		13.0	Y	Y	
Acceleration time curve pattern setting	1	4GAIN	2	1	ACCGAIN02	N	- F7	30.0	Y	Y	
Acceleration/decelerationurve		4GAIN	2		ACCOMING	'`	,,,	30.0	'	'	
			<u></u>		<u></u>	<u> </u>		<u> </u>	ــــــــــــــــــــــــــــــــــــــ		

Function mode			IOP, HRW	/ Displa	y with DOP, DRW	Function	lowithdigit	abperator	Data re	ad/copy	set
	Layer	Dat	a display	No.	Data display	Alterabilit	y No.	Data	HRW		value
Decelerationtimesetting	1	1		1			T -				
Firstsetting	3-2-2		30.00s	F-07	DEC I 0030.00 s	Y	F7	30.0	Y	Y	
Secondsetting	4	IDI	30.00s	_	DEC 1 0030.00s	Y	F7	30.0	Y	N	
2-stepdecelerationtimesetting	4	2D2	15.00s	_[DEC 2 0015.00s	Y	F7	15.0	Y	N	
Deceleration time curve pattern selection	늬	3LINE	0: L	_	DECLINE L	N] -		Y	Y	
Acceleration/decelerationurve		4GAIN	2	}	DECGAIN 02	N	T -		Y	Y	
constantselection		ļ	· · · ·	<u> </u>					L		ļ
Acceleration time stop frequency setting	3-3-1	IF	0.0Hz	F-08	FspF 0000.0 Hz	N	_	- I	Y	Y	
Accelerationtimestoptimesetting	ļ	2TIME	20.0	<u> </u>	FspT1ME00.0s	N		_	Y	Y	
Multi-stepspeed/processstepping	3-3-2			F-10							
selection	_	<u> </u>		_						i	İ
Operationmodeselection	_	IMODE	0: NOR	[RUN MODE NOR	Y	A59	0	Y	N	
Freerunstop		2FRS	1:ZST		RUNFRS ZST	Y	A54	01	Y	Y	
1stspeed of Multistage speed	3-3-3	ISI	0.00Hz	F-11	SPD 1 0000.00 Hz	Y	A12	0.0	Y	N	
2nd speed of Multistage speed	1	2S2	0.00Hz		SPD 2 0000.00 Hz	Y	A13	0.0	Y	N	
3rdspeed of Multistage speed	1	383	0.00Hz		SPD 3 0000.00 Hz	Y	A14	0.0	Y	N	
4th-7thspeedofMultistagespeed		454	0.00Hz]	SPD 4 0000.00 Hz	Y	F2	0.0	Y	N	
			to		to						-
		7 S 7	0.00Hz		SPD 7 0000.00 Hz		!				1
DCbraking selection	3-4-1	1SW	0:OFF	F-20	DCBSWOFF	N	_	T_	Y	Y	
DC braking type selection		2KIND	1:LVL		DCBKINDLVL	N			Y	Y	
DCbraking frequency selection	ĺĺ	3F	0.5Hz		DCBF0000.5Hz			11	Y	Y	
DCbrakingpowerselection		4V-STA	0		DCBV-STA00	N			Y	Y	
(startingtime)	[.]]	.	.	
DCbraking powerselection	ĺĺ	5V-STP	0		DCBV-STP00	N		_	Y	Y	
(stoppingtime)										•	
DC braking time selection		6V-STA	0.0s		DCB V-STA 000.0 s	N			Y	Y	
(startingtime)						ĺ					
DC braking time selection		7T-STP	0.0s		DCB T-STP 000.0 s	N	_	_	Y	Y	
stoppingtime)	Ĺ							İ			
OC braking output OFF time adjustment		8STOP-T	0.00s		DCB STOP-T 0.00 s	N		_	Υ	Y	
Regenerationbrakingsetting	3-4-2	1%ED	1.5%	F21	BRD-%ED 001.5%	Y	A38	1.5	Y	Y	
electronidhermalcharacteristics			ı								
selection								j			
Firstsetting	_	ICHAR	1:SUB	F23	E-THM CHAR SU	Y	A24	1	Y	Y	
Secondsetting		ICHAR	1:SUB		E-THM CHAR SUB	Y	A24	1	Y	N	
Electronicthermallevelsetting				 							
Firstsetting	_	2LEVEL	100%	ļ	E-THM LEVEL 100%		Aυ	100	Y	Y	
Secondsetting	_	2LEVEL	100%		E-THM LEVEL 100%	Y	A23	100	Y	N	
electronichermakharacteristics		3AI	15.8A		E-THM AI 15.8 A	N			Υ	N	
reesetting(current value I)	-	4=1			_						
electronichermatcharacteristics		4F1	0Hz		E-THM FI 0000 Hz	N	_	-	Y	N	
reesetting(frequency1)	-			, <u>l</u>							
electronichermalcharacteristics	:	5A2	15.8A	ļ	E-THM A2 15.8 A	N	-	-	Y	N	
reesetting(currentvalue2)		<u> </u>		1		1		<u> </u>			

4

Function mode	Disp	Display with HOP, HRW Di		V Display	with DOP. DRW	FunctionN	withdigita	bperator	Data re	ad/copy	set
	Laye	r Data	a display	N o	. Data display			Data		DRW	
Electronichermatharacteristics freesetting(frequency2)	3-5-1	6F2	0Hz	F-23	E-THM F2 0000 Hz	N	_	_	Y	·N	
Electronichermatharacteristics		7A3	24.0A	7	E-THM A3 24.0 A	H N	 		Υ	N	
freesetting(currentvalue3)		ļ								1.4	
Electronidhermatharacteristics freesetting(frequency3)		8F3	73Hz		Е-ТНМ F3 0073 ггд	N	-	-	Y	N	
Overloadlimitlevelsetting	3-5-2	ILEVE	125%	F-24	OLOADLEVEL125%	N			Υ	Υ	
Overloadlimitconstantsetting		2CONS	T1.0	7	OLOADC:ONST 01.0	N		_	Υ	у	_
Overload limits election during acceleration		3 ACC	l:ON		OLOADACCON	N	_	-	Υ	Y	
Frequencylowerlimitersetting	3-5-3	1LIML	0.0Hz	F-26	LIMIT L 0000.0 Hz	Y	A5	0.0	\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \	1,	
Frequencyuppertimitersetting		2LIMH	0.0Hz	† • • • • • • • • • • • • • • • • • • •	LIMIT H 0000.0 Hz	Y	A6	0.0	Y	Y	
Jumpfrequency(1)		3Fi	0.0Hz	1 .	JUMP FI 0000.0 Hz	Y	A7	0.0	Y	Y	
Jumpfrequency(2)		4F2	0.0Hz		JUMP F2 0000.0 Hz	Y	A8	0.0	Y	Y	
Jumpfrequency(3)		5F3	0.0Hz		JUMP F3 0000.0 Hz	Y	A9	 	Y	Y	
Jumpfrequency width setting		6WIDTI-			JUMPW 0.5Hz	N	Ay	0.0	Y	Y	
Allowableinstantaneoustime	3-5-4	ITIME	1.0s	F-22	IPSTIME 1.0s	N			Y	Y	
Reclosing stand-by after instantaneous powerfailurerecovered		2WAIT	1.0s	- 	IPSWAIT001.0s	N	=		Y	Y	
Instantaneouspowerfailurerestart selection	7	3POWR	0: ALM		IPSPOWRALM	Y	A34	0	Y	Y	
Tripselection during stop at under voltage		4TRIP	1:OFF		IPSTRIPOFF	N N		-	Y	Y	-
Max frequencyselection	3-5-5	1MAXF	0: 120 Hz	F-30	F-MAX-L120Hz	- ,				-	=
Softwarelockselection	† • • • • • • • • • • • • • • • • • • •	2SLOCK		F-25	S-LOCKMD1	Y	A64	120	Y	Y	==
STOPkeyvalidityselection	1	3STOP	1:ON	1-22	-STOP-3WON_	N N		+	Y	Y	==
Runningdirectionselection		4F/R	2:FRE	F-29	F/RSWFRE	N	_		Y	Y	
Reverserunprevention	1 1	5PREV.	0:OFF		F/RPREVOFF	N N			Y	Y	
Reduced voltage soft start setting	†	6RVS	6		F/RRVS6	N I		_	Y	v	
Analoginputvoltageselection	3-6-1	17	1:10	F-31	INANA 10V	Y	A58 A48	6	Y	N Y	
Externalfrequencystartsetting	1 1	2EXS	0.0Hz	• 5	INEXS 0000.0 Hz	iY	A26	,	<u>-</u> -		
Externalfrequencyendsetting	1	3EXE	0.0Hz	ľ	IN EXE 0000.0 Hz	Y Y	A20 A21	0.0	Y	Y	
External frequency start rate setting	Ī	4EX%s	0%		INEX%S000%	N	AZI	0.0	Y	N	
External frequency endrate setting		5EX%E	100%	1	INEX%E100%	N			Y	N	
External frequency start point setting		6LEVEL		ļ!	iNLEVELOHz	N I			Y	N	
Frequencycommandsampling	i †	7F-SAMP8		<u> </u>	INF-SAMP8		<u>- </u>	<u> </u>	- -	Y	—- ·
requencysetting	՝ <u></u>			Ţ.	1	i i	Ali	8	Y	N	h
Arrival signal output pattern selection	3-6-2	IPTN	0:CST	F-32	ARVPTNCST	Y I A4	0 1	n 1	v	v	
Arrival frequency setting for acceleration	/ -	_	0.0Hz	<u> </u>	ARV CC0.0Hz		A39	0	Υ	Y	
arrival frequency setting for deceleration	h-	3DEC	0.0Hz	'-	ARV DEC 0.0 Hz		A40	0	Y	Y	
vertorque signal rate for plus torque	.	4V	100%		0V-TRQV 100%	N			Y		
Wertorque signal rate for minus torque	Ι.	5R	100%	() -	OV-TROR 100%	N		_ }	Y	N N	

13.

Function mode	Displa	y with H	OP. HRW	Display	with DOP, DRW	FunctionNo	withdigital	operator :	Data re	ad/copy	set
Function mode	Layer	Data	display	NO.	Data display	Alterability	No.	Data	HRV	V DRV	v alu
Inputterminal I setting	s-6-s	[1]-1	18:RS	F-34	IN-TMIRS	l Y	CO	18	Y	Ņ	
Input terminal 2 setting]	21-2	16:AT] '	IN-TM2AT	Y	Cl	16	Y	N	
Input terminal 3 setting	1	31-3	5:JG	1	IN-TM3JG	Y	C 2	5	Y	N	
Inputterminal 4 setting	1	41-4	11:FRS]	IN-TM4FRS	Y	C 3	11	Y	N	
Inputterminal 5 setting	1	51-5	9:CH1	1	IN-TM5CH1	Y	C 4	9	Y	N	
Input terminal 6 setting		61-6	2:CF2		IN-TM6CF2	Y	C 5	2	Y	N	
Input terminal 7 setting		71-7	I:CFI	1	IN-TM7CF1	Y	C 6	1	Y	N	
Input terminal 8 setting	1	81-8	0:REV	1	IN-TM8REV	Y	C 7	0	Y	N	
Inputterminal I NO/NC setting	1	9I-OC1	0:NO	1	IN-TM0/C-INO	Y	C20	00	Y	N	
Inputterminal 2NO/NC setting	1	al-OC2	0: NO	1	IN-TM0/C-2NO				Y	N	
Input terminal 3 NO/NC setting		bI-OC3	0: NO	i	IN-TM0/C-3NO				Y	N	
Inputterminal 4NO/NC setting	1	cI-OC4	0:NO	†	IN-TMO/C-4NO		1		· Y	N	
Output terminal 11 setting		d0-1	0:FA1	1	OUT-TM1FA1	Y	CI0	0	Y	N	
Output terminal 12 setting	ĺ	e0-2	1:RUN	•	OUT-TM2RUN	Y	CII	1	Y	N	
AlarmoutputNO/NC setting		f0-OCA	1:NC		OUT-TM 0/C-A NC		C21	04	Y	N	
Output terminal 11 NO/NC setting		g0-OC1	0: NO	1	OUT-TM 0/C-1 NO	ı	(21	🗸	Y	N	
Output terminal 12NO/NC setting		h0-OC2	0:NO	{	OUT-TM 0/C-2 NO				Y	N	
Monitorsignal selection	1-6-4	ISEL		- 3 7	MONITORA-F	Υ	A44	0!	γ	Y	
Hostoperationat OP terror	4-I	10PI	I:STP	F-47	OP-ERRISTP	N I		1	/ Y	I N /	
HostoperationatOP2error	1.	2OP2	1:STP	,,	OP ERR2STP	" .		<u>.</u>	, . у	IN	1
Encodepulsenumbersetting	4-2	IENC-P	1024pls	F-39	OPP01024pulse	l N			γ	N I	•
Controlmodeselection	72	2MODE	0: ASR	1-37	OPMODEASR	N .	_ '		Υ	N I	1
Ro-tooptionselection		3RO-TO	0:OFF	Ì	OP-RO-TOOFF	· · · · · ·	A99	0	Υ	Υ	
Stopposition setting switch	4-3	IPOS	0: IN	F-40	ORPOSIN	i N		l ;	' Y	Y	! [
Stoppositionsetting	7.5	2P	0 pls	1	OR P00000 pulse	N		· — ;	Y	N I	
Speedsetting		3FC	5.0Hz		OR FC 00050 Ptrisc	N			Y	N N	
Directionsetting		0:FWD	3.0112	ł	FWD	N			Y	Y	
Completionrangesetting		5LIMIT	5 pls		OR L 0005 pulse	l N		<u> </u>	Υ	N I]
Completionalgesetting		6TW	0.0ms		ORTW00.0ms	N			Y	N	
	4-4	1EGRP	0: FB	F-41	POEGRPFB	N			Y	Y	
Electronic gear setting position selection Numeratorofelectronic gearratio	44	2EGR-N	l I	F-41	POEGR-N00001	N		- :	Y	N	
		3EGR-D			POEGR-D00001				Y	N	
Denominatorofelectronicgearratio			<u>'</u>		.00	N N		<u> </u>	Y	N N	
Feedforwardgain		0.00 5G	0.50rad		PO G 000.50 rad/s			_ :	Y	N	
Position loop gain	15			F 40							
Torquelimitersettingselection	4-5	ILIMIT	0: IN	F-42	TRQLIMITIN	N		<u> </u>	Y	N	
Plus torque limiter setting		2FWD	150%		TRQFWD150%	N			Y	N	
Minus torque limiter setting		3 R E V	150%		TRQREV 150%	N	 1	!		<u>N</u>	
PID target value setting method selection	4-6	I I-SEL	0: IN	F - 4 3	PIDIN-SELIN	Υ	A95	0 ;	Y	Y	
PIDtargetvaluesetting	ſ	2LVL	0.00%	Ì	PIDLVL000.0%	Y	A96	000	Y	N	
Pgainsetting	Ì	3P	1.0		PIDP 1.0	Y	A90	1.0	Y	N	
I gain setting	Ì	41	1.0s	j	PID I 1.00s	Y	A91	1.0	Y	N	
D gain setting	İ	5D	10.0	1	PID D 0100.0	Y	A92	0.0	Y	N	
PIDselection	Ì		0:MDO		PIDMODEMDO	Υ	A94	0	Υ	N	


Dis		ay with HOP, HRW Display with DC		with DOP, DRW	FunctionNowithdigitabperator			Data read/copy se		set	
Function mode	Layer	Data	display	NO.	Datadisplay	Alterability	No.	Data	HRW	DRW	value
Transmissionspeedselection	4 7	IBAUD	1:600 bps	F-46	COM BAUD 0600 bp	N.	_		Y	N	
Stationnumberselection		2NUMBE	R I		COM NUMBER 01	N	_	-	Y	N	
Bitlengthselection	,	3LENG1	TH 0:8		COMLENGTH8	N	_	_	Y	Y	
ParityON/OFFselection		4PAR-1	I:ON		COMPAR-SELION	N	_	_	Y	Y	
Odd/evenparityselection	7	5PAR-2	0:EVN		COM PAR-SEL2 EVI	N		_	Y	Y	
Stopbitlengthselection	7	6STOPB	IT 0: 2]	COMSTOPBIT2	N	_		Y	Y	
Relayoutputterminal RYA signal selection	4-8	IRYA	3:RUN	F-48	RELAYRYARUN	N	_		Y	N	
Relay output terminal RYB signal selection		2RYB	0:CST		RELAYRYBOST	N	_	_	Y	N	
Relay output terminal RYC signal selection		3RYC	4:OTQQ		RELAYRYCOTQ	N		_	Y	N	
Extensionfunctionsetting		Settingon	lyfordigital	operator		Y	F14	A 0	N	N	
Voltagecommandadjustment		Settingon	lly fordigital	operator		Y	A80		N	N	
Currentcommandadjustment	Ì	Settingon	lyfordigital	operator		Υ.	A81		N	N	

Appendix 8 PID Function

1. Function

The PID (Proportional, Integral, Differential) control functions can apply to controlling of the air (water) amount of a fan pump, etc., as well as controlling of pressure within a fixed value. Set the reference signal according to the frequency setting method or the internal level, Set the feed-back signal according to the analog voltage input (0 to 5V or 0 to IOV) or analog current input (4 to $20\,\text{mA}$).

[Wiring Sketch]



2. PID Gain

If the response is not stabilized in a PID control operation, adjust the gains as follows according to the symptom of the inverter.

- The change of controlled variable is slow even when the target value is changed...
 - Increase the P gain.
- . The change of controlled variable is fast, but not stable.
 - Decrease the P gain.
- It is difficult to make the target value match with the controlled variable.
 - Decrease the I gain.
- Both the target value an the controlled variable are not stable. They match after oscillation.
 - -Increase the I gain.
- The response is slow even when the P'gain is increased.
 - Increase the D gain.
- The response is not stabilized due to oscillation even when the P gain is increased.
 - Decrease the D gain.

3. Data Setting Method

(I) Digital operator

Refer to A 9 0 A 9 1 A 9 2 A 9 4 A 9 5 A 9 6 of the extended function mode contents (pages 7-26 and 7-27).


(2) Remote operator

Setting item	Setting	range
--------------	---------	-------

	PID IN-SEL	IN	The PID LVL set value is assumed as the target value.
		OUT	The target value depends on the frequency setting method.
F 43	PID LVL	0 to 200)%
	PID P	0 to 5.0	
	PIDI	0 to 15.	0
	PID D 0	to 100.0	
	PID MODE	MD0	Built-in PID control OFF
		MDI	An analog current input is used as the feed-back signal.
		MD2	An analog voltage input is used as the feed-back signal.
		MD3	An analog current input is used as the feed-back signal. I gain × 10.
		MD4	An analog voltage input is used as the feed-back signal. I gain × IO.

Notes:

- If the target value signal is to be entered to an external terminal, the signal should not be assigned to the terminal used by the feed-back signal input. If assigned, no PID operation is possible.
- The [PID LVL] value (0 to 200%) corresponds to 0 to IOV of analog voltage input. In other words, if the target value input of 5V is converted to an internal level, set 100% for the [PID LVL].
- If target values are to be entered with current (01-L input), turn on the AT terminal.



HITACHI INVERTER

L100 SERIES

INSTRUCTION MANUAL

Single phase input 200V class Three phase input 200V class Three phase input 400V class

After reading this manual, keep it at hand for future reference.

NB541XD

Hitachi, Ltd.
Tokyo Japan

SAFETY

For the Best Results with L100 Series inverter, read this manual and all of the warning sign attached to the inverter carefully before installing and operating it, and follow the instructions exactly. Keep this manual handy for your quick reference.

Definitions and Symbols

A safety instruction (message) is given with a hazard alort symbol and a signal word; WARNING or CAUTION. Each signal word has the following meaning throughout this manual.



This symbol means hazardous high voltage. It used to call your attention to items or operations that could be dangerous to your and other persons operating this equipment.

Read these message and follow these instructions carefully.



This is the 'Safety Alert Symbol..' This symbol is used to call your attention to items or operations that could be dangerous to your or other persons operating this equipment. Read these messages and follow these instructions carefully.



WARNING WARNING

Indicates a potentially hazardous situation which, if not avoided, can result in serious injury or death.



CAUTION CAUTION

Indicates a potentially hazardous situation which, if not avoided, can result in minor to moderate injury, or serious damage of product.

The matters described under A CAUTION may, if not avoided, lead to serious results depending on the situation. Important matters are described in CAUTION (as well as WARNING), so be sure to observe them.

NOTE

NOTE: Notes indicate an area or subject of special merit, emphasizing either the product's capabilities or common errors in operation or maintenance.




HAZARDOUS HIGH VOLTAGE

Motor control equipment and electronic controllers are connected to hazardous line voltages. When servicing drives and electronic controllers, there might be exposed components with cases or protrusions at or above line potential. Extreme care should be taken to protect against shock.

Stand on an insulating pad and make it a habit to use only one hand when checking components. Always work with another person in case an emergency occurs. Disconnect power before checking controllers or performing maintenance. Be sure equipment is properly grounded. Wear safety glasses whenever working on an electronic controllers or rotating electrical equipment.

PRECAUTIONS

i



- WARNING: The user is responsible for ensuring that all driven machinery, drive train mechanism not supplied by Hitachi, Ltd., and process line material are capable of safe operation at an applied frequency of 150% of the maximum selected frequency range to the AC motor. Failure to do so can result in destruction of equipment and injury to personnel should a single point failure occur.
- WARNING: For protection, install a leak breaker type with a high frequency circuit capable of large currents to avoid an unnecessary operation. The ground fault protection circuit is not designed to protect personal injury.
- **⚠ WARNING:** HAZARD OF ELECTRICAL SHOCK, DISCONNECT INCOMING POWER BEFORE WORKING ON THIS CONTKOL.
- (AUTION: These instructions should be read and clearly understood before working on L100 series equipment.
- (AUTION: Proper grounds, disconnecting devices and other safety devices and their location are the responsibility of the user and are not provided by Hitachi, Ltd.
- **CAUTION:** Be sure to connect a motor thermal switch or overload device to the L100 series controller to assure that the inverter will shut down in the event of an overload or an overheated motor.
- **⚠ CAUTION: DANGEROUS VOLTAGE EXISTS UNTIL POWER LIGHT IS OFF.**
- CAUTION: Rotating shafts and above ground electrical potentials can be hazardous. Therefore, it is strongly recommended that all electrical work conform to the National Electrical Codes and local regulations. Installation, alignment and maintenance should be performed only by qualified personnel.

 Factory recommended test procedures, included in the instruction manual, should be followed. Always disconnect electrical power before working on the unit.

MARNING This equipment has high leakage current and must be permanently (fixed) hard wired to earth via two independent cable.

ì

Λ motors

- a) Class I motor must be connected to protective earth via low resistive path (< 0.10hm)
- b) Any motor used must be of suitable rating.
- c) Motors may have hazardous moving parts, in this event suitable protection must be provided.

A CAUTION

Alarm connection may contain hazardous live voltage even when inverter is disconnected. In case of removing front cover for maintenance or inspection, confirm that incoming power for alarm connection is surely disconnected.

⚠ CAUTION


Hazardous (main) terminals for any interconnection (motor, contact breaker, filter etc.) must be inaccesible in endinstallation.

⚠ CAUTION

This equipment should be installed in IP54 or equivalent (see EN60529). The end application must be in accordance with BS EN60204-1 (with reference to manual page4-1 and 4-2, the diagram measurements to be suitably amended).

⚠ CAUTION

Connection to field wiring terminals must be reliably fixed having two independent means of support. Using terminal with cable support (figure below), or cable gland, cable clamp etc



riangle Caution

A double pole disconnection device must be fitted to the incoming mains supply close to the inverter. Additionally, a protection device meeting IEC947-1/IEC947-3 must be fitted at this point(protection device data shown in page S-8)

The above instructions, together with any other requirements highlighted in this manual, must he complied with for continued LVD compliance.

Precautions for EMC (Electro Magnetic Compatibility)

It is required to satisfy the EMC directive (89/336/EEC) when using L100 inverter in EU country. To satisfy EMC directive and to comply with standard, the followings should be kept.

/\WARNING:

This equipment should be installed, adjusted and serviced by qualified personal familiar with construction and operation of the equipment and the hazards involved. Failure to observe this precaution could result in bodily injury.

I. Power supply to L100 inverter

- 1) Voltage fluctuation ± 10% or less.
- 2) Voltage unbalance ± 3% or less.
- 3) Frequency variation \pm 4% or less.
- 4) Voltage distortion THD = 10% or less.

2. Installation

I) Use filler designed for L100 inverter.

3. Wiring

- Sielded wire(screened cable) is required for motor willing, and length is less than 50m.
- 2) Carrier frequency must be setting less than 5kHz to satisfy EMC requirement
- 3) Separate the main circuit wiring from signal/process circuit wiring.

4. Environment condition

When using a filter, keep the following condition.

- I) Ambient temperature: -10 to 40°C
- 2) Humidity: 20 to 90 % RH (no dew condensation)
- 3) Vibrations : $5.9 \text{ m/s}^2(0.6 \text{ G}) 10 55 \text{Hz}$
- 4) Location: 1000 meter or less altirude, indoor (no corrosive gas or dust)

Revision History Table

No.	Revision Contents	The Date of Issue	Operation Manual No.
_	Correction of the specification for the reset terminal. (Page 5-11; NOTE 2) Correction of the initial data [C 31], [C32]. (Page 8-14)	September,1997	NB541XC
2	Addition of 5.5kw and 7.5kw model. Addition of insulation resistance test. Addition of the reactive current setting parameter [b32].	July,1998	NB541XI)

TABLE OF CONTENTS

		Page
1.	SAFETY PRECAUTIONS	1 - 1
2.	INSPECTION UPON UNPACKING	2.
3.	APPEARANCE AND NAMES OF PARTS	3. ı
4.	INSTALLATION	4. 1
5.	WIRING	5-1
6.	OPERATION	6 - {
7.	FUNCTION OF CONTROL CIRCUIT TERMINAL	7.
8.	OPERATION OF THE DIGITAL OPERATOR	8-1
9.	PROTECTIVE FUNCTIONS	Y- ı
10	TROUBLESHOOTING	Ю- і
П	MAINTENANCE AND INSPECTION	11-1
12	STANDARD SPECIFICATIONS	12 I
13	FUNCTIONS WHEN USING THE OPTIONAL REMOTE OPERATOR	13 1
14	SERVICE	4-I
APP	ENDIX I L100 SERIES DATA SETTING VALUES (FOR THE DIGITAL OPERATOR):	A-I
APP	ENDIX 2 L100 SERIES DATA SETTING VALUES (FOR THE REMOTE OPERATOR)	A-6
APPI	ENDIX 3 INITIALIZATION	A-12
APPE	ENDIX 4 CAPACITOR LIFE CURVE	Λ-13

1. SAFETY PRECAUTIONS

1. **Installation**

/ CAUTION	
Bc sure to install the unit on flame resistant material such as metal. Otherwise, there is a danger of fire.	p. 4-1
Be sure not to place anything inflammable in the vicinity. Otherwise, there is a danger of fire.	p. 4-I
Be sure not to lot the foreign matter enter such as cut wire refuse, spatter from welding, iron refuse, wire, dust, etc. Otherwise, there is a danger of fire.	p. 4-I
Be sure to install it in a place which can bear the weight according to the specifications in the text (4. Installation). Otherwise, it may fall and there is a danger of injury.	p. 4-1
Be sure to install the unit on a perpendicular wall which is not subject	p. 4-1
Be sure not to install and operate an inverter which is damaged or parts of which are missing. Otherwise, there is a danger of injury.	p. 4-1
Be sure to install it in a room which is not exposed 10 direct sunlight and is well ventilated. Avoid environments which tend to be high in temperature, high in humidity or to have dew condensation, as well as places withdust, corrosive gas, explosive gas, inflammable gas, grinding-fluid mist, salt damage, etc. Otherwise, there is a danger of fire.	p. 4-I
Be sure that the wall surface is a nonflammable material, such as steel plate.	p. 4-2

2. Wiring

∕Û∖ WARNING	
	ρ. 5 -I
"Use 75°C (only for 055LFU) Cu wire or equivalent".	
⚠ "Open Type Equipment".	p. 5-I
⚠ "A Class 2 circuit wired with Class I wire" or equivalent.	p. 5 -l
Δ "Suitable for use on a circuit capable of delivering not more	p. 5-l
than 5,000 rms symmetrical amperes. 240 V maximum".	
For models with suffix Nor L.	
⚠ "Suitable for use on a circuit capable of delivering not more	p. 5-l
than $5,000\mathrm{rms}$ symmetrical amperes. 480 V maximum".	
For models with suffix H.	_ 5 1
A Be SUTE to groundtheunit.	p. 5-1
Otherwise, there is a danger of electric shock and/or fire.	
Wiring work shall be carried out by electrical experts. Otherwise, there is a danger of electric shock and/or tire.	p.5-1
Implement wiring after checking that the paver supply is off. It might incur electric shock and/or fire.	p. 5-l
\triangle After installing the main body, carry out wiring. Otherwise, there is a danger of electric shock and/or injury.	p.5-1

/\ Make sure that the input voltage is:

Single/Three phase 2(X) to 240 V 50/6() Hz(Up to 2.2kW)

Three phase 200 to 240V 50/60Hz(Abore 2.2kW)

Three phase 380 to 46() V 50/60Hz

 \triangle Be sure not to input a single phase to a 3 phase type.

p. s-2


p. 5-2

Otherwise, there is a danger of fire.

A Be sure not lo connect AC power supply to the output terminals. (U, V, W).

p. s-2

Otherwise, there is a danger of injury and/or fire.



Note: LI. N: Single phase 200 to 240V 50/60 Hz L1, L2, L3: Three phase 200 to 240V 50/60 Hz. Three Phase 380 to 460V 50/60 Hz

Power supply

1 Fasten the screws with the specified fastening torque. Check so that there is no loosening of screws.

p. s-2

Otherwise, there is a danger of fire.

Remarks for using earth leakage circuit breakers in the mains supply: Frequency inverters with CE-filters (RFI-filter) and screened motor cables have a higher leakage current against earth. Especially in the moment of switching on this can cause unintentional triggerings of earth leakage circuit breakers. Because of the rectifier on the input side of the inverter there is the possibility to stall the switch-off function through amounts of DC-current. The following should be observed:

Only short time-invariant and pulse current-sensitive earth leakage circuit breakers with higher trigger current should be used.

Other components should be secured with separate carthleakage circuit breakers.

Earth leakage circuit breakers in front of an inverter are not an absolute protection against direct touching.

.... p. 5-2 $\$ Be sure to setthe fusc(s)(the same phase as the main power supply) in the operation circuit.

Otherwise, there is a danger of fire.

1) As for motor leads, earth leakage breakers and electromagnetic contactors, be sure to use the equivalent ones with the specified capacity (rated).

p. 5-2

Otherwise, there is a danger of fire,

3. Control and operation

/ L. WARNING	
A Be sure to turn on the input power supply after closing the front case. While being energized, be sure not to open the front case. Otherwise, there is a danger of electric shock.	p. 6-1
A Be sure not to operate the switches with wet hands. Otherwise, there is a danger of electric shock.	p. 6-1
Mhile the inverter is energized, be sure not to touch the inverter terminals even during stoppage. Otherwise, there is a danger of electric shock.	ր. 6-I
Il the retry mode is selected, it may suddenly restart during the trip stop. Be sure not to approach the machine. (Be sure to design the machine so that personnel safety will be secured even if it restarts.) Otherwise, there is a danger of injury.	p. 6-1, p. 8-11
Even if the power supply is cut for a short period of time, it may restart operation after the power supply is recovered if the operation command is given. If it may incur danger to personnel, be sure to make a circuit so that it will not restart after power recovery. Otherwise, there is a danger of injury.	p. 6-1
The Stop Key is effective only when the function is set. De sure to prepare the Key separately from the emergency stop. Otherwise, there is a danger of injury.	p. 6- I
After the operation command is given, if the alarm reset is conducted. it will restart suddenly. Be sure to set the alarm reset after checking the operation command is off. Otherwise, there is a danger of injury.	p. 6-1 p. 7-12
Be sure not to touch the inside of the energized inverter or to put a bar into it.	p. 6-1
Otherwise, there is a danger of electric shock and/or fire. Mhenthe power is turned on when the running command is on, the motor starts rotation and it is dangerous. Before turning the power on, confirm that the running command is not on.	p. 7-4
Mhen the Slop key function is ineffective, pressing the Stop key does nor cancel the stop and trip. Be sure to provide an emergency stop switch separately. When the operation command destination is a digital operator, this selection es ineffective.	p. X-27

<u> </u>	
Cooling fm will have high temperature. Be sure not to touch them. Otherwise, there is a danger of getting burned.	p. 6-2
Low to high speed operation of the inverter can be easily set. Be sure to operate it after checking the tolerance of the motor and machine. Otherwise, there is a danger of injury.	ր. 6-2
If a motor is operated at a frequency higher than standard selling value(50Hz/60Hz), be sure to check the speeds of the motor and the machine with each manufacturer, and after gelling their consent, operate them. Otherwise, there is a danger of machine breakage.	p. 6-2
Check the following before and during the test run. Otherwise, there is a danger of machine breakage. Was the short-cut bar between + I and + removed? Was the direction of the motor correct? Was the inverter tripped during acceleration or deceleration? Were the rpm and frequency meter correct? Were there any abnormal motor vibrations or noise?	ր. 6-4

4. Maintenance, inspection and part replacement

<u> </u>			
After a lapse of more than 5 minutes after turning offlhe input power supply, perform the maintenance and inspection. Otherwise, there is a danger of electric chock.	p.	I	I-I
Make sure that only qualified persons will perform maintenance, inspection and part replacement. (Before starling the work, remove metallic objects from your person (wristwatch, bracelet, etc.) (Be sure to use tools protected with insulation.) Otherwise, there is a danger of electric shock and/or injury.	*******	р.	111

When removing connectors, never pull the wires. (Wires for cooling fan and logic p.c.board) Otherwise, there is a danger of fire due to wire breakage and/or injury.


∕Í∖ WARNING

Never modify the unit.

Otherwise, there is a danger of electric shock and/or injury.

∕Î∖ CAUTION


- Withstand voltage tests and Insulation resistance tests (megger tests) are executed before the units are shipped, so that there is no need to conduct these tests before operation.
- ⚠ Do not attach or remove wiring or connectors when power is applied. Also, do not check signals during operation.
- ⚠ Do not stop operation by switching off the electromagnetic contactors on the primary or secondary sides of the inverter.



When there has been an instantaneous power failure, and if an operation instruction has been given, then the unit may restart operation after the power failure has ended. If there is a possibility that such an occurrence may harm humans, then install an electromagnetic contactor (Mgo) on the power supply side, so that the circuit does not allow automatic restarting after the power supply recovers. If the optional remote operator is used and the retry function has been selected, this will also cause automatic restarting when an operation instruction has been input, so please be careful.

/ CAUTION

\(\sum \) Do not insert leading power factor capacitors or surge absorbers between the output terminals of the inverter and the motor.



- \triangle Be sure lo ground the grounding terminal, $\stackrel{\triangle}{=}$
- When inspecting the unit, after turning the power supply off be sure lo wail 5minutes before opening the cover.

⚠ MOTOR TERMINAL SURGE VOLTAGE SUPPRESSION FILTER (FOR THE 400 V CLASS)

in a system using an inverter of the voltage control PWM system, a surge voltage caused by the cable constants such as the cable length (especially when the distance between the motor and invener is 10 m or more) and cabling method may occur at the motor terminal.

A dedicated filter of the 400 V class for suppressing this surge voltage is available. Please order one.

⚠ PROTECTION AGAINST NOISE INTERFERENCE FROM INVERTER


The invener uses many semiconductor switching elements such as transistors and IGBTs. Thus, a radio set or measuring instrument located near the inverter is susceptible to noise interference.

To protect the instruments from erroneous operation due to noise interference, they should be installed well apart from the inverter. It is also effective to shield the whole inverter structure.

Addition of an EMI filter on the input side of the inverter also reduces the effect of noise from commercial power line on external devices.

Note that external dispersion of noise from the power line can be minimized by connecting an EMI filter on the primary side of inverter.

/ CAUTION



↑ EFFECTS OF DISTRIBUTOR LINES ON INVERTERS

In the cases below involving a general-purpose inverter, a large peak current flows on the power supply side, sometimes destroying the convener module. Where such situations are foreseen, or the paired equipment must be highly reliable, installan AC reactor between the power supply and the inverter.

- (A) The unbalance factor of the power supply is 3% or higher.
- (B) The power supply capacity is at least 10 times greater than the inverter capacity (and the power supply capacity, 500 kVA or more).
- (C) Abrupt power supply changes are expected.

Examples:

- (I) Several inverters are interconnected with a short bus.
- (2) A thyristor converter and an inverter are interconnected with a short bus.
- (3) An installed phase advance capacitor opens and closes.

In cases (A), (B) or(C), we recommend installing an AC reactor of 3% (in 3 voltage drop at rated current) with respect to the supply voltage on the power supply side.

- \triangle When occurring an EEPROM error (\boxed{E} \boxed{B}), be sure to confirm the setting value again.
- ([FW],[RV] terminal), the inverter starts automatically. Do not set to b contact without a purpose.

GENERAL CAUTION


In all the illustrations in this manual, covers and safety devices are occasionally removed to describe the details. When the product is operated, make sure that the covers and safety devices are placed as they were specified originally and operate it according to the instruction manual.

2. INSPECTION UPON UNPACKING

3


Before installation and wiring, be sure to check the following:

- Make sure that there was no damage during transportation the unit.
- After unpacking the unit, make sure that the package contains one inverter and one operation manual
- . Make sure that the product is the one you ordered by checking the specifications label on the side of the unit.



Contents of Specifications Label


If you discover any problems, contact your sales agent immediately.




3. APPEARANCE AND NAMES OF PARTS


3.1 Mechanical guidance and parts name

ĵ



Key cover can be opened by hand without any tool. And the signal wires can be connected to the control circuit terminals. Also the function keys are available.





, CAUTION

- As Be sure in install the unit on flame resistant material such as metal. Otherwise, there is a danger of fire.
- \underline{A}_{Δ} Be sure not to place anything inflammable in the vicinity. Otherwise, there is a danger of fire.
- De sure not to let the foreign matter enter such as cut wire refuse, spatter from welding, iron refuse, wire, dust, etc.


 Otherwise, there is a danger of fire.
- Be sure to install it in a place which can bear the weight according to the specifications in the text (4. Installation).

 Otherwise, it may fall and there is a danger of injury.
- As Be sure to install the unit on a perpendicular wall which is not subject to vibration. Otherwise, it may fall and there is a danger of injury.
- /13 Be sure to install the unit with opening the front case and tighten the mounting screw bolt. Otherwise, it may Call and there is a danger of injury.
- As Be sure not to install and operate an inverter which is damaged or parts of which are missing.
 - Otherwise, there is a danger of injury.
- He sure to install it in a room which is not exposed to direct sunlight and is well ventilated. Avoid environments which tend to be high in temperature, high in humidity or to have dew condensation, as well as places with dust, corrosive gas, explosive gas, inflammable gas, grinding-fluid mist, salt damage, etc. Otherwise, there is a danger of fire.

Inverter should be mounted vertically on no-flamable wall to prevent from over heating and fire. Make sure following clearance arround the inverter to keep cooling air flow.


This equipment should be mounted in IP54 or equivalent.

Foreign object should not be dropped into the equipment especially conductive chips, which may cause not only multunction and damage but also electrical and fire hazard.



Cover all ventilation holes on the inverter during installation to prevent from any foreign objects dropped into the equipment.

Be sure to remove those covers before start operation.



Be sure to check the ambient temperature -10 to $40\,^{\circ}\text{C}$.

In case of 50°C, set the carrier frequency 2 kHz or less and derate output current 80% or less and remove the top cover.

Higher ambient temperature cause shorter equipment life.

If there are some hot equipment near the inverter, keep it away from inverter as far as possible. When the inverter is installed in a cubicle and/or a box, temperature around inverter should be kept as above rating. Consider ventilation and clearance around the inverter.

For safety reason, front cover should be closed and don't open it during operation. For safety requirement, the end application must be in accordance with BS EN 60204-1.

Ĩ

5. WIRING

√Í\ WARNING

- ⚠ "Use 60/75°C Cu wire only" or equivalent.
 "Use*75 C (only for 055LFU) Cu wire or equivalent".
- ⚠ "Open Type Equipment".
- A Class 2 circuit wired with Class 1 wire" or equivalent.
- "Suitable for use on a circuit capable of delivering not more than 5,000 rms symmetrical amperes, 240 V maximum". For models with suffix N or L.
- △ "Suitable for use on a circuit capable of delivering not more than 5,000 rms symmetrical amperes, 480 V maximum". For models with suffix H.
- A Be sure to ground the unit.

 Otherwise, there is a danger of electric shock and/or fire.
- As Wiring work shall be carried out by electrical experts.

 Otherwise, there is a danger of electric shock and/or fire.
- 1 Implement wiring after checking that the power supply is off It might incur electric shock and/or fire.
- After installing the main body, carry out wiring.

 Otherwise, there is a danger of electric shock and/or injury.

A CAUTION

Make sure that the input voltage is:


Single/Three phase 200 to 240 V 50/60 Hz(Up to 2.2kW)

Three phase 200 to 24UV 50/60Hz(Abore 2.2kW)

Three phase 380 to 460 v 50/60 Hz.

1 Be sure not to connect AC power supply to the output terminals (U, V, W).

Otherwise, there is a danger of injury and/or fire.



Power supply

∑ Fasten the screws with the specified fastening torque. Check so that there is no loosening of screws.

Otherwise, there is a danger of fire.

Remarks for using earth leakage circuit breakers in the mains supply:

Frequency inverters with CE-filters (RFI-filter) and screened motor cables have a higher leakage current against earth. Especially in the moment of switching on this can cause unintentional triggerings of earth leakage circuit breakers. Because of the rectifier on the input side of the inverter there is the possibility to stall the switch-off function through amounts of DC-current. The following should be observed:

- Only short time-invariant and pulse current-sensitive earth leakage circuit breakers with higher trigger current should be used.
- Other components should be secured with separate carthleakage circuit breakers.
- Earth leakage circuit breakers in front of an inverter arc not an absolute protection against direct touching.
- \ Be sure to set the fuse(s) (the same phase as the main power supply) in the operation circuit.

Otherwise, there is a danger of fire.


\(\) As for motor leads, earth leakage breakers and electromagnetic contactors, be sure to use the equivalent ones with the specified capacity (rated).


Otherwise, there is a danger of fire.


- \(\) Double pole disconnection device must be fitted to the incoming mains supply close to the inverter. And protection device meeting IEC947-1/IEC947-3 must be fitted at this point.
- \sum Connection to wiring terminal must be reliabily fixed with two means of support.

į,

Main circuit terminals and alarm terminals will be exposed after front case open Refer page 3-1 APPEARANCE AND NAME OF PARTS.







- · Don't connect power source to any terminals except L1,L2,L3/N
- Don't connect any wires to no-assigned terminals on upper side.
 Those terminals are used for internal circuit.
- · Refer to page 5:10 Terminal dimensions.

(Power source)

· When pallarel motor operation is required, put thermal relays for each motor.


Motor

· Make sure power source type and terminals as below


AC power	type	Applicable terminals
Single Phase .	50/60Hz	Terminal L1,L3/N
Three Phase ,	50/60Hz	Terminal L1,L2,L3/N

Don't remove short bar between (+1) and (+) terminals.

Control circuit terminals




Control circuit terminal diagram (For example)



NOTE: See page 5-11 for changing function.

NOTE I: When changing the power supply of the motor between the inverter and commercial power, be sure to install mechanically interlocked switches Mg1 and Mg2.

Ţ




NOTE 2: Install an earth leakage breaker at the input of the inverter. (Select an earth leakage breaker whose sensitive current level is raised in high frequency range.)

When the cable between the inverter and motor is more than 10 m long, the thermal relay may malfunction due to high-frequency waves. To prevent this, install an AC reactor on the output side of the inverter or use a current sensor rather than a thermal relay.


NOTE 3: Be sure that the specified grounding is carried out. Be sure to separate the unit's grounding pole from those of other heavy electric machinery, and avoid using common grounding poles.

If multiple inverters are used, make sure that rhc grounding connections do not create a loop.




NOTE 4: When a frequency arrival signal is used, he sure to install a surge absorbing diode in parallel with the relay. Otherwise, the surge voltage created when the relay goes ON or OFF may damage the AK output circuit.

NOTE 5: Use a twisted and shielded wire for the signal line, and cut the shielded covering as shown in the diagram below. Make sure that the length of the signal line is 20 meters or less. If the line must be longer than 20 meters, please use a VX application control device RCD-A (remote control device) or CVD-E (insulated signal converter).



- NOTE 6: When the frequency setting signal is turned on and off with a contact, use a relay which will not cause contact malfunctions, even with the extremely weak currents and voltages, such as crossbar twin contacts, etc.
- NOTE 7: Use relays which do not have contact defects at 24 V DC. 3 mA for the other terminals.
- NOTE 8: Separate the main circuit wiring from the relay control circuit wiring. If they must cross, be sure that they cross at a right angle.




- NOTE9: Do not short circuit the terminals P24 and L,H,OI,FM by mistake. The control power supply may cause a failure.
- NOTE10: Do not short-circuit the terminals H and L.

 The control power supply may cause a failure

Connection to the Programmable Controller

į

(1) When the internal interface power source is used



NOTE 1: Do not short circuit the terminals P24 and L by mistake. The control power supply may cause a failure.

5.2 Wiring Equipment, Options

ACAUTION: Provide the wiring equipment in accordance with the safety codes required by jurisdictional authorities.

If specified in the standard or laws and regulations, follow their instructions,

Motor	Inverter	Wiring		Applicable equipment
(kW)	model	Power lines	Signat lines	Fuse(class J) rated 600 V
0.2	L100-002NFE L100-002NFU		(*)	10A
().4	L100-004NFE	AWG16/1.3mm*	0.14 to 0.75	10A
0.55	L100-005NFE		Shielded	10A
0.75	L 100 007NFE L 100-007NFU	AWG14/2.1mm²	wite	15.A
1.1	L100-011NFE			15/4
1.5	L100-015NFE L100-015NFU	AWG12/3.3mm²		20Λ (single ph.) 15Λ (three ph.)
2.2	L100-022NFE L100-022NFU	AWG10/5,3mm²		30A (single ph.) 20A (three ph.)
3.7	L100-037LFU	AWG12/3.3mm²		30A
5.5	L100-055LFE L100-055LFU	AWG10/5,3mm²		40A
7.5	L100-075LFE L100-075LFU	AWG 8/8,4mm²		50A
0.4	L100-004FIFE L100-004FIFU			34
0.75	L100-007HPE L100-007HPU	AWG16/1,3mm*		64
1.5	L 100-015HFU			100
2.2	£100-022HFE £100-022HFU			10A
3,0	L100-030HFE			15/
4.0	L100-040HFE L100-040HFU	AWG14/2.1mm ²		154
5.5	L100-055HFE L100-055HFU	A31471.272.23		20A
7.5	L100-075HFE L100-075HFU	AWG12/3.3mm²		25/\

NOTE 1: Field wiring connection must be made by a UL Listed and CSA Certified closed-loop terminal connector sized for the wire gauge involeved.

Connector must be fixed using the crimp tool specified by the connector manufacturer.

NOTE 2: Be sure to consider the capacity of the circuit breaker to be used.


NOTE 3: Be sure to use bigger wires for power lines if the distance exceeds 20 m.

NOTE 4: Install an earth leakage breaker meeting requirements of IEC947-1/IEC947-3 at the input.

(*) Use 0.75 mm² wire for the atarm signal wire.

Wire stripping lenght: 5 to 6 mm.

Max wire sleeve diameter except for the starm signal wire: 2mm.



NOTE 1: FFL100 series filter is required for EMC directive (Europe), C-TICK (Australia) but others are not for this purpose.


Reactor and others of the above table except EMI filter are for general use for

noise reduction.

5.3 Terminal

(1) Terminal dimensions Main circuit terminal

Terminal layout	Туре	Screw diameter	Width (mm)
	002NF 004NF	M3.5	7.1
	007NF ~ 022NF 037LF 004HF ~ 040HF	М4	9
	055,075LF 055,075HF	М5	13



Туре	002N 004N		007NF- 037LF 004HF-		055.075LF 055.075HF		
	Screw diameter	Width (mm)	Screw diameter	Width (mm)	Screw diameter	Width (mm)	
Main circuit	M3.5	7.1	M4	9	M5	13	
Control circuit	M2	_	M2	_	M2		
Alarm circuit	M3	_	М3		М3		
Grounding	M4	-	M4	-	M5	_	

Control circuit terminal														
L	_	5	ļ	4		3		2		1	P2	4		
н	•	O.	Ĩ	ы		L.	F	м	c	M2	12	Γ	11	7

Alarm Circuit Terminal

(2) Main circuit terminal function

Terminal symbol	Terminal description	Function	
LI L2 L3 (L1), (N)	Main power	Connect the power supply L1,L2,L3 Three phase L1, N Single phase	(L) (N) (T) (T3) (T3) (L) (L) (L) (L) (V W
U,V,W T1,T2,T3	Inverter output	Connect the motor	3, 3, 3,
+1,+	External DC Reactor	Usually the short-cut bar is attached between terminals +1 and +. When the DC Reactor is to be connected, be sure to remove the short-cut bar.	Power sumply
+, -	Braking unit	Connect the optional braking unit (when braking torque is required).	Make sure that the short-cut bar attached between +1 and + is not removed except when the DC reactor is to be mounted.
÷	Ground	Ground (connect grounding to avoid electric shock)	

Tightening torque

Screw	Tightening torque
M2	0.2 N·m (max. 0.25 N·m)
М3	0.5 N·m (max. 0.6 N·m)
M3.5	0.8 N·m (max. 0.9 N·m)
M4	1.2 N·m (max. 1.3 N·m)
M5	2.0 N·m (max. 2.2 N·m)

(3)Control circuit

	Terminal symbol	Terminal description and function	Initial setting (-FE/-FU)	Remarks			
	5	Intelligent input terminals 1 to 5	Reset input (Note 2)	Dry contact			
	4	Forward running Reverse running External command	trip Multispeed 2/USP	Close: ON (run) Open: OFF (stop)			
,	3	Multistage speed Jogging USP fun	Multispeed I/Analog input	7			
	2		Reverse running command	Min. ON time: 12 ms or more			
Input signal	1						
	P24	Common for input signals		24VDC max. 30 mA			
Monitor signal	FM	Analog frequency monitor/Digital freque monitor/Analog output current monitor	ncy Analog frequency monitor	mex. 50 thA			
	L	Common for monitor					
Frequency command	Н	Power supply for frequency comman	d	10 VDC max.10mA			
inpul .	0	Voltage frequency command		0-10 VDC (nominal (Input impedance 10 kΩ)			
	OI	Current frequency command		DC 4-20 mA (nominal) Input impedance 250Ω			
	L	Common for frequency command					
Output signal	11	Intelligent output terminal Arrival signal at constant speed, Arrival signal at set speed,	Arrival signal at constant speed	27 VDC 50 mA max			
	12	RUN signal, Overload signal, Deviation signal at PID control, Alarm signal	Run signal				
	CM2	Common for output signals					
Fault alarm	AL0	ALO ALI ALZ	Contact rating	Contact rating 250 VAC 2.5 A (Resistor load) 0.2 A (cos¿=0.4) 30 VDC 3.0 A (Resistor load) 0.7 A (cos¿=0.4) 100 mA 100 mA			
output	ALI						
	AL2	Normal : ALO-AL1 close Abnormal, Power off: ALO-AL1 open (Initial setting)	30 VDC 3.0 A (Resisto				

NOTE 1: USP: Prevention function of restart upon power on.
NOTE 2: The reset terminal can not be changed from "a contact" (NO) to "b contact" (NC)

NOTE 3: See page 7-14.

6. OPERATION

6.1 **BeforeStartingOperation**

Prior to the lest run, check the following.

WARNING Description on the input power supply after cloning the front case. While being energized, be sure not to open the front case.

Otherwise, there is a danger of electric shock.

Be sure not to operate the switches with wet hands.

Otherwise, there is a danger of electric shock

Otherwise. there is a danger of electric shock.

While the inverter is energized, be sure not to touch the inverter terminals even during stoppage.

Otherwise. there is a danger of electric shock.

As If the retry mode is selected, it may suddenly restart during the trip stop. Be sure not to approach the machine. (Be sure to design the machine so that personnel safely will be secured even if it restarts.)

Otherwise, there is a danger of injury.

Even if the power supply is cut for a short period of time, it may restart operation after the power supply is recovered if the operation command is given. If it may incur danger to personnel, be sure to make a circuit so that it will not restart after power recovery.

Otherwise, there is a danger of injury.

The Stop Key is effective only when the function is sel. Be sure to prepare the Key separately from the emergency stop.

Otherwise. there is a danger of injury.

After rhe operation command is given. if the alarm reset is conducted, it will restart suddenly. Be sure to set the alarm reset after checking the operation command is off. Otherwise, there is a danger of injury.

1 Be sure not to touch the inside of the energized inverter or lo put a bar into il.

Otherwise, there is a danger of electric shock and/or fire.

⚠ CAUTION

- Cooling fin will have high temperature. Be sure not to touch them. Otherwise, there is a danger of getting burned.
- Low to high speed operation of the inverter can be easily set. Be sure to operate it after checking the tolerance of the motor and machine.

 Otherwise, there is a danger of injury.
- 1 If a motor is operated at a frequency higher than standard setting value(50Hz/60Hz), be sure to check the speeds of the motor and the machine with each manufacturer, and after getting their consent, operate them.

Otherwise, there is a danger of machine breakage.

lote:

- (1) Make sure that the power lines (input power supply L1(L1), L2 and L3(N), and output terminals, U(T1), V(T2) and W(T3) are connected correctly.
- (2) Make sure that there are no mistakes in the signal line connections
- (3) Make sure that the ground terminal $(\frac{1}{2})$ is grounded.
- (4) Make sure that terminals other than those specified are not grounded
- (5) Make sure that the inverter is installed vertically on a wall, and a nonflammable material such as a steel plate is used as a mounting surface.
- (6) Make sure that there are no short-circuits caused by stray pieces of wire, solderless terminals or other objects left from wiring work. Also, make sure that no tools have been left behind.
- (7) Make sure that the output wires are not short-circuited or grounded.
- (R) Make sure that there are no loose screws or terminals.
- (9) Make sure that the maximum frequency setting matches the machine specifications
- (10) With the front case opened, do not operate the inverter. Make sure that the front case is completely closed and locked with the screw before operating the inverter.

Never test withstand voltage tests. Because this inverter has the surge absorber between the main circuit terminal and the ground.


6.2 Test Run

٨

An example of a general connection diagram is shown below

Operating with digital operator:

To set frequency, run and stop is used hy digital operator Frequency setting: Potentiometer on the digital operator Run and stop; key pad on the digital operator



Procedure(Operating with digital operator)

- (1) Turn on supply power to the inverter. Make sure that the POWER LED on the digital operator goes ON.
- (2) Set A 02 to 02.
- (3) Set A 01 to 00
- (4) Check to turn on the lamp above the potentiometer and turn the potentiometer.
- (5) Start running after pressing (SUP) once and turn on the RUN lamp
- (6) Check output frequency by monitor mode d 01.
- (7) Press STOP and decelerate to a stop.

A CAUTION

Check the following after the test run is complete. Otherwise, there is a danger of machine breakage.

- Was the direction of the motor correct?
- · Was the inverter tripped during acceleration or deceleration?
- · Were the frequency meter correct?
- · Were there any abnormal motor vibrations or noise?

When overcurrent tripping or overvoltage tripping occurs during the test run, increase the acceleration time or deceleration time.

Factory settings
(-FE/-FU)

Maximum frequency: 50 Hz/60 Hz Forward operation

7. FUNCTION OF CONTROL CIRCUIT TERMINAL

7.1 **List of Control Circuit Terminals**

rminal mbol	Func	tion	Contents
FW (00)	Forward run/stop		SWF Contact (close): Forward run (open): Stop SWR SWF Output frequency Forward Reverse SWR Contact (close): SWR SWF SWF ON OFF SWR OFF ON OFF
(01)	run/stop		Reverse run (open): Stop Both contacts SWF and SWR are close-sto
CF1 (02)	P	1	Frequency (Hz) Oth speed Third Terminal 2: R
CF2 (03)	Multistage speed	2	Second Second Terminal 3: C Terminal 4: C Terminal 5: R Speed Sp
CF3 (04)	Multi	3	Switch Time CF1 ON ON ON (VEO) CF2 ON ON
CF4 (05)		4	RV [Example for 4-stage multispeed]
JG (06)	Jogging		Jogging run
PTC (19)	PTC thermistor Thermal protection		When thermistor is connected with this terminal, the thermal protection can be used. The common is the terminal (L). NOTE:Refer to p.7-14 about details.
AT (16)	Analog o		Analog input voltage-current swiching(When this terminal is ON, current input signal to [OI]-[L] is active.)
2CH (09)	2 stage acceleration and deceleration		When the terminal [2CH] is turned on, the acceleration and deceleration can be execut by the 2nd stage acceleration and deceleration time.
FRS (11)	Free run	stop	When the terminal [FRS] is turned on, the inverter stops output and the motor enters the free run state.
EXT (12)	External	trip	When the terminal [EXT] is turned on, the inverter enters the trip state, stops output, and displays E12.
USP (13)	Power rectos- ing restart prevention		When the terminal [USP] is turned on, the restart when the power is turned on with the running command kept on can be prevented.
RS (18)	Reset		When the terminal [RS] is turned on, the trip state can be canceled. During turning on output is stopped. NOTE: The function cannot be used in the N.C. contact state.
SFT (15)	Software	lock	When the terminal [SFT] is turned on, the data of each function is locked.
224	24 V DC Common input		Common terminal for the intelligent input terminals

Termina symbol	Function	Contents				
н	Power supply terminal to command a frequency	• The external voltage signal is 0 to 9.6 V (10 V nominal).				
O O	Frequency command terminal (voltage command)	110				
OI	Frequency command terminal (current command)	NOTE: If there is no setting for [AT] at the input intelligent terminal, the sum of both analog input signals is outputted. When selecting one of analog input current				
L	Frequency command common	or voltage, make sure that the [AT] is allocated to the input intelligent terminal				
FM	Frequency monitor	Analog frequency monitor/Digital frequency monitor/Analog output current monitor				
FA1 (01) FA2 (02)	Frequency arrival signal	When [FA1]/[FA2] is selected as a terminal, at the time of constant speed arrival, two types of methods for outputting a frequency more than an optionally set frequency can be executed. Frequency Frequency Open collector output 27 V DC max 50 mA max On during this period FA1 terminal this period FA2 terminal this period				
RUN (00)	RUN signal	When [RUN] is selected as a terminal, the inverter outputs when the motor is driven.				
OL (03)	Overload signal	This signal is outputted when the motor current is more than the set value.				
OD (04)	at PID control	This signal is outputted when the difference between reference and feed-back is greater than the set value at PID control.				
(05)	Alarm signal	When an alarm occurs, this signal is outputted.				
CM2	Output Signal Common terminal	Common terminal for intelligent output terminal (Output terminals are open collector output and isolated from L common)				
AL0	Alarm terminal	In the normal state: ALO and ALI are closed. In the abnormal state or when power is turned off: ALO and AL2 are closed.				
AL1		Contact rating 250 V AC 2.5 A (resistance load) 0.2 A (cos≠= 0.4) 30 V DC 3.0 A (resistance load) 0.7 A (cos≠= 0.4) [Minimum 100 V AC 10 mA 5 V DC 100 mA]				

"N.O. contact" is set by initialization for terminal 11.12. When "N.C. contact" is to be used. switch the contact setting by [31, [32].

Terminal name: Monitor **terminal** [FM] (Analog, digital)

Function No. to **be** set


C[23], b [81] b [86]

Function contents

Monitor **output** frequency signal or the current of the **inverter** is output from the control circuit terminal.

Monitor output current signal is output as an analog signal only.

(I) Analog Frequency Monitor Signal
The meter outputs duty cycle in proportion to the output frequency with full scale
at the maximum frequency.




NOTE: This is a dedicated indicator, so that it cannot be used as a line speed signal.

Indication accuracy after adjustment: About ±5% (The accuracy of some meters may exceed this value.)

(2) Digital Frequency Monitor Signal
Pulse train of a frquency which is converted the output frequency is output.

(The convert value is setting by b 86.)
The duty is about 50%.



(3) Analog Current Monitor Signal
The duty cycle in **proportion** to the output current with full scale **at 200%** of the rated current of the **inverter**.
Specification of analog meter follows the

analog frequency monitor specifications.

Setting contents

- I. Select Frequency Monitor(Analog/Digital) or Current Monitor by C 23
- 2. When the analog meter is used. adjust the meter so that the needle of the meter indicates the maximum value at the time of maximum frequency by **b** [81] (analog meter adjustment).
- 3. In the case of digital **frequency** monitor, it is able to convert the scale by **b** 86

NOTE: The converted value of digital frequency monitor is limited IO about 3.6 kHz.


Accuracy of output current monitor

ccuracy: $\pm 20\%$

(A half base frequency or higher) he indication value may exceed this accuracy by **ie** load current condition.

se the moving tron type ammeter for the precise n-rent measurement.

Circuit for FM signal monitor for process control (just only for monitor)



7.3 Function Contents of Intelligent Input Terminals


Terminal name: Forward running/stop	
terminal [FW]	Function No. C 01 to C 05
terminai [F w]	to be set A 02
Function content	<u> </u>
. When the running command is inputted via the terminal [FW], the terminal executes the forward running command or stop command.	When the power is turned on when the running command is on, the motor starts rotation and it is dangerous. Before turning the power on, confirm that the running command is not on.
Terminal setting method Digital operator Set the set value 00 in one of the input terminals C 01 to C 05.	Precautions When the running command is inputted via the forward running terminal [FW] and reverse running terminal [RV] at the same time, the running command enters a state which is the same as stop. Note that when the [FW] terminal is set to N.C. contact, the running automatically starts. Set the value 01 to the A 02, then this terminal is available.
Terminal name: Reverse running/stop terminal [RV]	Function No. C 01 to C 05 to be set A 02
Function content	↑ WARNING
	· · · · · · · · · · · · · · · · · · · ·
When the running command is inputted via the terminal [RV] , the terminal executes the reverse running command or stop command.	When the power is turned on when rhe running command is on, the motor starts rotation and it is dangerous. Before turning the power on, confirm that the running command is not on.
via the terminal [RV], the terminal executes the reverse running command or	When the power is turned on when rhe running command is on, the motor starts rotation and it is dangerous. Before turning the power on, confirm that the

Function No. C 01 to C 05, F 01 Terminal name: Multistage speed A 20 to A 35 [CF1], [CF2], [CF3], [CF4] to be set Function] Example of the input terminal connection When [CF1], [CF2], [CF3], and [CF4] are CF4 CF3 CF2 CF1 selected as intelligent input terminals, Multispeed I to Multispeed 15 can be set. SW4 SW3 SW2 SW1 When the frequency command from the normal operator (or terminal) is combined with them, up to 16 stages of running are available. Setting of multispeed . When the control terminal is set at each speed by the switch, the numerical value Multispeed Control circuit terminal SW4 | SW3 | displayed at **d 01** indicates the output SW2 frequency at the time of each multispeed. Multispeed 0 OFF OFF OFF OFF Multispeed 1 OFF OFF OFF ON Set the speed as shown below. Multispeed 2 OFF OFF ON OFF (I) Turn the running command off. Multispeed 3 OFF OFF ON ON (2) Turn each switch on and set it to Multispeed 4 OFF ON OFF **OFF** Multispeed n. Display the data section of Multispeed 5 OFF ON OFF ON F 01. Multispeed 6 ON ON OFF OFF Multispeed 7 OFF ON ON (3) Set an optional output frequency by ON Multispeed 8 ON OFF OFF **OFF** pressing the (A) and (V) keys. Multispeed 9 ON OFF OFF ON Multispeed 10 ON OFF ON OFF (4) Press the (m) key once so as to store the Multispeed 11 ON OFF ON ON Multispeed 12 ON ON OFF OFF set frequency. If this occurs. F 01 indi-Multispeed 13 ON ON OFF ON cates the output frequency of Multispeed n. Multispeed 14 ON ON ON OFF (5) Press the key once. (Confirm that the Multispeed 15 ON ON ON ON indication is the same as the set frequency.) (6) When the operations in (I) to (4) are . Multispeed 0 is set by the frequency repeated. the frequency of Multispeed n can command of A 01 selection. be set. It can be set also by one of A 20 to A 35 **Precautions** Terminal setting method After any data is changed, be sure to press -Digital operator the (str) key every time and then set the next one. Note that when the (str) key is Set the set values 22 to 05 not pressed, no data will be set.

When a frequency more than 50Hz(60Hz) is to be set, it is necessary to switch the maxi-

mum frequency A 04 .

in the input terminals C 01 to C 05.



Terminal name: Analog input command [AT]

Function No. [C 01 lo C 05]
IO be set [A 01]

Terminal setting method

Digital operator

Function content

. When the terminal [AT] is turned on, it is possible to set the output frequency by current input signal (DC4~20mA) at [OI]-{L].

I Precautions

If there is no setting for [AT] at the input intelligent terminal, the sum of both analog input value is outputted.

Set the set value 1.16 in one of the

input terminals C 01 to C 05


When selecting one of analog input value (current or voltage), make sure that the [AT] is allocated to the input intelligent terminal.

Be sure to set the value 01 to A 01.

Function switching method

While the switch between the terminals [AT] and [P24] is on. it is possible to set the output frequency by the current input signal at [OI]-[L].

When **the** terminal is turned off. the voltage input signal at [O]-[L] is available.



Terminal name: Second stage acceleration and deceleration [2CH]


Function content

. When the terminal [2CH] is turned on, the equipment can be accelerated or decelerated (acceleration time 2. deceleration time 2) by the 2 stage acceleration and deceleration time.

Function switching method

While the switch between the set terminals [2CH] and [P24] is on, the equipment operates by the 2 stage acceleration and deceleration time (acceleration time 2. deceleration time 2).

When the **terminal** is turned off, the equipment is returned to the original acceleration and deceleration time (acceleration time **1**, deceleration time **1**).



When [2CH] is allocated to the terminal 3

Terminal setting method

Digital operator –

Set the set value $\boxed{09}$ in one of the input terminals $\boxed{C \mid 01}$ to $\boxed{C \mid 05}$.

2 stage acceleration and deceleration time setting method

Use A 92 (acceleration time 2) and A 93 (deceleration time 2) to set the 2 stage acceleration and deceleration time (acceleration rim 2. deceleration time 2).

Between terminals [2CH] and [P24]	Acceleration and deceleration time for operation
OFF state	Acceleration time 1, Deceleration time 1
ONstate	Acceleration time 2, Deceleration time 2

Precautions



Setting A 94 to 00 enable to switch by this terminal.


Terminal name: Free run stop [FRS]

Function content

. When **the** terminal **[FRS]** is turned on, the **inverter** stops output and the **motor** enters **the** free run stare.

Function switching method

. While the switch between the set terminals [FRS] and [P24] is on. the equipment operates the FRS operation.



When [FRS] is allocated IO the terminal 3

NOTE: When b contact is to be used.
switch the contact setting by

[C 11] to [C 15]


The contact setting cannot be switched only by selecting FRS by switching [C 01] to [C 05].

Terminal setting method


Digital operator

Set the ser value 11 in one of the input terminals C 01 to C 05

When b 88 is set 00,0 frequency start after resetting [FRS].



When b 88 is set 01, restart from the frequency, which is picked up from the free running motor



C 01 to C 05 Function No. Terminal name: External trip [EXT] to be set Function content Function switching method . When the terminal [EXT] is turned on. the When the switch between the set terminals inverter enters the trip state by an indica-[EXT] and [P24] is turned on. the equipment tion of E 12 and stops output. enters the trip state. Even when the switch is turned off, the trip Terminal setting method state will not be canceled. Reset the equipmer or turn the power off and on again to cancel - Digital operator the trip state. EXT FW Set the set value 12 in one of the L 5 3 P24 input terminals [C 01] to [C 05]. When [EXT] is allocated to the terminal 3 Running command [FW, RV] [EXT] terminal Free run Motor revolution speed [RS] terminal Alarm output terminal

Terminal name: Prevention function of restart upon power on [USP]

Function No. to be set

C 01 to C 05

Function content

- . If the running command is set when power is turned on, the inverter starts running immediately after it is activated. The USP function prevents it so that the inverter will not execute sudden running.
- . To reset an alarm and restart running. rum the running command off or perform a reset operation by the terminal [RS] or the @ k e y .

Refer to the lime chart indicated below.

Function switching method

While the switch between **the** set terminals [USP] and [P24] is on, the equipment execute the USP operation. If the power is turned on when the running command is inputted, the equipment enters the USP trip state ($\boxed{E \mid 13}$)



When (USP] is allocated to the terminal 3


Precautions

Note that when a USP error occurs and it is canceled by resetting in the state that rhe running command from rhe terminal is inputted, the inverter restarts running immediately.

Terminal	setting	method
----------	---------	--------

Digitalopcraror _

Set the value $\boxed{13}$ in one of the input terminals \boxed{C} $\boxed{01}$ to \boxed{C} $\boxed{05}$



Terminal name: Reset [RS]

Function No. to be set

Q 01 to C 05

Function content

. The trip content can be canceled


Terminal setting method

Digital operator

Set the set value $\boxed{18}$ in one of the input terminals \boxed{C} 01 to \boxed{C} 05.

Function switchine method

. When the switch between the set terminals [RS] and [P24] is turned on and off, the equipment executes the reset operation.




⚠ WARNING

After the operation command is given. if the alarm reset is conducted. it will restart suddenly. Be sure to set the alarm reset after checking that the operation command is off.

Otherwise. there is a danger of injury.

Precautions

- When the [RS] terminal is turned off from' on. it becomes valid.
- . The (STOP) key of the digital operator is valid only when an alarm occurs.
- Only' N.O. contact' can be set to the {RS} terminal. The terminal cannot be used in the' N.C. contact 'state.
- Even when the power is turned off or on.
 the function of the terminal is the same as
 that of the reset terminal.



- . The key on the inverter is available for a few second after reset signal coming with the remote operator connected.
- . When the [RS] is turned on while the motor is running ,the motor will be free running.

Terminal name: Jogging [JG]


Function No. CDI to COS to be set A 02, A 38, A 39

Function content

• When the terminal [JG] is turned on and the run command is issued, the inverter perform the jogging operation.

Function switching method

- While the switch between the set terminals [JG] and [P24] is on. the equipment operates the JG operation.
 - The frequency at jogging operation is set by A 38.
- . Set the value 101 (terminal mode) in the A 02 (Run command)
- . Since jogging is a direct input operation, set the jogging frequency A 38 to 5 Hz or less to prevent tripping,



When [JG] is allocated to the terminal 3

Terminal setting method

Set the set value 06 in one of the input terminals C 01 to C 05.

(JG) terminal		
run command [FW,RV] —		Tarregal Ca
Motor revolution speed	A section of	

According to the setting of A 39.

00 : Free run stop
01 : Deceleration and stop
02 : DC braking and stop

NOTE: No jogging operation is performed when the set value of jogging frequency A 38 is smaller than rhe start frequence b 82, or the value is 0 Hz.

Precautions

. Be sure IO stop the motor when switching this function[JG] for certain operation.

	Terminal name: PTC [PTC]	Function No. C 05
•	When the registance value of the thermistor connected with this terminal is more than 3 k ohm ± 10%, the equipment operates the trip operation (Cut off the output and indicates the trip status [E 351). Use this function to protect the motor driven by this equipment. (Thermal protection)	Terminal setting method Digital operator Set the set value 19 in the input terminal 0.05 NOTE: This function is assigned to the input terminal 5 only. If this function is assigned without connection the thermistor, the equipment operates the trip operation. Be sure the thermistor is connected with the terminal 5, and then restart

Terminal name: Terminal software lock [SFT]

Function No. to be set

C 01 to C 05

Function content

. When the terminal [SFT] is turned on, the data of all the functions except the output frequency is locked. When the data is locked, no data can be changed.


Terminal setting method

Digital operator

Set the set value 15 in one of the input terminals 0 10 to 0 5.

Function switching method

When the switch between the set terminals [SFT] and [P24] is turned on, the equipment enters the software lock state.



When [SFT] is allocated to the terminal 3

Precautions I


- When the [SFT] terminal is turned on, only the output frequency can be changed.
- . Software lock can be made possible also for the output frequency by b 31
 Software lock by the operator is also possible without the [SFT] terminal being used.

 (b 31)

7.4 Function Contents of Intelligent Output Terminals (Initial setting is "N.O. contact" state)

Terminal name: Frequency arrival signal [FA1]/[FA2] Function No. to be set Function content Terminal setting method When [FA1]/[FA2] is selected as an intelligent output terminal at the time of

When [FA1]/[FA2] is selected as an intelligent output terminal, at the time of constant speed arrival, two types of methods for outputting a frequency more than an optionally set frequency can be executed. Select the output method by C 21, C 22. Set an optionally set frequency by C 42 (setting at the time of acceleration) or C 43 (setting at the time of deceleration).



12

11


CM₂

50 mA max DC 27 V max Set the set value $\boxed{01}/\boxed{02}$ in the output terminal $\boxed{C21}/\boxed{C22}$.

Precautions

- At the time of acceleration, an output signal at a frequency between the set frequency 0.5 Hz to + I.5 Hz is turned on.
- At the time of deceleration, an output sign; at a frequency between the set frequency + 0.5 Hz to -1.5 Hz is turned on.

NOTE: The delay time of the output signal is 60 ms generally.



Terminal name: Run signal [RUN]


Function No. 10 **bc** set

C 21 . C 22

Function content

. When [RUN] is selected as an intelligent output terminal. the **inverter** outputs a RUN signal when the motor is driven.

Connection example of output terminal.




Terminal setting method

- Digital operator

Set the set value $\boxed{00}$ in the output terminal $\boxed{C 21}$, $\boxed{C 22}$.

Precautions

. RUN signal is outputted simultaneously when a frequency is outputted.



Terminal name: Overload advance notice signal [OL]

Function No. to be set

Terminal setting method

C	21, C	22
C	41	


Function content

. When an output current more than the set current flows. the terminal outputs a signal.

Digital operator

Set the set value $\boxed{03}$ in the output terminal \boxed{C} $\boxed{21}$ \boxed{C} $\boxed{22}$.


Connection example of output terminal



Precautions

A value of 100% is set by initialization. To change the level, change C 41 (overload level).

The accuracy of this level is same as the function of the output current monitor. (See 7-3)



Terminal name: Deviation signal al PID control [OD]


Function No. to be set

C 21, C 22 C 44

Function content

 This signal is outputted when the difference between reference and feedback is greater than the set value at PID conuol.

Connection example of output terminal




Terminal setting method

- Digital operator -

Set the set value $\boxed{04}$ in the output terminal $\boxed{C 21}$ $\boxed{C 22}$.

Precautions,

The difference value is set 3% by initialization. To change this value. change C 44 (deviation level).



Terminal name: Alarm terminal [AL]

Function No. to be set

C 21, C 22


Function content

. When an alarm occurs, the function outputs an alarm signal from the output terminal which is assigned to the intelligent output termnal(Open collector output).

Terminal setting method

Digital operator -

• Set the value 05 in the output terminal 0 21/ 0 22.



Precautions

- . When the alarm output is set to N.C.. a tim delay occurs until the contact is closed when the power is turned on. Therefore. when the alarm contact output is to be usec set a delay of about 2 seconds when the power is turned on.
- This terminal is an open collector output. so the electric specification of [AL] is different from the contact output terminal [AL1],[AL2]-[AL0].
- The sequence of this terminal is same as [AL0]-[AL1].
- . See the description of [AL1],[AL2]-[AL0].

When the power supply is turned off. the alarm signal output is valid while the power of control circuit is live.

NOTE: This signal output has the delay time (generally 300ms) from the fault alam output.

7.5 Function Contents of Alarm Terminals

Terminal name: Alarm terminal [AL1, AL2-AL0]

Function No. [C]33 to be set

Function content

. When an alarm occurs, the function outputs an alarm signal from the terminal: [AU)]. [AL1], and [AL2] via the c contact. If this occurs, the operator displays the alarm content.

Terminal setting method

Digital operator -

'N.O. contact' or 'N.C. contact' can be selected by [C 133] The initialization is 'N.C. contact'.

Precautions

Holding of an alarm signal

When an alarm signal is **outputted**, the alarm content will be stored even if the input power is turned off. Therefore. by turning the power on again, the content **ca** be **confirmed**. However, when the input power is turned off, the alarm output will reset (canceled) when the power is turned on again. Therefore. to hold the alarm output. hold the alarm once by the extema sequence.

When the alarm contact output is set to N.C., a time delay occurs until the contact is closed when the power is turned on. Therefore, when the alarm contact output to be used. set a delay of about 2 seconds when the power is turned on.


Contact specification

Maximum	Minimum
AC 250V, 2.5A (load R) $0.2A$ (cos $0 = 0.4$)	AC 100 V. 10 mA
DC 30 Vm. 3.0A (load R) $0.7A$ (cos $0 = 0.4$)	DC 5 V, 100 mA
De 60 viii. 5.071 (1044 71) 0.771 (205 0 -0.4)	DC 3 1, 100 HB1


The alarm output terminals are connected as shown in Fig. (a) at the time of initialization. The can be changed as shown in Fig. (b) by setting C 33.

	(a)N.C. contact (at the	time of initialization)	(b)N.O.contact	
	During normal running	When an alarm occurs a power is turned off	During normal running or when power is turned off	
	ALO ALI AL2	ALO ALI ALZ	ALO ALI ALZ	
	Contact Power Running #1	RE ALO-AL1 ALO-AL2	Contact Power Running state ALO-AL1 ALO-AL2	_
Ш	N.C. ON Normal	Closed Open	N.O. ON Normal Open Closed	
Н	(Initialized ON Trip	Open Closed	ON THE Closed Open	
Ш	Value) OFF _	Open Closed	OFF — Open Closed	

8. OPERATION OF THE DIGITAL OPERATOR



8.2 Operation Procedure (Example for the digital operator.)




8.3 Key Description


FUNC

[Function key] This key allows the chang from parameter area to daw area and extended function entrance alternately.

When each time the key is pressed, the display changes as follows.



[Up key. Down key]. These keys change rhe values of data, and parameters.



(FUP)

[RUN key]. . This key SW the run.

The set value of F $\overline{U}Y$ determines forward run or reverse run.




[STOP/RESET key] This key stops the run.

When a trip occurs, this key becomes the reset key.

Data setting for extended function

When an extended function is to be used, select the extended function group from hand a select the extended function group

by using the keys and so as to enter the extended function mode.



' Explanation of display at power on

When the inverter is turned on, the display which is displayed when the power is turned off before it is turned on appears. (Except the extended function mode.)

Initialization List of Digital Operator a.4

Diaplay order	Function name	Туре	Paramete r display	Settable during running	Range of set value	Initializ ation
1	Output frequency monitor	Monitor- ing		-	Display from 0.5Hz to 360.0Hz. Light on "Hz" LEI	
2 	Output current monitor	Monitor- ing	d02	-	Display from 0.01 to 999.9A Light on "A" LED.	
3	Running direction monitor	Monitor- ing	d03		" F " "	
4	Feedback data of PID control monitor	Monitor- ing	d04	~	Display the converted feed back value scaled by "A75".	
5	Condition of input intelligent terminal monitor	Monitor-	d05	7	Display the condition of inpi intelligent terminal,	
6	Condition of output intelligent terminal monitor	Monitor- ing	406		Display the condition of output intelligent terminal and alarm. OFF	
7	Output frequency converted value monitor	Monitor- ing	d07	(Display the output frequency converted value scaled by "586" Display =(output frequency) ("586" value) (1)0.01 to 99.99 1 1 1 1	

Accuracy of output current monitor

Accuracy: ± 20%

(A half base frequency or higher)

The indication value may exceed this accuracy by the load current condition.

Use the moving tron type ammeter for the precise current measurement.

8	Trip monitor	Monitor- ing	d08	Display latest trip contents -Display order and operation Alarm cause press FUNC key Output frequency at trip press FUNC key Motor current at trip press FUNC key DC voltage at trip press FUNC key "d08" display -There is no latest trip
9	Trip history monitor	Monitor- ing	d09	Display last 2times trip except latest trip. Displays only alarm cause "d09" display press FUNC key Cause of the last trip press FUNC key Cause of the last trip but one press NNC key "d09" display If there is no trip,display

Ŷ

(1-2)Basic function mode

This mode can be set the basic function.

liaplay	Function name		Paramete			
der		Type		during	Range of set value	Initiali
			display	running	and contents	ation
1	Output frequency	Set	F01	possible	0.5-360.0Hz / Resolution ± 0.1Hz	0.0Hz
	setting	value			(1)Digital Operator on the front case	1
					In this function the output frequency can be set in	
			•	ŀ	the inverter by using the key pad. But it is	
			l		necessary to set the frequency distination to the	
				ŀ	digital operator("A01"=02).	
	1				(2) Multispeed	
	1				The output frequency in the multispeed mode can	
				i	be set as specified following;	1
			1		Connect the multispeed terminal for setting the	
]		frequency, that is to say, to set the frequency of each	
		1			multispeed must be made the relation between	
		1			multipeed 1 to 15 on the terminal.	
					(3)Remote operator, Terminal, Potentiometer	
	1				In setting the frequency from the remote operator	
	ļ	1	1		(DOP), the terminal (O-L,OI-L) or the potentiometer	
	il	1			on the front case, data of this function is just	i
2	Acceleration 1	Set	F02		monitored the frequency from each device.	<u> </u>
4	Acceleration 1	value	FUZ	possible	0.1 second to 3000 seconds	10
		Value	! ,	1	[Resolution of setting]	seconds
		1 :			0.1 - 999.90.1 second 1000 - 30001 second	
3	Deceleration 1	Set	F03	. 11	0.1 second to 3000 seconds	
J	Decereration 1	value	rus	possible	Resolution of setting	10
		Palue	i		0.1 - 999 90.1 second	seconds
		11 1			1000 - 30001 second	
4	Running direction	Set	F04	Not	Set the motor direction	00
•	setting	value	104		Set the motor direction when running by pressing	00
		1		hogginie		
					(RUN) key.	
		1 1				
		11 1			00forward run	
		<u></u>			01reverse run	
5	Extended function	Set	A		Extended function of A group can be entered from	
į	of A group setting	value			"A" function.A group regards control setting or	
		1 1		L <u></u>	function setting.	
	Extended function	Set	B		Extended function of B group can be entered from	
	of b group setting	value]		"b" function. B group regards protection setting or	
		1	<u> </u>		others.	
	Extended function	Set	C		Extended function of C group can be entered from	
	of C group setting	value			"C" function.C group regards intelligent terminal	
		11 1	į	1 1	setting.	

(2)Extended function mode A group

₫,

Display order	Function name	Туре	Parameter display	Settable during running		Initializ ation (-FE/-FU)
	ameter setting					
1	Frequency distination setting (Multi speed 0 setting)	Set value	A01	Not possible	Method to command output frequency is selected by this function. 00 Potentiometer on the front case 01 Control terminal on the logic board (0,0I input) 02 Digital operator (PD) setting)	01
2	Running command distination setting	Set value	A02	Not possible	Method to command running is selected by this function. 01 Control terminal on the logic board 02 Digital operator	01
3	Base frequency setting	Set value	A 03	Not possible	50 to maximum frequency / Setting resolution 1Hz 100% Base Maximum frequency frequency	50/60Hz
4	Maximum frequency setting	Set value	A04	Not possible	base frequency to 360Hz / Setting resolution 1Hz (NOTE 1)	50/60Hz
	input setting	6.	T 4.11		0. 90011.10	
5	External frequency setting start	Set value	A11	Not possible	0 to 360Hz /Setting resolution 0.1Hz This function set the start frequency when the inverter receives 0V or 4mA analog input Presservy	0Hz
					A12 A13 A14 10V 20mA Analog input	
6	External frequency setting End	Set value	A12	eldiaaoq	0 to 360Hz /Setting resolution 0.1Hz This function set the end frequency when the inverter receives 10V or 20mA analog input.	0Hz
7	External frequency setting start rate	Set value	A13	Not possible	0 to 100% /Setting resolution 1% This function set the rate of starting point of analog input for full scale(10V or 20mA). In other words, the bias of analog input can be set.	0%
8	External frequency setting end rate	Set value	A14	Not possible	0 to 100% /Setting resolution 1% This function set the rate of endding point of analog input for full scale(10V or 20mA). In other words, the bias of analog input can be set.	100%
9	External frequency start pattern setting	Set value	A15	Not possible	This function should set the starting pattern if the start irrequecy and starting rate of analog input are set some value as following: All Als of Invalid In	01
	Time constant of he filter of analog input setting	Set value	A16	Not possible	11 OHz start to 8 This value is average time of calculating filter.For example, 8 is Stimes average for analog input	a
ıltispeed	frequency setting			19	Addies a ver age for analog input.	
11	Multispeed requency setting	Set value	A20-A35]1	1.5 to 360.0Hz/setting resolution 0.1Hz These parameter are set frequency of multistage speed. Standard(0th) speed can be set A20 parameter, and they can	All parameter are 0Hz

isplay	Function name	Туре	Parameter	Settable	Range of set value	Initializa
der			display	during		ation
12	Jogging trequency	Set	A38	running		
	setting	value	A36	possible	0.5 to 9.99Hz / setting resolution 0.01Hz The jogging frequency is inching operation by external signal from terminal.	1.0Hz
13	Stop mode of jogging	Set value	A39	Not possible	00 Freerun stop after stop signal 01 Deceleration stop after stop signal 02 De braking after stop signal	00
/F char	cteristic					
14	Selection of method of torque boost	Set value	A41	Not possible	100 Manual torque boost 101 Automatic torque boost	00
15	Value of manual torque boost setting	Set value	A42	possible	Set voltage of manual torque boost Motor torque can be adjusted to increase the output voltage when the starting torque is not sufficient in V/F control. Pay attention not to cause the motor to burnout and an inverter trip. 100% Ad2=11 > 11.8%	11
16	Manual torque	Set	A 12		6.0Hz 30.0Hz f base = 60.0Hz	
	boost frequency adjustment	value	A43		Set the point A in the above torque boost graph within the range of 0% to 50% of the base frequency.	10.0%
17	V/F characteristic setting	Set value	A44	Not possible	Set V/F characteristic 00 ··· Constant torque characteristic 01 ··· Reduced torque characteristic 01 ··· Reduced torque characteristic 0 ··· Reduced torque characteristic 0 ··· Reduced Torque Torque (requency)	00
18	V-Gain setting	Set value	A45	possible	Set the voltage gain of V/F characteristic 100% 50%	100
braki	g setting		<u> </u>	1		
19	Selection of DC braking operation	Set value	A51	Not possible	Selected which DC braking is avilable or not. 00 not available	00
20	DC braking frequency setting	Set value	A52	Not	01 ··· available 0.5 to 10.0 Hz / setting resolution 0.1Hz The frequency at which the DC braking is set.	0.5
21	DC braking waiting time setting	Set value	A53	Not possible	0.1 to 5.0 seconds / setting resolution 0.1 second This time is interval from end of running to start of DC braking.At this interval the motor is free running. DC braking	0.0
					Running A53 A55	
22	DC braking force setting	Set value	A54	possible	0 to 100% / setting resolution 1% Set the force of DC braking	0
23	DC braking time setting	Set value	A55		0.1 to 60 seconds / setting revolution 0.1 second Set time during DC braking operates.	0.0
	n relation to frequ					
24	Frequency upper limiter setting	Set value	A61	possible	0.5 to 360.0 Hz/setting resolution 0.1Hz Set the limits of frequency setting within the maximum frequency. If 0.0Hz is set, upper limiter is not available. output (requency AG1 upper hmiter AG2 lower AG2 lower AG3 lower AG3 lower AG3 lower AG3 lower AG3 lower AG4 lower AG5 lower A	0.0Hz
25	Frequency lower	Set	A62). 	Traducticy committee	0.011
	limiter setting	value :	A04	possible	0.6 to 360.0 Hz / setting resolution 0.1Hz Set the limits of frequency setting within upper limiter frequency. If 0.0Hz is set, lower limiter is not available.	0.0Hz
26	Jump frequency setting	Set value	A63,A65, A67	Not possible	0.0 to 360.0 Hz /setting resolution 0.1Hz.0.0 Hz is not available. To avoid a resonance with load, the frequencies at up to 3 points can be jumped. The frequency equivalent to the jump	0.0 Hz
27	Jump frequency width setting	Set value	A64,A66, A68	Not possible	frequeny setting cannot be set. 0.0 to 10.0 Hz /setting resolution 0.1Hz The frequency width where frequencies are jumped is set.	0.5Hz


Display	Function name		Parameter	Settable		1
order	[Туре	display	during	Range of set value	Initializ-
PiDec	nItol	 	<u> </u>	running	and contents	(FF/FU
28	Selection of	Set	A71	Not	This parameter release which BID and all all and all all and all and all all and all all and all all and all all and all all all all all all all all all al	
_~	PID control	value	^''		This parameter selects which PID control operates or not. 00 PID control is not available	0 0
]		01 PID control is available	
29	P(proportion)	Set	A72	possible	0.2 to 5.0 times /setting resolution 0.1 time	1.0
	gain	value	}	ľ	This function is used to set proportional gain of PID control	1.0
- -	netting		<u> </u>		operation.	
30	l(Integral)	Set	A73	possible	0.0 to 150.0 seconds /setting resolution 0.1 second	1.0
ľ	gain setting	value			This function is used to set integral gain of PID control	
31	D(Differential)	Set	A74	Possible	operation 0.0 to 100.0 seconds /setting resolution 0.1 second	<u> </u>
	gain	value		Possible	This function is used to set differential gain of PID control	0.0
	setting	_	li .		operation.	i
32	Scale conversion	Set	A75	Not	0.01 to 99.99 / setting resolution 0.01	1.0
	of PID control	value	Į.	possible	This function is used to convert target value which feedback is	l ""
	setting				fit.	
33	feedback destination	Set	A76	Not	Set the destination which feedback come from.	000
	setting	value		possible	00 Ol terminal(current input)	
		1			01 O terminal(voltage input)	
,						
		1	ŀ			
		4	i		(NOTE 2 : PID feedback diagram)	
		1				
		1				
		1]	
AVR func	tion		<u> </u>	<u> </u>		
34	Selection of	Set	A81	Not	Select the operation of AVR function	02
	AVR function	value		possible	00 AVR function is available at all range of operation	UZ
		Í			01 AVR function is not available at all range of operation	
					02 AVR function is not available at deceleration	
		İ			AVR function is that the output voltage from the inverter	
35	Selection of	Set	A82	Not	keeps constant even if input power varies. 200/220/230/240/ for 200V class inverter	
	voltage of AVR	value	702	Dossible	380/400/415/440/460 for 400V class inverter	230/230
ļ	function for the			7	This function is used to select the output voltage which is given	400/460
	motor		j		the motor. However the inverter cannot output the voltage over	
					input power source.	
36 (seleration(acc) an					
×	acceleration	Set Value	A92	possible)	0.1 to 999.9seconds / setting resolution 0.1 second	15.0
ĺ	time	ABIRE			1000 to 3000 seconds /setting resolution 1 second	
	setting	ĺ]	Acceleration 2 is worked by 2CH terminal input or setting changed frequency.	
37	Second	Set	A93	possible	0.1 to 999.9seconds / setting resolution 0.1 second	15.0
	deceleration	value			1000 to 3000 seconds /setting resolution 1 second	15.0
-	time	ļ		ì	Deceleration 2 is worked by 2CH terminal input or setting	1
38	Setting				changed frequency.	
36	Selection of method to use	Set value	A94	Not	00 ··· 2CH input from terminal	00
	second	Amine		possible	01 changed frequency from acc/dec1 to acc/dec 2	Į
l,	acceleration /				frequency Acc1 acc2	
į,	deceleration	ŧ	1	į.		ļ
1	(acc2/dec2)			ı	A95	1
		l				
	i			ł	time	1
	}	1			2CH or A95	
39	Changed	Set	40/			
	frequency from	value	A95	Not (0.0 to 360.0Hz / setting frequency 0.1Hz	0.0
	accl to acc2	-=145	i '	ossible /	When output frequency reaches this frequency acceleration	}
	eetting				ime changes from acc1 to acc2. NOTE 3)	
40	Changed	Set	A96		0.0 to 360.0Hz/setting frequency 0.1Hz	0.0
Į į	requency from	value		osuible N	When output frequency reaches this frequency acceleration	0.0
[]	dec1 to dec2	()		Į.	ime changes from dec2 to dec1.	•
	setting	[]	l [NOTE 3)	1

Display order	Function name	Туре	Parameter display	Settable during running	Range of set value and contents	Initializ- ation
41	Pattern of acceleration setting	Set value	A97	possible	Set the pattern of acceleration 1 and acceleration 2 00 linear 01 S-curve setting frequency linear S-curve time	00
42	Pattern of deceleration setting	Set value	A98		Set the pattern of acceleration 1 and deceleration 2 00 ··· linear 01 ··· S-curve	00

NOTE 1: To keep the motor stability, the output frequency exceeds the maximum frequency set by [A04]. (Max.1.5Hz)

Adjust the output frequency setting.

NOTE 2 : PID feedback diagram



NOTE 3: When the acceleration or the deceleration time is set small value (less than 1.0 s), the actual changed frequency delays to the set value.

(3) Extended function mode of B group

Display	Function name		Parameter			T
order		Туре	display	during running	Range of set value	Initializ.
Restart n	node	L	·	runmng	and contents	etion
1	Selection of	Set	b01	Not	Select the inverter retry method.	1
•	restart mode	value	507	possible		00
			1		01 OHz start at the time of restart	ļ
				1	02 Frequency matching start at the time of restart	i
				ĺ	03 Frequency matching at the time of restart and then	ļ
	(NOTE I)		}	ነ	deceleration stop and display Trip information.	1
					Trips of restart are overcurrent trip, overvoltage trip and	l
	1		1	ı	undervoltage trip. The number of restart is 3 times at overcurrent	ļ
			<u></u>	Į	trip and overvoltage trip, and 16 times at undervoltage trip.	i
2	Allowable	Set	b02	Not	0.3 to 25 seconds / setting resolution 0.1 second	1.0
	undervoltage	value	,	possible	When an undervoltage power failure occurs, the allowable time until	}
	power failure				the power failure is recover is set.	
	time actting		1	1	If the time of the undervoltage power failure is over this parameter,	
			<u> </u>	!	the inverter trips even if the restart mode is selected.	
3	Retry waiting	Set	ъ03	Not	0.3 to 100 seconds /setting resolution 0.1 second	1.0
	time setting	value	ĺ	possible	The restart waiting time after an undervoltage power failure is	•
					recovered is set.	
				!	powerfailure	
]	}		
			1		motor	
			1		speed b 02 ★ b 03	
Electronic			<u>. </u>			L
		C.4	Lio	N		- D-4-1
5	Level of	Set	b12	Not	Set a level of electronic thermal which is range between 50% to 120%	Rated current fo
	electronic thermal setting	value		boserpre	for the rated current of the inverter. It can be set by ampere.	each
!	therman setting		ĺ		Range of setting 0.5 * (Rated current of the inverter)	inverter
1	l l		,		to 1.2 * (Rated current of the inverter)	(NOTE 2)
6	Selection of	Set	b13	Not	setting resolution 0.01A Select the characteristic of electronic thermal whether CRT(constant	
	electronic	value	0.53	noeribie.	torque characteristic or SUB(reduced torque characteristic)	01
	thermal	*8.01	ł	possible	The thermal characteristic accords with the load to be used because	
	characteristic		l		kt	
					DO SUB Constant torque(CRT)	
			il i		DI CRT	
			ll l	i	Output current 60 Reduced torque(SUB)	
	l		[]	-		
			[]		0 Li	
					5 Output frequency(Hz)	
Overload	restriction					
7	Selection of	Set	b21	Not	This function is used to select the mode to operate overload	01
	overload	value			restriction.	1
	restriction				00 Not available .	
	operation mode			1	01 Available at acceleration and constant speed	
	· \			1	02 ··· Available at constant speed	
			<u> </u>		At deceleration overload restriction function is not available always	<u> </u>
8	Level of	Set	b22	Not	Set a level of overload restriction which is range between 50% to	Rated
	overload	value		possible	50% for the rated current of the inverter. It can be set by ampere.	current
	restriction				Range of setting 0.5 * (Rated current of the inverter)	*1.25 for
[setting] [to 1.5 * (Rated current of the inverter)	each
]	setting valueCurrent (A)	inverter
	<u></u>				setting resolution 1% of the rated current	(NOTE 2)
9 [Rate of	Set	b23	Not	Set the deceleration rate at operation of overload restriction function	1.0
	deceleration at	value		possible	0.1 to 30.0 / setting resolution 0.1.	
l i	overload				Marca b22	
Ì	restriction				M0001	
		l i			current	
],						
]					Output	
]	•	l i			frequency b23	
	1				<u> </u>	

NOTE 1: In case the restart mode [b 01] is set [00], if inverter is reset by long power failure with the run command setting, inverter restarts immediately after power coming. See the other warning at p.1-3.

NOTE 2: The initialize data of 005N , 011N , 030H are set the value which same as 007N , 015N , 040H . So be sure to set the value again for each motor driven by the inverter.

Display	Function name		Paramete			Initializ-
order	1	Туре	τ	during	Range of set value	ation
0.1	1.	<u> </u>	display	running	and contents	(-FE/-FU)
Other pr			1			
10	Selection of	Set	b31	Not	Software lock is the function that cannot be changed any parameter	01
İ	software lock mode	value		possible	except this function. This function is set by the set-maker in order to avoid that end-user change the parameter and missoperation of	ŀ
	mode			ŀ	the system.	!
					00 It is impossible to change all parameter except this function	
	1				when SFT from terminal is on.	1
		i			01 It is impossible to change all parameter except this function	•
					and frequency setting function when SFT from terminal is on.	1
			1		02 It is impossible to change all parameter except this function	ŀ
					as soon as 02 is set.	
				ł	03 It is impossible to change all parameter except this function	
			_	ļ	and frequency setting function as soon as 03 is set.	
11	Reactive	Set	ь32	Not	Setting resolution: 1% Amps of inverter rated current.	Rated
	Current setting	value		possible	Set the no load current of motor at the down sized motor, multiple	Current
	(NOTE 3)		1	i	motor or 230V / 460V motor driving.	*0.58
ł				ı		for each inverter
Others	ł			L		mverter
13	Analog meter	Set	b81	noseible	This function is used to adjust the analog meter connected to the	80
	adjustment	value	551	Possinic	frequency monitor(FM).	30
ļ.	24,200	10.00			0 to 255 / setting resolution 1	
14	Start frequency	Set	b82	Not	0.5 to 9.9 Hz / setting resolution 0.1Hz	0.5
	adjustment	value		possible		
15	Carrier	Set	b83	Not	0.5 to 16.0 kHz / setting resolution 0.1kHz	5
	frequency	value		possible	Set the carrier frequency for PWM waveform output of the inverter.	
	setting				When the carrier frequency over 12kHz is set, the rated current of	
	(NOTE 1)				the inverter has to be reduced.	
16	Selection	Set	b84	Not	Select whether it is data initialization or trip history clear.	00
	data	value		possible	00 Trip history clear	
	initialization				01 Data initialization	
	or	ľ			The method of this function is that ;	
	clear of trip				1)set the this function 00 or 01,	
	history				2) (FUNC) (A) (V) on the operator are pressed at same time, 3) and then continue this condition and press (STOP) key.	
					3) and then continue this condition and press STOP key.	
	(NOTE 2)			•	4)Wait 2 seconds holding the key (FUNC)	
	(1,0124)				will	
					blink " d = 00 ". Then release the all keys.	
					5) Then the initialize operation starts.	
17	Selection of	Set	b85	Not	Select the initalized date	01/02
	initialized data	value		possible	00 Japan version	
					01 Europe version	
			1		02 US version	
					03 Exclusive version(Do not set)	
18	Frequency	Set	ხ86	possible	Set the frequency converted value which is related d07 monitor	1.0
	converted value	value			0.1 to 99.9 / setting resolution 0.1	
10	setting Selection of	S-4	h07	Max	Deside the STOP has maning when maning the	
19	Selection of STOP key	Set value	b87	Not	Decide the STOP key meaning when running destination is terminal	00
		ABINE			terminal 00 STOP key is available at terminal condition	ļ
	meaning				00 StOP key is available at terminal condition 01 STOP key is not available at terminal condition	
20	Selection of	Set	ъ88	Not	Select the operation after freerun function is canceled.	- 00
	operation at	value			00 ··· Restart from 0Hz	••
	FRS signal				01 Restart from the frequency which is picked up at the real	
	canceled				speed of the motor.	1
21	Selection of	Set	b89	possible	Select the monitoring data for using the digital operator.	01
	the contenta	value	ļ		01 ··· Output frequency monitoring (d 01)	
1	for digital	1			02 ··· Output current monitoring (d 02)	
	operator				03 Running direction monitoring (d 03)	
	(OPE-J)				04 Feedback data of PID control monitoring (d 04)	
.					05 Condition of input intelligent terminal monitoring (d 05)	J
.					06 Condition of output intelligent terminal monitoring (d 06)	
					07 Scale conversion data of output frequency monitoring (d. 07)	

NOTE 1: While the DC braking is performed, the carrier frequency is held to 1kHz automaticaly. NOTE 2: This function is not performed when the remote operator is connected.

Take off the remote operator and operate from the key pad on the inverter.

NOTE 3: The set value links with the detection current of output current monitor, electric thermal protection and overload limit.

(4)Extended function of C group

Ē

These function have relation with terr	minal
--	-------

Type		nction have relat	ion with				
Input terminal Set terminal Set the function of input terminal Set the function of input terminal Set	Display	Function name		Paramete			Initializ
Imput terminal Value	order	ĺ	Туре	r dissless	-		ation
Punction of Set training Set tra	Input ter	minel(function)	1	grapiay	Irunning	and contents	(-FE/-FU
terminal 1 setting value possible (codes) On PW((Greward command) On PW((Greward comma			Set	C01	Not	Set the function of input terminal 3	00,000
00 - FW (fervare command) 01 - FW (fervare command) 02 - CF1 (multispeed) 03 - CF2 (multispeed) 03 - CF2 (multispeed) 04 - CF3 (multispeed) 05 - JG(logging command) 05	i - I				A		00/00
02 CP4 (multispeed2) 03 CP2 (multispeed2) 04 CP3 (multispeed2) 04 CP3 (multispeed3) 05 CP4 (multispeed4) 06 JG(jorging command) 09 2CP4 (multispeed4) 06 JG(jorging command) 11 PRS) Pres run command) 12 EXTICATOR (mainly command) 12 EXTICATOR (mainly command) 13 DEPTICS (furse role command) 13 DEPTICS (furse role command) 14 PRS) Pres run command) 15 DEPTICS (furse role command) 16 AT (analog input voltage/current awitching) 16 AT (analog input voltage/current awitching) 16 AT (analog input voltage/current awitching) 16 AT (analog input voltage/current awitching) 16 AT (analog input voltage/current awitching) 17 Value	í	setting		•	,		i
03 - CP2 (multispeed2) 04 - CP3 multispeed3 05 - CP4 (multispeed3) 05 - CP4 (multispeed3) 05 - CP4 (multispeed3) 05 - CP4 (multispeed3) 05 - CP4 (multispeed3) 05 - CP4 (multispeed4) 06 - J@(opging command) 11 - FP8(Fre run command) 12 - EXT(External trip) 13 - USP(USP function) 15 - SPT(Sefivare lock) 16 - AT1 analog input voltage/current switching) 18 - EST(Sect)]					01 RV (reverse command)	
04 - CP3 (multispeed3) 05 - CP4 (multispeed4) 06 - JG(jogging command) 09 - 20 tfl(3-stage aceleration and deceleration) 11 - PRS(Pre run command) 12 - EXT(External trip) 13 - USP(USP function) 15 - SPT(Software lock) 16 - ATI analog input voltage/current switching) 18 - BS(resct) 16 - ATI analog input voltage/current switching) 18 - BS(resct) 16 - ATI analog input voltage/current switching) 18 - BS(resct) 18 - BS(resct) 18 - BS(resct) 19 - PS(Software) 19 - PS(Soft			ll.				
05CP4 (multispeed4) 06J@(oggring command) 092CH(2-stage acceleration and deceleration) 11FRS(Free run command) 12EXT(External trip) 13USP(USP function) 15SPT(Software lock) 16AT (analog input voltage/current switching) 18EST(sect)							
06 - JGtografing command) 11 - FRS/Free run command) 12 - EXT(External trip) 13 - USP(USP function) 15 - SFT(Software lock) 16 - ATI analog input voltage/current switching) 18 - SFT(software lock) 16 - ATI analog input voltage/current switching) 18 - SFT(software lock) 16 - ATI analog input voltage/current switching) 18 - SFT(software lock) 16 - ATI analog input voltage/current switching) 18 - SFT(software lock) 16 - ATI analog input voltage/current switching) 18 - SFT(software lock) 16 - ATI analog input voltage/current switching) 18 - SFT(software lock) 16 - ATI analog input verminal 2 2 - 20 - 20 - 20 - 20 - 20 - 20 - 2							
O9 2CH(2-stage acceleration and deceleration) 11 FRS(Free run command) 12 EXTEXECTION 13 USP(USF function) 15 SFT(Software lock) 15 SFT(Software lock) 15 SFT(Software lock) 15 SFT(Software lock) 15 SFT(Software lock) 15 SFT(Software lock) 15 SFT(Software lock) 15 SFT(Software lock) 15 SFT(Software lock) 16 ATT analog input voltage/current switching) 18 SFT(Software lock) 16 ATT analog input voltage/current switching) 18 SFT(Software lock) 18 -	}						i
11 - FRS/Free run command) 12 - EXT(External trip) 13 - USP(USP function) 15 - SFT(software lock) 16 - AT (analog input voltage/current switching) 18 - EST(resct) 16 - AT (analog input voltage/current switching) 18 - EST(resct) 16 - AT (analog input voltage/current switching) 18 - EST(resct) 16 - AT (analog input voltage/current switching) 18 - EST(resct) 16 - AT (analog input voltage/current switching) 18 - EST(resct) 16 - AT (analog input voltage/current switching) 18 - EST(resct) 16 - AT (analog input voltage/current switching) 18 - EST(resct) 16 - AT (analog input voltage/current switching) 18 - EST(resct) 18 - EST(resct) 18 - EST(resct) 19 - EST(resct)							
13 - USPUSP function 15 - STT(56) function 15 - STT(56) function 15 - STT(56) function 16 - ATI canalog input voltage/current switching) 16 - ATI canalog input voltage/current switching) 16 - ATI canalog input voltage/current switching) 18 - FSGrees 18 - FSGrees 19 - FSGREES 19 - FSG					Į.		
15 - SFT(Software lock) 16 - AT(santog input voltage/current switching) 18 - PST(Software lock) 18 - PST(resct) 18 - PST(resct) 18 - PST(resct) 18 - PST(resct) 18 - PST(resct) 18 - PST(resct) 18 - PST(resct) 18 - PST(resct) 18 - PST(resct) 19 - PST(resct)			1		l	,	
16 - ATT analog input voltage/current switching) 18 - PSGreast) 18 - PSGreast 18 - PSGreast 18 - PSGreast 18 - PSGreast 18 - PSGreast 18 - PSGreast 19 - PSGreast 19 - PSGreast 19 - PTC(motor of input terminal 3 outles 19 - PTC(motor of input terminal 3 outles 19 - PTC(motor therminal 4 outles 19 - PTC(motor therminal 5 outles 19 - PTC(motor therminal 1 outles 19 - PTC(motor therminal 1 outles 19 - PTC(motor therminal 1 outles 19 - PTC(motor therminal 1 outles 19 - PTC(motor therminal 1 outles 19 - PTC(motor therminal 1 outles 19 - PTC(motor therminal 1 outles 19 - PTC(motor therminal 1 outles 19 - PTC(motor therminal 1 outles 19 - PTC(motor therminal 2 outles 19 - PTC(motor therminal 1 outles 19 - PTC(motor therminal 2 outles 19 - PTC(motor therminal 2 outles 19 - PTC(motor therminal 2 outles 19 - PTC(motor therminal 2 outles 19 - PTC(motor therminal 2 outles 19 - PTC(motor therminal 2 outles 19 - PTC(motor therminal 2 outles 19 - PTC(motor therminal 3 outles 19 - PTC(motor therminal 2 outles 19 - PTC(motor therminal 3 outles 19 - PTC(motor therminal 3 outles 19 - PTC(motor therminal 2 outles 19 - PTC(motor therminal 1 outles 19 - PTC(motor therminal 3 outles 19 - PTC(motor therminal 2 outles 19 - PTC(motor therminal 3 outles 19 - PTC(motor therminal 2 outles 19 - PTC(motor therminal 3 outles 19 - PTC(motor therminal 3 outles 19 - PTC(motor therminal 2 outles 19 - PTC(motor therminal 3 outles 19 - PTC(motor therminal 3 outles 19 - PTC(motor therminal 3 outles 19 - PTC(motor therminal 4 outles 19 - PTC(motor therminal 4 outles 19 - PTC(motor therminal 3 outles 19 - PTC(motor therminal 3 outles 19 - PTC(motor therminal 3 outles 19 - PTC(motor therminal 3 outles 19 - PTC(motor therminal 3 outles 19 - PTC(motor therminal 4 outles 19 - PTC(motor therminal 4 outles 19 - PTC(motor therminal 3 outles 19 - PTC(motor therminal 4 outles 19 - PTC(motor therminal 4 outles 19 - PTC(motor therminal 4 outle							
18. PS(react)						_	
2 Function of terminal 2 value setting							
terminal 2 value possible (codes) same CO1 3 Function of cerminal 3 setting 4 Function of terminal 5 set possible (codes) same CO1 5 Function of terminal 5 set value setting 5 Function of terminal 5 set value setting Input terminal 6 condition of condition of condition of condition of terminal 1 value setting 7 Condition of terminal 1 value setting 8 Condition of terminal 3 setting 8 Condition of terminal 3 setting Condition of terminal 3 setting Condition of terminal 3 setting Condition of terminal 3 setting Condition of terminal 4 value setting Condition of terminal 5 set to condition of input terminal 2 which is normally open possible or normally close. 8 Condition of terminal 6 possible or normally close. 8 Condition of terminal 7 value setting Condition of terminal 8 possible or normally close. 9 Condition of terminal 9 possible or normally close. 9 Condition of terminal 1 value setting Condition of terminal 1 value setting 10 Condition of terminal 6 possible or normally close. 11 Punction of terminal 6 possible or normally close. 12 Punction of terminal 6 possible or normally close. 13 Function of terminal 12 value setting 14 Function of terminal 12 value setting 15 Punction of terminal 12 value setting 16 Condition of terminal 12 value setting 17 Condition of terminal 12 value setting 18 Condition of terminal 10 possible or normally close. 19 Condition of terminal 10 possible or normally close. 10 Possible terminal 11 possible (code) 10 Possible (code) 11 Function of terminal 10 possible (code) 12 Punction of terminal 10 possible or normally close. 19 Condition of terminal 10 possible (code) 10 Possible (code) 11 Possible (code) 12 Punction of terminal 12 possible (code) 13 Function of possible (code) 14 Punction of possible (code) 15 Punction of possible (code) 16 Punction of possible (code) 17 Punction of possible (code) 18 Punction of possible (code) 19 Possible (code) 10 Punction of possible (code) 10 Punction of possible (code) 11 Punction of poss	2	Function of	Set	C02	Not		01/01
Function of terminal 3 Set value setting 4 Function of terminal 5 Set value setting 5 Function of terminal 6 Set value setting Input terminal 6 Set value setting 7 Condition of terminal 1 value setting 8 Condition of terminal 2 setting 8 Condition of terminal 3 setting Condition of terminal 3 setting 8 Condition of terminal 3 setting Condition of terminal 3 setting 8 Condition of terminal 3 setting Condition of terminal 3 setting Condition of terminal 3 setting 8 Condition of terminal 4 value setting Condition of terminal 5 Set the condition of input terminal 2 which is normally open ploy() or normally close. 8 Condition of terminal 6 Set value setting Condition of terminal 7 value setting Condition of terminal 8 Set value setting Condition of terminal 9 Set value setting Condition of terminal 1 value setting Condition of terminal 1 value setting Condition of terminal 4 value setting Condition of terminal 6 Set value setting Condition of terminal 6 Set value setting Condition of terminal 6 Set value setting Condition of terminal 6 Set value setting Condition of terminal 6 Set value setting Condition of terminal 7 Set value setting Condition of terminal 8 Set value setting Condition of terminal 1 Set value setting Condition of terminal 1 Set value setting Condition of terminal 1 Set value setting Condition of terminal 1 Set value setting Condition of terminal 1 Set value setting Condition of terminal 1 Set value setting Condition of terminal 1 Set value setting Condition of terminal 1 Set value setting Condition of terminal 1 Set value setting Condition of terminal 1 Set value setting Condition of terminal 1 Set value setting Condition of terminal 1 Set value setting Condition of terminal 1 Set value setting Condition of terminal 1 Set value setting Condition of terminal 1 Set value setting Condition of terminal 1 Set value setting Condition of terminal 1 Set value setting Condition of terminal 1 Set value setting Condit		terminal 2	value		possible		0.701
terminal 3 value possible (codes)—same C01 4 Function of terminal 4 value setting 5 Function of terminal 5 value setting 5 Function of terminal 1 value setting Input terminal (condition) 6 Condition of terminal 1 value setting 7 Condition of terminal 2 value setting 8 Condition of terminal 3 value setting 8 Condition of terminal 3 value setting 9 Condition of terminal 3 value setting 10 Condition of terminal 5 value setting 10 Condition of terminal 5 value setting 10 Condition of terminal 5 value setting 10 Condition of terminal 5 value setting 10 Condition of terminal 5 value setting 10 Condition of terminal 5 value setting 10 Condition of terminal 5 value setting 10 Condition of terminal 5 value setting 10 Condition of terminal 5 value setting 10 Condition of terminal 5 value setting 10 Condition of terminal 6 value setting 10 Condition of terminal 6 value setting 10 Condition of terminal 7 value setting 10 Condition of terminal 8 value setting 10 Condition of terminal 9 value setting 10 Condition of terminal 10 va					·		
4 Function of terminal 4 value setting 5 Function of terminal 5 value setting Input terminal 5 value setting Input terminal 6 value setting Input terminal 6 value setting Input terminal 6 value setting Input terminal 6 value setting Input terminal 6 value setting Input terminal 6 value setting Input terminal 7 value setting Input terminal 8 value setting Function of terminal 9 value setting Condition of terminal 9 value setting Condition of terminal 4 value setting Condition of terminal 4 value setting Condition of terminal 4 value setting Condition of terminal 5 value setting Condition of terminal 6 value setting Condition of terminal 6 value setting Condition of terminal 6 value setting Condition of terminal 6 value setting Possible or normally close. Condition of terminal 6 value setting Input terminal 6 value setting Possible or normally close. Condition of terminal 6 value setting Input terminal 6 value setting Input terminal 6 value setting Possible or normally close. Condition of terminal 6 value setting Input terminal 6 value setting Input terminal 6 value setting Condition of terminal 6 value setting Input terminal 6 value setting setting on normally close. Input terminal 6 value setting setting on normally close. Input terminal 6 value setting setting setting setting setting setting setting setting setting s	3			C03		Set the function of input terminal 3	02/16
4 Function of terminal 4 value 5 Function of terminal 5 value 5 Function of terminal 6 value 6 Condition of terminal 1 value 8 Condition of terminal 2 value 8 Condition of terminal 3 value 8 Condition of terminal 3 value 8 Condition of terminal 3 value 8 Condition of terminal 3 value 8 Condition of terminal 3 value 8 Condition of terminal 3 value 8 Condition of terminal 3 value 9 Condition of terminal 4 value 8 Condition of terminal 5 value 9 Condition of terminal 5 value 9 Condition of terminal 6 value 9 Condition of terminal 6 value 9 Condition of terminal 7 value 9 Condition of terminal 8 value 9 Condition of terminal 6 value 9 Condition of terminal 6 value 9 Condition of terminal 6 value 9 Condition of terminal 6 value 9 Condition of terminal 6 value 9 Condition of terminal 6 value 9 Condition of terminal 6 value 9 Condition of terminal 6 value 9 Condition of terminal 6 value 9 Condition of terminal 6 value 9 Condition of terminal 6 value 9 Condition of terminal 6 value 9 Condition of terminal 7 value 9 Condition of terminal 8 value 9 Condition of terminal 9 value 9			value		possible	(codes) same C01	
terminal 4 value possible (codes) same CO1 5 Function of terminal 5 value possible (codes) same CO1 and there is additional code. 10/10 possible (codes) same CO1 and there is additional code. 11/10 possible (codes) same CO1 and there is additional code. 11/10 possible (codes) same CO1 and there is additional code. 11/10 possible (codes) same CO1 and there is additional code. 11/10 possible (codes) same CO1 and there is additional code. 11/10 possible or normally close. 11/10 possible or no	4		C	004	N2		
Setting Setting Set Cos Set Cos Set Setting Sett	•			C04		Set the function of input terminal 4	03/13
Input terminal 5 value setting Input terminal (condition)			14,00		possioie	(codes) same Cot	
Input terminal (condition) 19 PTC(motor thermistor input)	5			C05	Not	Set the function of input terminal 5	18/18
Input terminal (condition) 6 Condition of Condition			value		possible		
Condition of terminal 1 value setting Condition of terminal 2 value setting Condition of terminal 3 value setting Condition of terminal 4 value setting Condition of terminal 5 value setting Condition of terminal 6 value setting Condition of terminal 6 value setting Condition of terminal 7 value setting Condition of terminal 8 value setting Condition of terminal 8 value setting Condition of terminal 9 value setting Condition of terminal 10 value setting Condition of terminal 11 value setting Condition of terminal 11 value setting Condition of terminal 11 value setting Condition of terminal 11 value setting Condition of terminal 11 value setting Condition of terminal 11 value setting Condition of terminal 11 value setting Condition of terminal 11 value setting Condition of terminal 11 value setting Condition of terminal 12 value setting Condi	2					19 PTC(motor thermistor input)	
terminal 1 setting			C				
Setting	ľ			CH			00 /00
7 Condition of terminal 2 setting 8 Condition of terminal 3 setting 9 Condition of Set value setting 10 Condition of terminal 4 setting 10 Condition of terminal 5 set value setting 10 Condition of terminal 5 set value setting 10 Condition of terminal 1 setting 11 Function of terminal 11 setting 12 Punction of terminal 12 setting 13 Function of Set value setting 14 Function of terminal 12 setting 15 Function of terminal 12 setting 16 Function of Set value setting 17 Function of terminal 12 setting 18 Function of Set value setting 19 Condition of Set value setting 10 Condition of Set value setting 11 Function of terminal 11 setting 12 Function of Set value setting 13 Function of Set value setting 14 Function of Set value setting 15 Function of Set value setting 16 Condition of Set value setting 17 Function of Set value setting 18 Function of Set value setting 19 Condition of Input terminal 5 which is normally open on one of terminal 11 possible or normally close. 10 Function of Set value setting 11 Function of Set value setting 12 Function of Set value setting 13 Function of Set value setting 14 Function of Set value setting 15 Function of Set value setting 16 Condition of Input terminal 2 which is normally open or normally close. 18 Function of Set C21 Not Set the function of output terminal 11 (code) 19 Condition of Input terminal 11 (code) 10		•	'"		possible		
7 Condition of terminal 2 value setting 8 Condition of terminal 3 value setting 9 Condition of terminal 4 value setting 10 Condition of terminal 5 value setting 10 Condition of terminal 5 value setting 10 Condition of terminal 5 value setting 11 Function of terminal 11 setting 12 Punction of terminal 12 value setting 13 Function of terminal 12 value setting 14 Punction of terminal 12 value setting 15 Punction of terminal 12 value setting 16 Condition of terminal 11 value setting 17 Condition of terminal 11 value setting 18 Condition of terminal 11 value setting 19 Condition of terminal 1 value setting 10 Condition of terminal 1 value setting 10 Condition of terminal 1 value setting 11 Function of terminal 1 value setting 12 Punction of terminal 12 value setting 13 Function of Set FM terminal setting 14 Punction of Set FM terminal setting 15 Punction of Set Value setting 16 Condition of Set FM terminal 2 value setting 17 Punction of Set FM terminal 2 value setting 18 Punction of Set FM terminal setting 19 Condition of Set FM terminal setting 10 Condition of Set FM terminal setting 10 Condition of Set FM terminal setting 11 Punction of Set FM terminal setting 12 Punction of Set FM terminal setting 13 Punction of Set FM terminal setting 14 Punction of Set FM terminal setting 15 Punction of Set FM terminal setting 16 Condition of Set PM terminal setting 17 Punction of Set FM terminal setting 18 Punction of Set FM terminal setting 19 Punction of Set PM terminal setting 10 Punction of Set PM terminal setting 10 Punction of Set PM terminal setting 10 Punction of Set PM terminal setting 10 Punction of Set PM terminal setting 10 Punction of Set PM terminal setting 10 Punction of Set PM terminal setting 10 Punction of Set PM terminal setting 10 Punction of Set PM terminal setting 10 Punction of Set PM terminal setting 10 Punction of Set PM terminal setting 10 Punction of Set PM terminal setting 10 Punction of Set PM terminal setting 10 Punction of Set PM terminal setting 10 Punction of Set PM terminal setting setting set							
8 Condition of terminal 3 value setting 9 Condition of terminal 4 value setting 10 Condition of terminal 5 value setting 10 Condition of terminal 5 value setting 10 Condition of terminal 6 value setting 10 Condition of terminal 6 value setting 11 Function of terminal 11 setting 12 Function of terminal 12 value setting 13 Function of terminal 12 value setting 15 Function of terminal 12 value setting 16 Function of terminal 12 value setting 17 Function of terminal 12 value setting 18 Condition of terminal 12 value setting 19 Condition of terminal 12 value setting 10 Condition of terminal 12 value setting 11 Function of terminal 12 value setting 12 Function of terminal 12 value setting 13 Function of FM terminal value setting 15 Function of terminal 2 value setting 16 Condition of terminal 2 value value value value setting 17 Function of terminal 12 value value value value value setting 18 Function of FM terminal value	7		Set	C12	Not		00/00
Set train Set value Set value Set the condition of input terminal 3 which is normally open 00/00	Į.		value		possible	or normally close.	00.00
terminal 3 setting 9 Condition of terminal 4 setting 10 Condition of terminal 5 set terminal 5 walue setting 10 Condition of terminal 6 setting 10 Condition of terminal 6 setting Output terminal 6 setting Output terminal 11 setting Output terminal 11 setting Output terminal 12 setting Output terminal 12 setting 12 Function of terminal 12 setting 13 Function of FM terminal setting Function of FM terminal atting setting Output terminal 12 setting Total possible or normally close. Output terminal 4 which is normally open or normally close. Output terminal 5 which is normally open or normally close. Output terminal 10 possible or normally close. Output terminal 11 possible or normally close. Output terminal 12 possible or normally close. Output terminal 11 possible or normally close. Output terminal 12 possible or normally close. Output terminal 11 possible or normally close. Output terminal 12 possible or normally close. Output terminal 5 which is normally open or normally close. Output terminal 5 which is normally open or normally close. Output terminal 5 which is normally open or normally close. Output terminal 5 which is normally open or normally close. Output terminal 5 which is normally open or normally close. Output terminal 5 which is normally open or normally close. Output terminal 5 which is normally open or normally close. Output terminal 5 which is normally open or normally close. Output terminal 5 which is normally open or normally close. Output terminal 5 which is normally open or normally close. Output terminal 5 which is normally open or normally close. Output terminal 5 which is normally open or normally close. Output terminal 6 which is normally open or normally close. Output terminal 6 which is normally open or normally close. Output terminal 6 which is normally open or normally close. Output terminal 6 which is normally open or normally close. Output terminal 6 which is normally open or normally close. Output terminal 6 which is normally open or normally	-						
9 Condition of terminal 4 setting 10 Condition of terminal 5 set value setting 10 Condition of terminal 5 set value setting 10 Condition of terminal 5 set value setting Output terminal 6 set value setting Output terminal 11 setting Output terminal 11 setting Output terminal 11 setting Output terminal 11 setting Output terminal 11 setting Output terminal 11 setting Output terminal 12 setting Output terminal 13 setting Output terminal 14 which is normally close. Output terminal 5 setting output terminal 5 which is normally close.	•			C13		Set the condition of input terminal 3 which is normally open	00/00
Condition of terminal 4 setting Condition of terminal 5 setting Condition of terminal 5 setting Output terminal 11 setting Continuous of terminal 11 setting Composible Condition of terminal 5 setting Condition of terminal 11 setting Composible Condition of terminal 11 setting Condition of terminal 11 setting Condition of terminal 11 setting Condition of terminal 11 setting Condition of terminal 11 setting Condition of terminal 11 setting Condition of terminal 12 setting Condition of terminal 12 setting Condition of terminal 12 setting Condition of terminal 12 setting Condition of terminal 12 setting Condition of terminal 12 setting Condition of terminal 12 setting Condition of input terminal 4 which is normally open of normally close. Condition of normally close. Set the condition of input terminal 5 which is normally open ovious. Condition of normally close. Set the function of output terminal 11 output terminal 11 output signal at the time of constant speed arrival signal at the time of set frequency or more of constant speed arrival signal at PID control of Set terminal 12 (code) Al(alarm signal) Condition of terminal 4 which is normally open ovious of normally close. Condition of normally close. Not speed the condition of input terminal 5 which is normally open ovious on normally close. Collaboration of possible or normally close. Collaboration of normally close. Collaboration of normally close. Collaboration of normally close. Collaboration of normally close. Collaboration of normally close. Collaboration of normally close. Collaboration of normally close. Collaboration of normally close. Collaboration of normally close. Collaboration of normally close. Collaboration of normally close. Collaboration of normally close. Collaboration of normally close. Collaboration of normally close. Collaboration of normally close. Collaboration of normally close. Collaboration of normally close. Collaboration of normally close. Collaboration of normally close. Collabo			Value		possible	or normally close.	
terminal 4 setting Condition of terminal 5 setting Output terminal (function) 11 Function of terminal 11 setting Condition of terminal 11 setting Condition of terminal 12 setting Discreption of terminal 12 setting Condition of terminal 12 setting Condition of terminal 12 setting Condition of terminal 12 setting Condition of terminal 12 setting Condition of terminal 12 setting Condition of terminal 12 setting Condition of terminal 12 setting Condition of terminal 12 setting Condition of terminal 12 setting Condition of terminal 12 setting Condition of terminal 12 setting Condition of terminal 12 setting Condition of terminal 12 setting Condition of terminal 4 setting Condition of input terminal 5 which is normally open convenient of understance of the condition of output terminal 11 convenience of constant speed arrival) Output terminal 11 setting Condition of input terminal 11 convenience of output terminal 11 convenience of constant speed arrival) Output terminal 11 setting Condition of input terminal 11 set in output terminal 11 convenience of constant speed arrival) Output terminal 11 setting Condition of input terminal 11 set in output terminal 11 convenience of constant speed arrival) Output terminal 11 setting Condition of input terminal 11 set in output terminal 12 set in output terminal 12 set in output terminal 12 set in output set in output terminal 12 set in output set in output terminal 12 set in output set	— ₉ †		Set	C14	Not	Set the condition of input to-right death in the second	00/01
Setting Condition of terminal 5 Set value Set the condition of input terminal 5 which is normally open or normally close.	1			0.,		or normally close	00/01
Comput terminal 5 setting						,	
Output terminal (function) 11 Function of terminal 11 setting 12 Function of terminal 12 setting 13 Function of FM terminal setting 14 Function of FM terminal setting 15 Function of FM terminal setting 16 Set the function of output terminal 12 value setting 17 Function of FM terminal setting 18 Set the function of set value setting 19 Set the function of fequency arrival signal: at the time of constant speed arrival) 10 Function of terminal 12 value setting 10 Set the function of output terminal 12 (code) code) 11 Set the function of output terminal 12 (code) code	10		4	C15		Set the condition of input terminal 5 which is normally open	00/00
Output terminal(function) 11 Function of terminal 11 setting 12 Function of terminal 12 setting 13 Function of terminal 12 setting 14 Function of terminal 12 setting 15 Function of terminal 12 setting 16 Function of terminal 12 setting 17 Function of terminal 12 setting 18 Function of terminal 12 setting 19 Function of terminal 12 setting 10 Function of Function of Function of Set value setting 10 Function of Function of Set value setting 10 Function of Function of Function of Set value setting 10 Function of Function of Function of Function of Set value setting 10 Function of Function of Function of Function of Set value setting 11 Function of Function of Function of Function of Including Setting 12 Function of Function of Function of Function of Including Setting 13 Function of Function of Set value setting 14 Function of Function of Set value setting 15 Function of Function of Set value setting 16 Function of Function of Including Setting Set the function of Including Setting Set Value setting 17 Function of Function of Including Setting Set Value setting Set Value value setting Set Value setting Set Value valu		-	value		possible	or normally close.	
Function of terminal 11 setting Set value setting Not Code possible (code) O RUN(signal during running) O1 FA)(frequency arrival signal:at the time of constant speed arrival) O2 FA2(frequency arrival signal:at the time of set frequency or more) O3 OL(overload signal) O4 OD(deviation signal at PID control) O5 AL(alarm signal) 12 Function of terminal 12 value setting Set C22 Value setting Not Set the function of output terminal 12 (code) same C21 Not possible (code) O0 A-F(monitor of analog output frequency) O1 A(monitor of analog output current)	Output te						
terminal 11 setting value possible (code) 00 RUN(signal during running) 01 FA)(frequency arrival signal:at the time of constant speed arrival) 02 FA2(frequency arrival signal:at the time of set frequency or more) 03 OL(overload signal) 04 OD(deviation signal at PID control) 05 AL(alarm signal) 12				C21	Not	Set the function of output tage (- al. 1)	-
setting 00 RUN(signal during running) 01 FA1(frequency arrival signal:at the time of constant speed arrival) 02 FA2(frequency arrival signal:at the time of set frequency or more) 03 OL(overload signal) 04 OD(deviation signal at PID control) 05 AL(alarm signal) 12				·			U1
O1 FA)(frequency arrival signal:at the time of constant speed arrival) O2 FA2(frequency arrival signal:at the time of set frequency or more) O3 OL(overload signal) O4 OD(deviation signal at PID control) O5 AL(alarm signal) O6 O7 O8 O8 O9 O8 O9 O9 O9 O9 O9 O9 O9	1						
Speed arrival	i			į		01 FA)(frequency arrival signal:at the time of constant	
frequency or more) 03 OL(overload signal) 04 OD(deviation signal at PID control) 05 AL(alarm signal) 12 Function of terminal 12 value setting 13 Function of Function of FM terminal setting Set value setting 14 Set value (code) same C21 Set the function of frequency monitor FM (code) Output terminal 12 (code)	ļ				J	speed arrival)	
12 Function of terminal 12 setting 13 Function of FM terminal setting 14 Set C23 Not possible (code) 15 Function of FM terminal setting 16 Set C23 Not possible (code) 17 Set the function of output terminal 12 (code) 18 Function of FM terminal setting 19 Set C23 Not possible (code) 10 Set the function of frequency monitor FM (code) 10 Output terminal 12 (code) 11 Set the function of frequency monitor FM (code) 12 Set C23 Not possible (code) 13 Set C23 Not possible (code) 14 Output terminal 12 (code) 15 Output terminal 12 (code) 16 Output terminal 12 (code) 17 Output terminal 12 (code) 18 Output terminal 12 (code) 19 Output terminal 12 (code) 10 Output terminal 12 (code) 10 Output terminal 12 (code) 10 Output terminal 12 (code) 10 Output terminal 12 (code)	1				į		
12 Function of terminal 12 setting 13 Function of FM terminal setting 14 OD(deviation signal at PID control) 15 Set C22 Not possible (code) same C21 16 Set the function of output terminal 12 (code) same C21 17 Set the function of frequency monitor FM (code) 18 Set C23 Not Set the function of frequency monitor FM (code) 19 OO OO OO OO OO OO OO OO OO OO OO OO OO	1					frequency or more)	
Punction of terminal 12 setting 13 Function of FM terminal setting Set Value setting Set Value possible (code) same C21 Not Set the function of output terminal 12 (code) same C21 Not Set the function of frequency monitor FM possible (code) Output terminal (code) same C21 Not Set the function of frequency monitor FM possible (code) Output terminal 12 (code) same C21	1			ļ		03 OL/deviation signal)	
Punction of terminal 12 value setting 13 Function of Function of FM terminal setting Set C23 Not possible (code) same C21 Not Set the function of frequency monitor FM possible (code) OO code) OO code) OO code) OO code) OO code) OO code) OO code) OO code) OO code) OO code) OO code) OO code) OO code) OO code) OO code) OO code) OO code) OO code) OO code)	ļ		<u> </u>				
terminal 12 setting possible (code) same C21 13 Function of FM terminal setting value setting code) 14 Function of FM terminal setting code code code code code code code code							
terminal 12 setting possible (code) same C21 13 Function of FM terminal value possible (code) same C21 Not Set the function of frequency monitor FM possible (code) same C21 Not Set the function of frequency monitor FM possible (code) same C21	12	-		C22	Not	Set the function of output terminal 12	00
Function of FM terminal value possible (code) setting Function of Set C23 Not Set the function of frequency monitor FM (code) output frequency) output current)			value	ľ	possible	(code) same C21	
FM terminal value possible (code) setting (code) 00 A.F(monitor of snalog output frequency) 01 A(monitor of snalog output current)	 ₩			00.			
setting 00 ··· A·F(monitor of analog output frequency) 01 ··· A(monitor of analog output current)	13			C23	Not	Set the function of frequency monitor FM	00
01 A(monitor of analog output current)			ABING				
02 ··· D·F(monitor of digital output frequency)						01 A(monitor of analog output frequency)	
					į.	02 ··· D-F(monitor of digital output framency)	
la constant de la con							

Output t	erminal(condition	N				· · · · · ·
14	Condition of	Set	C31	Not	Set the condition of intelligent output terminal 11 which is	
1	terminal 11	value	(3)			00
ļ		ATTOE	Ì	possiole	normally open or normally close.	
1	setting		ļ		00 normally open	
 	, i i i	-		-	01 normally close	
15	Condition of	Se	C32	Not	Set the condition of intelligent output terminal 11 which is	00
1	terminal 12	value	Į	possible	normally open or normally close.	
	etting				00 normally open	
					01 normally close	
16	Condition of	Set	C33	Not	Set the condition of alarm relay which is normally open or	01
	terminal AL	value	İ	possible	normally close. (See 7-21)	
	setting		1		00 normally open	
				1	01 normally close	l i
Function	relation with out	nut term	lir ol		or a tionnally close	
17	Level of	Set	C41	Not	Set the level of overload signal which is range between 0%	P
1 ''	overload signal	value	, ~i			Rated
		Agride		bogmore	and 200% for rated current of the inverter.	current of
1	setting	l i			Range of setting 0.0 * (Rated current of the inverter)	each
					to 2.0 * (Rated current of the inverter)	inverter
					metting resolution 0.01A	
1					C41	
1					motor current	
	ľ				everload	
ł					signal	
18	Arrival	Set	C42	Not	Set the frequency that the arrival signal should be outputted	0.0
1	frequency	value			at acceleration.	0.0
JI i	setting for			hogerore	0.0 to 360Hz	
i i	acceleration				0,0 to 300/12	
ll l	acceleration				output frequency	i
		ł			C42	i
il i		1		İ	C43	
	1	ľ		1		
	l				arrivel signal	
					• .	
19	Arrival	Set	C43	Nat	Set the frequency that the arrival signal should be outputted	0.0
	frequency	value			at acceleration.	
	setting for				0.0 to 360Hz	1
	deceleration					
20	Level of	Set	C44	Not	This function sets deviation level between target and	3.0
	deviation signal	value	0.,	possible		3.0
	eetting			Looping		i
					0.0 to 100.0% / setting resolution 0.1%	
					100% means fullscale	
					Feedback	į l
	ł				Tarret	fl.
	1				PID control	
					C41	1
1						f
1. 1	1				Deviation signal	1
	[ı ·		il

9. PROTECTIVE FUNCTIONS

The L100 series inverters trip by protective functions against overcurrent, overvoltage, and undervoltage which protect the invener. If the protective functions are engaged, the output is shut down, motor runs free and holds that condition until it is reset.

Trip	Contents	Display
Over current	When output of an invener is short circuited, the motor is locked	-Constant speed
protection	or drives sudden heavy load, the inverter output current exceeds a	
	certain level, and the inverter output is cut off.	-at Dannauno
		F 0 7 1
		-at Acceleration
		E 0 3 1 -at the others
		E 04
Overload	When a motor overload is detected by the electronic the rmal	
protection	function, the output of the inverter is cut off.	E 05
Overvoltage	When the inverter DC bus voltage exceeds a certain level due to	
protection	regenerative energy from the motor, this protection engages and the output of the invener is cut off.	E 07
<u>EE</u> PROM	When the memory built in has problems due to noise or	
епог	excessive temperature rise, this protection engages and the output	E 081
(NOTEI)	of the invener is cut off.	
Undervoltage protection	A decrease of DC bus voltage of an invener results in improper function of the control circuit. It also generates the motor hea and causes low torque. Output is cut off when the DC bus voltage goes down to less than a certain level.	E 091
CP U enorl	Malfunction or abnormality on built-in CPU and the output of the	_
	inverter is cut off.	<u>E 1 11</u>
		E 22
External trip A	n abnormality signal from external equipment cuts off the output of the invener.	F 12
	It is necessary to assign the external trip on the intelligent terminal.	
USP error	It indicates an error when power is turned on while the inverter is	
	being run. (When USP function is selected)	E 13
Ground fault	The inverter is protected by detection of ground faults between	
protection	the inverter output and the motor upon power on before the inverter works. This protection is provided for the inverter, not for humans.	E 14
Input	When the input voltage is higher dun the specified value, it is	_
overvoltage	detected 100 seconds after power is turned on and the output is cut off.	E 15
Therma	When the temperature of the inverter module is higher, the	
protection	thermal sensor in the invener module detects the higher temperature of power chip and the invener is cut off.	E 21
PTC error	When the resistance value of the external thermistor is too	
	large, the equipment detects the abnormal condition of the thermistor and then cut off the output.	E 35
<u> </u>	(When PTC function is selected)	

NOTE 1: If an EEPROM error occurs, be sure to confirm the setting value again

If the power is turned off while the [RS] is held [ON],the EEPROM error occurs
at the power is turned on in the next time.

Other display

Contents	Display
Under stand-by condition at power on. At reset signal coming.	
It is displayed when the under voltage or the power is shut off.	
It displays the rest time of retry waiting time after the power recovery of undervoltage when selecting the retry mode.	0000
During the initialization of the parameters [EU] : European version [USA] : American version [JP] : Japanese version	5 EU 505A 5 JP
During the initialization of the trip history data	S HE
During the copy operation by the copy unit.	<u> [[]P</u> Y
No data(Trip history. PID feedback data).	<u></u>

For display contents when the **remote** operator or copy unit is used, see page 13-1 and the subsequent **pages**.

10. TROUBLESHOOTING

Sy	mptom	Probable cause	Countermeasure
The notor vill nor un.	The inverter outputs u. V and W are not supply	*Is the parameter selling of the frequency command destination[A01] correct? Is the parameter setting of the running command destination[A02] correct?	. Make sure of the Parameter setting [A01]. *Make sure of the parameter setting [A02].
 -	ing voltage.	. Is power being supplied to terminals L1, L2, and L3(N)? If it is, the POWER lamp should be on.	• Check terminals L1, L2, and L3(N), U, V. and W. • Turn on the Power supply.
		·Is the display E [][]?	. Press FUNC and check the content. Then press the reset key.
		. Is the allocation of intelligent input terminal correct? . Is the operation instruction RUN ON? . Is terminal FW (or RV) connected to terminal P24?	. Make sure of the allocation of the terminal [C 01] ~ [C OS] Set to ON Connect terminal P24 to terminal FW (or RV) (When the terminal mode is selected.)
		Has the frequency setter been turned on by pushing (A) (V) key to select	. Push down keys and sct When terminal mode is selected, connect the potentiometer to H, O, and L, and then set.
		[F 01] and then@@ key. Are the control circuit terminals H. 0 and L connected to the potentiometer?	
		. Has RS/FRS been left ON?	. Release reset.
	Inverter outputs U, V. and w arc supplying voltage.	. Has the motor the load too heavy?	. Reduce the load. Test the motor independently.
	The optional remote operator is used. (copy unit)	. Are the operational settings between the remote operator and inverter unit correct?	ON OFF 1: OFF 2: ON (Same as 1300)
nc rection the otor is versed.		. Are the connections of output terminals U. V. and W correct? . Is the phase sequence of the motor forward or reverse in respect to U. V. and W?	. Make the connections according to the phase sequence of the motor. (In general, forward should be in the sequence: U. V. and W.)
		. Are the control terminal connection correct? - Is the parameter [F 04] set correctly?	. Terminal FW for forward. and RV for reverse.

Syn	nptom	Probable cause	Countermeasure
The rpm of the motor will not		• After checking the wiring of the frequency setter, the rpm still doer no, increase when the setter is turned.	• Replace the frequency setter.
increase.		. Is the load too heavy?	 Reduce the load. When the load is too heavy, the overload restriction will be activated, so that the rotational speed will be lower than the setting.
Rotation is "Instable.		Is the fluctuation in load too great? Is the power supply voltage fluctuating? Is some peculiar frequency causing the problem?	Increase the capacity. (Both of the motor and inverter.) Decrease the fluctuation. Change the output frequency slightly. Change the carrier frequency(b83 p.8-12)
The rpm of the motor does not match the inverter.		. Is the maximum frequency setting correct?	Check the V/F pattern against the motor specifications.
ne data is incorrect.	The data has not changed.	• Was the power turned off without pushing the STR key after the data was changedwith.	. Input the data and push the STR key once.
		The data is memorized upon power off. Is the time from power OFF to ON less than six seconds?	•Take six seconds or more when turning power OFF and ON after changing the data.
	Data copied by the copy unit is not input.	Is the power turned off within six seconds after the display changed from REMT to INV.	. Copy again and keep the power on during six seconds or more after copying.

Sym	nptom	Probable cause	Countermeasure
The data is nor changed.	requency setting can not be changed. Run and stop can not be done.	•The change of the terminal mode and digital operator mode were correct?	* Confirm the change in[A 01], IA 02] setting mode. (See page 8-7.)
	The data can not be changed.	• Is software lock ON? • Is software lock ON with software lock selection [b 31] • Is the switch 4 mounted on the back of the remote operater (copy unit) ON? (See page 13-2)	. Open SFT terminal and PV24. . Change the data of [b 311. • Turn the switch OFF.

Precautions for data setting

When changing any set data by one of the following methods, keep the equipment unoperated for 6 seconds or more after the selected method is executed. When any key is pressed, or the reset operation is performed. Of the power is turned off within 6 seconds, correct data may not be set.

- I) Changing the data and pressing the STR key to store the data
- 2) Operating the ECOPY | key when copying another inverter data using the copy unit (DRW) (See page 13-12.)

11. MAINTENANCE AND INSPECTION

11.1 Maintenance and Inspection Precautions

M WARNING

After a lapse of more **than** 5 minutes after turning off the input power supply. perform the maintenance and inspection.

Otherwise, there is a danger of electric shock

Make sure that only qualified persons will perform maintenance. inspection and pan replacement. (Before starting the work, remove metallic objects from your person (wristwatch, bracelet, etc.)

(Be sure IO use tools protected with insulation.)

Otherwise, there is a danger of electric shock and/or injury.

A CAUTION

When removing connectors, never pull the wires. (Wires for cooling fan and logic P.C. board)

Otherwise, there is a danger of fire due to wire breakage and/or injury


. General precautions

Always keep rhe unit clean so that dust or other foreign matter does not enter the inverter. Take special care in regard to breaking lines and connection mistakes. Firmly connect terminals and connectors. Keep electronic equipment away from moisture and oil. Dust, steel filings and other foreign matter can damage insulation. causing unexpected accidents. so take special care.

11.2 Inspection Items

- (I) Daily inspection
- (2) periodic inspection (Approximately once a year)
- (3) Insulation resistance test

Conduct the insulation resistance test by short circuiting the terminals as shown below.



Use 500V DC megohm meter, and make sure that 5M ohm or greater is indicated

Never test withstand voltage test. Because this inverterhas the surge absorber between the main circuit terminal and the ground.

We recommend that the following pans be stocked to reduce down time

Recommended Spare Parts

Pan description	Pan description Symbol		antity	Remarks	
i an description	Symbol	Used	Spare	I/Gillal K5	
Cooling fan	FAN	1	I	022NF* 037LF* to 075LF* 015HF* to 075HF*	
Case		I		Frontcase Key cover case Rear cover	

Daily Inspection and Periodic Inspection (1/3)

Inspection	Inspection item	Inspection content	Inspe	ction cycle	Inspection method	Criteria	Standard replacement	Instruments
location	•		Daily	Periodic	,	Citicina	period	2113G Giffelig
Overall	Ambient environment	Check ambient temperature. humidity. dust. corrosive gases, oil mist. etc.	V			Ambient temperature between -10 to +40°C; no icing. Ambient humidity 20 to 90%: no dew condensation.		Thermometer
	Devices overall	Check for abnormal vibrations and noise.	~		Visual and aural inspection.			Hygrometer
	Power supply voltage	Check the input line voltage.	~		Measure the voltage between inverter terminals LI. L2, and L3(N).	No abnormalities. (200V class) 200 to 240V 50/60Hz (400V class) 380 to 460V 50/60Hz		Tester
Main zircuit	Overall	 (1) Insulation resistance test. (2) Check installation for looseness. (3) Check for evidence of overheating in the various components. (4) Clean. 		~ ~ ~	(1) Tighten. (2) Visual inspection.	No abnormalities. Tightening torque (except for terminal block) M3: 0.5 - 0.6 N.m M4: 0.98 - 1.3 N·m · M5: 1.5 - 2.0 N·m		500V DC Mcgohm mete

Inspection	Inspection item	Inspection content	Inspe	ction cycle	Inspection method	Criteria	Standard	Instruments
ocation	inspection nem	inspection content	Daily	Periodic	mspection mealou		replacement period	msų gments
Main circuit	Terminal block	No damage.		~	Visual inspection	No abnormalities.		
	Smoothing capacitor	(1) Check for leaking (2) Check for swelling	レ レ		Visual inspection of (1) and (2).	No abnormalities in (1) and (2).		
	Relays	(1) Check for stuttering noise when operating		~	(1) Aural inspec-	(I) No abnormalities.		
	Resistors	(1) Check for large cracks or changes in color		~	(1) Visual inspection	(1) No abnormalities.		Tester
	Cooling fan	(I) Check for abnormal vibrations and noise	V		(I) Rotate manually with power off. (2) Increase tightening	(1) Smooth rotation	2 3 years	
		(2) Check for dust	~			(2) No abnormality		

and Periodic (3/3)

Ġ,

ŝ

uonaadsiin l	Increasion in	-	hadem !	التعاصدين والمتوا			n manuero l	
location	makerion rich	rispection content	Daily	Daily Periodic	Inspection method	Criteria	replacement period	Instruments
Control	Operation check	(1) Check the balance of the output voltage of individual phases when operating the inverter independently.		7	(1) Measure the voltage between the phases of inverter output terminals U. V. and W.	(1) Within 2% voltage difference between phases.	1 -	
		(2) Conduct a sequence protection operation test.		7	(2) Simulate operation of the	(2) Operate without any abnormalities.		
		and make sure that there are no errors in the protec- tion and display circuits.	ì		inverter protect- ion circuit.			
	Compo- Overall nent	(1) No abnormal odor or changes in color.	```	7	Visual inspection	No abnormalities	,	
	including printed- circuit	(2) No significant corrosion.		7				
	boards Capacitor	r No fluid leakage or deformation.	>		Visual inspection			1
Display	Digital operation	(1) No illegible display	7		Visual inspection	Normal operation		1
		(2) No Jack of character	7			Display can be read out.		
		(3) No blown out LEDs	7	<u>-</u>				

2. The inverter must be cleaned periodically. If dust accumulates on the fan and heat sink, it can cause overheating of the inverter. NOTE: 1. The lite of capacitor will be affected by the amibient temperature. See Appendix 4 Capacitor Life Curve.

113 Measurement Method for I/O Voltage, Current, and Power

General measuring instruments for **I/O** voltage. current, and power are indicated below. The voltage to be measured is the fundamental wave effective voltage and **the** power to be measured is the total effective value.




Table 3 Parts lo be measured

Measurement item	Parts to be measured	Мо	asuring instrument	Remarks	Reference value
Supply voltage E ₁	Between L1 and L2, L2 and L3, L3 and L1 (ER) (Es) (ET)	*	Moving-iron type voltmeter or rectifier type voltmeter	Fundamental wave effective value	Commercial supply voltage (200 V class) 200-240 V, 50/60 Hz (400 V class) 380-460 V 50/60 Hz
Supply current I ₁	Li, L2, L3 (lr)(ls)(lt)	\$	Moving-iron type ammeter	Total effective value	
Supply power W ₁	Between L1 and L2, L2 and L3 (W11)(W12)		Electrodynamic type wattmeter	Total effective value	·
Supply power factor Pf 1	Calculate the supply power supply current I_1 and suppl $Pf_1 = \frac{W_1}{\sqrt{3} \cdot E_1 \cdot I_1} \times 100(\%)$				
Output voltage E ₀	Between U and V, V and W, W and U (EU)(EV)(EW)	+	Rectifier type voltmeter	Total effective value	
Output current L ₀	U, V, W (IU)(IV)(IW)	\$	Moving-iron type ammeter	Total effective value	
Output power W ₀	Between U and V, V and W(W01)(W02)		Electronic type wattmeter	Total effective value	
Output power factor Pf ₀	Calculate the output power and output power W. $Pf_0 = \frac{W_0}{\sqrt{3} \cdot E_0 \cdot I_0} \times 100(\%)$		om the output voltage E,	output current I,	

- NOTE 1: Use a meter indicating a fundamental wave effective value for voltage. and meters indicating total effective values for current and power.
- NOTE 2: The inverter output waveform is a distorted wave, and low frequencys may cause errors. However, the measuring instruments and methods indicated above provide comparatively accurate values.
- NOTE 3: A tester (general purpose) may not be suited often to measurement of a distorted wave.

12. STANDARD SPECIFICATIONS

Model name (L100-)		002 NFE	004 NFE	005 NFE	007 NFE	OII NFE	015 NFE	022 NFE					
	200V Class,	002 NFU	004 NFU		0 07 NFL		015 NFU	022 NF U	037 LFU	055 LFU	075 LF U		
Protective	e structure (NOTE I)					IF	20				_		
Over volu	age category					ľ	11						
Maximun	n motor size (4P, kW)(NOTE 2)	0.2	0.4	0.55	0.75	1.1	1.5	2.2	3.7	5.5	7.5		
Maxim capacit	230 v	0.5	1.0	1.1	1.5	1.9	2.8	3.9	6.3	9.5	12.7		
(kVA)	240 V	0.5	1.0	1.2	1.6	2.0	2.9	4.1	6.6	9.9	13.3		
Input sup	ply phase		2NF - ; Si /5LF - ; TI			shase							
Rated inp	ut AC voltage (V)	200V -10%-240V +5% , 50/60 Hz ±5%											
Rated output voltage (V) (NOTE 3)		Three-phase 200 to 240V (Corresponds to input voltage.)											
Rated inp	(Single-phase/Three-phase)	3.1/1.8	5.8/3.4	6.7/3.9	9.0/5.2	11.2/6.5	16.0/9.3	22.5113.	- /20.0	-130.0	-140.0		
Rated out	put current (A) (NOTE 4,	1.4	2.6	3.0	4.0	5.0	7.1	10.0	15.9	24.0	32.0		
Output fr	equency range (NOTE 5)	0.5 to 3	860 Hz										
Frequenc	y accuracy(at 25 ±10℃)	Digital Analog	command command	:±0.01% 1:±0.2 %	of Max. f	requency requency							
Frequenc	y setting resolution	Digital	setting : 0	.l Hz , A	nalog setti	ing : Max	. frequenc	y devided	by 1000		•		
Voltage/f	requency characteristics	Constan	nt or Redu	ced torqu	e with an	y variable	voltage/f	requency.					
Overload	current capacity	150%,	60 second	s							-		
Accelerat	ion/deceleration time	0.1 to 3000 seconds, in selectable linear or non-linear mode, second-acceleration/deceleration usable.											
Starting to	orque	100% o	er more (W	hen torq	ue boost h	as been s	et)			*-	-		
	Dynamic braking (NOTE 6) Feedback to capacitor	Approx. 100% Approx. 70% Approx. 20%											
	DC injection braking							an be selec g force car		_			

Model designation (L100-)			002 NFE	004 NFE	005 NFE	007 NFE	011 NFE	015 NFE	022 NFE					
{ 2	200V Class	J .	002 NFU	004 NFU		007 NFU		015 NFU	022 NFU	037 LFU	055 LFU	075 LFU		
nput ignals	Frequency setting	Digital operator	Scitings	with the	potentio	meter or	(A)) in the k	cey pad.	-				
		External signals	$0 \cdot 10$ VDC (Input impedance 10 kΩ) 4 - 20 mA(Input impedance 250Ω) 1kΩ to 2 kΩ (1 W) Variable resistor											
	Forward/ reverse	Digital operator	RUN/	RUN/STOP switch (The forward run (FW) when shipped from the factory)										
	run, stop	External signals	Intellige	Intelligent input terminal (FW/RV)										
	Intelligent input terminal		FW: Forward run/stop RV: Reverse run / stop CF1-4: Multi-stage speed JG: Jogging command AT: Analog current input selection 2CH: Change of 2nd accel/deceltime FRS: Free run EXT: External trip USP: USP function RS: Reset SFT: Software lock PTC: Thermal protection											
utput gnals	Intelligent	output terminal	FAI/FA2: Frequency arrival signal RUN: RUN signal OL: Overload previous notice siganl OD: Deviation signal at PID control AL: Alarm signal											
	Frequency monitoring		Analog meter (0 - 10 VDC full-scale max1 mA) Selection of the digital frequency signal ,analog frequency signal or analog output current monitor.											
ult ala	um contact		ON when the inverter trips.(Ic contact)											
ther functions			automatic voltage regulation retry, analog gain/vias adjustment, frequency jump, upper/lower limiter, output frequency display, trip bistory monitoring. carrier frequency setting(0.5~16kHz), PID control, automatioc torque boost, etc.											
otectio	on functions		overcurrent, overvoltage, undervoltage, electronic thermal, temperature abnormality, ground fault upon starting, overload limit											

	Model name (L100-)	002 NFE	004 NFE	005 NFE	007 NPE	011 NFE	015 NFE	022 NFE						
	[200V Class]	002 NFU	004 NFU		007 NFU		015 NFU	022 NFU	037 LFU	055 LFU	075 LFU			
General specifi-	Ambient temperature (NOTE 7)	-10 to 5	-10 to 50°C											
cations	Storage temperature/ Humidity	-25 to 70°C (during short-term transportation period) / 20 to 90% RH (no dew condensation)												
	Vibration	5.9 m/S ² (0.6G) 10 - 55 Hz												
	Installation location	1,000 meter or less altitude, indoors (IP54 or equivalent)												
	External color	Blue												
Options		remote o	operator, or impro	copy uni	t, cable f ver facto	or digita r, noise f	l operato ilter for i	r, nverters,	OPE-J					
Estimate	d mass (kg)	0.	85	1	.3	2.	2	2.8 5.5 5.1						

- NOTE 1: Protective structure is based upon EN60529
- NOTE 2: The applicable motor is a Hitachi standard four-pole motor. When using another motor, make sure that the rated motor current does not exceed the rated inverter current.
- NOTE 3: The output voltage will decrease if input voltage decreases.
- NOTE 4: The initial data setting value of 005N/01IN are same as 007N/015N.

 So be sure to set the value b 12 (Level of the electric thermal) and b 22 (Level of overload restriction setting) of 005N/007N for each motors.
- NOTE 5: Confirm with the motor manufacturer the motors maximum **rpm** when using a motor running at frequency higher than 50/60 Hz.
- NOTE 6: Torque will be reduced when the base frequency exceeds 50 Hz
- NOTE 7: In range of 40 to 50° C . reduce carrier frequency 2kHz and **derate** output current 80% , and remove the top cover.


Model name (L100 -)		004 H A	007 HA	015 HFE	022 HFE	0 I 0 HFE	040 HFE	OSS HFE	075 HFE				
	[400V Class]	004 HFU	007 HFU	015 HFU	022 HFU		040 , HFU	055 HFU	075 HFC				
Protecti	ive structure (NOTE I)				1P20								
Over ve	oltage category		iii										
Maxim	um motor size (4P, kW)(NOTE 2	0.4	0.75	1.5	2.2	3.0	4.0	5.5	7.5				
Maximum (kVAj³y 460 V		1.1	1.9	3.0	4.3	6.2	6.8	10.3	12.7				
Input st	upply phase	Three-phase (For Low Voltage directive, supply 4 wire earthed neutral)											
Rated i	nput AC voltage (V)	380V -10%-460V +10% , 50/60 Hz ±5%											
Rated o	Rated output voltage (V) (NOTE 3)		Three-phase 380 to 460V (Corresponds to input voltage.)										
Rated in	npul current (A)	2.0	3.3	5.0	7.0	10.0	110	16.5	20 0				
Rated o	output current (A)(NOTE 4)	1.5	2.5	3.8	5.5	7.8	86	130	160				
Output	frequency range (NOTE 5)	0.5 to 360	Hz										
Frequen	ncy accuracy(at 25 ±10 _i C)			01% of Max .2% of Mar.		_							
Frequen	cy setting resolution	Digital set	ting : 0.1 H	z , Analog se	tting : Max. f	requency devic	dcd by 1000						
Voltage	/frequency characteristics	Constant	or Reduced t	orque with a	ny variable v	oltage/frequen	су.						
Overloa	d current capacity	150%. 60 seconds											
Acceler	ation/deceleration time) seconds, ir on/decelerati		near or non-	i ncar mode, se	cond						
Starting torque		100% or n	nore (When	torque boost	has been set)							
	Dynamic braking (NOTE 6) eedback to capacitor	Approx.100% Approx. 70% Approx.20%											
	DC injection taking	Braking it the operate	ON at the m or. (Min. fre	in. frequenc	y or less. Br ring time and	aking cm be se braking force	elected by can be set.)						


Model name (L100 -)			004 HFE	007 HFE	015 HFE	022 HFE	030 HFE	040 HFE	055 HFE	075 HFE			
	[400V Class	5]	004 HFU	00 7 H FU	015 HFU	022 HFU		040 HFU	055 HFU	[0,5			
iput gnals	Frequency setting	Digital operator	Settings v	vith the pot	entiometer	or 🕭 🗨	in the ke	y pad.					
		External signals	0 - 10 VDC (Input impedance 10 kΩ) 4 - 20 mA(Input impedance 250Ω) 1kΩ to 2 kΩ (I W) Variable resistor										
	Forward/ reverse	Digital operator	RUN/S' the factor		h (The forv	vard run (F	W) when s	hipped fror	n				
	run, stop	External signals	Intelligent input terminal (FW / RV)										
	Intelligent input terminal		FW: Forward run/stop RV: Reverse run / stop CFI-4: Multi-aagc speed JG: Jogging command AT: Analog current input selection 2CH: Change of 2nd accel/decel time FRS: Free run EXT: External trip USP: USP function RS: Reset SFT: Software lock PTC: Thermal protection										
utput gnals	Intelligent (output terminal	FA1/FA2: Frequency arrival signal RUN: RUN signal OL: Overload previous notice signal OD: Deviation signal at PID control AL: Alarm signal										
	Frequency	monitoring	Analog meter (0 - 10 VDC full-scale Max,1 mA) Selection of the digital frequency signal analog frequency signal or analog output current monitor.										
ault ala	rm contact		ON when the inverter trips.(1c contact)										
ther fu	nctions		automatic voltage regulation, retry, analog gain/vias adjustment, frequency jump, upper/lower limiter, output frequency display, trip history monitoring, carrier frequency setting(0.5~16kHz), PID control, automatioc torque boost, etc.										
rotectio	on functions						ectronic the erload limi	rmai, tempi t	erature	" '			

N	Model name (L100-)		007 HFE	015 HFE	022 HFE	030 HFE	040 HFE	055 HFE	075 HFE		
(400V Class j	004 HFU	007 HFU	015 HFU	022 HFU		040 HFU	055 HFU	075 HFU		
General specifi-	Ambient temperature (NOTE 7)	-10 to 50°	-10 to 50°C								
cations	Storage temperature/ Humidity	-25 to 70°C (during short-term transportation period) / 20 to 90% RH (no dew condensation)									
	Vibration	5.9 m/S ² (0.6G) 10 - 55 Hz									
	Installation location	1,000 meter or less altitude, indoors (IP54 or equivalent)									
	External color	Blue									
Options				y unit, cable power fac			erters,OPE	-J			
Estimated	mass (kg)	1.3	1.7	,		2.8		5.5	5.7		

- **NOTE 1:** Protective **structure** is based upon EN60529
- **NOTE** 2: The applicable motor is a Hitachi standard four-pole motor. When using another motor, make sure that the rated motor current does not exceed the rated inverter current.
- **NOTE** 3: The **output** voltage will decrease if input voltage decreases.
- NOTE 4: The initial data setting value of 030H are same as 040H.


 So be sure to set the value b 12 (Level of the electric thermal) and b 22 (Level of overload restriction setting) of 030H for the motor.
- **NOTE** 5: Confirm with the motor manufacturer the motors maximum **rpm** when using a motor running at frequency higher than 50/60 Hz.
- **NOTE 6:** Torque will be reduced when the base frequency exceeds 50 Hz.
- **NOTE** 7: In range of 40 to 50°C. reduce carrier frequency 2kHz and **derate** output current **80%**, and remove the top cover.





NOTE 1: Common terminal for each terminal is different.


Terminal name	1, 2, 3, 4, 5	FM	н, о, оі	11,12
Common	P24		L	CM2




NOTE 2: When the operation command is input first and the main circuit power is turned ON, a direct start results and a trip occurs.

NOTE 3: Do not input the operation command simultaneously when the main circuit is turned on.

NOTE 4: Do not turn OFF the main circuit power during running.




L100 -011NFE -015NFU -




L100 -055LFU -055HFE -055HFU -075LFU -075HFE -075HFU

Ġ



· }.)




170

13. FUNCTIONS WHEN USING THE OPTIONAL REMOTE OPERATOR

13.1 Connecting the remote operator

Before connect the optional remote operator (digital operator, OPE-J), turn the power supply(power source) off.




- (I) Connect the remote operator cable with the inverter
- (2) Turn the power supply (power source) on
- (3) Make sure that the liquid crystal display(LCD) of the remote operator is lit

When the power supply of the **inverter** is turned **on**, FS000.0....of the monitoring mode will be displayed, If. however, any of the following is displayed at **the** moment of the invener is turned off, they will **be** displayed again when the power is turned on at the next time.

Only the copy unit (DRW-OA2) is able to copy the data of L100 series. The old type (DRW-OA) is not available for L100 series. Do not use the copy unit (DRW-OA) for this function.

NOTE :Do not connect or disconnect the remote operator, during the power is supplied to the invener.

NOTE: When the remote operator is connected, the key pad of the inverter is not available NOTE: When OPE-J is connected, the keys of OPE-J are not available except for (See p.8-12 "B89")



Setting and change are possible?

Y: Selling CM be changed during operation N: Setting can not be changed during operation -: Display only

Monitoringmode displays (when the remote operator is used)

isplay quence	Monitor name	Display content	Standard setting	Setting range	Y/N/-	Remarks	Digital operate
1	Frequency setting destination and output frequency Multistage-speed	FS 000.0 0.0Hz TM 000.0 0.0Hz VR 000.0 0.0Hz JG 000.0 0.0Hz	000.0	000.0 to 360.0	Y	(1) displays the setting. (2) displays the output ((()) is displayed when run	Monitor d 01
	setting and out- put frequency	(IS 005.0 0.0Hz	000.0	1	}	instruction is ON.	
		(000.0	-		F: Forward run R: Reverse run	Setting
		15S040.0 0.0Hz	000.0			Displayed during	1
	PID reference	FSP000.0		1		multistage operation.	F01
	value setting	TMP000.0 : 0.0Hz VRP000.0 : 0.0Hz 1P 000.0 : 0.0Hz	000	-		TM: Terminal setting VR: Potentiometer JG: Jogging	
	\ 	15P000.0 0.0Hz	<u> </u>				
2	Acceleration time setting	ACC1 0010.0S	10.0 (15.0)	0.1 to 3000.0	Y		F 02
3	Deceleration time setting	DEC1 0010.0S	10.0 (15.0)	0.1 to 3000.0	Y		F 03
4	Frequency setting command	F-SET-SELECT VR	TRM	VR/TRM /REM	Ŋ	VR : Inverter pot meter TRM: Inverter terminal	A 01
5	Operation command method	F/R-SELECT REM	TRM	TRM /REM	א	REM: Remote operator	A 02
6	Frequency converted value setting and converted value monitor	/Hz01.0 0.00	01.0	0.1 to 99.9	Y	The arithmetic value by the frequency converted value is displayed.	D 07 b 86
7	Output current display	Im 0.0 A 0.0%	,	-	Y	(1) displays the rated current of the inverter (2) displays output current	d 02
8	Reactive current setting	10 A	-	0 to 32	Y	Initial setting Inverter rated current * 0.58	b 32
9	Manual torque boost adjustment	V-Boost Code<11>	11	00 to 99	Y	-	A 42
10	Boost F setting	V-Boost F 10.0%	10%	0.0 to 50.0%	Y		A 43
11	Torque boost mode selection	V-Boost Mode 0	0	0 /1	N		A 41
12	Output voltage gain adjustment	V-Gain 100%	100	50 to 100	Y		A 45
13	Jogging frequency adjustment	Jogging 1.00Hz	1.0Hz	0 to 9. 9 9	Υ		A 38
14	Jogging mode selection	Jog Mode 0	0	0 to 2	N		A 39
15	Analog meter adjustment	ADJ 80	80	80	Y		ъ81
10	Panel display selection	PANEL dOI	40 I	d01 to d07	Y		ь 89
	Terminal monitor	TERM LLL LLLLL	-	_	-		d 05 d 06

isplay equence	Monitor name	Display content	Trip cause, cintents	Remarks	
18	Alarm display	ERRI -#		Not occuerd	
	Tii	ERRI OVER. V	<trip 1="" cause=""> Trip cause</trip>	The message is displayed on a prior	
	Trip monitor	ERR1 31.0Hz	Output frequency when tripped	basis when an alarm occurs.	
		ERR1 12.5A	Output current when tripped	Trip cause Overvoltage trip	
		ERR1 787.0Vdc	Voltage between P and N when tripped		
		ERR1 RUN 000002H	Cumulative hours when tripped		
19	Total alarm count	ERROR COUNT 0		Not occuerd	
		ERROR COUNT 25	Total trip count		
20	Trip history monitor	ERR2 #		Not occuerd	
	Last trip contents	ERR2 OC.Accel	<trip 2="" cause=""> Тrip cause</trip>	Trip cause Overcurrent trip fo	
		ERR2 5.0Hz	Output frequency when tripped	acceleration	
	·	ERR2 20.1 A	Output current when tripped		
		ERR2 560.0 Vdc	Voltage between P and N when tripped		
		ERR2 RUN 000002H	Cumulative hours when tripped		
	Contents of last trip but one	ERR3 #		Not occuerd	
	dip out one	ERR3 EXTERNAL	<trip 3="" cause=""> Trip cause</trip>	Trip cause External trip	
:		ERR3 5.0Hz	Output frequency when tripped	_	
		ERR3 20.1 A	Output current when tripped		
		ERR3 560.0 Vdc	Voltage between P and N when tripped		
		ERR3 RUN 000001H	Cumulative hours when tripped		
	-				

NOTE: When data is changed. be sure to press the street key. (Otherwise, the changed data may not be stored.)

The following functions can be obtained with connection of L-100-series to the remote operator (DOP) or the copy unit (DRW).

Function mode

Section Publish South	0.	Function name	Display co	ontent	Standard	setting	Setting	Digital
Maximum frequency setting			(Function n	noac 2)	-FE	-FU	range	operator
Setting	W	setting	F-BASE	060 Hz	50Hz	60Hz		A03
Motor input voltage SVR AC 200 230V/400V 30V/460V 300,220,230,240 380,400,415,440,460 400,415,440,460	m		≃-MAX.	060 Hz	50Hz	60Hz	50.0 to 360.0	A04
Setting	117	· · · · · · · · · · · · · · · · · · ·	Fmin. 0.5	5 Hz	0.5	0.5	0.5 to 9.9 (Hz)	b82
Deceleration AVR MODE DOFF WFF DOFF ON/OFF/DOFF			AVR AC	200 v	230V/400V	30V/460V		A82
Acceleration time Setting ACC O010.0 s 10.0 s 10.0 s 0.1 to 3000.0		deceleration	AVR MOD	E DOF	F WFF	DOFF	ON/OFF/DOFF	A81
Setting	· •	settino	CONTROL	VC	vc	vc	vc , VPl	A44
Selection ACC CHG TM TM TM TM TM TM FRE Acceleration time 2 Setting ACC 2 0015.0 s 15.00 s 15.00 s 0.1 to 3000.0 ACC ACC 2 0015.0 s 15.00 s 0.1 to 3000.0 ACC ACC ACC CHFr 000.0Hz 0.0Hz 0.0Hz 0.0 to 360.0 ACC LINE L L L L L L L L L	06	Acceleration time I setting	ACC 1 C	0010.0 s_	10.0 s	10.0 s	0.1 to 3000.0	F02
Setting		_	ACC CHG	TM	TM	TM	TM / FRE	A94
Change frequency setting			ACC 2	0015.0 s	15. 0 0 s	15.00 s	0.1 to 3000.0	A92
Deceleration DEC DOI DOS D		change frequency	ACC CHFr	000.0Hz	0.0Hz	0.0Hz	0.0 to 360.0	A95
Deceleration time 2 setting Deceleration time 2 because the property of the p			ACC LIN	E L	L	L	L/S	A97
DEC 2 0013.0 s 013.0 s 013.0 s 013.0 s 014	07	Deceleration time 1 setting	DEC I 0	010.0 s	10.0s	10.0 s	0.1 to 3000.0	F03
change frequency setting Pattern selection for deceleration 10 Restarting after FR: signal selection 11 Multistage speed SPD 1 005.0Hz OHz OHz OHz OHz OHz OHz OHz OHz OHz O	ı		DEC 2 0	015.0 s	015.0 s	015.0 s	0.1 to 3000.0	A93
deceleration Restarting after FR: RUN FRS ZST ZST ZST ST/ZST Il Multistage speed SPD I 005.0Hz OHz OHz 0.0 to x.0.0 Multistage speed SPD 2 005.0Hz OHz OHz 0.0 to 360.0 Multistage speed SPD 2 005.0Hz OHz OHz 0.0 to 360.0 Multistage speed SPD 15 005.0Hz OHz OHz 0.0 to 360.0		change frequency	DEC CHFr	000.0Hz	0.0Hz	0.0Hz	0മു.(രോ60.060.0	A9896
Signal selection			DEC LIN	E L	L	L	L/S	A98
1 speed setting Multistage speed SPD 2 005.0Hz 0Hz 0Hz 0.0 to 360.0	10	•	RUN FR	rs zsi	ZST	ZST	fST/ZST	b88
2 speed setting Multistage speed SPD 15 005.0Hz 0Hz 6H.? 6.0 to 360.d	11		SPD I 00	05. 0Hz	0Hz	0Hz	0.0 to x.0.0	A21
			SPD 2 00	05. 0H z	0Hz	0Hz	0.0 to 360.0	A22
		5	5		5	5	5	5
			·SPD 15 0	05.0Hz	0Hz	6н.?	6.0 to 360.d	A35

play	No.	Function name	Display co (Function n	ontent node 2)	ļ	d setting	Setting range	Digital operator
0	F-20		DCB SW	OFF	-FE OFF	-FU OFF	ON/OFF	A51
		selection DC braking frequency setting	DCB F	00.5Hz	0.5Hz	0.5Hz	0.0 to 10.0Hz	A52
		DC braking delay time setting	DCB WAT	T 0.0 s	0.0 s	0.0 s	0.0 to 5.0 s	A53
i		DC braking force setting	DCB V	000	0	0	0 to 100	A54
_		DC braking time setting	DCB T	00.0 s	0.0 s	0.0 s	0 to 60	A55
l	F-22	Allowable instantaneous power failure	IPS UVTIM	E 01.0 s	1.0 s	1.0 s	0.3 to 25.0	ь02
		Reclosing standby after instantaneous power failure recovered	IPS WAIT	010.0 s	1.0 s	1.0 s	0.3 to 100.0	ь03
		Instantaneous power failure restart selection	IPS POWR	ALM	ALM	ALM	ALM/FTP /RST/ZST	ь01
2	F-23	Electronic thermal characteristic selection	Е-ТНМ СН	AR SUB	CRT	CRT	CRT/SUB	b13
		Electronic thermal level setting	E-THM LVL	. 16.50A	Rated output current	Rated output current	50 to 120 % of Rated output current	ы2
}	F-24	Overload limit level setting	OLOAD LVI	L 20.63A	Rated output current *1.25(A)	Rated output current *1.25(A)	50 to 150 % of Rated output current	ь22
		Overload limit constant setting	OLOAD CON	IST 01.0	1.0	1.0	0.1 to 30.0	ь23
		Overload limit mode selection	OLOAD MO	DE ON	ON	ON	OFF/ON/CRT	b21
	F-25	Software lock selection	S-LOCK	MDI	MDI	MDI	MD0/MDI /MD2/MD3	631
5	F-26	Frequency lower limiter setting	LIMIT L 00	0.0Hz	0.0Hz	0.0Hz	0.0 to 360.0	A62
		Frequency upper limiter setting	LIMIT H OC	00.0Hz	0.0Hz	0.0Hz	0.0 to 360.0	A6I


play N	ا ۱۰۰۰	Function mm	Display c	ontent	Standard	setting	Setting	Digital
nec			(Function I		-FE	-ru	range	operato
6 F	-27	Jump frequency setting (1)	JUMP FI	000.0Hz	0Hz	0Hz	0.0 to 360	A63
		Jump frequency setting (2)	JUMP F2	000.0Hz	0Hz	0Hz	0.0 to 360	A65
	į	Jump frequency setting (3)	JUMP F3	000.0Hz	0H2	0Hz	0.0 to 360	A 67
		Jump frequency width setting (1)	JUMP W	00.5Hz	0.5Hz	0.5Hz	0.0 to 360	A64
		Jump frequency width setting (2)	JUMP W	2 00.5Hz	0.5Hz	0.5Hz	0.0 to 360	A66
		Jump frequency width setting (3)	JUMP W	00.5Hz	0.5Hz	0.5Hz	0.0 to 360	A68
7 F -	-28	STOP key validity selection during terminal running	STOP-SW	ON	ON	ON	ON/OFF	ъ87
8 F-	-31	External frequency start setting	IN EXS O	00.0Hz	0Hz	0Hz	0.0 to 360	A 11
		External frequency end setting	IN EXE 0	00.0Hz	0Hz	0Hz	0.0 ιο 360	A12
		External frequency start setting rate	IN EX%S	000%	0%	0%	0 ю 100	A13
		External frequency end setting rate	IN EX%E	100%	100%	100%	0 to 100	A14
		External frequency start point setting	IN LEVEL	0Hz	0Hz	0Hz	0Hz/EXS	A15
		Frequency command sampling setting	IN F-SAMP	8	8	8	1 to 8	A16
9 F-	-32	Arrival frequency setting for acceleration	ARV ACC	000.0Hz	0Hz	0Hz	0.0 to 360	C42
		Arrival frequency setting for deceleration	ARV DEC	000.0Hz	0 H∠	0Hz	0.0 το 360	C43
0 F-	33	Overload previous notice levelsetting	OV Load	16.50A	Raied current	Rated current	Rated current * 0-200%	C41
		Overdifferetial signal output level	OV PID	003.0%	3%	3%	0.0 το 100.0	C44
ı F-		Intelligent input terminal I setting	IN-TM I	FW	FW	FW	FW and 13 other terminals	C01
		Intelligent input terminal 2 setting	IN-TM 2	RV	RV	RV	RV and 13 other terminals	C02
	-	Intelligent input terminal 3 setting Intelligent input	IN-TM 3	CF1	CFI .	AT	CFI and 13 other terminals CF2 and 13	C03
		terminal 4 setting Intelligent input	IN-TM 5	RS RS	CF2 RS	USP	other terminals RS and 13	C04
		terminal 5 selling	114-11413	ΝO	N.S	кə	other terminals	co5

Display sc-	No.	Function name	Display content	Standar	d setting	Setting	Digital
quence:	, 10.	Tuttedon name	(Function mode 2)	-FE	-FU	range	operator
(21)	F-34	Input terminal 1 NO/NC setting	IN-TM O/C-1 NO	NO	NO	NO/NC	CII
		Input terminal 2 NO/NC setting	IN-TM O/C-2 NO	NO	NO	NO/NC	C12
		Input terminal 3 NO/NC setting	IN-TM O/C-3 NO	NO	NO	NO/NC	CI3
	Ĭ	Input terminal 4 NO/NC setting	IN-TM O/C-4 NO	NO	NC	NO/NC	CI4
		Input terminal 5 NO/NC setting	IN-TM O/C-5 NO	NO	NO	NO/NC	C15
22	F-35	Output terminal 11 setting	OUT-TM FAI	FA1	FAI	RUN/FA1/FA2 /OL/OD/AL	C21
		Output terminal 12 setting	OUT-TM 2 RUN	RUN	RUN	RUN/FAI/FA2 /OL/OD/AL	C22
		Alarm output terminal NO/NC setting	OUT-TM O/C-A NC	NC	NC	NO/NC	C33
		Output terminal 11 NO/NC setting	OUT-TM O/C-1 NO	NO	NO	NO/NC	C31
		Output terminal 12 NO/NC setting	OUT-TM O/C-2 NO	NO	NO	NO/NC	C32
23	F-36	Carrier frequency setting	CARRIER 12.0kHz	5.0kHz	5.0kHz	0.5 to 16.0kHz	b83
24	F-37	Monitor signal selection	MONITOR A-F	A-F	A-F	A-F/A/D-F	C23
25	F-38	Initial setting selection	INIT SEL EUR	EUR	USA	JPN/EUR/USA /(SP1)	b85
		Debug mode display selection	INIT DEBG OFF	OFF	OFF	ON/OFF	C91
		Digital operator rotation diction selection	INIT DOPE FWD	FWD	FWD	FWD/REV	F04
	ĺ	Initial mode selection	INIT MODE TRP	TRP	TRP	TRP/DATA	b84
26	F-43	PID function selection	PID SW OFF	OFF	OFF	OFF/ON	A71
		P gain setting	PID P 1.0	1.0	1.0	0.2 to 5.0	A72
]=	I gain setting	PID I 001.0 s	1.0	1.0	0.0 to 150	A73
	_	D gain setting	PID D 000.0	0.0	0.0	0.0 to 100.0	A I 4
	-	PID scale rate setting	PID CONV 01.00	1.00	1.00	0.01 to 99.9	A75
	-	Feedback PID selection	PID INPT CUR	CUR	CUR	CUR/VOL	Al6


	Contents		Display
Over-	The output current of the inverter is detected. When it exceeds the specified value, the output is turned off.	Constant	Drive
current protection	oxecous the opening relation, the darpartic termos on	Decel.	OC. Decel
protoction		Accel.	OC. Accel
		Other	
Overload protection	When a motor overload is detected by the electronic therm the output of the invener is cut off.	al function.	over. L
Over- voltage	When the DC bus voltage exceeds a certain level due to re energy from the motor, this protection function engages, a of invener is cut off.		Over. v
protection	This is an error display when the input voltage supplied texceeds the specified value.	OV. SRC	
EEPROM error	When the memory built in has problem by noise and exces ture rise. protective function works and output of inverter		EEPROM
Under- voltage protection	A decrease of the input voltage of an inverter results in im tion of the control circuit. It also generates motor heat and corque.	Under. V	
CPU error	Malfunction or abnormality on built in CPU and the output invener is cuts off.	CPU I	
External trip	An abnormality signal from external equipment cuts off the inverter. (When the external trip function is selected)	output of the	EXTERNAL
USP error	It indicates an error when power is turned on while the inv	erter is being	USP
Ground fault protection	The inverter is protected by detection of ground fault between inverter output and rhe motor upon power on. There may be the possibility of power module failure.	GND. Flt	
PTC error	When the resistance value of the external thermistor is too la equipment detects the abnormal condition of the thermisto off the output. (When PTC function is selected)	J PTC	
Thermal protection	When the temperature of the inverter module exceeds a de the output of invener is cut off.	OH FIN]	

Remote operator/Copy unit

Dimension (unit:mm)




L100 CABLE (Same as J 100)



NOTE 1: For connection to L100, use the accessory modularjack cable adaptor.

Digital operator (OPE-J)

Dimension (unit:mm)



1.

NOTE: Digital operator (OPE-J) is available for monitoring only, when it is connected wirh L100 inverter.(See 8-12 [b 89])
Only the [STOP] key on the OPE-J is available, the other keys do not function.

Copy unit function

Op	Operation example (Procedure to transfer the data of inverter A to B,C, and D inverters)						
Se- quence	Operation	Key	Operation result				
Į.	Set data is read out from the inverter A (It is stored into the memory).	READ	Inverter A Copy unit				
2	Turn off the power supply to inverter A and remove the cable.						
3	Connect the cable to inverter B and turn on the power.						
4	Copy data stored in the copy unit is written to inverter B.	(* I)	Daia copy				
5	Cut off the power supply to inverter B. (* 1)		Inverter B Inverter C Inverter D				
6 .	Perform the above processes from 3 to 5 sequentially for inverters C and D. That is, the same process as at for inverter B.						

	Operation example (Process to change and transfer to inverters B, C and D)					
1	Connect the cable and press the remote key. Change the data of the inverter with copy unit.	MON FUN STR	Data change Copy unit Inverter A			
2 to 6	Read out the data from inverter A (It is stored into the memory area of the copy unit). The following procedures are the same those of the operation I. Change the data setting first:	READ	Inverter A Copy unit			

*! When pressing any key or resetting the unit after the COPY key is pressed, be sure to wait for at least six seconds. (When any key is pressed, the unit is reset, or the power is turned off within six seconds, the data may not be copied.)

NOTE: Only the copy unit (**DRW-0A2**) is able to copy the data of **L100** series. The old type (**DRW-0A**) is not available for **L100** series. Do not **use** the copy unit (**DRW-OA**) for this function.

- NOTE 1: The following settings cannot be copied by the copy function. Note that the current set data is saved as it is.
 - . Monitor mode

 Trip history monitor

 (Counts of latest three alarms)
 - . Function mode F-25 Software lock setting
- NOTE 2: Do not copy the **setting** from the 200 V class to the **400** V class or from the **400** V class to the 200 V class. (When the setting is copied to a different voltage class by mistake. reset F-03 (motor input voltage setting).)
- NOTE 3: Do not copy the setting from the Japanese version to the European or American version or from the European or American version to the Japanese version.
- NOTE 4: When the V/f control setting data is copied from a different capacity (for example, copied from L100-004NFE to L100-022NFE), change F-23,F-24 and F-33 in relation with the current value of the applied motor.

14. SERVICE

When inquiring about **inverter trouble**, please be ready to inform the shop where you purchased your unit or following address if you are in Europe.

Hitachi Europe **GmbH** Am **seestern** 18 (**Euro.center**) 40547 Dusseldorf. Germany

TEL: 0211-5283-0 FAX: 021 1-5283-649

- (i) Type
- (2) Purchased date
- (3) Manufacturing No. (MFG. No.)
- (4) Malfunction symptoms

If the contents are unclear due to an old nameplate, give only the clear items. To reduce the non-operation time. it is recommended IO stock a spare invener.

Warranty

The warranty period under normal installation and handling conditions shall be one (I) year after the date of delivery The warranty shall cover the repair of only the invener to be delivered.

- I. Service in the following cases, even within the warranty period, shall be charged to the purchaser.
 - (a) Malfunction or damage caused by misoperarion or remodelling or improper repair
 - (b) Malfunction or damage caused by a drop after purchase and transportation
 - (c) Malfunction or damage caused by fire. earthquake, flood, thunderbolt. or other natural calamities. pollution or abnormal voltage.
- 2. When service is required for the **product at** your **worksite**, all expenses associated **with** field repair shall be charged to the purchaser.
- 3. Always keep it handy. Please do not loose it. We are sorry but this manual can **not** be re-issued.

Appendix 1 L100 series data setting values

L100 series inverters provide many functions and their parameters can be set by the user. It is recommended to record the parameters that have been set by the user, in order to speed the investigation and repair in the event of a failure.

Invertermodel	L100	This information is written on the
		specification label located on the right
MFG. No.		side of the inverter

For the digital operator

Display sequence	Function name	Standar	d setting	Set value
		-FE	-FU	
F01	Output frequency setting	0.0	0.0	
F02	Acceleration 1	IO.0	10.0	
F03	Deceleration I	10.0	10.0	
F04	Running direction setting	00	00	

(2) Extention Function Mode

(I)Extended function mode A group

Parameter display	Function name	Initialization (Europe)	Initialization (USA)	Sct value
A01	Frequency distination setting	01	01	
A02	Run command distination setting	01	01	
A03	Base frequency selling	50.0	60.0	
A04	Maximum frequency setting	50.0	60.0	. =
All	External frequency setting start	0	0	
AI2	External frequency setting End	0	0	
A13	External frequency setting start rate	0	0	
A14	External frequency setting end rate	100	001	
A15	External frequency start pattern setting	01	01	
A16	Time constant of the filter of analog input setting	8	8	
A20-A35	Multispeed frequency setting	All data are 0.0Hz.	Ali data are 0.0Hz.	:
A38	Jogging frequency setting	1.0	1.0	
A39	Stop mode of jogging	00	00	
A41	Selection of method of torque boost	0	0	
A42	Value of manual torque boost setting	11	11	
A43	Manual torque boost frequency adjustment	10.0	10.0	
A44	V/F characteristic setting	00	00	
A45 I	/-Cain setting	100	100	
ASI	Selection of DC braking operation	00	00	
A52	DC braking frequency setting	0.5	0.5	
A53	DC braking waitingtime setting	0.0	0.0	
A54	DC baking force setting	0	0	
A55	DC braking time setting	0.0	0.0	
A61	Frequency upper limiter setting	0.0	0.0	

Parameter Display	Function name	Initialization (Europe)	Initialization (USA)	Set value
A62	Frequency lower limiter setting	0.0	0.0	
A63,A65	Jump frequency selling	0.0	0.0	
A64,A66 ,A68	Jump frequency width setting	0.5	0.5	
A71	Selection of PID control	00	0 0	
AI2	P(proportion) gain setting	1.0	1.0	
A73	l(Integral) gain setting	1.0	1.0	
A14	D(Differential) gain setting	0.0	0.0	
A75	Scale conversion of PID control setting	1.00	1.00	
A76	Feedback signal destination setting	00	00	
A81	Selection of AVR function	02	02	
A82	Selection of voltage of AVR function for the motor	2301400	230/460	
A92	Second acceleration time setting	IS.0	15.0	
A93	Second Deceleration time setting	IS.0	15.0	
A94	Selection of method to use second acceleration I deceleration (acc2/dec2)	00	00	
A95	Changed frequency from acc1 to acc2 setting	0.0	0.0	
A96	Changed frequency from dcc I to dec2 setting	0.0	0.0	
A91	Pattern of acceleration setting	0 0	I 00 I	
A98	Pattern of deceleration setting	00	'00	

(2) Extended function mode of B group

Parameter Function name display		Initialization (Europe)	Initialization (USA)	Set value
ь01	Selection of restart mode	00	00	
ь02	Allowable undervoltage power failure time setting	1.0	1.0	
ь03	Reclosing standby time after under voltage power failure recovered setting	1.0	1.0	
b12	Level of electronic thermal selling	Rated current for each inverter	Rated current for each inverter	
b13	Selection of electronic thermal characteristic	01	01	
ь21	Selection of overload restriction operation mode	01	10	
ь22	Level of overload restriction setting	Rated current	Rated current	
		* 1.25 for	• 1.25 for	
		each inverter	eachinverter	
b23	Rate of deceleration al overload restriction	1.0	1.0	
b31	Selection of software lock mode	01	01	
b32	Reactive current setting	Rated current	Rated current	
		* 0.58	* 0.58	
b81	Analog meter adjustment	80	80	
b82	Start frequency adjustment	0.5	0.5	
bg3	Carrier frequency selling (kHz)	5.0	5.0	
b84	Selection data initialization or clear of trip history	90	00	
b85	Selection of initialized data	10	0 2	
bg6	Frequency convened value setting	1.0	1.0	
b87	Selection of STOP key ON/OFF	00	00	
b88	Selection of operation at FRS signal canceled	00	al	
bg9	Selection of OPE-J monitor	01	01	

(3)Extended function of C group

These function have relation with terminal.

Parameter display	Function name	Initialization (Europe)	Initialization (USA)	Set value	
6	Function of terminal 1 setting	00	00		
C 022	Function of terminal 2 setting	01	01		
œ	Function of terminal 3 setting	02	16		
CD4	Function of terminal 4 setting	03	13		
COS	Function of terminal 5 setting	18	18		
CH	Condition of terminal 1 setting	00	00		
Cl2	Condition of terminal 2 setting	00	00		
Cl3	Condition of terminal 3 setting	00	00 00		
Cl4	Condition of terminal 4 setting	00	01		
C15	Condition of terminal 5 setting	00	00		
Q 1	Function of terminal 11 setting	01	01 01		
C22	Function of terminal 12 setting	00	00		
C23	Function of FM terminal setting	00	00		
C31	Condition of terminal 11 setting	00	00		
C3 2	Condition of terminal 12 setting	00	00		
C33	Condition of terminal AL setting	01	01		
C41	Level of overload signal setting	Rated current of each inverter	Rated current of each inverter		
C42	Arrival frequency setting for acceleration	0.0	0.0		
C43	Arrival frequency setting for deceleration	0.0	0.0 0.0		
C44	Level of PID deviation signal setting	3.0	3.0		

o er i

Appendix 2 L100 series data setting values (For the remote operator)

L100 series inverters provide many functions and their parameters can be set by the user. It is recommended to record the parameters that have been set by the user. in order to speed the investigation and repair in the event of a failure.

Inverter model	L100	This information is written on the
		nameplate located on the
MFG. No.		side cover of the inverter.

Monitor mode

)isplay equence	Monitor name	Display content	Set value
1	Frequency setting and output frequency	FS00.0 000.0Hz	
	Multistage-speed setting and output frequency	: 1S 005.00.0Hz	
,			
	Acceleration time setting	15S040 0 0.0Hz	·
3	Deceleration time setting	DEC: 0010.0S	···
4	Frequency setting command	F-SET-SELECT TRM	
	Operation command method	F/R-SELECT TRM	
6	Frequency converted value setting and converted value monitor	/Hz01.0 0.00	<u>.</u> . <u></u>
7	Output current display	Im 0.0 A 0.0%	· · · · · · · · · · · · · · · · · · ·
8	Reactive current setting	10 A	
9	Manual torque boost adjustment	V-Boost Code<11>	
10	Boost F setting	V-Boost F 10.0%	
11	Torque boost mode selection	V-Boost Mode 0	
12	Output voltage gain adjustment	V-Gain 100%	
13	Jogging frequency adjustment	Jogging 1.00Hz	
14	Jogging mode selection	Jog Mode 00	
15	Analog meter adjustment	ADJ 80	· · · · · · · · · · · · · · · · ·

)isplay equence	Monitor name	Display content	Set value
16	Panel display selection	PANEL d01	
17	Terminal monitor	TERM LLL LLLLL	
18	Alarm display	ERR1 #	-
	Trip monitor	ERRI OVER. V	
		ERRI 31.0Hz ERRI 12.5A 1	
		ERR1 787.0Vdc	
	Total alarm count	ERR1 RUN 000002H	
19		ERROR COUNT 25	-
20	Trip history monitor	ERR2 #	
	Last trip contents	ERR2 OC.Accel	
		(ERR2 \$.0Hz	
		[ERR2 20.1 A	
		ERR2 560.0 Vdc	
		ERR2 RUN 000002H	
	Contents of last tip but one	ERR3 #	
		ERR3 EXTERNAL	-
		ERR3 5.0Hz	
		ERR3 20.1 A	
		ERR3 560.0 Vdc	
		ERR3_RUN 000001H	
		!	

Function mode

NO.		Display (Functio	/ content n mode 2	Standard wing) FE FU		Set value
3.00	Base frequency setting	F-BASE	0060 Hz	50Hz	60Hz	
- 0	setting	F-max.	0060 Hz	50Hz	60Hz	
	Start frequency adjustment	Fmin.	00.5 Hz	0.5	0.5	
F-03	setting	AVR AC	200 V	230V/400V	230V/460V	
_ _	AVR function for deceleration	AVR MO	DE DOFF	DOFF	DOFF	
04	setting	CONTROL	. vc	VC	VC	
:-06	setting	ACC I	0010.0 s	10.0 s	10.0 s	
	2-stage acceleration selection	ACC CHO	G TM	TM	TM	
	Acceleration time 2 setting Acceleration time	ACC 2	0015.0 s	15.00 s	15.00 s	
	change frequency setting	ACC CHF	r 000.0Hz	0.0Hz	0.0Hz	
_	Pattern selection for acceleration	ACC LIN	NE L	Ĺ	L	
-07	Deceleration time I setting	DEC I	0010.0 s	10.0s	10.0 s	
	Deceleration time 2 setting	DEC 2	0015.0 s	015.0 s	015.0 s	
	Deceleration time change frequency setting	DEC CHF	r 000.0Hz	0.0Hz	0.0Hz	
	Pattern selection for deceleration	r DEC L	INE L	L	L	
-10	Restarting after FF signal selection	RS RUN F	RS ZST	ZST	ZST	
-11	Multistage speed [SPD I	005.0Hz	0Hz	0Hz	
''	Multistage speed 2		005.0Hz	0Hz	0Hz	
	Multistage speed 3	SPD 3	005.0Hz	0Hz	0Hz	
	Multistage speed 4		005.0Hz	0Hz	0Hz	
	Multistage speed 5		005.0Hz	0Hz	0Hz	
	Multistage speed 6	·	005.0Hz	0Hz	0Hz	
	Multistage speed 7		005.0Hz	0Hz	0Hz	
	Multistage speed 8	SPD 8	005.0Hz	0Hz	OHz I	
	Multistage speed 9	SPD 9		0Hz	0Hz	
	Multistage speed 10	SPD 10 (0Hz	0Hz	
	Multistage speed 11	SPD 110	005.0Hz	0Hz	0Hz	•
	Multistage speed 12	SPD 12 (0Hz	OHz	
	Multistage speed 13	SPD 13 (0Hz	0Hz	
	Multistage speed 14	SPD 14 (OHz	0Hz	
	Multistage speed 15	SPD 15 (0Hz	0112	

Display		•	Display content	Standard	d setting	Set value
se. quence	No.	Function name	Display content (Function mode 2)	-FE	-FU	Set value
10	F-20	DC braking selection	DCB SW OFF	OFF	OFF	
		DC braking frequency setting	DCB F 00.5Hz	0.5Hz	0.5Hz	
		DC braking delay time setting	DCB WAIT 0.0 s	0.0 s	0.0 s	
		DC braking force setting	DCB V 000	0	0	
		DC braking time setting	DCB T 00.0 s	0.0 s	0.0 s	
11	F-22	Allowable instantaneous power failure	IPS UVTIME 1.0 s	1.0 s	1.0 s	
		Reclosing standby after instantaneous power failure recovered	IPS WAIT 010.0	1.0 s	1.0 s	
		Instantaneous power failure restart selection	IPS POWR ALM	ALM	ALM	
12	F-23	Electronic thermal characteristic selection	E-THM CHAR SUI	CRT	CRT	
		Electronic thermal level setting	E-THM LVL 16.50A	Rated output current	Rated output current	
13	F-24	Overload limit level setting	OLOAD LVL 20.63	Rated output current *1.25(A)	Rated output current *1.25(A)	
		Overload limit constant setting	OLOAD CONST 01.	1.0	1.0	
		Overload limit mode selection	OLOAD MODE ON		ON	
		Software lock selection	S-LOCK MD	MDI	MDI	
15 F	-26 F	requency lower limiter setting	LIMIT L 000.0Hz	0.0Hz	0.0Hz	
		Frequency upper limiter selling	LIMIT H 000.0Hz	0.0Hz	0.0Hz	

No.	Function name	Display content	Standare	d setting	Set value
uence		(Function mode 2)	-łŁ	-FU	
F-27	Jump frequency setting (1)	JUMP FI 000.0Hz	0Hz	0Hz	
	Jump frequency setting (2)	JUMP F2 000.0Hz	0Hz	0Hz	
	Jump frequency setting (3)	JUMP F3 000.0Hz	0Hz	0Hz	
	Jump frequency width setting (1)	JUMP WI 00.5Hz	0.5Hz	0.5Hz	
	Jump frequency width setting (2)	JUMP W2 00.5Hz	0.5Hz	0.5 Hz	
	Jump frequency width setting (3)	JUMP W3 00.5Hz	0.5Hz	0.5Hz	
F-28	STOP key validity selection during terminal running	STOP-SW ON	ON	ON	
F-31	External frequency start setting	IN EXS 000.0Hz.	0Hz	0Hz	
	External frequency end setting	IN EXE 000.0Hz	0Hz	0Hz	
	start setting rate	IN EX%S 000%	0%	0%	
	end setting rate	IN EX%E 100%	100%	100%	·
	start point setting		OHz	0Hz	····
_	sampling setting	IN F SAMP 8	8	8	
F-32	Arrival frequency setting for acceleration	ARV ACC 000.0Hz	0Hz	0Hz	
	Arrival frequency setting for deceleration	ARV DEC 000.0Hz	0Hz	0Hz	
F-33	Overload previous notice levelsetting	O V Load 16.50A	Rated current	Rated current	
	Overdifferetial signal output level	OV PID 3.0%	3%	3%	
	terminal I setting	IN-TM I FW	FW	FW	
	terminal 2 setting	IN-TM 2 RV	RV	RV	
	terminal 3 setting			AT	
-	terminal 4 setting Intelligent input				
-	terminal 5 setting	114 - 1141 3 113		100	
	F-32	setting (1) Jump frequency setting (2) Jump frequency setting (3) Jump frequency width setting (1) Jump frequency width setting (2) Jump frequency width setting (3) F-28 STOP key validity selection during terminal running External frequency start setting External frequency end setting External frequency start setting rate External frequency start setting rate External frequency start setting Frequency end setting Frequency start point setting Frequency command sampling setting Frequency setting Frequency setting for acceleration Arrival frequency setting for deceleration Overload previous notice levelsetting Overdifferetial signal output level F-34 Intelligent input terminal 1 setting Intelligent input terminal 2 setting Intelligent input terminal 3 setting Intelligent input terminal 4 setting Intelligent input	setting (1) Jump frequency setting (2) Jump frequency setting (3) Jump frequency width setting (1) Jump frequency width setting (2) Jump frequency width setting (2) Jump frequency width setting (3) F-28 STOP key validity selection during terminal running External frequency start setting External frequency end setting rate External frequency start setting rate External frequency end setting rate External frequency start setting rate External frequency start setting rate External frequency IN EX%S 000% start point setting Frequency command sampling setting Frequency command setting Frequency command sampling setting Frequency command setting Frequency command sampling setting Frequency command setting Frequency command sampling setting Frequency command setting Frequency command setting Frequency command setting Frequency command setting Frequency command setting setting setting setting setti	Jump frequency setting (1) Jump frequency setting (2) Jump frequency setting (3) Jump frequency setting (3) Jump frequency width setting (1) Jump frequency width setting (2) Jump frequency width setting (2) Jump frequency width setting (3) Jump frequency width setting (3) Jump frequency width setting (3) Jump frequency width setting (3) Jump frequency width setting (3) Jump frequency width setting (3) Jump frequency width setting (3) Jump frequency width setting (3) Jump frequency width setting (3) Jump frequency width setting (3) STOP-SW ON ON ON STOP-SW ON ON ON External frequency in EXS 000.0Hz OHz on setting in External frequency in EXS 000.0Hz OHz on setting in External frequency in EX\$ External frequency in EX\$	F-27 Jump frequency setting (1) Jump frequency setting (2) Jump frequency setting (3) Jump frequency JUMP F3 000.0Hz 0Hz 0Hz 0Hz setting (3) Jump frequency width setting (1) Jump frequency width setting (2) Jump frequency width setting (3) Jump frequency width setting (3) Jump frequency width setting (3) F-28 STOP key validity selection during terminal running F-28 STOP key validity state setting at terminal running F-29 External frequency state setting at External frequency state setting at External frequency state setting at External frequency state setting rate External frequency state setting at External frequency state setting are External frequency state setting are External frequency state setting are External frequency state setting are External frequency state point setting Frequency command sampling setting Frequency command sampling setting F-32 Arrival frequency ARV ACC 000.0Hz 0Hz 0Hz 0Hz setting for acceleration Arrival frequency setting for acceleration Arrival frequency ARV DEC 000.0Hz 0Hz 0Hz 0Hz setting for acceleration Arrival frequency Setting for acceleration Arrival frequency ARV DEC 000.0Hz 0Hz 0Hz 0Hz 10Hz 10Hz 10Hz 10Hz 10Hz

ola			Disales	ontent Standard settin		
	0.	Function name	Display content (Function mode 2)			Set value
<u>-</u>		Input terminal I	IN-TM 0/C-1 NO	-FE NO	.FU NO	
1)	34	NO/NC setting				
		Input terminal 2 NO/NC setting	IN-TM 0/C-1 NO	NO	NO	
		Input terminal 3 NO/NC setting	IN-TM 0/C-I NO	N O	NO	
		Input terminal 4 NO/NC setting	IN-TM 0/C-1 NO	NO	NC	
		Input terminal 5 NO/NC setting	IN-TM O/C-I NO	NO	NO	
. 1	35	Output terminal I I setting	OUT-TM I FAI	FAI	FAI	
		Output terminal li! setting	OUT-TM 2 RUN	RUN	RUN	
		Alarm output terminal NO/NC setting	OUT-TM O/C-A NC	NC	NC	
		Output terminal I I NO/NC setting	OUT-TM 0/C-1 N(NO	NO	
		Output terminal 12 NO/NC selling	OUT-TM O/C-2 N(NO	NO	
3	-36	Carrier frequency setting	CARRIER 12.0kH:	5.0kHz	5.0kHz	
1	37	Monitor signal selection	MONITOR A-F	A-F	A-F	
5	38	Initial setting selection	IN!T SEL EUR	EUR	USA	
		Debug mode display sele ction	INIT DEBUG OFF	OFF	OFF	
		Digital operator rotation direction selection	INIT DOPE FWC	FWD	FWD	
		Initial mode selection	INIT MODE TRP	TRP	TRP	
6 43	43	PID function selection	PID SW OFF	OFF	OFF	
		P gain setting	PID P 1.0	1.0	1.0	
		I gain setting	PID I 001.0 s	1.0	1.0	
		D gain setting	PID D 000.0	0.0	0.0	
		PID scale rate setting	PID CONV 01.00	1.00	1.00	,
		Feedback PID selection	PID INPT CUR	CUR	CUR	

Appendix 3 Initialization

If it is necessary to initialize the L100 inverter because of some reason, operate, the following way.

At first ,confirm the model name on specification label.

```
L100 - #### FE ----> Europen virsion
L100 - #### FU ---> The United States virsion
```

Select the initialized data by [b 85]

```
European virsion ----> set the [ 01]
The United Stares virsion ----> set the [ 02]
```

Initialization by [b 84]


- I) Whether it is data initialization or trip history clear.

 Sclect the Data initialization ---> [01]
- 2) (on the operator arc pressed at same time.
- 3) And then continue this condition and press the (state) key.
- 4) Wait 2 seconds holding the key (i) the display will blink " d 00".
- 5) The indication is blinking, release the all keys
- 6) Then the equipment starts the initialize operation
- 7) When the initialize operation is completed, the display indicates " 00". (Output frequency monitor).

NOTE I) Do not rum off the power until the initialize operation is completed.

NOTE 2) The initialize operation can not be performed by the remote operator, the copy unit and OPE-J.

Appendix 4 Capacitor Life Curve



* When the inverter is stored in the cabinet, the ambient temperature is the temperature in the cabinet.

0

*

HITACHI INVERTER

L300P SERIES


INSTRUCTION MANUAL

Three phase input 200/400V class

After reading this manual, keep it at hand for future reference.

NB601AX

Hitachi, Ltd.
Tokyo Japan



1.Function table (Page 4-7)

Function Mode

Code	Function name	Setting range	mitial data -FE/-FU	Setting on run	Change mode on run	Page
6004	Instantaneous power- failure/under-voltage trip	00(invalid/01(valid)/ 02(invalid during stop and deceleration by stop command)	00	•	1	4-34


2.Instantaneous power failure lunder-voltage (Page4-34)

Set item	Function code	Data	Description
Instantaneous power	6004	00 01	Invalid: Trip isn't caused and alarm isn't output. Valid: Trip is cause and alarm is output.
failure/under-voltage trip during stop	8004	02	Invalid Trip isn't caused and alarm isn't output during stop and deceleration by stop command.

When using control power supply terminal Ro∼To and connecting DC voltage (P-N) to Ro∼To, an under-voltage may be detected at power off and give trip signal. If this may cause any problem to your system, set data in 00 or 02.

Alarm output at an instantaneous power feiture and under-voltage during standstill.

Alarm signal performance when connecting DC voltage (P-N) to Ro-To terminal.



3. Carrier Frequency (Page 4-18)

Correcting about carrier frequency and addition of derating data about 37kW or more.

Voltage class	200	V class	400V class		
Contents, (kW)	Maximum carrier frequency (kHz)	Derating on carrier frequency = 12kHz	Maximum carrier frequency (kHz)	Derating on carrier frequency = 12kHz	
11	12	100%	12	100%	
15	12	100%	12	100%	
18.5	10	90%	12	100%	
22	4	80%	12	100%	
30	3	70%	8 .	90%	
37	8	80%	10	80%	
45 ·	10	95%	10	95%	
55	6	75%	10	95%	

CAUTION: Be sure to keep the above-mentioned table. Otherwise, there is a danger of inverter unit breakage.

Precautions for EMC (Electromagnetic Compatibility)

You are required to safety the EMC directive (89/336/EEC) when using an L300P inverter in a European country. To safety the EMC directive and to comply with standard, follows the checklist below

⚠WARNING: This equipment should be installed, adjusted, and serviced by qualifyed personal familiar with construction and operation of the equipment and the hazards involved. Failure to observe this precausion could result in bodily injury.

- I. The power supply to L300P inverter must meet these specifications:
 - a. Voltage fluctuation +/-IO% or less.
 - b. Voltage imbalance +/-3% or less.
 - c. Frequency variation +I-4% or less.
 - d. Voltage distortion THD = 10% or less.

2. Installation measure:

a. Use a filter designed for L300P inverter.

3. Wiring

- a. Shielded wire (screened cable) is required for motor wiring, and the length must be less than 20 meters.
- b. The carrier frequency setting must be less than 3 kHz to satisfy EMC requirements.
- c. Separate the main circuit from the signal/process circuit wiring.
- 4. Environmental conditions -when using a filter, follow these guidelines:
 - a. Ambient temperature: -10 +40 degrees.
 - b. Humidity: 20 to 90% RH (non-condensing)
 - c. Vibration: 5.9 m/sec² (0.6 G) 10 55 Hz.
 - d. Location: 1000meters or less altitude, indoors (no corrosive gas or dust)

L300P Instruction Manual Correction

Please exchange [6.1 Standard specification list] m page 6.1 to the following list.

NBM601X-11 NBM601AX-11 NBM601BX-11

6.1 Standard specification list

					1	200V		1	1	T	ļ		T . 24	400V		1	1.25	.,
Inverter Model			L300P-	L300P-	L300P	L300P-	L300F	L300P-	L300P-	L300P-	L300P-	L300P	1300P	L300P-	1,300P- 300HF	1.300P-	L300P-	L300P
	sction struct	ura en	110LF	150LF	185LF	220LF	300LF	(370LF	450LF	550LF (IP200)	(110HF (EMA1)	150HF	185HF	220HF	30048-	370HF	450HF	550HF
	Applicade	Motor 4P	11	15	18.5	22	30	37	45	55	11	15	18.5	22	30	37	45	55
	(nots2)	200v/	15.2	20.0	25.2	29.4	39.1	48.4	58.5	72.7	15.2	20.0	25.6	29.7	39.4	48.4	58.8	72.7
	meting ge(kVA)	400V 240V/	18.2	24.1	30.3	36.3	48.9	58.1	70.2	87.2	18.2	24.1	30.7	36.7	47.3	58.1	70.1	87.2
Rated input stemating voltage		Three-pi	ms o 200-24	√ (~10%)	50Hz/80Hz		.1	1		Three-pt	ese 380-48	DV (+-10%)	50Hz/80Hz	•		·	·	
Rated output voltage (note3)		Three pi	nes o 200-24	OV (This cor	responds to	receiving v	oltage.)			Three-ph	me 380-48	OV (This cor	responds to	receiving v	pitage.)			
Reted output current (A) Control system			44	44 58 73 85 113 140 169 210 22 29 37 43 57 70 85 105 Sine-wave modulation PWM system.														
_	ut frequenc	y range	0.1-400F		n PWM sys	tem.									-			
	UBNCY BOOL	пасу	Digital co	rnmend +/-C	.01% for M	ex. frequenc	y, anelog fr	squency +/-(2%/25+-10	(C)								
_	uency resol			ding 0.01Hb						_				,			7	
	ge/frequence actors ic	Ŋ	V/f option	veriable, V7	control. (co	vristant torqu	re, reduced	torque)										
	load curren	t rade	120% fo	60 seconds	, 150% for (5.5second												
	ileration/ leration time		0.01-3,6)Oseconds (traight or S	Curve on a	oceleration,	deceleration	is optional (ating individ	iumly), 2" as	justable set	ting is possi	ble.				
Regenerative Control (short duration) (notes)			BRD crout builden (Discharge main- Regenerative unit is required. (Discharge resis- tende is required. (Discharge resis- tende is required.)										d.					
(notes) DC Braking		0		ng and dece power, time				operates un	der operation	sating freq	uency. Or in	verter opera	ins with exte	rmal input		, ,		
1	Operator Setting by				∛ kays													
ł	Freq- Estimal control							as standard ance 10k oh			tance 100 o	hm)						
	,	Signal External	1.	th RS485 c														
		Dometor	Run/Stop	Run/Stop (forward changes with code) Forward Run/Stop (1a connect), reverse command is impossible on assigning of seminal (selection of 1a, 1b is possible), input of 3 wires is possible.														
	Runst	External agree	Forward															
Op Esternal port			Setting with RS485.															
		Reverse USP funt 3 wire di	tion (USP), rection selec	RV), multi-sp commercial ston (F/R), P	change (CS 1D selection	S),satiwere i velidinvelia	ging (JG), a lock (SFT), a I (PID), PID -SF7), overlo	nalog input Integrating n	voltage / cum seat (PIDC),	rent / select (remote cont	AT), resetin rotup tunck	werter (RS),	3 wire run (STA),3 wire	kasap (STP)		,	
Ī	Thermistor	input	1 termina		 (/-				•									
,	Intelligent of	utput						y salection a		cv. PID over	r-deviation)				.			
Intelligent monitor output terminal			(selection from during numming, on arrivel with constant speed, over setting frequency, PED over-deviation) Analog voltage output, analog current output, pulse line output															
	ny monitor rfunction		V/f free s Starting f	sting (5 pair	s), Upper/	lower freque	ency imiter,	elue, trip his Frequency nic thermal f	ump, Curve	adjustrable s	peed, Manu	ed torous bo	costlevel/8	raking point				
Center frequency range Protection function Frequency temperature //Preservation temperature (notel) /humidy		0.5-12 kb	0.5-12 ld-k															
			Over-current, over-voltage, under-voltage, electronic thermal level, abnormal trouble, ground fault current on starting, instantaneous stop, USP error, open-phase error, control resistor overload, CT error, expensel trip, communication error															
		ature Aston ature	-10 to 40	degrees (no	te7) / -20 to	65 degrees	/ 20 to 90%	RH (installe	d with no de	w condens a	tion)							
5 5	Vibratio	n (note7)			S (0.8G), 1				/S (0.3G),			5.9m²/	S (0.6G), 1	0-55Hz		2.94m	¹ /S (0.3G),	10- 65) tz
_	Utting p	lace		00m above C14 version		idoors (insta	fied away fi	OM COTOSM			BL	C14	No ess		 	Die Ac	Necil Ba	VD0 25
	re re		Remote		y unit, cable			ing resistor,	NSELL 8.5			C14 version eactor, D.C.		C Mairs fit	er, higher he		NSELL 8.5	1 KO 270.
								n) (nota9)										

(Note 1) Protective system bases on JME1030.

(Note 2) Applicable motor indicates HITACH three-phase motor. When you use other motor, set so that the motor current doesn't asseed the relatioument of the inventer.

(Note 3) Output voltage will reduce when the power voltage is reduced. (Except when AVR function is selected.)

(Note 4) When you operate motor over 50/60Hz, inquire about the allowable max, revolution time of motor etc. from motor manufacturer.

(Note 5) Braking resistance isn't installed in the inverter. When the inverter requires a high regenerative torque, use optional braking resistance and regenerative braking unit.

(Note 5) Protective temperature is temperature during transportation.

(Note 7) This bases on the test methods of JIS C0911(1984).

(Note 8) When the inverter is used in a place with dust, we recommend the optional vernish coating specification. Before it is required.

(Note 9) When you use cable for remote operation, please remove connector. Please reter to 1.3 Appearance.

(Note) Insulation distance is based on UL, CE standard.

SAFETY

For the Best Results with **L300P** Series **inverter**, read this manual and all of the warning sign attached to the **inverter** carefully before installing and operating it, and follow the instructions exactly. Keep this manual handy for your quick reference.

Definitions and Symbols

A safety instruction (message) is given with a hazard alert symbol and a signal word;

WARNING or **CAUTION.** Each signal word has the following meaning throughout this manual.



This symbol means hazardous high voltage. It used to call your attention to items or operations that could be dangerous to your and other persons operating this equipment.

Read these message and follow these instructions carefully.



This is the "Safety Alert Symbol:.' This symbol is used to call your attention to items or operations that could be dangerous to your or other persons operating this equipment. Read these messages and follow these instructions carefully.

WARNING

WARNING

Indicates a potentially hazardous situation which, if not avoided, can result in serious injury or death.

COUTION

CAUTION

Indicates a potentially hazardous situation which, if not avoided, can result in minor to moderate injury, or serious damage of product.

The matters described under Aution may, if not avoided, lead to serious results depending on the **situation. Important** matters are described in CAUTION (as well as WARNING), so be sure to observe them.

NOTE

NOTE

Notes indicate an area or subject of special merit, emphasizing either the product's capabilities or common errors in operation or maintenance.



HAZARDOUS HIGH VOLTAGE

Motor control equipment and electronic controllers are connected to hazardous line voltages. When servicing drives and electronic controllers, there might be exposed components with cases or protrusions at or above line potential. Extreme care should be taken to product against shock.

Stand on an insulating pad and make it a habit to use only one hand when checking components. Always work with another person in case an emergency occurs. Disconnect power before checking controllers or performing maintenance. Be sure equipment is properly grounded. Wear safety glasses. whenever working on an electronic controllers or rotating electrical equipment.

WARNING: .This is equipment should be installed, adjusted and serviced by qualified electrical maintenance personal familiar with the construction and operation of the equipment and the hazards involved. Failure to observe this precaution could results in bodily injury.

WARNING: The user is responsible for ensuring that all driven machinery, drive train mechanism not supplied by Hitachi, Ltd., and process line material are capable of safe operation at an applied frequency of 150% of the maximum selected frequency range to the AC motor. Failure to do so can result in destruction of equipment and injury to personnel should a single point failure occur.

EXARNING: For protection, install a leak breaker type with a high frequency circuit capable of large currents to avoid an unnecessary operation. The ground faults **protection** circuit is not designed to protect personal injury.

NARNING: HAZARD OF ELECTRICAL SHOCK. DISCONNECT INCOMING POWER BEFORE WORKING ON THIS CONTROL.

NARNING: SEPARATE MOTOR OVERCURRENT, OVERLOAD AND OVERHEATING PROTECTION IS REQUIRED TO BE PROVIDED IN ACCORDANCE WITH THE SAFETY CODES REQUIRED BY JURISDICTIONAL AUTHORITIES.

 $\hat{\Gamma}$ **CAUTION**: These instructions should be read and clearly understood before working on L300P series equipment.

CAUTION: Proper ground&disconnecting devices and other safety devices and their location are the responsibility of the user and are not provided by Hitachi, Ltd.

↑ CAUTION: Be sure to connect a motor thermal switch or overload devices to the L300P series controller to assure that inverter will shut down in the event of an overload or an overheated motor.

A CAUTION: DANGEROUS VOLTAGE EXISTS UNTIL CHARGE LIGHT IS OFF.

⚠ CAUTION: Rotating shafts and above ground electrical potentials can be hazardous. Therefore, it is strongly recommended that all electrical work conform to the National Electrical Codes and local regulations. Installation, alignment and maintenance should be performed only by qualified personnel. Factory recommended test procedures, included in the instruction manual, should be followed. Always disconnect electrical power before working on the unit.

NOTE: POLLUTION DEGREE 2

The inverter must be used environment of the degree 2.

Typcal constructions that reduce the possibility of conductive pollution are;

- 1) The use of an un-ventilated enclosure
- 2) The use of a **filtered** ventilatied enclosure when the ventilation is fan forced that is, ventilation is accomplished by one or more blowers within the enclosure that provide a positive intake and exhaust.

R&i&n History Table

ĩ

Ê

No.	Revision Contents	The Date of Issue	Operation Manual No.
1	Initial Release of Manual NB601AX	Sep. 1999	NB601AX

1. Instrallation and Wiring

⚠WARNING Do not remove the rubber bush. Due to the possibility that a wire may be damaged, shorted or may have a ground fault with the edge of the wiring p.2-1 cover. Be sure to ground the unit. Otherwise, there is a danger of electric shock and/or fire. p.2-5 Otherwise. there is a danger of electric shock and/or injury. Only qualified personnel shall carry out wiring work. p.2-5 Otherwise, there is a danger of electric shock and/or tire. Implement wiring after checking that the power supply is off. p.2-5Otherwise, there is a danger of electric shock and/or injury. Be sure to implement wiring after installing the body. p.2-5 Otherwise, there is a danger of electric shock and/or injury.

⚠ CAUTION	
Install using non-combustible materials (metal etc.) It is a fire risk.	p.2-1
Do not install combustible materials nearby. It is a fire risk .	 p.2-1
Do not carry unit by top cover. always carry by supporting base of unit. There is a risk of falling and injury.	p.2-1
Do not allow substance of cutting waste, sputtering of welding, waste of iron, wire and dust etc. to come into contact with the unit. It is a fire risk.	p.2-1
Make sure the surface the unit is installed onto can support the weight of the unit comfortably. There is a risk of falling and injury.	 p.2-1

riangle CAUTION

Do not install or operate the unit if the unit appears damaged. There is a risk of injury.	 p.2-1
Avoid locations of high temperatures, high humidity, dew condensation, dust. corrosive gases, explosive gases, combustible gases, coolant mist and sea damage etc. Install indoors, to avoid direct sunlight and the unit should be well ventilated.	 p.2-1
Be sure that the rated voltage matches the AC power supply voltage of the unit. Otherwise, there is the danger of injury and/or fire.	 p.2-5
Be sure not to connect an AC power supply to the output terminals. Otherwise, there is the danger of injury and/or fire.	 p.2-5
Be sure not to connect an AC power supply to the output terminals. Otherwise, there is the danger of injury and/or fire.	 p.2-5
Be sure not to connect the resistor to the direct current terminals (PD. P , and N). Otherwise. there is the danger of tire.	 p.2-5
Be sure to install the earth leakage circuit breaker on the inputting side. Otherwise, there is in the danger of fire.	 p.2-5
Be sure to use power cables, earth leakage breakers and electromagnetic contactors that are rated correctly. Otherwise, there is the danger of fire.	 p.2-5
Do not use the electromagnetic contactors to stop the Motor running always use the inverters internal controls. Otherwise, there is the danger of injury and/or fire.	 p.2-5

2. Operation

⚠ CAUTION

Make sure that the direction of the motor is correct. It is in danger of injury or machine damage.	 p.3-4
Make sure there is no abnormal noise and vibration. It is in danger of injury or machine damage	 p.3-4

TABLE OF CONTENTS

Chapter 1 General Descriptions	
1.1 General Description	1-1
1.1.1 Inspection of the unit	1-1
1.12 Operation manual	1-1
1.2 Question and Warranty of the Unit	1-2
1.2.1 Request upon asking	1-2
1.2.2 Warranty for the unit	.1-2
1.3 Appearance	1-3
1.3.1 Appearance and Names of Parts	. 1- 3
Chapter 2 installation and Wiring	
2.1 Installation	.2-1
2.1.1 Installation	.2-2
2.1.2 Blind cover of wiring parts	2-4
2.2 Wiring	2-5
2.2.1 Terminal Connection Diagram	2-6
2.2.2 Main circuit wiring	2-6
2.2.3 Terminal Connection Diagram	2-13
Chapter 3 Operation	
3.1 Operation	3-I
3.2 Test Run	.3-2
Chapter 4 Explanation of Function	
4.1 About Digital Operator (OPE-SR)	4-I
4.2 Code list	.4-5
4.3 Explanation of function	4-10
4.3.1 Monitor mode	4-10
4.3.2 Function mode	4-14
4.4 Protect/on function list	4-75
4.4.1 Protection function	.4-75
4.4.2 Trip monitor display	.4-77
4.4.3 Warning Monitor display	4-76

Chapter 5 Maintenance, Inspection	
5.1 Precaution for Maintenance/Inspection	5- 1
51.1 Dailyinspection	5-1
	5-1
5.1.3 Regular inspection	5-I
5.2 Daily inpection and regular inspection5	5-2
5.3 Megger test	
	5-3
5.5 The method to check Inverter, converter part	5-4
5.6 Capacitor Life Curve5	5-5
Chpter 6 Specification	
6.1 Standard specification list 6	3-l
6.2 Dimension	6-2


1.1Inspection upon Unpacking

1.1.1 Inspection of the unit


Open the package and pick out the inverter, please check the following item.

If you discover any unknown parts or the unit is in bad condition. please contact your supplier or the local Hitachi Distributor.

- (1) Make sure that there was no damage (injury. falling or dents in the body) during transportation of the unit.
- (2) After unpacking the unit. make sure that the package contains one operation manual for the Inverter.
- (3) Make sure that the product is the one you ordered by checking the specification label.



Picture 1-1 Position of specification



Picture 1-2 Contents of specifications label

1.1.2 Operation manual

This operation manual is the manual for the HITACHI Inverter L300P Series.

Before operation of the **Inverter**, read the manual carefully. After Reading this manual, keep it to hand for **future** reference.

When using optional units for this **inverter**; please refer to the operation manuals packed with the optional' units.

This operation manual was correct at the time of going to press.

1.2 Question and Warrantv of the Unit

1.2.1 Reauest upon asking

If you have any questions regarding damage to the unit. unknown parts or for general enquiries please contact your supplier or the local Hitachi Distributor with the following information.

- (1) Inverter Model
- (2) Production Number (MFG. NO)
- (3) Date of Purchase
- (4) Reason for Calling

Damaged part and its condition etc.

Unknown parts and their contents etc.

12.2 Warranty for the unit

The warranty period of the unit is one year after the purchase date.

However within the warranty period. the warranty will be void if the fault is due to;

- (1) Incorrect use as directed in this manual, or attempted repair by unauthorised personnel
- (2) Any damage sustained, other than from transportation (Which should be reported immediately)
- (3) Using the unit beyond the limits of the specification.
- (4) Act of God (Natural Disasters: Earthquakes. Lightning. etc)

The **warranty** is for the inverter only, any damage caused to third party equipment **by** malfunction of the inverter is **not** covered by the warranty.

Any examination or repair **after** the warranty period (one year) is not covered. And within the warranty period any repair and examination which results in information showing **the** fault was caused by any of the items mentioned above.. the repair and examination cost are not covered.

If you have any questions regarding the warranty please contact either your supplier or the local Hitachi Distributor.


Please refer to the back cover for a list of the local Hitachi Distributors.


1.3 Appearance

1.3.1 Appearance and Names of Paris

Appearance from the front







2.1 Installation

MWARNING

Do not remove the rubber bush. Due to the possibility that a wire may be damaged. shorted or may have a around fault with the edge of the wiring cover.

A CAUTION

Install using non-combustible materials (metal etc.)

It is a fire risk.

Do not install combustible materials nearby.

It is a fire risk.

Do not carry unit by top cover. always carry by supporting base of unit.

There is a risk of falling and injury.

Do not allow substance of cutting waste, sputtering of welding, waste of iron, wire and dust etc. to come into contact with the unit.

It is a fire risk.

Make sure the surface the unit is installed onto can support the weight of the unit comfortably.

There is a risk of falling and injury.

Do not install or operate the unit if the unit appears damaged.

There is a risk of injury.

Avoid locations of high **temperatures**, high humidity, dew condensation, dust, corrosive gases, **explosive** gases. **combustible** gases. coolant mist and sea damage etc. **Install** indoors, to avoid direct sunlight and the unit should be well ventilated.

2.1.1 Installation


1. Transportation

This inverter has plastic parts. So handle with care.

Do not **over tighten** the wall mounting fixings as the mountings may crack, causing is a risk of falling. Do not install or operate the inverter if there appears to be damage or parts missing.

2. Surface for Mounting of Inverter

The temperature of the Inverter heatsink can become very high (the highest being about 150°C). The surface, which you are mounting the Inverter onto, must be made of a non-flammable material (i.e steel) due to the possible risk of fire. Attention should also be made to the air gap surrounding the Inverter. Especially when there is a heat source such as a breaking resistor or a reactor.



3. Operating Environment-Ambient Temperature

The ambient temperature surrounding the Inverter should not exceed the allowable temperature range (usually -10 to 50°C).

The temperature should be measured in the air gap surrounding the Inverter. shown in the diagram above. If the temperature exceeds the allowable temperature, the component life will become shortened especially in the case of the Capacitors.

4. Operating Environment - Humidity

The humidity surrounding the Inverter should be within the limit of the allowable percentage range (usually 5% to 90%). Under no circumstances should the Inverter be in an environment where there is the possibility of moisture entering the Inverter.


Also avoid having the Inverter mounted in a place that is exposed to the direct sunlight.


5. Operating Environment-Air


Install the Inverter avoiding any place that has dust, corrosive gas, explosive gas, combustible gas, mist of coolant and \$88 damage.

6. Mounting Position

Mount the **Inverter** in a vertical position using **screws** or bolts. The surface **you** mount **onto** should also be free **from.vibration** and **can** easily hold the weight of the **Inverter**.








7. Ventilation within an Enclosure

If you are installing one or more **Inverters** in a" enclosure a ventilation fan should be installed. Below is a guide to the positioning of the fan to take the airflow into consideration. The positioning Of **Inverter**, cooling fans and air intake is very important. If these positions are wrong, airflow around the Inverter decreases and the temperature surrounding the **Inverter** will rise. So please make **Sure** that the temperature around is within the limit of the allowable range.



8.External cooling of Inverter

It is possible to install the **inverter** so that the **heatsink** is out of the back of the enclosure. This method has two advantages, cooling of the Inverter is greatly increased and the size of the enclosure will be **smaller**.

To install it with the **heatsink** out of the enclosure. a metal fitting option is required to ensure heat **transfer**.

Do not **install** in 8 place where water. oil mist, flour and dust **etc can** come in contact with the **inverter as there are** cooling fans fitted to the heatsink.


9. Approximate loss for each capacity

Inverter capacity (kW)	11	15	16.5	22	30	37	45	55
70% of rated output (W)	435	575	698	620	1100	1345	1625	1975
100% of rated output (W)	600	600	975	1150	1550	1900	2300	2600
100% of rated efficiency(%)	94.5	94.6	94.7	94.6	94.6	94.9	94.9	94.9

2.1.2 Blind cover of wiring parts


(1) Cable entry through Rubber Bushes

The wiring should be done after making a cut in the rubber bushes with nippers or cutters.



(2) Cable entry through Conduit

After taking out the rubber bushes, connect the conduit.



Note: Except for when connecting conduit, Do not take out the rubber bushes. It is possible that the wiring insulation is broken and a possible earth fault is caused.

2.2 Wiring

riangleWARNING

Be sure to ground the unit. Otherwise, there is a danger of electric shock and/or fire

Otherwise, there is a danger of electric shock and/or injury.

Only qualified personnel shall carry out wiring work.

Otherwise, there is a danger of electric shock and/or fire.

Implement wiring after checking that the power supply is off.

Otherwise, there is a danger of electric shock and/or injury.

Be sure to implement wiring after installing the body.

Otherwise, there is a danger of electric shock and/or injury.

A CAUTION

Be sure that the rated voltage matches the AC power supply voltage of the unit.

Otherwise, there is the danger of injury and/or fire:

Be sure not to connect an AC power supply to the output terminals.

Otherwise, there is the danger of injury and/or fire.

Be sure not to connect the resistor to the direct current terminals (PD. P, and N).

Otherwise, there is the danger of fire.

Be sure to install the earth leakage circuit breaker on the inputting side.

Otherwise, there is in the danger of fire,


Be sure to use power cables, earth leakage breakers and electromagnetic contactors that are rated correctly.

Otherwise, there is the danger of fire,

Do not use the electromagnetic contactors to stop the Motor running always use the Inverters internal controls.

Otherwise, there is the danger of injury and/or fire.

2.2.1 Terminal Connection Diagram



(1) Explanation of main circuit terminals

(F4)

ויין באף ומווי	Ly Explanation of many shown to mindre	
Symbol	Terminal Name	Explanation of contents
R, S, T	Main power	Connect alternating power supply. When using regenerative converter
(L1.L2,L3)		and RG series, don't connect.
U, V, W	Inverter output	the contract of the contract o
(T1,T2,T3)		רסווופכן ווופפ-טומספ וווסוסני
PD, P	D.C.reactor	Remove the short bar between PD and P, connect optional Power
(+1.+)		factor reactor (DCL-XX).
P. RB	External braking resistor	
(+,RB)		Connect optional External braking resistor.
Z d	External braking unit	Connect optional Braking unit (BRD-XX).
(+,-)		(installed on 11kW and 15kW)
ල €	Inverter earth terminals	It is earth terminals of inverter case.
)		

(2) Explanation of control circuit terminal

		- I			
		Symbol	Terminal Name	Explanation of contents	
*** ···		9311	Analogue power common	It is common terminal of frequency command signal (0, 02, 01) and analogue output. AM, AMI. Don't earth.	1) and analogue output,
	woq	Н	Frequency power	It is the DC+10V power for terminals.	Altowable toad current 20mA
·	Бu	0	Frequency command power terminal (voltage)	When inputting DC 0 - 10V, it is maximum frequency on 10V. When maximum frequency is expected to be on being less than 10V, set with A014.	Input Impedance 10k ohm Allowable maximum voltage 12V
anbojeu	ency setti	02	Frequency command support (voltage)	When inputting DC 0 - +-10V, this signal is added to frequency command of O or OI terminal.	Input Impedance 10k ohm Allowabie maximum load voltage +-12V
٧	upaı∃	ö	Frequency command . Terminal (current)	When inputting DC 4 - 20mA, 20mA is maximum frequency. When only At terminal Is ON, this input signal is effective.	Input Impedance 100 ohm Allowable maximum current 24mA
		AM	Digital monitor (voltage)	Output one selected from monitor item, output frequency,	Allowable maximum current 2mA
	votino	AMI	Analogue monitor (current)	output current, torque, output voltage, input electric power, electric thermal rate.	Allowable output less than Impedance 250 ohm
	W	FM	Digital monitor (voltage)	Output the output frequency with digital besides above monitor.	Allowable maximum current 1.2mA Maximum frequency 3.6kHz
		P24	Interface power	It is DC24V power for connection input signal. When selecting source logic, it's for connection input common.	Allowable maximum output current 100mA
	19W0 ^G	CM1	Interface power common	The common terminal is FW terminal, 1 - 5 terminal, TH terminal, FM terminal. Don't earth.	ninal, FM terminal,
(6		PLC	Intelligent input common	Change sink type and source type by short bar on control terminals. P24-PLC: Sink type CM1-PLC: Source type	minals.
nection	<u> </u>	A. Surries	Forward command		Allowable maximum voltage 27V
noo) letigiO	sngi2 tuqnt nortanutvortsreqQ	The nection at the case of the	Input intelligent	Select 5 functions from 33 functions, and divide between 1 terminal and 5 terminals.	Input ON condition of terminal voltage Over 18V Input OFF condition of terminal voltage
		11A	Intelligent output terminal 11	Select output function and assign it output terminal 11	Contact specification
		110	Common terminal	It is common terminal of intelligent output terminal 11.	AC250V,5A (R load) 1A (L load)
	len mie			It is common terminal of Intellinent output terminal 12	
	JudfuO roifibnoO	AL1 AL2	Alarm output terminal	Assign output function. Output is c contact.	Maximum AL1-ALO AC250V.2A (R load) 0.2A (L load)
	 -	AL0	Common terminal	It is common terminal of alarm output terminal.	ALZ-AL0 AC250V,1A,(R load) 0.2A (L load) minimum AC100V 10mA
Analogue	Sensor	HT -	Thermistor input terminal	When a Thermistor signal is Inputted to terminals TH and CM1, the Inverter checks for over-temperature and will cause trip event and turn off output motor	Allowable maximum resistance 10k ohm , minimum power 100mW

2.2.2 Main circuit wiring

(1) Warning on wiring

When carrying out work on the Inverter wiring make sure to wait for at least ten minutes before you remove the cover. Making **sure** to check that the charge lamp is not illuminated.

A final check should always be made with a voltage meter.

After removing the power supply, there is a time delay before the capacitors will dissipate their charge.

1. Main power terminals(R, S, T)

Connect the main power terminals (R, S, and T) to the power supply through a electromagnetic contactor or an earth-leakage breaker.

We recommend connecting the electromagnetic contactor to the main power terminals. Because when the protective function of inverter operates, it isolates the power supply and prevent the spread of damages and accidents.

This unit is for the three-phase power supply. It isn't for the single-phase power supply. If you require a single phase power supply unit, please contact us.

2. Inverter output terminats (U, V, and W)

Wire with thicker wire than the applicable wire to control the voltage drop.

Particularly when outputting low frequencies, the torque of the motor will reduce by the voltage drop of the wire.

Do not install power factor correction capacitors or a surge absorber to the output.

The inverter will trip or sustain damage to the capacitors or the surge absorber.

In the case of the cable length being more than 20 meters, it is possible that a surge voltage will be generated and damage to the motor is caused by the floating capacity or the inductance in the wire (400V especially).

An EMC Mains Filter is available. please contact us.

In the case of two or more motors, install a thermal relay to each motor.

3. Direct current reactor (DCL) connection terminals (PD. P)

These are the terminals to connect the current reactor DCL (Option) to help improve the power factor.

The short bar is connected to the terminals when shipped from the factory, if you are to connect a DCL you will need to **disconnect the** short bar first.

When you don't use a DCL. don't disconnect the short bar.

4. External braking resistor connection terminals (P. RB)

The regenerative braking circuit (BRD) is built-in es standard up to the 15kw Inverter.

When braking is required, install en external-braking resistor to these terminals.

The cable length should be less than 5 metres, and twist the two connecting wires to reduce inductance.

Don't connect any other device other than the external braking resistor to these terminals.

When installing en external braking resistor make sure that the resistance is correctly rated to limit the current drawn through the BRD.

5. Regenerative breaking unit connection terminals

The Inverters rated more than 18.5kw don't contain a BRD circuit. If regenerative braking is required an external BRD circuit (Option) is required along with the resistor (Option).

Connect external regenerative braking unit terminals (P, N) to terminals (P,N) on the inverter. The braking resistor is then wired into the External Braking unit and not directly to the Inverter.

The cable length should be less than 5 meters. and twist the two connecting wires to reduce inductance.

6. Earth (G 🖹)

Make sure that you securely ground the Inverter and motor for prevention of electric shock.

The inverter and motor must be connected to an appropriate safety earth and follow the local standard. Failure

to do so constitutes an electrical shock hazard.

Chapter 2 Installation and Wiring

(2) Wiring of main circuit terminals

The wiring of main circuit terminals for inverter is the following picture.

Wiring of terminals										Corresponding type	
	R (L1)	S (L2)	T (L3)	U (T1)	V (T2)	W (T3)		Ro	То		L300P-110 150LF/HF Ro-To: M4
	PD (+1)	P (+)	N (-)	RB	G G	G 😩			,		Other: M6
Short bar			<u>`</u> @(Charge	lamp						
	Ro To Charge lamp										L300P-185LF L300P-185-370HF Ro-To: M4 Other: M6
G 😩 (R (L1) (S (L2)		PD F			U T1)	V (T2)	W (T3)		L300P-370LF L300P-450,550HF
Short bar									Ro-To: M4 Other: M8		
										Ro-To: M4 Earth terminal: M6 Other: M8	
R (L1)	S (L2)	T (L3)	PD (+1)	P (+)	N (-)	U (T1)	V (T2)	(T3))		L300P-550LF Ro-To: M4 Earth terminal: M6
(Short ba	ar 🔌						=			Other.: MIO



Electric

Motor

contactor

Refer to '(4) Common applicable tools'

Note1: The applicable tools indicate for Hitachi standard four-pole squirrel-cage Motor.

Note2: Select applicable tools for breakers examining the capacity of breakers.

(Use inverter type.)

Note3: It needs bigger wires for power lines, if the distance exceeds 20m.

Note4: Use earth-leakage breakers (ELB) for safety.

*Use 0.75mm² for Alarm output contact.

Separate by the **sum(** wiring distance from **Inverter** to power supply. from **inverter** to motor for the sensitive current of leak breaker (ELB).

	Wiring distance	Sensitive
		Current(mA)
	100m and less	50
	300m and less	100
_		

Note5: When using CV line and wiring by rigid metal conduit, leak flows.

Note6: IV line is high dielectric constant. So the current increase 8 times.

Therefore, use the sensitive current 5 times as large as that of the left list. And if the distance of wire is **over 100m**, use CV line.

	Name	Function
	Input reactor(harmonic control, electrical coordination, power- factor improvement)(ALI-***)	This part is used when the unbalance voltage rate is 3% or more and power supply is 500 kVA or more, and there is a rapid change in the power supply/. It also improves the power factor.
	Radio noise filter (zero-phase reactor)(ZCL-*)	Using the inverter may cause noise on the peripheral radio through the power lines. This part reduces noise.
R S T PD S Power supply	Noise filter for Inverter (JF-***)	This part reduces common noise generated between the power supply and the ground, as well as normal noise. Put it in the primary side of inverter.
RB RB TO NO.	Input radio noise filter (capacitor filter)(CFI-*)	This part reduces radiation noise emitted from wire at the input.
	Direct reactor(DCL-*-**)	This part control harmonic from inverter.
	Breaking resistor Regenerative breaking unit	This part is used for applications that need to increase the brake torque of the inverter or to frequently turn on and off and to run high inertia load.
<u> </u>	Output noise filter(ACF-C*)	This part reduces radiation noise emitted from wire by setting between inverter and motor. And it reduces wave fault to radio and TV, it is used for preventing malfunction of sensor and measuring instruments.
—	Radio noise filter(zero-phase reactor(ZCL-***)	This part reduces noise generated at the output of the inverter. (it is possible to use for both input and output.)
	(Output alternation reactor IReducing vibration, thermal IRelay, preventing misapplication (ACL-*-**)	Running motors with the inverter generates vibration greater than that with commercial power supply. This part installed between the inverter and motor reduces torque ripple. When the cable length between the inverter and motor is long (10m or more), a countermeasure for a malfunction of the thermal relay by harmonic due to switching on inverter is taken by inserting reactor.
(M)	LCR filter	There is the way to use current sensor in stead of thermal relay. Sine-wave filter at the output.
Motor		

(4) Common applicable tools


				External resister Between P and RB	Screw size of terminal			Applicable	tools
	Motor Output (kW)	Applicable Inverter model	Power lines R.S.T.U.V, W.P.PD,N			Terminal	Torque Nm	Leak breaker (ELB)	Electro -magnetic controller (Mg)
	11	L300P-110LF	14 mm² or more	5.5 mm ²	M6	14-6	2.5	RX100(75A)	H50
	15	L300P-150LF	22 mm² or more	5.5 mm²	М6	22-6	2.5	RX100(100A)	H65
	18.5	L300P-185LF	30 mm² or more	-	M6	38-6	2.5	RX100(100A)	H80
s	22	L300P-220LF	38 mm² or more	-	M8	38-8	6	RX225B(150A)	H100
as	30	L300P-300LF	60 mm ² or more	_	M8	60-8	6	RX225B(200A)	H125
200V class	37	L300P-370LF	100 mm² or more (38×2)	-	М8	100-8	6	RX225B(225A)	H150
	45	L300P-450LF	100 mm² or more (38×2)	`	M10	100-10	6	RX225B(225A)	H200
	55	L300P-550LF	160 mm² or more (60×2)	-	M10	150-10	6	RX400B(350A)	H250
	11	L300P-110HF	5.5mm² or more	5.5 mm²	M6	5.5-6	2.5	EX50C(50A)	H25
	15	L300P-150HF	8mm² or more	5.5 mm ²	M6	8-6	2.5	EX60B(60A)	H35
55	18.5	L300P-185HF	14 mm² or more	-	М6	14-6	2.5	EX60B(60A)	H50
class	22	L300P-220HF	14 mm² or more	-	М6	14-6	2.5	RX100(75A)	H50
400	30	L300P-300HF	22 mm² or more	-	М6	22-6	2.5	RX100(100A)	H65
4	37	L300P-370HF	38 mm² or more	-	М6	38-6	2.5	RX100(100A)	H80
1 '	45	L300P-450HF	38 mm² or more	-	MB	38-8	6	RX225B(150A)_	H100
	55	L300P-550HF	60 mm² or more	•	M8	60-8	6	RX225B(175A)	H125

5) Connecting power to the control circuit, separating from main power

When the protection circuit of inverter is activated and **the** electromagnetic **contactor on** the input supply to the inverter isolates the power supply, the control circuit power supply from the inverter will also switch off and the alarm output signal will not be held.

The power terminals Ro and To are designed to allow **a** supply to go direct to the control circuit and therefore keep the alarm output signal on.

In this case, please connect power terminals Ro and To, to the primary side of the electromagnetic contactor. (inverter unit side of ACL. EMI filter, on using input ACL. EMI filter).




2.2.3 Terminal Connection Diagram

(1) Wiring

1. **Both** the CM1 and L terminal is insulated to both the common terminal of the input and output signals.

Do not short or earth these common terminals.

- 2. Use twisted screened cable. for the input and output wires of the control circuit terminals. Connect the screen to the common terminal.
- 3. Limit connection wires to **20m**. When it is necessary to wire over **20m**, use a VX applied controller RCD-A (Remoter operation bar) or a CVD-E (Insulated signal transducer).
- 4. Separate the control circuit wiring from the main power and relay control wiring.
- 5. If control and power wires must cross make sure they cross et 90 degrees to each other.
- 6. When connecting **a** thermistor to the TH and CM1 terminal, twist the thermistor cables separate from the rest.



- 7. When using relays for the FW terminal or an intelligent input terminal use a control relay es they are designed to work with 24Vdc.
- 6. When the relay is used as an intelligent output, connect **a** diode for surge protection parallel to the coil.
- Do not short the analogue voltage terminals H and L or the internal power terminals PV24 and CM1.

There is risk of Inverter damage.

(2) Layout of control circuit terminals

H	1	02	AM	FM	TH	FW	5	4		3	2	1	AL	_1	
<u>.</u>	'0	Oi	A	VI P	24 PL	c a	V 11 -	lx	12A	11C	11	A F	PLO	AL	2


The terminal screw size: M3

(3)Change of input logic type

The logic type of intelligent input terminals is sink type (Factory Default).

To change the input logic type into source type, take off the short bar between P24 and PLC on the control terminal and connect it between PLC end CM1.

Chapter 2 Installation and Wiring



3.1 Operation

This inverter requires two different signals in order for the **Inverter** lo operate correctly. The **Inverter requires** both en operation setting and **8** frequency setting.

The following Indicates the details of each method of operation end the necessary instructions for operation.

(1) Operation setting and a frequency setting by the terminal control.


This is the method by connecting signals from the outside (the frequency setting, the starting switch etc.) with the control circuit terminals.

The operation is started when the operation setting (FW, RV) is turned ON while the input power is turned ON.

NOTE: The methods of the setting frequency with **terminal are** the voltage setting and the **electric** setting.

And they are selective by each system. The control circuit terminal list shows this in detail. (Necessary things for operation)

- [1] The operation setting: switch, relay etc.
- [2] The frequency setting: signals from volume or outside (DCO-10V, DC-10-10V, 4-20mA etc.)




(2) Operation Setting and frequency setting with the digital operator.

This is the method for operation from the digital operator, which comes equipped with the inverter es standard. or the remote operator keypad.

When the digital operator sets the operation, the terminals (FW, RV) don't need to be linked.

And it is possible to select frequency from the digital operator es **a** method of the frequency setting too. (Necessary things for operation)

[1] Remote Operator (It's unnecessary in case of digital operator operation)




(3) Operation setting and frequency setting from both digital operator and terminal operator

This is the method of inverter operating from both of the above two operating methods. It is possible that the operation setting and the frequency setting can be selected for both **the** digital operator and the terminal operator each separately.

This is the common connection example. Please refer to 4.1 Digital Operator, for the detailed use of the digital operator (OPE-SR).

(1) To input the operation setting and the frequency setting from terminal control.



(Arrangements)

- [1] Please make sure that the connections are correctly secure.
- [2] Turn the ELB ON to supply power to the inverter.

(The red LED 'POWER' on the digital operator should illuminate.)

[3] Set terminal with the frequency setting selection.

Set A001 as indication code. press the (FUNC) keyonce. (Two figures are shown.)

Set 01 with the key or the key, press the key once to set the frequency setting for terminal. (Indication code turns back to A001.)

[4] Set terminal with the operation setting selection.

Set A002 as indication code, press the (runc) key once. (Two figures are shown.)

Set 01 with the key or the key; press the key once to set the operation setting for terminal (Indication code turns back to A002.)

[5] Set monitor mode.

When monitoring the output frequency, set indication code to $\ensuremath{\text{d001}}\xspace$, and $\ensuremath{\text{press}}\xspace$ the

(func) key once.

Or when monitoring the operating direction, set indication code to d003. press the

key once.

[6] Input starting operation setting.


Turn ON between [FW] and [CM1] of terminal.

Impress voltage between [0] and [L] of terminal to start operation.

[7] Input ending operation setting.

Turn OFF between [FW] and [CM] to stop slowly down.

(2) Operation setting and the frequency setting from **the** digital **operator** '(Copy **unit** (SRW) is also **same** use.)



(Arrangements)

- [1] Please make sure that there isn't matter about the connection
- [2] Turn the ELB on to supply power to the inverter.

 (The red LED 'POWER" on the digital operator should illuminate.)
- [3] Set operator with the frequency setting selection.

 Set A001 as indication code. press the (TUNE) key once (Two figures are shown.)

Set 02 with the key or the key, press the key once to set the frequency setting for the operator.

(Indication code turns back to A001.)

[4] Set operator with the operation setting selection.

Set A002 as indication code. press the (TUNC) key once. (Two figures are shown.)

Set 02 with the key or the key press the key once to set the operation setting for the operator.

(Indication code turns back to A002.)

Set **F001** as indication code. as press the (FUNC) key once. (Indication code of four figures is shown.)

Set to the desired output frequency with the key or the key or the key or the key once to store it.

(Indication code turns back to F001.)

[6] Set the operation direction.

Set FO04 as indication code. press the (runc) key once (00 or 01 is shown.)

Set operation direction to 00 in case of forward, or to 01 in case of reverse with the key or the key. Press the key once to establish it.

(Indication code turns back to FO04.)

[7] Set monitor mode.

When monitoring the output frequency, set indication code to d001, and press the (tune) key once. Or when monitoring the operation direction, set indication code to d003. press the (func) Func key once.

(Indication code are \bigcap forward, \bigcap reverse or \bigcap stop.)

- (The green LED 'RUN' turns on a light, and the indication changes in response to the monitor mode
- [9] Press the key to decelerate to a stop.

 (When the frequency turn back to 0, the green LED "RUN' light will switch off.)



Make sure that the direction of the motor is correct. It is in danger of injury or machine damage. Make sure there is **no** abnormal noise and vibration. It is in danger of injury or machine damage.


Make sure that there is no tripping during the acceleration and deceleration and check that the revolution per minute and the frequency meter are correct.

When overcurrent tripping or overvoltage tripping occurs during the test run. increase the acceleration time or the deceleration time.

4.1 About Digital Operator (OPE-SR)

Explanation of operating the digital operator (OPE-SR) L300P series operates by using the digital operator, which is fitted es standard.

1. Name and contents of each part of the digital operator



Name	Contents
Monitor	Dis la offre uency, output current and set value
Lamp on RUN (Operation)	Light on when the inverter is running
Program lamp	Light on when displaying set value of each function in monitor section Light will flash On and Off as a warning (when set value is incorrect)
POWER lamp	Power lamp of control circuit
ALARM lamp	Light on when the Inverter trips
Monitor lamp	Lamp display state of monitor section. Hz: Frequency V: Voltage A: Current kW: Electric power %: Rate
Volume lamp	Light on when the frequency can be set by the volume for frequency setting
Operation command Display lamp	Light on only when operating command (RUN/STOP) is set in operator
Run key	Run command to start the motor. But this is only valid when operation command is from the operator. (Be sure that the operation command display lamp is illuminated.)
Stop (stop/reset) key	This key is used to stop motor, or reset an alarm.
Volume for frequency	This can be used to set the output frequency. But this is only valid when the frequency
setting	command part is set in volume.
FUNC (Function) key	The key containing monitor mode, basic setting mode, extension functions mode.
STR (Store) key	The key to store the data set. (On changing set value, must be pushed or value is lost.)
UP/DOWN key	The keys to change extension function mode, function mode and set value.

[5] Display monitor code No.


HITACHI

(Display d001)

- 2. Operating method
- (1) Method to display monitor mode, basic setting mode. extension function mode Power on



[1] Display of monitor contents set (Display 0.00 in initial state)




When power is turned off while the basic setting mode or the extension setting mode is displayed. The display will be different from the one above when the power is restored.

Push the




Return to the state of [2].

[2] Display monitor code No. (Display d001)




Monitor mode is displayed by pushing FUN (Function) key once when display of Monitor mode No.

[4] Display extension function mode (Display A - - -)




Extension function mode Display in the order of

 $A \leftarrow \rightarrow b \leftarrow \rightarrow C \leftarrow \rightarrow H \leftarrow \rightarrow P \leftarrow \rightarrow U$



key.


[3] Display code No. of basic setting mode.



*1(3) Refer to setting method of function (18 times) code.


(2) Selling method of functionChange operation command part. (Operator → Control terminal)

[1] Display extension function mode




Make monitor display 'A - - * by referring to (1) displaying method.


Now operating command part is by the operator. so operating command display lamp should illuminate...




[2] Display code No. of function mode











[3] Display contents of function mode







Operation command part displays

Program (PRG) light on by displaying contents of function mode


[5] Display extension **function** mode (Display A - - -)



It is possible to shift to **other** extension function modes, monitor modes and basic modes in this state




[4] Display code No. of monitor mode. (Display A002)



The changed **set value** is confirmed by pushing the STR key.

Operation command display lamp light will switch off **so** that operation command is now changed to the control terminal.






Change operation command part to control terminal 01.

(3) Setting method of function code

Code No. of monitor modes. basic setting modes and extension function codes can be set easily. Indicate the method to change code No. d001 of monitor mode to function code No. A029 simply.

[1] Display code No. of monitor mode. (Displayd001)






(Display A029)










Finish setting A029

(Note) When you input code No. there isn't in the code list. 'A' of left end blinks again. Confirm code No and input it again.

[2] Change extension function mode



Push the (/

function code No.


[5] Change first figure of



First figure. '1'




(Display A001)




'A' blinks.

The figure lighting is decided by pushing STR key.




Second figures. "2" blinks.

(Display A021)




[3] Change third figure of function code No

[4] Change second figure of function code No.



First figure '0' blinks.

Don't change third figure and push the STR key and confirm 0.



Second figure, "0" blinks

4.2 Code list

Monitor code

(Notel)

Monito	r coae				(,	
Dis- play code	Function name	L300P monitor or data range (digital operator)	initial data	Setting On	Chang e mode during running	Paragge
d001	output frequency monitor	0.00-99.99/100.0-400.0(Hz)				4-10
d002	output current monitor	0.0-999.9(A)				4-10
d003	Operation direction				-	4-10
d004	P.D.ifeedback monitor	0,00-99,99/100,0-999,9/18899999./ 1000-9999/(100-{999}) (10000-999900)	-	I	-	4-10
d005	Intelligent input terminal monitor	(Example) FW, terminal 2, and 1: ON FW Terminal 5, 4, 3: OFF ON OFF 5 4 3 2 1	- !	-		4-11
d006	Intelligent output terminal monitor	(Example) Terminal2, 1:ON	-	-	-	4-11
d007	Frequency conversion monitor	0.00-99.99/100.0-999.9/10009999. / 1000-3996	-	-	-	4-12
d013	Output voltage monitor	0.0-600.0 V	-	-	-	4-12
d014	Electric power monitor	0.0-999.9 kW	-	-	-	4-12
d016	Accumulated time monitor during RUN	09999./1000-9999/{100-{999 hr	-	-	-	4-13
d017	Power ON time monitor	09999./1000-9999/(100-{999 hr	-	•	-	4-13
d080	Number of trip time monitor	09999./1000-6553(10000-65530) (time)	-		-	4-13
d081	Trip monitor 1	Trip Code, frequency(Hz), current(A), voltage(V),RUN time(hr) power ON time(hr)	-	-	-	4-13
d082	Trip monitor 2	Trip Code, frequency(Hz), current(A), voltage(V),RUN time(hr) power ON time(hr)	-	-	-	4-13
d083	Trip monitor 3	Trip Code, frequency(Hz), current(A), voltage(V),RUN time(hr) power ON time(hr)	- '	-	-	4-13
6084	Trip monitor 4	Trip Code, frequency(Hz), current(A), voltage(V),RUN time(hr) power ON time(hr)	-	-	-	4-13
d085	Trip monitor 5	Trip Code, frequency(Hz), current(A), voltage(V),RUN_time(hr)	-	-	· -	4-13
d086	Trip monitor 6	Trip Code, frequency(Hz), current(A), voltage(V),RUN_time(hr)	-	-		4-13
q0a0	Warning monitor	Warning code	-	-	-	4-76
F001	Output frequency	0.0, starting frequency-Max. frequency (2 nd max. frequency)(Hz)	0.00	✓	1	4-14
F002	1 st acceleration time	0.01-99.99/100.0-999.9/10003600.(s)	30.00	. 1	✓	4-16
F202	2 nd acceleration time	0.01-99.99/100.0-999.9/10003600. (s)	30.00	✓	✓	4-16
F003	1 st deceleration time	0.01-99.99/100.0-999.9/10003600. (*)	30 000	<u> </u>	✓	4-16
F203	2 nd deceleration time	0.01-99.99/100.0-999.9/10003600. (3)	30.00	✓	✓.	4-16
F004	Gneration direction selection	00(forward)/01(reverse)	00	•		4-16

(Note1) Change mode during run by selection of b031 (software lock selection).

(Note2) Do not forget to press "STR" key when you change the display.

_	Code	Function name	Setting range	Initial data -FE/-FU	Setting on run	mode on run	Peg
	A001	Frequency setting selection	00(VR)/01(terminal)/02(operator)/03(RS485)/04 (option1)/05(option2)	01	-	•	4-14
ا ہو	A002 Operation setting selection 01		01(terminal)/02(operator)/03(RS485)/04(option1)/05(option2)	01	-	-	4-19
setling	A003	Base frequency	30 Maximum, frequency(Hz)	50./60.	-	-	4-1
2	A203	Base frequency, 2nd motor	30 2 nd Maximum, frequency (Hz)	50./60.	-	-	4-1
Base	A004	Maximum frequency	30 400. (Hz)	50./60.	-	-	4-1
•	A204	Maximum frequency, 2nd motor	30 400. (Hz)	50./60.		-	4-1
	A005	AT terminal selection	00(Changing of O and O! with AT terminal)/01(Changing of O and O2 with AT terminal)	00	-	_	4-11
Analog input setting	A006	02 selection	00(single)/01(auxiliary speed of O. OI) [no reversible] /02(auxiliary speed of O. OI [reversible]	00	-	-	4-1
ĕ	A011	0 start	0.00-99.99/100.0-400.0 (Hz)	0.00	-	1	4-2
≦	A012	0 end	0.00-99.99/100.0-400.0 (Hz)	0.00	-	1	4-2
60	A013	0 start rate	0100.0 (%)	O.	-	1	4-2
	A014	0 end rate	0100.0(%)	100.		1	4.2
` [A015	0 start selection	00 (external starting frequency)/01(OHz)	01	•	1	4-2
Ī	A016	O, Ot, O2 sampling 130.(times)		8.		1	4.2
	A019	MuitI-speed selection	00(binary : range is to 16 stage speed with 4 terminals)/01(bit : range is to 6 stage speed with 5 terminals)	00	•	•	4-4
Ì	A020	Multi-speed 0	0.00, starting frequency-maximum, frequency(Hz)	0.00	1		4-4
ı	A220	Multi-speed 0, 2" motor	0.00, starting frequency-2 nd maximum frequency(Hz)	0.00	7	7	4-4
ı	A021	Multi-speed1	0.00, starting frequency-maximum frequency(Hz)	0.00	1	1	4-4
,	A022	Multi-speed2	0.00, starting frequency-maximum frequency(Hz)	0.00	1		4.4
,	A023	Multi-speed3	0.00, starting frequency-maximum frequency(Hz)	0.00	/	-	4-4
ŀ	A024	Multi-speed4	0.00, starting frequency-maximum frequency(Hz)	0.00	1	7	4.4
·	A025	Multi-speed5	0.00, starting frequency-maximum frequency(Hz)	t	-	7	
ŀ				0.00	7	-	4 -
ŀ	A026	Multi-speed6	0.00, starting frequency-maximum frequency(Hz)	0.00			4
ŀ	A027	Multi-speed?	0.00, starting frequency-maximum frequency(Hz)	0.00	4	· ·	4-
H	A028	Multi-speed8	0.00, starting frequency-maximum frequency(Hz)	0.00	· · · · · ·	· · · · · ·	. 4.
	A029	Multi-speed9	0.00, starting frequency-maximum frequency(Hz)	0.00		-	4-
}	A030	Multi-speed10	0.00, starting frequency-maximum frequency(Hz)	0.00	1		4-
}	A031	Multi-speed11	0.00, starting frequency-maximum frequency(Hz)	0.00	/		4-
-	A032	Multi-speed12	0.00, starting frequency-maximum frequency(Hz)	0.00	· · · · · ·	/	4-
1	A033	Multi-speed13	0.00, starting frequency-maximum frequency(Hz)	0.00	/		4
ŀ	A034	Multi-speed14	0.00, starting frequency-maximum frequency(Hz)	0.00			4.
-	A035	Multi-speed15	0.00, starting frequency-maximum frequency(Hz)	0.00			4-4
1	A038	Jogging frequency	0.00, starting frequency-9.99(Hz)	1.00		*	_4
	A039	Jogging selection	00(free-run on JG stop / invalid on running) / 01(stop decelerating on JG stop / invalid on running) / 02(DC braking on JG stop/invalid on running) / 03(free-run on JG stop/valid on running(JG after stop decelerating)) / 04 (stop decelerating on JG stop/valid on running) / 05 (DC braking on JG stop/valid on operating)	. 00	•	*	4 -4
Ĺ	A041	Torque boost selection -	00 (manual torque boost) / 01 (automatic torque boost)	00	·		4.2
	A241	Torque boost selection, 2 rd motor	00 (manual torque boost) / 01 (automatic torque boost)	00	-	-	4-2
	A042	Manual torque boost	0.0-20.0(%)	1.0	1	1	4-2
	A242	Manual torque boost, 2 nd motor	0.0-20.0(%)	1.0	1	1	4.1
}	A043	Manual torque boost point Manual torque boost point, 2 nd	0.0-50.0(%) 0.0-50.0(%)	5.0 5.0	1		4-
F	A044	motor 1*1 control	00/(VC)/01(VP1.7power)/02(free V/f setting)	00	-		4-:
L	A244	2 ^{-d} control .	00/(VC)/01(VP1.7power)/02(free V/f setting)	00	•	•	4-7
	A045	Output voltage gain	20 100.	100.	1	✓	4-
1	A051	DC braking selection	00(invalid)/01(valid)			1	4-2
	A052	DC braking frequency	0.00-60.00(Hz)		-	✓	4-7
L	A053	DC braking wait time	0.0 - 5.0(s)			1	4-7
Ĺ	A054	DC braking power	g power 0, - 70, (%)		•	1	4-2
	A055			0.0		1	4
	A058	DC braking edge/level	00(edge action)/01(level action)	01	•	,	4.2
	A057	DC braking power (starting time)	0 70. (%)	0.	-	4	4-2
	A058	DC braking time (starting time)	0.00-80.0(a)	0.0	-	1	4.2
	A059	DC carrier frequency	0.5-12(kHz) Derating	3.0			4-2

		on Mode		,		Change	1
Code Function name A 081 1st frequency upper limiter			Setting range	Initial data -FE/-FU	Setting on run	mode on run	Page
2		<u> </u>	0.00, 1** frequency lower limiter-maximum frequency(Hz)	0.00	ļ	1	4-28
quint,	A261	2 nd frequency upper limiter	0.00, 2" frequency lower limiter-2" setting maximum frequency(Hz)	0.00	•	1	4-28
-	A062	1st frequency lower limiter	0.00, start frequency-maximum frequency(Hz)	0.00		/	4-28
	A282	2 rd frequency lower limiter	0.00, start frequency-2** setting maximum frequency(Hz)	0.00		1	4-28
	A063	Jump frequency1	0.00-99.99/100.0-400.0(Hz)	0.00		7	4-29
	A064	Jump frequency Width 1	0.00-10.00(Hz)	0.50	-		4-29
	A085	Jump frequency2	0.00-99.99/100.0-400.0(Hz)	0.00	 	- Z	4-29
	A086			0.50		· ·	4-29
Š		Jump frequency3	0.00-10.00(Hz)		 	1	
· č	A067		0.00-99.99/100.0-400.0(Hz)	0.00	•	/	4-29
ΥĒ	A088	Jump frequency Width 3	0.00-10.00(Hz)	0.50	-	1	4-29
frequency	A089	Acceleration stop frequency	0.00-99.99/100.0-400.0(Hz)	0.00	•	1	4-29
	A070	Acceleration stop time	0.00-60.0(s)	0.0		1	4-29
	A071	PID selection	00(invalid)/01(valid)	00	· ·	1	4-30
5	A072	PID-P gain	0.2-5.0	1.0	1	1	4-30
control	AD73	PID-I gain	0.0-3800.(s)		/		4-30
ខ	A074	PID-D gain	0.00-100.0(s)	0.00	7	1	4-30
5	A075	PID scale	0.01-99.99(%)	1.00		1	4-30
ā	A076	PID feedback selection	00(feedback : OI)/01(feedback : O)	00	-	7	4-30
œ	A081	AVR selection	00(ON always)/01(OFF always)/02(OFF on decelerating)	02		-	4-17
A.	A082	Motor vottage selection	200/215/220/230/240, 380/400/415/440/480/480, 575/60D(V)	230/230		1 .	4-17
_		_		460/460		<u> </u>	
	A085	Operation mode selection	00(normal operation)/01(energy-saving operation)	00			4.31
ç	A086	Energy-saving response-	0.0-100.0(s)	50.0	/	1	4-31
function		accuracy adjustment					
5	A092	Acceleration time2	0.01-99.99/100.0-999.9/10003600.(#)	15.00	/	1	4-32
	A292	2 nd acceleration time2	0.01-99.99/100.0-999.9/10003600.(#)	15.00	/	/	4-32
5	A093	Deceleration time2	0.01-99.99/100.0-999.9/10003600.(a)	15.00	1	-	4-32
Ħ	A293	2 nd deceleration time2	0.01-99.99/100.0-999.9/10003600.(*)	15.00	- i	1	4-32
S	A094	2 nd stage adjustable selection	00(change with 2CH terminal)/01(change with setting)	00	•	-	4-32
mode/ adjustable	A294	2 nd stage adjustable	00(change with 2CH terminal)/01(change with settion)				4-32
ž		selection(2" motor)		0.00		<u> </u>	
Ř	A095	2 [™] acceleration frequency					4-32
Ĕ	A295	2 [™] acceleration			1	l _	4-32
5		rrequency(2 motor)		0.00	<u> </u>	1	i
	A098	2 nd deceleration frequency	0.00-99.99/100.0-400.0(Hz)	0.00	<u> </u>	<u> </u>	4-32
Opera	A296	2 rd deceleration frequency	0.00-99.99/100.0-400.0(Hz)	0.00			4-32
6		(2 [™] motor)	, ,		<u> </u>	ļ <u>.</u>	
~	A097	Acceleration pattern selection	00(straight line)/01(S-curve)/02(U-curve)/03(reverse U-curve)	00	· · ·		4-33
	A09B	Deceleration pattern selection	00(straight line)/01(S-curve)/02(U-curve)/03(reverse U-curve)	00			4-33
-	A101	Olstert	0.00-99.89/100.0-400.0(Hz)	0.00	<u>-</u>	/	4-20
irequency at	A102	OI end	0.00-99.99/100.0-400.0(Hz)	0.00		/	4-20
<u> </u>	A103	Ol start rate	0100. (%)	20.	·	1	4-20
g	A104	Ol end rate	0100. (%)	100.		1	4-20
= 5	A105	Ol start selection	00(external start frequency)/01(0Hz)	01		/	4-20
ustme	A111	O2 start	-400100./-99.9-0.00-99.9/100400.(Hz)	0.00	. •	-	4-20
rernai iri Justment	A112	O2 end	-400100./-99.9-0.00-99.9/100400.(Hz)	0.00	-	1	4-20
ad ja	A113	O2 start rate	-100 100. (%)	-100.	-		4-20
	A114	O2 end rate	-100 100. (%)	100.	•	1	4-20
Decel	A131	Acceleration curve constant	01(small swelling)-10(large swelling)	02		1	4-33
ίğ	A132	Deceleration curve constant	01(small swelling-10(large swelling)	02	_	,	4-33
٠.			00(trip)/01(0Hz start)/02(start after equal frequency)/		-	· · · · · · · · · · · · · · · · · · ·	1 33
.	6001	Retry selection	00(trip)/01(0Mz start)/02(start after equal frequency)/ 03(trip after equaling frequency and deceleration stop)	- 00		/	4-34
121107		Allowable under-voltage			· · · · · · · · · · · · · · · · · · ·	 	
Ē	6002	power failure time	0.3-1.0(s)	1.0	-	/	4-34
	b003	Retry wait time	0.3-100.(*)	1.0		-	4-34
		Instantaneous power-				 	
Ď	6004	faiture/under-voltage trip	00(invalld/01(valid)	00		/	4-34
9		during stop	~ ~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~		l	1	' "
ě		Instantaneous power-					
_		i iustaurausoht Dowat-			1		4-34
-	b005	failure/under-voltage	00(16 times)/01(free)	00	•	1	
tart	ь005		00(16 times)/D1(free)	00	•	1	1 7 7
estart	b005 b006	failure/under-voltage	00(16 times)/01(free) 00(Invelid)/01(valid)	00 00	•		
restart	b005 b006 b007	failure/under-voltage retry time selection Open-phase selection	00(Invalid)/01(valid)	00	•		4-35
restart		failure/under-voltage retry time selection		00 0.00		,	
restart		failure/under-voltage retry time selection Open-phase selection	00(Invalid)/01(valid) 0.00-99.99/100.0-400.0(Hz)	00		,	4-35 4-34
restart	ь007	failure/under-voltage retry time selection Open-phase selection Frequency setting to match	00(Invalid)/01(valid)	00 0.00 Rated	-	7	4-35
restart	ь007	failure/under-voltage retry time selection Open-phase selection Frequency setting to match Electronic thermal level	00(Invalid)/01(valid) 0.00-99.99/100.0-400.0(Hz)	00 0.00 Rated Current of inverter	-	7	4-35 4-34
restart	ь007	failure/under-voltage retry time selection Open-phase selection Frequency setting to match Electronic thermal level	00(Invalid)/01(valid) 0.00-99.99/100.0-400.0(Hz)	00 0.00 Rated Current of	-	7	4-35 4-34
restari	ь007 b012	failure/under-voltage retry time selection Open-phase selection Frequency setting to match Electronic thermal level Electronic thermal level (2 ⁻⁴ motor)	00(Invalid)/01(valid) 0.00-99.99/100.0-400.0(Hz) 0.2*constant current-1.20*constant current(A) 0.2*constant current-1.20*constant current(A)	00 0.00 Rated Current of inverter Rated	-	,	4-35 4-34 4-36
restart	b007 b012 b212	failure/under-voltage retry time selection Open-phase selection Frequency setting to match Electronic thermal level (2 rd motor) Electronic thermal	00(Invelid)/01(valid) 0.00-99.99/100.0-400.0(Hz) 0.2*constant current-1.20*constant current(A) 0.2*constant current-1.20*constant current(A) 00/(reduced characteristic)01(constant characteristic)/	00 0.00 Rated Current of inverter Rated Current of Inverter	: - -	,	4-35 4-34 4-36 4-36
	ь007 b012	failure/under-voltage retry time selection Open-phase selection Frequency setting to match Electronic thermal level (2" motor) Electronic thermal level (characteristic selection	00(Invalid)/01(valid) 0.00-99.99/100.0-400.0(Hz) 0.2*constant current-1.20*constant current(A) 0.2*constant current-1.20*constant current(A)	00 0.00 Rated Current of inverter Rated Current of	-	,	4-35 4-34 4-36
	b007 b012 b212 b013	failure/under-voltage retry time selection Open-phase selection Frequency setting to match Electronic thermal level (2** motor) Electronic thermal characteristic selection Electronic thermal	00(Invelid)/01(valid) 0.00-99.99/100.0-400.0(Hz) 0.2*constant current-1.20*constant current(A) 0.2*constant current-1.20*constant current(A) 00/(reduced characteristic)01(constant characteristic)/ 02(free setting)	00 0.00 Rated Current of inverter Rated Current of inverter 01	: - -		4-35 4-34 4-36 4-36 4-38
	b007 b012 b212	failure/under-voltage retry time selection Open-phase selection Frequency setting to match Electronic thermal level (2"d motor) Electronic thermal characteristic selection Electronic thermal characteristic selection	00(Invalid)/01(valid) 0.00-99.99/100.0-400.0(Hz) 0.2*constant current-1.20*constant current(A) 0.2*constant current-1.20*constant current(A) 00/(reduced characteristic)/01(constant characteristic)/ 02(free setting)	00 0.00 Rated Current of inverter Rated Current of Inverter	: - -	,	4-35 4-34 4-36 4-36
	b007 b012 b212 b013	failure/under-voltage retry time selection Open-phase selection Frequency setting to match Electronic thermal level (2 nd motor) Electronic thermal characteristic selection Electronic thermal characteristic selection (2 nd motor)	00(Invelid)/01(valid) 0.00-99.99/100.0-400.0(Hz) 0.2*constant current-1.20*constant current(A) 0.2*constant current-1.20*constant current(A) 00/(reduced characteristic)01(constant characteristic)/ 02(free setting)	00 0.00 Rated Current of inverter Rated Current of inverter 01	-		4-35 4-34 4-36 4-36 4-36
	b007 b012 b212 b013 b213	failure/under-voltage retry time selection Open-phase selection Frequency setting to match Electronic thermal level (2" motor) Electronic thermal characteristic selection Electronic thermal characteristic selection (2" motor) Free electronic thermal	00(Invelid)/01(valid) 0.00-99.99/100.0-400.0(Hz) 0.2*constant current-1.20*constant current(A) 0.2*constant current-1.20*constant current(A) 00/(reduced characteristic)01(constant characteristic)/ 02(free setting) 00/(reduced characteristic)11(constant torque characteristic)/ 02(free setting)	00 0.00 Reted Current of inverter Reted Current of Inverter 01		,	4-35 4-34 4-36 4-36 4-38
	b007 b012 b212 b013	failure/under-voltage retry time selection Open-phase selection Frequency setting to match Electronic thermal level (2 nd motor) Electronic thermal characteristic selection Electronic thermal characteristic selection (2 nd motor) Free electronic thermal frequency 1	00(Invalid)/01(valid) 0.00-99.99/100.0-400.0(Hz) 0.2*constant current-1.20*constant current(A) 0.2*constant current-1.20*constant current(A) 00/(reduced characteristic)/01(constant characteristic)/ 02(free setting)	00 0.00 Rated Current of inverter Rated Current of inverter 01	-		4-35 4-34 4-36 4-36 4-36
	b007 b012 b212 b013 b213 b015	failure/under-voltage retry time selection Open-phase selection Frequency setting to match Electronic thermal level (2" motor) Electronic thermal characteristic selection Electronic thermal characteristic selection (2" motor) Free electronic thermal frequency 1 Free electronic thermal	00(Invalid)/01(valid) 0.00-99.99/100.0-400.0(Hz) 0.2*constant current-1.20*constant current(A) 0.2*constant current-1.20*constant current(A) 00/(reduced characteristic)/01(constant characteristic)/ 02(free setting) 00/(reduced characteristic)/01(constant torque characteristic)/ 02(free setting) 0400.(Hz)	00 0.00 Rated Current of inverter Rated Current of Inverter 01 01		· · · · · · · · · · · · · · · · · · ·	4-35 4-34 4-36 4-36 4-38 4-38
	b007 b012 b212 b013 b213	failure/under-voltage retry time selection Open-phase selection Frequency setting to match Electronic thermal level (2** motor) Electronic thermal characteristic selection Electronic thermal characteristic selection (2** motor) Free electronic thermal frequency 1 Free electronic thermal current; 1	00(Invelid)/01(valid) 0.00-99.99/100.0-400.0(Hz) 0.2*constant current-1.20*constant current(A) 0.2*constant current-1.20*constant current(A) 00/(reduced characteristic)01(constant characteristic)/ 02(free setting) 00/(reduced characteristic)01(constant torque characteristic)/ 02(free setting) 0.400.(Hz)	00 0.00 Reted Current of inverter Reted Current of Inverter 01		,	4-35 4-34 4-36 4-36 4-38
	b007 b012 b212 b013 b213 b015	failure/under-voltage retry time selection Open-phase selection Frequency setting to match Electronic thermal level (2" motor) Electronic thermal characteristic selection Electronic thermal characteristic selection (2" motor) Free electronic thermal frequency 1 Free electronic thermal current 1 Free electronic thermal	00(Invalid)/01(valid) 0.00-99.99/100.0-400.0(Hz) 0.2*constant current-1.20*constant current(A) 0.2*constant current-1.20*constant current(A) 00/(reduced characteristic)01(constant characteristic)/ 02(free setting) 00/(reduced characteristic)01(constant torque characteristic)/ 02(free setting) 0400.(Hz) 0.0-1000.(A)	00 0.00 Reted Current of inverter Reted Current of Inverter 01 01 0.		,	4-35 4-34 4-36 4-36 4-38 4-38 4-37
	b007 b012 b212 b013 b213 b015 b018	failure/under-voltage retry time selection Open-phase selection Frequency setting to match Electronic thermal level (2" motor) Electronic thermal characteristic selection (2" motor) Free electronic thermal frequency 1 Free electronic thermal current 1 Free electronic thermal current 1 Free electronic thermal	00(Invalid)/01(valid) 0.00-99.99/100.0-400.0(Hz) 0.2*constant current-1.20*constant current(A) 0.2*constant current-1.20*constant current(A) 00/(reduced characteristic)/01(constant characteristic)/ 02(free setting) 00/(reduced characteristic)/01(constant torque characteristic)/ 02(free setting) 0400.(Hz)	00 0.00 Rated Current of inverter Rated Current of Inverter 01 01		· · · · · · · · · · · · · · · · · · ·	4-35 4-34 4-36 4-36 4-38 4-38
	b007 b012 b212 b013 b213 b015 b018	failure/under-voltage retry time selection Open-phase selection Frequency setting to match Electronic thermal level (2** motor) Electronic thermal characteristic selection Electronic thermal characteristic selection (2** motor) Free electronic thermal frequency 1 Free electronic thermal current: 1 Free electronic thermal frequency 2 Free electronic thermal	00(Invelid)/01(valid) 0.00-99.99/100.0-400.0(Hz) 0.2*constant current-1.20*constant current(A) 0.2*constant current-1.20*constant current(A) 00/(reduced characteristic)01(constant characteristic)/ 02(free setting) 00/(reduced characteristic)01(constant torque characteristic)/ 02(free setting) 0400.(Hz) 0400.(Hz)	00 0.00 Reted Current of inverter Reted Current of inverter 01 01 0. 0.0		· · · · · · · · · · · · · · · · · · ·	4-35 4-34 4-36 4-36 4-38 4-36 4-37 4-37
Electronic thermal instanta	b007 b012 b212 b013 b213 b015 b018	failure/under-voltage retry time selection Open-phase selection Frequency setting to match Electronic thermal level (2" motor) Electronic thermal characteristic selection Electronic thermal characteristic selection (2" motor) Free electronic thermal frequency 1 Free electronic thermal frequency 2 Free electronic thermal frequency 2 Free electronic thermal	00(Invalid)/01(valid) 0.00-99.99/100.0-400.0(Hz) 0.2*constant current-1.20*constant current(A) 0.2*constant current-1.20*constant current(A) 00/(reduced characteristic)01(constant characteristic)/ 02(free setting) 00/(reduced characteristic)01(constant torque characteristic)/ 02(free setting) 0400.(Hz) 0.0-1000.(A)	00 0.00 Reted Current of inverter Reted Current of Inverter 01 01 0.		,	4-35 4-34 4-36 4-36 4-36 4-37 4-37
	b007 b012 b212 b013 b213 b015 b018	failure/under-voltage retry time selection Open-phase selection Frequency setting to match Electronic thermal level (2 nd motor) Electronic thermal characteristic selection Electronic thermal characteristic selection (2 nd motor) Free electronic thermal frequency 1 Free electronic thermal current 1 Free electronic thermal current 1 Free electronic thermal frequency 2 Free electronic thermal frequency 2 Free electronic thermal current 1 Free electronic thermal	00(Invelid)/01(valid) 0.00-99.99/100.0-400.0(Hz) 0.2*constant current-1.20*constant current(A) 0.2*constant current-1.20*constant current(A) 00/(reduced characteristic)01(constant characteristic)/ 02(free setting) 00/(reduced characteristic)01(constant torque characteristic)/ 02(free setting) 0400.(Hz) 0400.(Hz)	00 0.00 Reted Current of inverter Reted Current of inverter 01 01 0. 0.0		· · · · · · · · · · · · · · · · · · ·	4-35 4-34 4-36 4-36 4-38 4-36 4-37 4-37
	b007 b012 b212 b013 b213 b015 b016 b017	failure/under-voltage retry time selection Open-phase selection Frequency setting to match Electronic thermal level (2" motor) Electronic thermal characteristic selection Electronic thermal characteristic selection (2" motor) Free electronic thermal frequency 1 Free electronic thermal frequency 2 Free electronic thermal frequency 2 Free electronic thermal	00(Invalid)/01(valid) 0.00-99.99/100.0-400.0(Hz) 0.2*constant current-1.20*constant current(A) 0.2*constant current-1.20*constant current(A) 00/(reduced characteristic)01(constant characteristic)/ 02(free setting) 00/(reduced characteristic)01(constant torque characteristic)/ 02(free setting) 0400.(Hz) 0.0-1000.(A) 0.400.(Hz]	00 0.00 Rated Current of inverter Rated Current of Invarter 01 0. 0.0		,	4-35 4-34 4-36 4-36 4-38 4-37 4-37 4-37

	Code	Function name	Setting range	Initial data	Setting on run	Change on	Page
	b021	Overload restriction selection	00(Invalid)/01(enabled on acceleration / constant speed)/02(enabled on constant speed)	01		1	4-38
Overload limit	b022	Overload restriction level	0.50° rated current-1.50° rated current(A)	Rated current of inverter x 1 20	-		4-38
Ē	6023	Overload restriction limit constant	0.10-30.00(=)	1.00			4-38
10 a d	b024	Overload restriction 2	00(invalid)/01(valid on acceleration / constant speed)/02(valid on	01		1	4 38
Over	b025 Overload restriction level 2 0.50*rated current-1.50*rated current(A)			Rated current of inverter x1.20		,	4-38
	p028	Overload restriction constant 2	0.10-30.00(s)	1.00		1	4-38
Lock	b031	Software lock mode selection	00(Impossible to change the data except this Item when SFT terminal is ON)/ 01(Impossible to change the data except setting frequency item when SFT terminal is ON)/02(Impossible to change the data except this item)/ 03(Impossible to change the data except setting frequency item)/ 10(possible to change data on operating) 0 Free VII frequency2(Hz)	01		,	4-45
	b101	Free V/f voltage 1	0800.0(V)	0.0	-	 	4.23
	b102	Free V/f frequency 2	0. Free V/f frequency3(Hz)	0.			4-23
ł	b103	Free V/f voltage 2	0800.0(V)	0.0		<u> </u>	4.23
6	b104	Free V/f frequency 3	0 Free V/f frequency4(Hz)	0			4.23
setting	b105	Free V/f voltage 3	0800.0(V)	0.0			4.23
=	b108	Free V/f frequency 4	0 Free V/I frequency5(Hz)	Ō			4-23
=	b107	Free V/f voltage 4	0800 <u>.0(V)</u>	0.0			4-23
3	b108	Free V/I frequency 5	0 Free V/I frequency8(Hz)	0			4-23
Free	5109	Free V/f voltage 5	0800.0(V)	0.0			4.23
<u> </u>	b110	Free V/f frequency 6	0 Free V/f frequency7(Hz)	D.			4-23
l	b111	Free V/f voltage 8	0.800.0(V)	0.0			4-23
	b112	Free V/f frequency 7 Free V/f voltage 7	0400.(Hz)	0			4-23
setting	C001	Intelligent Input 1 setting	0R00.0(V) 01/(RV:Reverse is velid)/02(CF1:Multi-speed1)/ 03(CF2:Multi-speed2)/ 04(CF3:Multi-speed3)/ 05(CF4:Multi-speed4)/ 06(JG:Jogging)/ 07(DB:External OC braking)/08(SET:2 nd control)/	18/18	-	1	4-23
inal se	C002	Intelligent input 2 setting	09(2CH:two-stage adjustable speed)/11(FRS:Frae-run)/ 12(EXT:External trip)/13(USP:Unattended start protection)/ 14(CS:commercial change)/15(SFT:software lock)/ 15(AT:Analog input voltage/current select)/15(FS:Reset Inverter)/	16/18		,	4-42
pul ter	C003	Intelligent input 3 setting	20(STA:3wire run)/ 21(STP:3wire keep)/22(F/R;3wire forward/reverse)/ 23(PID:PID selection valid/invalid)/24(PIDC:PID integrating reset)/ 27(UP:Remote control UP function)/	03/13		,	4-42
Intelligent input terminal	C004	Intelligent input 4 setting	28(DWN:Remote control DOWN function)/ 29(UDC:Remote control data clear)/ 32(SF1:Multi-speed bit1)/ 33(SF2:Multi-speed bit2)/34(SF3:Multi-speed bit3)/ 35(SF4:Multi-speed bit4)/38(SF5:Multi-speed bit5)/	02/02	-	1	4-42
<u>=</u>	C005	Intelligent input 5 setting	37(SF6:Multi-speed bit5)/33(SF7:Multi-speed bit5)/ 37(SF6:Multi-speed bit5)/33(SF7:Multi-speed bit7)/ 39(OLR:Overload restriction change)/no(NO:No assign)	01/01	-	<i>,</i>	4-42
	C011	Intelligent input1 a/b (NO/NC) selection	00(NO)/01(NC)	00/00		,	4-42
	C012	Intelligent Input2 m/b (NO/NC) selection	00(NO)/01(NC) ·	00/00	•	1	4-42
ופר וחפסו	C013	Intelligent input3 a/b (NO/NC) selection	00(NO)/01(NC)	00/01	-	1	4-42
er E	C014	Intelligent input4 a/b (NO/NC) selection	00(NO)/01(NC)	00/00	-	1	4-42
Input terminal setting intelligent	C015	Intelligent input5 a/b (NO/NC) selection	00(NO)/01(NC)	00/00	•	,	4-42
	C019	Input FW s/b (NO/NC) Selection	00(NO)/01(NC)	00/00	•		4-42
ting	C021	Intelligent output 11 setting	00(RUN:running)/01(FA1:Frequency arrivaltype1 signal)/	01		,	4.51
1 20	C022	Intelligent output 12 setting	02(FA2:frequency arrival type2 signal)/03(OL:Overload advance notice signal)/04(OD:Output deviation for PID control)/05(AL:Alarm signal)/	00	-	1	4-51
erm:	C026	Alarm relay output	DS(FA3:Only setting frequency)/08(IP:On instantaneous stop/ 09(UV:Under voltage)/11(RNT:RUN time over)/12(ONT:ON time over)/ 13(THM:thermal caution)	05	-		4-51
output terminal setting	C027	FM selection	00(Output frequency)/01(Output current) / 03(Digital output frequency)/04(Output voltage)/ 05(Input electric power)/06(thermal load rate)/07(LAD frequency)	00	-	,	4-58
i den	C028	AM selection	00(Output frequency)/01(Output current)/04(Output voltage)/ 05(Input electric power)/08(thermal load rate)/07(LAD frequency)	00		,	4-57
12 e E	C029	AMI selection	00(Output frequency)/01(Output current)/04(Output voltage)/ 05(Input electric power)/08(Thermal load rate)/07(LAD frequency)	00	-	,	4-57
	C031	Intelligent output 11 a/b	00(NO)/01(NC)	00	·· .		4-52
Ē	C032	Intelligent output 12 a/b	00(NO)/01(NC)	00		-	4-52
ž.	C038	Alarm relay output a/b	00(NO)/01(NC)	01		7	4-52
State ting	C040	Overload advance notice signal output mode	00(On accel. And decel, constant speed)/01(Only constant speed)	01			4-39
Output lerminal state setting. Output level setting	C041	Overload advance notice level	0.0-2.0*rated current(A)	Inverter rated current	.]	,	4-38
it put	C042	Frequency arrival setting for acceleration.	0.00-99.99/100.0-400.0(Hz)	0.00	-		4-53
ōδ	C043	Arrival frequency setting for deceleration.	0.00-99.99/100.0-400.0(Hz)	0.00		1	4-53
1	C044	PID deviation setting level	3.0			4-31	

	_	on Mode		A_164.4.4.4	Setting on	Change	
	Code	Function name	Setting range	Initial data	run	mode on	Page 4-61
- 1	C070	Data command Communicating	02(operator)/03(RS485)/04(option1)/05(option2)				
inction	C071	transmission speed	03(2400bps)/04(4800bps)/05(9800bps)/05(19200bps)	04	-	1	4-61
,	C072	Communication code	132.	1.		1	4-61
اے	C073	Communication bit	7(7bit)/8(8bit)	7	<u> </u>	/	4-61
Ž	C074	Communication parity	00(no parity name)/01(even parity)/02(odd parity)	00	-		4-61
	C075	Communication stop bit Communication waiting	1(bii)/2(bit) 01000.(ms)	0.		-	4-61 4-61
	COBI	time O adjustment	09999./1000-6553(10000-65530)			7	
setting	C082	Ol adjustment	09999./1000-6553(10000-65530)	forwarding Setting on forwarding	1	1	-
8 10	C083	O2 adjustment	09999./1000-6553(10000-65530)	Setting on forwarding	,	1	-
Ē	C085	Thermistor adjustment	0.0 - 1000.	105.0	7	7	4-57
	C086	AM offset adjustment	0.0 - 10.0(V)	0.0	7	7	4-57
유	C087	AMI adjustment	0 255.	50	-	7	4-57
Analog	C088	AMI offset adjustment	0, - 20,0(mA)	Selling on	1	1	4-57
_		RUN time/Power QN time		forwarding	·		
	6034	level	09999,/1000-8553(10000-85530)hr	0.	-	<i>*</i>	4-55
	b035	Operation direction restrict	00(Reverse is valid)/01(Only forward)/02(Only reverse)	00	•	×	4-14
	ь036	Start reduced voltage	00(Start reduced voltage time small)-06(Start reduced voltage time large)	06	-		4-40
į	ь037	Display selection	00(all display)/01(each function display)/02(User setting / main setting)	00		4	4-59
-	ь080	AM adjustment	0. · 265.	150	· ·	1	4-57
	ь081	FM adjustment	0. · 255.	60	7	/	4-56
	b082	Start frequency adjustment	0.10-9.99(Hz)	0.50		1	4-40
	6083 6084	Carrier frequency setting	0.5-12.0(kHz) Derating enable, 00(Trip history clear)/01(Data initialization)/02(Trip history clear + data	3.0	-		4-18 4-58
	b085	Country code for	Initialization) O0(Interior)/01(EC)/02(USA)	01/02			4-58
	b086	initialization Frequency scalar		1.0	,	1	4-12
	-b087	STOP key enable	0.1-99.9 00(velid)/01(invalid)	00			4-15
- 1		Resume on FRS				,	
	6088 6090	cancellation mode	00(0Hz start)/01(Start f-equaling)	0.0	-	,	4-46
	b090	BRD usage ratio Stop mode selection	0.0-100.0(%) 00(deceleration stop)/01(Free-run stop)	00			4-15
	b092	Cooling fan control	00(Always ON)/01(ON during run, After power ON, then for 5 minutes	00			4-41
	b095	BRD selection	on stop is Implied.) 00(invalid)/01(valid <invalid during="" stop="">)/02(valid<valid during="" stop="">)</valid></invalid>	00		7	4-41
	b096 b098	BRD ON level Thermistor selection	330-380/860-780(V) 00(invalid)/01(Positive temperature coefficient enable)/02 (NTC	360/720 00		1	4-41 4-57
	P088		enable) 0 9999. (ohm)	3000.		7	4-57
others	C061		0 100. (%)	80	·	4	4-36
€i	C091	Debug mode selection	00(No display)/01(Display)	00		1	
	C101	UP/DWN selection	00(No frequency data)/01(Keep frequency data)	00	-	1	4-49
The	C102	Reset selection	00(Trip cancel during ON)/01(Trip cancel during OFF)/ 02(Valid only during trip <cancel during="" on="">)</cancel>	00	1	1	4-48
	C103	Reset f frequency matching selection	00(0Hz start)/01(Start f-equaling)	00	•	1	4-48
	C121	O zero adjustment	09999./1000-6553(10000-65530)	Set on forwarding		1	
į	C122	Ol zero adjustment	09999./1000-6553(10000-65530)	Sel on	-	,	_
		-		forwarding Set on			ļ
	C123	O2 zero adjustment	09999./1000-6553(10000-65530)	forwarding		1	_
	H003	1" allowable motor selection	0.20-75.0(kW)	Set on forwarding	-	•	4-80
	H203	2 rd allowable motor selection	0.20-75.0(kW)	Set on forwarding		•	4-80
-	H004	1" motor pole selection	2/4/6/8(pole)	4			4-80
-	H204	2 rd motor pole selection	2/4/6/8(pole)	4	-	•	4-80
ļ	H008	1°1 stabilized factor	0 255.	100.	· · ·		4-60
}	H208	2 rd stabilized factor Option1 operation selection	0 255.	100.	1		4-80
ļ		on error 00(TRP)/UT(RUN)		,00	-	1	4-80
ļ	P002	Option2 operation selection on error 00(TRP)/01(RUN)		00	·	1	4-80
ŀ	U001		no/d001-P002	no			4-59
ŀ	U002		! no/d001 P002	no		1	4-59
- }	U003	User3 selection	no/d001 -P002	no		•	4-59
- }	U005	User4 selection	no/d001-P002	no	-		4-59
}	U006		no/d001-P002	no			4-59
ļ	U007	User7 selection	no/d001-P002 no/d001-P002	no			4-59
}	U008	User8 selection	no/d001-P002	no		-	4-59
Ì	U009	User9 selection	no/d001-P002	no	-	-	4-59
	U010	User10 selection		no	-	7	4-59
[U011		no/d001-P002	по			4-59
	U012	User12 selection	no/d001-P002	no			4-59

4.3 Exdanation of function

4.3.1 Monitor mode

Output freauency monitor

Indication code d001 displays the frequency the inveter outputs The data is displayed as follows.

When $\textbf{d001}\ \text{is}\ \text{displayed,}$ the monitor lamp 'Hz' is illuminated.

(Display)

0.00 - 99.99 : Display is in **0.01Hz** unit. 100.0 - 400.0 : Display is in **0.1Hz** unit.

Output current monitor

Indication code d002 displays the output current value.

The data is displayed as follows.

In case of displaying d002, the monitor lamp 'A' is illuminated (Display)

0.0 • 999.9 : Display is in **0.1A** unit.

Relation code

d001: Output frequency monitor

Relation code

d002: Output current monitor

Oceration directon monitor

Indication code d003 displays the direction that the Inverter output is Rotating. Forward, reverse or stop.

On operating the inverter (in case of forward or reverse). the RUN lamp will illuminate.

(Display)

F : Forward

o : stop

r : Reverse

Relation code d003: Operation direction monitor

PID feedback monitor

When you select PID function (01) in A071. the inverter displays the feedback value changed by A075 (PID scale).

"Display of monitor part " = "Feedback quantity " x " PID scale "
(Frequency command value) (A075)

(Setting)

A071: 0.1(PID is effective)

A075 : 0.01-99.99(Display is 0.01-99.99(Set with the 0.01 unit)

(Display)

0.00 - 99.99 : Display is in 0.01 unit. 100.0 - 999.9 : Display is in 0.1 unit. 1000 - 9999 : Display is in 1 unit. (100 - (999 : Display is in 10 unit. Relation code

d004; PID feedback monitor

A071:PID selection


A075: PID scale

Intelliaent input monitor

The LED display will monitor the state of the intelligent inputs.


(Example)

FW; input intelligent 2,1:ON Input intelligent 5, 4. 3:OFF



Relation code
d005:Inteiligent input monitor

Display



In case of FW
Lights up: ON
Lights out: OFF

Intelligent output monitor


The LED display will monitor the state of the intelligent outputs

Relation code

d006: Output intelligent monitor

(Example)

Output intelligent 12. 11: ON Output alarm A: OFF



Display

(Black): Lights up

(White): Lights out

Relation code

monitor

factor

d007: Frequency conversion

b086: Frequency conversion

Freauency conversion monitor

This inverter displays **the** value changed by the **Inverter** output frequency and the value set in **b086** on the monitor **part**.

'Monitor part of display' • " output freque"cy(d001)' x " output frequency factor(b086)"

(Display) Display of d007

0.00 - 99.99: Display is in 0.01 unit. 100.0 - 999.9: Display is in 0.1 unit. 100. - 9999.: Display is in 1 unit. 1000 - 3996 : Display is in 10 unit.

(Range of setting) The setting range of b066

0.1 - 99.9 :Set it with the 0.1 unit.

(Example)Output frequency (d001):50.00Hz

When the frequency conversion factor (b086) is 1.1, the frequency conversion monitor (d007) displays '55.00' as '50 \times 1 .1 = 55.00

Output voltaae monitor

This inverter displays the output voltage of the inverter converted into the alternating Voltage.

The monitor lamp "V" should illuminate while the contents of d013 are displayed.

Relation code

d013: Output voltage monitor

(Display)

0.0 - 600.0 :Display is in 0.1V unit

Input electric Dower monitor

Display output electric power from inverter.

The monitor lamp "kw" ("V" and "A") should illuminate while the contents of d014 is displayed.

Relation code

d014: Input electric power monitor

(Display)

0.0 - 999.9 :Display is in 0.1 kw unit.

Accumulated time monitor on RUN

The operation time of inverter is **accumulated** and the value is displayed. (Display)

0. • 9999. : Display is in 1 hour units.
1000 • 9999 : Display is in 10 hour units.
(100 • (999 : Display is in 100 hour units.

Relation code
d016: Accumulated time
monitor on RUN

Power ON time monitor

This accumulates the time running to **the** inverter and **displays** the **value**. (Display)

0. - 9999. : Display is in 1 hour units.1000 - 9999 : Display is in 10 hour units.(100 - (999 : Display is in 100 hour units.)

Relation code
d017: Power ON time
monitor

Trip time monitor

This displays the number of inverter trips. (Display)

9999. : Display is in 1 times unit.
 1000 - 6553 : Display is in 10 times unit.

Trip monitor I-6

This displays the details for the last six protective trips.

The trip monitor 1 displayed the details of **the** last trip. (Display contents)

[1] Trip Code (Display anything from E01 to E79.)(Notes1)

[2] Output frequency on tripping (Hz)

[3] Output current on tripping (A)


[4] The direct voltage (between P and N) on tripping (V)


[5] The accumulated time inverter was operating until'tripping (hr)

[6] The accumulated time inverter was run until tripping (hr)

(Note 1) Please refer to the pages 4.4 Protection function list (2) Trip monitor display.

The methods of trip monitor





(Note2) In case of no Iripping is displayed

F001

A001

Relation code

:Output frequency

A020/A220: 1st/2nd multistage

C001-C005: Output intelligent

speed zero

:Frequency command select

4.3.2 Function mode

Setting of the output freauency

Setting the output frequency of the motor.

The output frequency is set by F001, when the frequency command select (A001) is set to 02.

Please refer to the frequency command select (A001) about other methods of frequency **setting**.

When a frequency is set in F001, the same value is automatically set in

both Multispeed 0 (A020 and the second set of motor data multispeed 0 (A220) when the SET terminal is ON. In the case of using SET, you will need to assign 08(SET) to an intelligent input terminal.

Set item	Function	Data	Contents	
	code			
Output frequency	F001	0.0 start frequency-First/Second	Unit : Hz "F001" = "A020"	
Multistage speed zero	A0244A220	highest frequency	Second control setting of "F001" = "A220"	

Operation direction

This is effective when the operating command is set by the digital operator.

Function code	Data	contents
FO04	00	Forward
F004	01	Reverse

Relation code
F004: Operation direction
select

Selection with limits of operation direction

The direction of the motor can be restricted.

Function code	Data	Contents
F035	00	Forward/reverse is effective.
b035	01	Only forward
	02	Only reverse

Relation code
b035: Selection with limits
of operation direction

Freauency command selection

Select the method of frequency command.

When 0-10Vdc is inputted to the frequency command by 02-L terminal. operation direction of motor reverses.

Relation code

A001:Frequency command selection

On output frequency monitor d001, you can't get information about forward/reverse. So be sure with operation direction monitor d002.

Function c <u>ode</u>	Data	contents
	00	Setting frequency with the potentiometer the digital operator has.
	01	Setting frequency with control terminals (Terminals: O-L. 01-L. 02-L)
A001	02	Setting frequency with digital operator(F001), remote operator.
!	03	Setting frequency with RS485 terminals for communication.
	04	Setting frequency with option board 1.
	05	Setting frequency with option board 2.

A002

C019

F004

Relation code

selection

C001-C005: Input intelligent

:inputting

:Operation command

FW a/b (NO/NC) selection

:Operation direction select

Operation command selection

Select the control of RUN/STOP commands.

Operation command from the control terminals (Terminal)

Start/Stop by ON/OFF of control terminals.

Forward : FW-CM1 terminal

Reverse : RV-CM1 terminal

Put 01(RV) to an intelligent Input terminal.

When using the FW terminal, it is possible to change the contact from NO to NCby settin a orb (respectively) in C019.

When operating from the digital operator, set operation direction in FO04.

or operate Start/Stop with RUN key/STOP key on the digital operator.

Setting item	Function code	Data	Contents
		01	Start/Stop with control terminals(Terminal).(FW, RV)
Operation		02	Start/Stop with digital operator, remote operator.
command	A002	03	Start/Stop with RS485 terminals for communications.
selection		04	Start/Stop with option board 1.
		05 Sta	rt/Stop with option board 2.
Input FW a/b	co19	00	a contact (NO)
(NO/NC) selection	C011-C015	01	b contact (NC)

Selection on stop

When stop is commanded from the digital operator or the control terminals (Terminal). select the stop after **slowing-down** according to slowing-down time or the free run stop.

When the second cycle is started while in free run stop, the **inverter** follows **the** free-run stop selection **b088** and restarts.

(Refer to the item of free-run stop.)

Relation code

b091 :Selection on stop

F003/F203: First/Second deceleration time

b003 :Waiting time for retrying b007 :Frequency setting of

frequency coincidence

b088 :Select for free-run stop

Setting item	Function code	Data	contents
Selection on Stop	b091	00	Normal stop (Decelerated stop)
		01	Free-run stop
Selection of free-run	ь088	00	0Hz start
stop		01	Start frequency matching
Frequency setting of frequency matching	b007	0.00-400.0 l	Jnit : Hz
Wailing time for retrying	b003	0.3-100.	Unit: second

Selection of Stop key

Even though the control terminals are selected for the operation command, you can still set whether the stop key of operator (digital operator **etc**) is effective or not.

Function code	Data	Contents
ь087	00	The stop key is effective.
	01	The stop key is ineffective.

Relation code

b087: Selection of stop key

Adiustable time

The acceleration and deceleration lime can be **set**.

Set a long time to accelerate or decelerate slowly or **set** a short lime lo **accelerate** or decelerate quickly.

The time setting is **the** time it takes to accelerate from **zero** to the maximum frequency and to decelerate from the maximum **frequency** to **zero**.

Relation code

F002/F202: First/Second acceleration

time


F003/F203: First/Second deceleration

time

A004/A204: 1st/2nd maximum

frequency

Set item	Function code	Limit of setting	contents
Acceleration time	F002/F202	0.01-3600.	Unit: second Setting acceleration time from zero to maximum frequency.
Deceleration time	F003/F203 ().01-3600.	Unit: second Setting deceleration time from maximum frequency to zero.



However short you set the adjustable time, the adjustable time of the actual motor can't be shorter than the shortest adjustable time determined by the inertial Effect J of the mechanical system and motor torque.

If you set the time shorter than the shortest adjustable time, a protection trip of OC or OV may occur.

Acceleration time ts

$$t_s = \frac{(JL + JM) \times NM}{9.55 \times (Ts + TL)}$$

JL: J of the load converted into motor shaft (kg/m²)

JM: J of the motor (kg/m²)

NM: Motor revolving (r/min)

Deceleration time to

Ts: The maximum motor acceleration torque on inverter driving (Nm)

Ts: The maximum motor deceleration torque on inverter driving (Nm)

(JL + JM) x NM TL: Needed transit torque (Nm)

 $t_{B=}$ $\frac{(JL + JM) \times NM}{9.55 \times (TB+TL)}$

Base frequency

Base frequency and motor voltage

AVR function


(1) Base frequency and motor voltage

Relation code A003/A203: 1st/2nd base frequency

A081: AVR selection

A082: Motor voltage selection

On selection of base frequency and motor voltage, set the output of the inverter (frequency voltage) lo the motor rating.



The Base frequency is the nominal frequency of the motor. this value can be found on-the nameplate of the motor. It is important to match the Base frequency (A003) lo this nominal value or there is risk of damage to the motor.

If a motor has a base frequency higher than 60Hz, it is considered to be a special motor. In this situation, it is important lo make sure the maximum output current of the inverter is higher than the FLC of the motor.

The Motor Voltage Selection is the nominal voltage of the motor. this value can be found on the nameplate of the motor. It is important to match the Motor Voltage (A082) to this nominal value or there is risk of damage lo the motor.

When changing second base frequency (A203) an intelligent input terminal must be set lo 08(SET) and switched on.

Selling item	Function code	! Setting limit	Contents
Base frequency	A003/A203	301st/2nd maximum _firequency	Unit:Hz
		200/215/220/230/240	Unit:V When inverter is 200V class, selection is possible.
Motor voltage selection	A082	380/400/415/440/460/480	Unit:V When inverler is 400V class, selection is possible.
		575/600	Unit:V When inverler is 600V class. selection is possible.

(2) AVR function

Even if the incoming voltage changes, this function will keep the output voltage and a constant voltage level. The output voltage lo the motor in this function references lo the voltage selected on motor voltage selection. Select Yes/No of this function on A081 AVR selection.

Function code	Data	Contents	Description
	00	Always ON	This function is effective on acceleration, constant speed, deceleration.
	01	Always OFF	This function is ineffective on acceleration, constant speed,
A 0.04			deceleration.
A08 1	02	On decelerating OFF	This increases a loss of motor and reduces the energy regenerated to inverter on decelerating.

Relation code

frequency

A004/A204: 1st/2nd maximum

Maximum freauency

Set the maximum frequency value of the inverter.


This set value is the maximum frequncey that the inverter will achieve when

It receives top speed reference from the control terminals or the digital operator.

To the change the 1s1/2nd maximum frequency, set an intelligent input terminal to 08(SET) and switch the input ON.

The **Inverter** output voltage from the base **frequencey to** the maximum frequency is the same level as **the** voltage selected on **the** motor voltage selection.

Function code	Limit of setting	Contents
A004/A204	30400.	Unit : Hz



Carrier freauency

The carrier frequency of the PWM wave-form output from the inverter is adjustable by changing **b083**.

If the carrier frequency is set higher, the audible noise from motor will be reduced but the RFI noise and the leakage current may be increased.

This function may help to avoid the resonant frequency of the motor or the mechanical system.

	Function code	Limit of setting	Contents
Į	b083	0.5-12.0 (Note1)	Unit:kHz

(Note1) The maximum value of the carrier frequency in order to achieve full output current is different depending on the capacity. When raising the carrier frequency, the rated output current will be reduced.

Contents	Maximum carrier frequency	Derating on carrier frequency = 12kHz
11kW	12	100%
15kW	12	100%
18.5kW	10	90%
22kW	6	60%
33kW	3	70%

Relation code b083: Carrier frequency

External analog output

This inverter has three kinds of external analog ouput terminals.

O-L terminal : 0 • 10Vdc
OI-L terminal : 4 • 20mA
02-L terminal : -10 • 10V

The setting contents of this function is as follows.

Relation code

A005: AT terminal selection

A006: 02 Selection

C001-C005; Intelligent imput terminal

Setting item	Function code	Data	Contents		
AT terminal selection	A005	00	Change of 0/01 (AT terminal ON : 0I-L valid With AT terminal OFF : O-L valid)		
		01	Change of O/O2 AT terminal ON: 02-L valid with AT terminal I AT terminal OFF: O-L valid		
		00	Single		
02 selection	A006	01	Auxiliary frequency command of O, Ol(No reverse)		
					02


Assign 11(AT) to intelligent input terminal.

The frequency setting is the values from terminals O, OI and 02 when 11(AT) isn't assigned.

The following frequency command methods are available by combining A005. A006 with the intelligent output AT terminal.

In the case that reverse and **FW(forward)** terminals are ON, the **inverter** operates reversely when (main **frequency command** + **auxiliarly** frequency command)< 0.

	A006	A 005	AT terminal	Main frequency command	Existence of Auxiliarly frequency command(02-L)	Existence Of Reverse		
		00	OFF	O-L	No			
	00	00	ON	OI-L	No	No		
	00	01	OFF	0-L	No			
		01	ON	02-L	No	Yes		
Intelligent input terminal on assigning AT	01	1	out	00	OFF	O-L	Yes	
		(Example1)	ON	OI-L	Yes	No		
		01	OFF	0-L	Yes	· · · · · · · · · · · · · · · · · · ·		
			ON	O2-L	No			
		00	OFF	O-L	Yes			
	02	(Example2)	ON	OI-L	Yes	Yes		
	02	ì	OFF	O-L	Yes			
		01	ON	02-L	No			
Intelligent input	00	-	-	02-L	No	Yes		
Terminal when	01	<u> </u>	-	Adding O-L and OI-L	Yes	No		
Don't assign AT	02	-	-	Adding O-L and OI-L	Yes	Yes		



Output Freauencv Start/End

External analog signal from the control terminals

(frequency command)

O-L terminal : 0 - 10V
OI-L terminal : 4 - 20mA
02-L terminal : -10 - 10V

Set output frequency for one of the above

(1)Start, End of O-L terminal. OI-L terminal

Relation code

A011: 0 start A103: Oi start rate
A012: 0 end A104: Ol end rate

A013: 0 start rate A105: OI start selection'

A014: 0 end rate **A111**: 02 start **A015**: 0 start selection **A112**: 02 end


A101 : OI start


Set item	Function code	Data	Contents
O/OI start	A011/A101	0.00-400.0	Unit: Hz Set starting frequency
O/OI end	A012/A102	0.00-400.0	Unit: Hz Set ending frequency
O/OI start rate	A013/A103	0100.	Unit: % set start rate for output frequency command 0-10V, 4-20mA
O/OI end rate	A014/A104	0100.	Unit: % Set end rate for output frequency command 0-10V, 4-20mA
O/OI start	A015/A105	00	External start frequency Output frequency from 0 to A013/A103 outputs the value of A011/A101
Selection		01	OHz Output frequency from 0 to A013/A103 outputs the value of OHz

When the input is from 0 to 5V with O-L terminal, set A014 to 50%.

(Example 1) A015/A105: 00

(Example 2) A015/A105: 01






(2) Start, End of 02-L terminal

(Z) Otart, Er	14 01 02 1	Cililia		
Set_item	Function code	Data	contents	Notes
02 start	A111	-400,~400.	Unit: Hz Set starting frequency	
02 end	AII2	-400.~400.	Unit: Hz Set ending frequency	
02 start rate	AII3	-100.~100.	Unit: % Set starting rate for output frequency command -10-10V (Notes)	(Example 3)
02 end rate	AII4	-100.~100.	Unit: % Set ending rate for output frequency command -10-10V(Notes)	}

(Notes) The rates of -10V-10V is following.

-10V- 0V:-100-0% 0V-10V:0-100%

For example. in case of use with 02-L terminal, set -50% to A113. 50% to A114.



Setting analoa input filter

î.

Set the internal filler of the frequency setting signal of **voltage** or current from **the control terminals**

Relation code

A016: O, OI, O2 filter

Il is important to first remove the source of the noise to the system.

When stable operation can not be achieved due to the effect of electrcal noise, set a larger value.

The response will be slower by setting a larger value. The limit of setting is about 10ms-60ms(set value : 1-30)

Function code	Limit lo set	Contents
A016	130.	Can set with the 1 unit.


Output voltage gain

Regarding the voltage selected on A082 motor voltage selection as 100 %, set the rate of the voltage which the inverter outputs for the voltage selected.

R	_	۱.	4:	-	_	_	~	4	_
	12.	11	11	C)	n			п	м

A045: Output voltage gain
A082: Motor voltage selection

Ī	Function code		Limit to set	ļ	Contents	
j	A045	I	20100.	I	Unit:%	1



Control system (V/f Characteristic)

Set V/f (output voltage/output frequency) characteristic.

To change 1st /2nd control system (V/f characteristic), set

08(SET) to an intelligent input terminal and switch it ON.

Relation code

A044/A244:1*1/2nd control s system b100/b102/b104/b106/b108/b110/b112/2

FFeee scatting V/f frequencyc1/2/3/4/5/6/7/7 b101/b103/b105/b107/b109/b111/b113/3


: Free setting V/f voltatosog/1/2/3/4/5/6/7/7

Function code	Data	V/f characteristic
	00	Constant torque characteristic(VC)
A044/A244	01	Reduced torque characteristic(VP1.7power)
	02	Free setting V/f characteristic

(1) Constant torque characteristic (VC)

Output voltage outputs proportionally lo the output frequency.

Output voltage outputs proportionally from 0 to the base frequency. but the output voltage from the base frequency to the maximum frequency is constant regardless of frequency.




output frequency (Hz)

(2) Reduced torque characteristic (VP1.7 power)

This characteristic can be used when a large starting torque isn't required.

At low speeds, it can cause improvement of efficiency, **low** noise and low vibration because of lowering the output **voltage**.

V/f characteristic is as follows.



Period (a): The limit from 0 to 10% of base frequency is the constant characteristic.

(Example) If the base frequency is 60Hz, the limit from 0 lo 6Hz is constant characteristic.

Period **(b)**: **The** limit from 10% of base frequency **to** base frequency is reduced torque characteristic. The voltage is output in the curve of 1.7 power for frequency.

Period (c) :The voltage is constant from the base frequency to the maximum frequency

1

(3) Free V/f setting

The free V/f setting sets optional V/f characteristics by setting the voltage end frequency in seven parts.(b100-b113)


The setting of free V/f setting operates always to be $1 \le 2 \le 3 \le 4 \le 5 \le 6 \le 7$.

Please set first free V/f setting 7 because the initial value is all 0Hz.


When the free V/f setting is valid, the function of torque boost(A041/A241), base frequency(A003/A203), is invalid.

Set item	Function code	Data	Contents
Free V/f frequency7	b112	0 400.	Į
Free V/f frequency6	b110	0 Free V/f frequency7	
Free V/f frequency5	ь108	0 Free V/f frequency6	
Free V/f frequency4	b106	0 Free V/f frequency5	Unit : Hz
Free V/f frequency3	b104	0 Free V/f frequency4	
Free V/f frequency2	b102	0 Free V/f frequency3	
Free V/f frequency1	ь100	0 Free V/f frequency2	
Free V/f voltage7	b113		
Free V/f voltage6	b111		
Free V/f voltage5	ь109		
Free V/f voltage4	b107	0.0 - 800.0	Unit : V
Free V/f voltage3	b105		(Notes)
Free V/f voltage2	ь103		
Free V/f voltage1	b101		





(Note) Even if you set 800V for free V/f voltagel-7, output of inverter can't be more than the input voltage or the AVR setting voltage.



Toraue boost

A correctly installed motor and careful attention to voltage drop in the wiring will improve the motor torque at low Speed. Setting of A041/A241 will select between manual torque boost and automatic torque boost, the level of torque boost corresponds to the set motor capacity selection (H003/H203) and the motor pole selection (H004/H204).

Relation code

A041/A241: 1st/2nd torque boost selection

A042/A242:1^{et}/2nd manual operation torque boost

A043/A243:1°1/2nd manual operation torque boost

break point

H003/H203:1st/2nd motor capacity selection

H004/H204:1*1/2nd motor pole selection

Set item	Function code	Data	contents
		00	Manual torque boost
Torque boost	A041/A241	01	Automatic torque boost
			Unit:%
Manual torque boost	A042/A242	0.0-20.0	Level corresponding to output
			Voltage (100%)
Manual torque boost	A043/A243	0.0-50.0	Unit:%
break point	AU43/AZ43	0.0-50.0	Level corresponding to base frequency

(1) Manual torque boost

The values set up with A042/A242 and A043/A243 is outputted.


A042/A242 sets a percentage level where the base frequency voltage is 100%.

The level set is the value of torque boost output voltage at 0 Hz.

When using the manual torque boost, it should be noted that overuse will cause saturation of the motor and may cause damage.

The manual torque boost break point is the frequency at which the voltage **torque** boost is switched off and normal operation **resumes**.

To change from A041and A042 to A241and A242 an intelligent input needs to be set to 08(SET) and switched on.



(2) Automatic torque boost

The output voltage is adjusted automatically by the condition of the load.

When using automatic torque boost it is important that the following two parameters are set correctly.

Set item	Function code	Setting limit	contents
Motor capacity selection	H003/H203	0.20-75.0	Unit: kW
Motor pole selection	H004/H204	2/4/6/8	Unit : pole

Direct current braking

A dc voltage can be applied to the motor windings in order to lock the motor shaft and avoid **overun** at low speeds.

There are Iwo methods of activating the dc braking,
Outside which is through the intelligent input
terminals and Inside which is automatically started
at **a** specific frequency.

Relation code

A051: DC braking selection
A052: DC braking frequency

A053: DC braking late time

A054: DC braking power A055: DC braking time

A056: DC braking edge/level selection


A057: **Starting** DC braking power A058: Starting DC braking time

A059: DC carrier frequency

	r <u> </u>		
Set item	Functin code	Data	Contents
DC braking selection	A051	00	Inside DC braking : invalid
Do braking selection	A031	01	Inside DC braking : valid
DC braking frequency	A052	0.00-60.00	Unit: Hz When the output reaches the set frequency and Inside DC braking is valid, DC braking is started.
DC braking late time	A053	0.0-5.0	Unit: second After DC braking time is reached, or DB terminal is ON, the late time is a delay before DC braking is started .
DC braking power		0.	Unt: %
/Starting DC braking	A054/A057	\	Weak (Zero current)
power		70.	Strong (Inverter rating fairly 70% the DC current)
DC braking time	A055	0.0-60.0	Unit: second The DC braking is stopped after this time delay has elapsed. The time is tarted when the late time has elapsed.
DC braking edge/level	A056	00	Edge movement (Example 1-6-a)
selection	AUSO	01	Level movement (Example 1-6-b)
Starting DC bra	aking time	A056	Unit: second It is valid for inside DC braking. When operating command is ON. DC current is started.
DC braking carrier Frequency	A059	0.5-12	Unit: kHz

(1) DC braking carrier frequency

It is possible to alter the DC braking carrier frequency. However, if the DC braking carrier frequency is set higher than 3kHz, the value of maximum braking power level is automatically reduced as follows. Set DC braking carrier frequency with A059.



Direct braking power limiter

(2) Outside DC braking

Set 07(DB) to an intelligent input terminal.

DC braking is then switched by ON/OFF of OS terminal irrespective of DC braking selection A051.


Set strength of DC braking power with A054.

If DC braking late lime A053 is set, the **Inverter outpuit** is cut off for this time period, the motor will be free running.

After the late time passes. DC braking is started.

Please set DC braking time A055 or DC braking time by OS terminal paying attention to the heat of the motor.

Please set each setting in accordance with the system. after level action or edge action are selected with A056



(3) Inside DC braking

When the inverter starts, and the DB terminal is not ON the inverter can operate dc braking.

When using inside DC braking, the DC braking selection A051 should be set 01.

Starting DC braking power is set with A057. DC braking time at starting is set with A056.

Braking power setting except starting time, set with A054.

If DC braking late lime A053 is **set** and the dc braking frequency is reached, the operating command (FW) is switched OFF. The inverter cuts the output and for the set time of A053, free running of the **motor** will occur. After finishing **the** set lime in A053, DC braking is started.


Set the frequency at which the DC braking will operate at with A052.

The operation of Edge/Level selection when using inside DC braking is different.

Edge action: Give priority to A055 DC braking action time, operate DC braking according to set time.

After turning operating command (FW) OFF, when output frequency **reachs** the set value of A052. during setting A055 DC braking is run. Even if operation command is turned ON, during setting time of A055. DC **braking** is **run.(Example 5-a),(Example 6-a)**

Level action: Give priority to **operaing** command, ignore DC braking time A055 and **move** lo normal operation. When operation command is turned .ON during DC braking. set time of A055 is ignored and normal operation is restored. (Example 5-b), (Example 6-b)



Freauency limiter

This **function** can set a maximum and minimum limit of the output frequency.

Even if a frequency command exceeds the maximum and minimum limiter the **inverter** will ignore this value and stop at the **values set**. Set first maximum limiter **on** setting.

Relation code

A061/A261: 1st/2nd frequency maximum

limiter

A062/A262: 1st/2nd frequency minimum


limiter

Be Sure that the maximum limiter (A061/A261) > minimum limiter (A062/A262).

The maximum and minimum limiter will not operate if OHz is set.

Set item	Function code	Setting limit	Contents
Fragueney, may		0.00.	Unit: Hz
Frequency max.	A061/A261	frequency min. limiter - max.	Setting max. of output
limiter		frequency	frequency
		0.00,	Unit: Hz
Frequency min. limiter	A062/A262	starting frequency - max.	Setting min. of output
		limiter frequency	frequency


(1) I" use O-L. OI-L case



When frequency command is control terminal (Terminal), by setting Min. limiter, even if OV is input, it is not possible to output **less** than the frequency Set with Min. limiter.

Frequency command

(2) In use O2-L case



When using the minimum frequency limiter and **0v** is inputted into 02 terminal, A062 applies to both **forward** and reverse directions

(a) When operation command is control terminal (Terminal)(A002:01)

	•			
Terminal	Revolution when 02 is OV			
	N) A062 on forward side			
REV(ON)	A062 on reverse side			

(b) When operation command is operator (A002:02)

on command is operator (Novelley)		
FO04	Revolution when 02 is OV	
00	A062 on forward side	į
01	A062 on reverse side	ļ

Freauency Jump Function

Frequency jump can be used to avoid resonance points on machinery.

Frequency jump is to jump the **frquency** command and avoid usual operation within the limit of the jump frequency.

Output frequency changes continuously according to adjustable time.

It is possible three different points are set for the jump frequency.

Relation code

A063:Jump frequency1

A064:Jump frequency band1

A065:Jump frequency2


A066:Jump frequency band2

A067:Jump frequency 3

, A068: Jump frequency band3

Set item	Function code	Setting limit	Contents
Jump frequency 1/2/3	A063/A065/A067	0.00-400.0	Unit: Hz
			Set the frequency fj of center to jump.(Note)
Jump Width 1/2/3	A064/A066/A068	0.00-10.00	Unit:Hz
			Set 1/2 value of frequency band to jump (Note)

(Note) The frequency to jump is fj + 2 (Hz).



Acceleration stop function

When the inertial moment of a toad is high, this is the function to wait until the slip of the motor on starting becomes smaller.


Use when the overcurrent trip occurs an starting.

Relation code

N A069:Acceleratioation) - frequency

A A070: Acceleration stop titmee

Set item	Function	on code i	Data	Contents
Acceleration	A069	0.00-400.0	Unit: Hz	
stop frequency			Set the fr	equency to be held.
Acceleration	A070	į	Unit: s0.0	0-60.0
stop time				Set the time to hold the frequency.



PID Function

This integrated process control function can be used for controls such as constant **flow** and control for fan and pump applications.

When using this function set A071 to 01 or assign an intelligent input terminal to 23(PID: valid / invalid).

	<u> </u>			
	Set item	Function code	Data	Contents
	DID i d	0.074	00	Invalid
	PID selection	A071	- 4	
	PID P gain	A072	0.2-5.0	Proportional gain
	DID L goin	4072	0.0.2600	Integration Gain
	PID I gain	A073	0.0-3600.	Unit: seconas
	D. (1)	0.74	0.0-100.0	Derivative gain
РΙ	D D gain	A074	0.0-100.0	Unit: seconds
	PID scale	A075	0.01-99.99	Unit :%
	PID feedback	4070	00	OI-L:4-20mA
	selection	A076	01	O-L : 0-1 ov
	Maximum PID	2011	0.0.400.0	Unit :%
	Deviation level co44		0.0-100.0	OTIIL . 76

	Relation code
A001	Frequency command
	selection
A005	:AT selection
A006	:O2 selection
A071	:PID selection
A072	:PID P gain
A073	:PID I gain
A074	:PID D gain
A075	:PID scale
A076	:PID feedback selection
d004	:PID feedback monitor
C001-0	0005:Intelligent input terminal
C021-0	0022:Intelligent output termina


CO44:PID deviation setting level

(1) Feedback selection


Select which analogue input terminals will be the feedback reference (A076).

Set the set frequency command selection with A001. (It should not be the same as the terminals selected with A076). Or when the control terminal 01 is set with A001, the setting of AT selection A005 is invalid. The contents changes when 02 is selected with A006.


(2) Basic operation of PID control




- (3) Components of PID Kp:Proportional gain. Ti:Reset time. Td:Rate time. s:Operator, £:Deviation
- [1] P action This is the action that the manipulated variable is in proportion to the command.



(2) Laction This is the action that the manipulated variable increases with time in a straight line



[3] D action This is the action that the manipulated variable is in proportion to the changing rate of command,



PI action combines above [I] and [2], PD action does [1] and [3], PID action does [1], [2] and [3]

(4) The adjustment of gain

Please adjust each gain according to the state as the following, when the response on the functional operation PID is not stable.

Inspite of changing command, the change of feedback signal is slow.

Raise P gain.

The feedback signal changes instantly but is not stable.

Lower P gain.

The command and feedback signal doesn't coincide instantly.

Lower I gain.

The feedback signal oscillates and is not stable.

Raise I gain.

Raise D gain.

When P gain is raised, the feedback signal oscillates and is not stable.

Lower D gain.

(5) The Maximum PID Deviation Level/Output

It is possible to establish the maximum deviation level CO44 on PID control. When the PID deviation amount reaches the set level C044, it is possible to set an intelligent output.

CO44 can be set from 0 to 100 and corresponds with the command; from 0 to maximum.

Assign 04 (OD) to intelligent output terminal 11. 12(C021, C022).

(6) Feedback monitor of PID

Feedback signal of PID can be monitored.

The monitor value can be displayed by the product of PID scale A075 "Monitor display" = 'Feedback (%)" x 'A075 setting"

(7) PID integral reset

This is the function to clear integral value of PID action.

Assign 24(PIDC) to intelligent input terminal.

It is cleared whenever PIDC is turned ON.

Don't turn absolutely ON PID terminal during PID action, because there is a possibility of **overcurrent** trip. Turn ON PIDC terminal after turning OFF PID action.

Automatic enerw-savina operation function

This function regulates the **inverter** output power automatically to a minimum while operating at constant speed.

This fits for the load of reduced torque characteristic of fans or pumps. In case of operating by this function, set A085 to '01'.

A086 can adjust the automatic operation, response time.

- Relation code -

A085:Operation mode selection

A086: Energy-saving response Accuracy adjustment

Setitem	Function code	Deta	Contents
Operation	:	00	Normal operation
mode selection	A085	: 01	Energy-saving operation

Set item	Function code	Deta	Response	Accuracy
Energy saving Response /accuracy Adjustment	A086	100	Slow Fast	High

Two-staae Acceleration and Deceleration Function

By setting this function, it is possible to change the rate of acceleration and deceleration.

As methods to change the rate of acceleration and deceleration, you can **select** the method of changing by intelligent input terminal and the method of automatic changing by optional frequency.

In case of changing by intelligent input terminal, assign 09(2CH) to an Intelligent input terminal

Relation code

F002/F202: 1⁸¹ /2nd acceleration 1

F003/F203: 1st /2nd deceleration time 1

A092/A292: 1st /2nd acceleration time 2

A093/A294:111 /2nd deceleration time 2

A094/A294: 1st /2nd two-stage acceleration

and deceleration selection

A095/A295:1*t /2nd two-stage acceleration

frequency

A096/A296: 1st /2nd two-stage deceleration


frequency


C001-C005: Intelligent input terminal

Set item	Function code	Data	contents
Acceleration time 2	A092/A292	0.01-3600.	Unit: second (Example1,2)
Deceleration time 2	A093/A293	0.01-3600.	Unit : second (Examplel.2)
Two-stage		00	Changing by intelligent input terminal 09 (2CH) (Examplel)
acceleration a n d deceleration selection	A094/A294	01	Changing by two-stage acceleration and deceleration frequency (A095/A295, A096/A296) (Example2)
Two-stage acceleration frequency	A095/A295	0.00-400.0	Unit: Hz It is valid when two-stage acceleration and deceleration selection (A094/A294) is 01. (Example2)
Two-stage deceleration frequency	A096/A296	0.00-400.0	Unit: Hz It is valid when two-stage acceleration and deceleration selection (A094/A294) is 01. (Example2)

(Examplel) In to set A094/A294 to 00 case

(Example2) In to set A094/A294 to 01 case





Acceleration and deceleration pattern

(1) Selection of pattern

Pattern of acceleration and deceleration speed is possible to set up corresponding to each system.

Select the pattern of acceleration and deceleration with A097 and A098.


Relation code -

A097: Acceleration pattern selection

A098: Deceleration pattern selection

A131: Acceleration curve constant


A132: Deceleration curve constant



It is possible to set the pattern of both acceleration, deceleration

(2) The curve constant (the swelling degree)

It makes the rough sketch reference and please decide the swelling degeree.



There is the range which the midway adjustable-speed time becomes fast in the S character pattern,

Instantaneous Dower failure / under-voltaae

Instantaneous stop and start

occur on the forth time.

(1) You can select whether the inverter trips or retries (restart) when an instantaneous power failure/under-voltage occurs. When retry function is selected with b001, and an instantaneous Stop/under-voltage trip occurs restart is tried 16 times and a trip will occur after 17 times. And when retry function is selected. and an over-current or an over-voltage occurs, restart is tried 3 times and a trip will

Relation code

b001 :Retry selection

b002 :Allowable under-voltage power failure time

b003 :Retry delay time

b004 :Instantaneous power failure under-voltage

trip during stop

b005 :Instantaneous power failure under-voltage

retry time time selection

b007 :frequency setting for matching frequency


When an instantaneous power failure/under-voltage occurs, you can select execution of trip with b004. To select a **retry** function with **b001**, set the **following retry** mode correspondent to each **system**.

Set item	Function code	Data Description	
	00		Trip.
	b001	01	Restart from 0Hz on retry.
Retry selection		02	Start equaling frequency on retry. (examplel)
_		03	Start f-equaling and stop decelerating on retry After stop. start trip. (examplel)
Allowable under- voltage power failure time	b002	0.3-1.0	Units: second If the instantaneous power failure time is shorter than the set time, a restart will occur. (examplel) If the instantaneous stop time is longer than set time, trip. (example2)
Retry wait time	b003	0.3-100.	Units:second Delay before motor restart time.
Instantaneous power	•		Invalid Trip isn't caused and alarm isn't output.
failure/under-voltage b 0 0 4 trip during stop 01		01	Valid Trip is cause and alarm is output.
Instantaneous power		00	Restart to 16 times on instantaneous stop under-voltage.
failure/under-voltage retry time selection	b005 01		Restart freely on instantaneous stop under-voltage.
Frequency setting for f-equaling	b 0 0 7	0.00-400.0	Units:Hz When the frequency of the motor during free-run is less than this set frequency, restart with 0Hz is caused. (example3.4)

F-equaling start: The inverter reads the motor RPM and direction and restarts the inverter to match these readings.

Retry function (b001: 02): The timing chart in case of selection is following.


- to :Instantaneous stop power failure
- t1 :Allowable under-voltage power failure time(b002)
- t2 :Retry Wait time(b003)




After wait for t2 seconds according to t0 < t1, restart.

Trip according to t0 > t1

(example3) Motor frequency(revolution time) >b007 (example4) Motor frequency (revolution time) cbOO7



(2) Instantaneous power failure during stop alarm output during under-voltage Select yes/no of alarm output when instantaneous power failure or under-voltage occurs with b004 Alarm outputs while control power of inverter remains.



(3) It is possible to use an output by assigning the signal (IP: 06) during instantaneous slop. by setting (RNT: 09) during under-voltage to an intelligent output terminal 11. 12(C021, C022) or alarm relay output terminal (C026).

Open phase protection function selection

This is the function to warn when the inverter input supply opens.

Function code	Date	Description
	00	Invalid
b006		Don't trip when the input supply opens
0000	01	Valid
		Trip when the input supply opens

Relation code

When an open phase occurs, there is a danger that the inverter could produce one of the following states;

- (1) Ripple current of main capacitor increases, life of main capacitor shortens remarkably,
- (2) In case of load, there is danger that the capacitors or thyristors inside the inverter could be damaged.
- (3) There is a risk that the in-rush resistor to limit the current inside the inverter may burn out.

Electrionic thermal function

Set the **Inverter** according to motor rated current to protect the motor from overloading, overheating and damage.

A warning signal is outputted before tripping on electronic thermal **protection**.

Relation code

b012/b212:111/2nd electric thermal level

b013/b213:11/2nd electric thermal

characteristic selection

b015/b017/b019:free electric thermal frequency 11213

b016/b018/b020:Free thermal current 1/2/3

C021-C022:Intelligent output terminal

C026:Alarm relay output terminal

(1) Electronic thermal level

Function code	Setting range	Description
b012/b212	Rated Current x 0.2 to	Units:A
0012/0212	Rated Current x 1.2	Utilis.A

(example) L300P-110LF

Motor current:44A

Setting range: 8.8 to 52.8A

When electronic thermal level b012=44A, time limit characteristic is right diagram.

Trip time (s)

0 51 52.8 66 (116%) (120%) (150%)

Motor current (A) (Ratio for inverter rated current)

(2) Electronic thermal characteristic

Frequency characteristic is added up to set value of b012.


Function code	Deta	Electronic thermal characteristic
b013/b213	00	Reduced torque characteristic
	01	Constant torque characteristic
	02	Free setting

When output frequency of general motor decreases, cooling function of self-cooled fan will fall.

Reduced **torque** characteristic is calculated according to heat of an HITACHI genera, motor.


(a) Reduced torque charcteristic

To add to the time limit characteristic set with the reduced time rate b012/b212 by each frequency.






(example)b012 = 44(A), when output frequency = 20Hz




(b) Constant torque characteristic

Set this in to use constant torque motor case.

(Example)b012 - 44(A), when output frequency=2.5Hz.









ق -

BYPASS



Hitachi VFD Software Parameter Sheet

J100 Series

- OPE
- DOP

5300 Series

- OPE NB501X
- OPE NB506X and newer
- DOP NB501X
- DOP NB506X and newer
- HOP NB506X and newer

L100 Series

- OPE
- DOP

L300 Plus Series

- OPE
- DOP

SJ100 Series.

- OPE
- DOP

000526

WWW.mgitech.com


MGI Technologies Inc. 275 West 4th Ave, Vancouver, BC Canada


(3) Free/thermal characteristic

It is possible'to set the electronic thermal characteristic freely according to the load in order to protect the motor and the **inverter**.


Setting range is shown es follows:

Set item	Function code	Set range	Description
Free electronic thermal frequency	b015/b017/b019	0 to 400	/Units : Hz
1/2/3			
Free electronic thermal current 1/2/3	b016/b018/b020	-0.0	Don't operate.
rice electronic thermal current 1/2/3		0.1 to 999.9	Units: A





(Example) b012=44(A), output frequency=b017



- (x):b018x116%
- (y):b018x120%
- (z):b018x150%

(3) Thermal warning

A warning signal is outputted before overheat protection by the electronic thermal protection occurs. Warning level is set with C061.

Assign 13(THM) to en intelligent output terminal (C021, C022) or the alarm relay output (C061).

Function code	Data	Description
C061	0.	Don't operate.
	1,-100.	Units : %

Relation code

Overload restriction

(1) Overload restriction

The Inverter monitors the motor current on acceleration and constant speed.

When the **inverter** reaches the overload restriction level, the Inverter will reduce the output frequency automatically to restrict the overload.

This function prevents an over-current trip by inertia during acceleration or radical changes in load at constant speed.

Two kinds of overload restriction function are set with **b021**, **b022**, b023 and **b024**, b025, b026.

To change b021. b022, b023 and b024. b025, b026, assign 39(OLR) to an intelligent input terminal.

The current value this function operates at is set in overload restriction level.

b021:Overload restriction selection
b022:Overload restriction level
b023:Overload restriction constant
b024:Overload restriction 2 selection
b025:Overload restriction level2
b026:Overload restriction constant2
C001-C005:Intelligent input
C021-C022:Intelligent output
C026:Alarm relay output setting
C040:Overload advance notice signa
output mode
C041: Overload notices level

The overload restriction constant is the time to decelerate to 0Hz from max. rrequency.

b021, b022. b023 and b024. b025, b026 is changed with OLR.

As this function operates. the acceleration time is longer than setting time.

If the overload restriction constant is set too short, in spite of accelerating, an over-voltage trip is caused with regenerative **enegy** from the motor on automatic deceleration by this function.


When this function operates in the midst of accelerating. the frequency will not reach the goal frequency. the Inverter will adjust in the following way.

Make acceleration time longer.

Raise torque boost.

Raise overload restriction level.

Set item	Function code	Data	Description
Overload		00	Invalid
restriction	b021/b024	01	Acceleration/valid on constant speed.
Selection.		02	Valid on constant speed.
Overload restriction	b022/b025	Rated current x 0.5 to Rated current x 1.5	Units :A Current value overload restriction operates.
Overload restriction constant.	b023/b026	0.1 to 30.0	Units :second Deceleration time when overload restriction Operates.




(2) Overload advance notice

1

When the load is high, it is possible to adjust the load again by outputting an overload advance notice. It is used to prevent damage to the machine from too much load. i.e. baggage on a conveyor. the **Inverter** overload protection will operate.

Assign 03(OL) to an intelligent output terminal 11. 12 or the alarm relay output terminal.

Set item	Function code	: Data	Description
Overload		00	On acceleration. constant speed, this is valid.
advance notice signal output mode selection	co40	01	On constant speed only, this is valid.
Overload advance notice level	co41	0.1 to	Don't operate. /Units: A As load reaches overload advance notice level. OL signal is output.



Start frequency

This frequency is **the** value the operator must set before the **Inverter** will give an output.

 Relation code = b082:Start frequency

Mainly used when an operator adjusts the start torque.

By setting the start frequency higher, direct starting is caused and the starting current increases. Therefore an overload is within **the** restriction range and the inverter has a tendency to trip on over-current protection.

	Function code	Set range	Description	
	b082	0.10 to 9.99	Units:Hz	
FW				
outp	output frequency b082			
out	out voltage			

Reduced voltage start selection


This function is to raise the voltage slowly on motor starting.

The lower this value the more torque is available on starting..

However. by making this value lower. the **inverter** has a tendency of tripping on over-current protection. because of almost direct starting.

b082:Start frequency	
start selection	
b036:Reduced voltage	!
Relation code	

Function code	Data	Time to take for reduced voltage starting
	00	No reduced voltage start
	01	Short (about 6ms)
b036	. 🗘	1
	06	Long (about 36ms)



BRD (regenerative breaking) function

This function only operates with the L300P - 15kW and lower, as they have the built-in BRD.

This function is to consume regenerative energy from the motor as heat by the use of an external resistor.

Regeneration occurs when **the** motor is decelerated to quickly and the **motor** turns into **a** generator and voltage flows back into the **Inverter**.

To use the BRD function. set following condition.

Set item	Function c o d e	Data	Description	
		0.0	BRD don't operate.	
			The usage ratio of BRD is set by 0.1% unit. When inverter exceeds the usage ratio. trip.	
BRD usage Ratio	, b090	0.1-100.0	BRD action ON ON ON 100 second	
			Usage ratio (%) = (t1+t2+t3) X100	
	•	00	BRD don't operate,	
Selection of BRD	b095	01	During run: valid (BRD operates.) During stop: invalid (BRD doesn't operate.)	
	ļ 	02	During run. stop, valid (BRD operates.)	
BRD ON	1	(Note) 330-380	Units: V In case of 200V class inverter, setting is valid.	
Level	b096	(Note) 660-760	Units: V In case of 400V class inverter. setting is valid,	

(Note) ਲਮਹਾਹੀ ਅਰਪਵਾਲੇ ਸ਼ਾਦ voltage setting of the DU (direct current) voltage of the inverter.

Coolina fan operating selection

You can select whether the fan operates continuously or operates only when the inverter is in ${\it the}$ running operation.

Function code	Data	Description	
	00	Always run	
b092 L	01	Only during run However, inverter operates for five minutes after power ON, and for five minutes after inverter operation stops.	

Relation code

b092:Cooling fan
operation selection

Intelliaent input terminal setting

It is possible to operate functions by assigning those functions to the intelligent input terminals 1-5 (C001-C005).

Relation code

C001-C005: Intelligent input terminal

The intelligent input terminals I-5 can be selected individually **whether** the contact input specification is either a NO or a NC **contact**

Two or more intelligent input terminals can't be assigned to be the same function.

If a" intelligent input is assigned a function which is already assigned to another terminal it will automatically be restored back to the setting before.

Function Code	Data	Description	Reference item
	01	RV:Reverse command	Operation run
	02	CF1:Multi-speed 1 (binary operation)	
	03	CF2:Multi-speed 2 (binary operation	Multi-speed operation function
	04	CF3:Multi-speed 3 (binary operation	
	05	CF4:Muiti-speed 4 (binary operation	
	06	JG:Jogging	Jogging operation
	07	DB:External DC braking	DC braking(external DC braking)
i	08	SET:2 nd Set of Motor Data	2 nd Set of Motor Data
	09	2CH:Two-stage adjustable-speed	Two-stage adjustable-speed function
	11	FRS:Free-run stop	Free-run stop
	12	EXT:External trip	External trip
	13	USP:Unattended start protection	Unattended start protection function
	14	CS:Commercial change	Commercial change
	15	SFT:Software lock (control terminal)	Software lock
	16	AT:analog input voltage/current select	Analog external input
	18	RS:Reset inverter	Reset inverter
C001- coo5	20	STA:3 wire run	
	21	STP:3 wire keep	3 wire input function
	22	F/R:3 wire forward/reverse	
-	23 F	PID:PID selection (valid/invalid)	PID function
I	24 Jr	സ്. Printégrathig≏teset	T ID TUTOUOTI
		UP:Remote control UP function	
	26	DWN:Remote control DOWN function	UP/DOWN function
	29 UD	C:Remote control data clear	
	32	SF1:Multi-speed 1 (bit run)	
	33	SF2:Multi-speed 2 (bit run)	
	34	SF3:Multi-speed 3 (bit run)	
	35	SF4:Multi-speed 4 (bit run)	Multi-speed operation function
	36	SF5:Multi-speed 5 (bit run)	
	37	SF6:Multi-speed 6 (bit run)	
	38	SF7:Multi-speed 7 (bit run)	
		LR:Overload restriction change	Overload restriction
_	no	NO:No_assign	

Input terminal a/b (NO/NC) selection

It is possible to set a contact input or b contact input to intelligent input terminals 1-5 and FW terminals individually.

Set item	Function code	Data	Description
Intelligent input 1-5	C011-C015	00	A contact(NO)
a/b(NO/NC)selection	[01	B contact(NC)
Input FW	C019	00	A contact(NO)
a/b(NO/NC)selection		01	B contact(NC)

Relation code

C011-C015: Intelligent input a/b (NO/NC)

C019 Input FW a/b (NO/NC) selection

a contact: 'ON' with Close. 'OFF' with Open b contact: 'ON' with Open, 'OFF' with Close RS terminal can set only a contact.

Multi-speed operation function

It is possible to set multiple operation speeds and switch between the speeds with the terminals.

Multi-speed operation can be selected by binary operation(max 16 speeds) with 4 terminals or by bit operation (max. 6 speeds) with 5 terminals.

Relation code

A019: Multi-speed selection A020/A220: 1st/2nd/multi-stage speed

zero speed A021-A035: Multi-speed t-15 C001-C005: Intelligent input terminal

L	•		
Set item	Functin c o d e	: set value	Description
Multi-speed	A019	00	Change to binary operation 16 speed.
selection	71010	0 1	Change to bit operation 5 speed
Multi-speed	A020/A220-A035	0.00. start frequency-	
O-15		max. frequency	

(1) Binary operation


It is possible to set multi-speed 0 to 15 by selecting 02 to 05 (CF1 to CF4) on the intelligent input terminals,

Set frequency setting for speed 1 to 15 with A021-A035.

Set 0 speed with A020/A220 or F001 when frequency command is operator.

Or when frequency command is control terminal (Terminal), set with O, OI, 02 terminal.

Multi-speed	CF4	CF3	CF2	CF1	
0 speed	OFF	OFF	OFF	QFF	
1 speed	OFF	OFF	OFF	ON	
2 speed	<u>O</u> FF	OFF	ON	OFF	
3 speed	OFF	OFF	ON	ON	
4 speed	OFF	ON	OFF	OFF	
5 speed	OFF	ON	OFF	ON	
6 speed	OFF	O N	O N	OFF	
7 speed	OFF	ON	On	ON	
8 speed	ON	OFF	OFF	OFF	
9 speed	ON	OFF	OFF	ON	
10 speed	ON	OFF	ON	OFF	
i 11 speed	ON	OFF	ON	ON	
OF12 speed	ON	ON C	FF		
13 speed	ON	ON	OFF	ON	
14 speed	ON	ON	ON!	OFF	
! 15 speed	ON	ON	ON	ON	
i io speed	ON	ON	I ON !	ON	



(2) Sit operation

It is possible to set multi-speed 0 to 5 by assigning 32 to 36 (SF1-SF7) to the intelligent input terminals. Set frequency SFI-SF7 to A021-A027

			NOL I NO.	- , .	
Multi- speed	SF5	SF4	SF3	SF2	SF
Ospeed	OFF	OFF	OFF	OFF	OFF
1 spee	d -	-			ON
2 speed		-	-	O-N	OFF
3 spee	d •	-	ON	OFF	OFF
4 speed	j - t	ON	OFF	OFF	OFF
5 speed	i ON	OFF	OFF	OFF	OFF

Frequency command from operator or analog external input terminal SES SF4 SF5

When each terminal turns ON simultaneously. the lower number has priority.

In order for the inverter to operate both the frequency and the RUN operation (FW,RV) must be applied.

Joaaina operation

This function can be used to rotate the motor in **small** steps **to** allow fine-tuning.


Set an intelligent input terminal to 06(JG).

Relation code

A038 : Jogging frequency

A039 : Jogging selection

C001-C005 : Intelligent input setting




The jogging operation does not "se acceleration, therefore it would be advisable to set the jogging frequency to limit the starting current to a minimum or tripping may occur. Adjust A036 to the jogging frequency required.

Function code	Data	Description
A036	0.0, start frequency-9.99	Units:Hz

(2) Jogging operation selection

Function code	Data	Description	Jogging operation during run Valid / Invalid	
	00	Free-run on jogging stop	Invalid (example1)	
ŗ	01	Decelerating stop on jogging stop.	(notes)	
A039	02	Direct braking on jogging stop.	(Hotes)	
	03	Free-run on jogging stop (example2)	Valid (example2)	
Ī	04 Decelerating stop on jogging sto	Decelerating stop on jogging stop.	(notes)	
	05	Direct braking on logging stop.		

(Note) When using the jogging function, turn FW terminal or RV terminal ON after the JG terminal is turned ON. (It is the **same** when the operation command point is from the operator.)



When setting of A039 is 00,01 or 02 and FW terminal is turned ON beforehand. the inverter doesn't operate jogging.

When setting of A039 is 03.04 or 05 and FW terminal is turned ON beforehand, the inverter output is cut off

Second control function

This control function is used when the **Inverter** is connected to two different types of motors. By assigning **O8(SET)** to an intelligent input terminal and turning SET terminal ON/OFF you can switch between two different **Inverter** set-ups.

Select 2nd control function while the Inverter is in the STOP condition.

The functions which can change with SET terminal

F002/F202: 1" / 2nd acceleration time

F003/F203:1st / 2nd deceleration time

A003/A203:1st / 2nd base frequency

A004/A204:1*t / 2nd max. frequency

A20/A220:1st / 2nd multi-speed 0 setting

A041/A241:1st / 2nd torque boost selection

A042/A242:1st / 2nd manual torque boost

A043/A243:1st / 2nd manual torque boost point

A044/A244:1*t / 2" control system

A061/A261:1*t / 2nd frequency upper limiter

A062/A262:1st / 2"" frequency lower limiter

A092/A292:1st / 2nd acceleration time 2

A093/A293:1st / 2nd deceleration time 2

A094/A294:1*1 / 2nd two-stage adjustable speed selection

A095/A295:1st / 2nd two-stage acceleration frequency

A096/A296:1st / 2nd two-stage deceleration frequency


b012/b212:1st / 2nd electronic thermal level

b013/b213:1at / 2nd electronic thermal characteristic selection

H003/H203:1*t / 2nd allowable motor selection

H004/H204:1st / 2nd allowable motor pole selection

H006/H206:1st / 2nd stabilized constant



Even if 1" / 2"" control is changed during run. it will not be active until the inverter is stopped.

Software lock mode selection

This function is used to prevent changing data by mistake. When you want to use an intellignent input terminal. assign 15(SFT). Below is the software lock code selection,

Relation code

b031 :Jogging frequency

C001-C005: Intelligent input setting

Function co	de Data	SFT terminal	Description
	00	ON/OFF	Write disable except for b031/write enable
	0 1	ON/OFF	Write disable except for b031,F001,A020,A220, A021~A035,A038 / write enable
b031	02		Write disable except for b031
0031	03 1		Write disable except for b031,F001,A020,A220, A021~A035,A038
	10		Write disable except for change mode during running (code list reference)

b088

ь003

b007

b091

Relation code

: Free-run stop selection

: Stop mode selection

frequency setting to match

: Retry wait time

C001-C005 : intelligent input terminal

Free-run stop (FRS)

By operating the free-run stop (FRS) function. the inverter output is cut off.

The motor will free wheel under its own momentum.

This function is used when the motor is to be stopped by the use of a brake, like en electromagnetic brake.

If you stop the motor with a machine brake while the inverter is still Outputting to the motor an over-current trip may occur.

Assign 11(FRS) to en intelligent input terminal.

This free-run stop function will operate when the FRS terminal is ON.

If you turn FRS terminal OFF the inverter will restart after the retry wait time b003 passes

However when the operation command selection A002 is set to control terminal (01). the inverter restarts during free-running

This function will only operate when the FW terminal is ON

On restart it is possible to select 0Hz start or matching frequency start es output methods with the free-run stop selection b088. (Example 1. 2)

When you set the frequency **setting** b007 to match and the frequency detected is under this setting when the free-run stop is released, the inverter is restarted from **0Hz**.

The setting of this function is valid for selection b091 on stopping and reset (RS) action

Set item	Function code	Data	• Description
Francium eton Coloction	b088	<u>i</u> 00	0Hz star(example 1)
Free-run stop Selection	0000	- 01	Foualing frequency start (example 2)
		0.3-100.	Units:second
Retry wait time	b003		Time until restart after FRS terminal is OFF.
		•	(This is also used for Instantaneous restart.)
			Units:Hz (instantaneous stop. reference to item :
/Fraguency cotting to moteh	h007	0.00-400.0	of insufficiency)
/Frequency setting to match	b007	0.00-400.0	This sets the level to match frequency.
1			(Refer to item of instantaneous stop and restart.)'

(Example 1) OHz start

(Example2) Equating start

FW ____

Free-run OHz start

The number of motor revolution time

The number of motor revolution time

0

bood

Start equaling frequency

Start 0Hz regardless of the motor speed.
On 0Hz start, the retry wait time is disregarded.
When 0Hz start is used and the motor speed is still high there is the possibility of over-current trips.

After FRS terminal is switched OFF, the Inverter reads the frequency of the motor and when it reaches the value in b007 the Inverter will begin to RUN again.

On frequency matching start if an over-current trip occurs. try extending the retry time.

Commercial Dower source switching(CS)

This function is used for systems with an excessive amount of starting torque requirements. The motor would be started direct-on-line and **then** when **the** motor had started the inverter would take over. This function is **comonly** used to reduce the costing **of** the inverter. A system may

Relation code

h003 : retry waiting time

b007 : frequency setting to

match frequency

C001-C005 : Intelligent input terminal

require 55KW's to start but only 15KW's to run at constant speed, therefore, a 15KW rated inverter would be sufficient when using this function. Assign 14(CS) to an intelligent input terminal.

Using the example below. When the motor has been started direct-on-line, Mg2 is switched OFF and Mg3 is switched on. With the Forward command to the inverter already on the CS terminal is switched on and Mgl is closed. The Inverter will then read the motor RPM and when the CS terminal is switched OFF the retry wait time (b003) is started.


Once the wait time has elapsed the inverter will then start and match the frequency which is set (b007).

When the Earth Leakage Breaker (ELB) trips on ground fault, the commercial circuit will not operate. When a backup is required, take the supply from the commercial circuit ELBC.

For FWY, RVY, CSY, use control relays. The sequence above is reference to the circuit and timing diagram below.

If an over-current trip occurs when frequency matching, extend the retry wait time (b003).

Connection figure example and timing on commercial power source switching



Reset (RS)

This function resets the inverter when a protective trip has **occured**. The method of reset is to either push the STOP/RESET key on the digital operator or to switch the RS terminal ON.

To reset the inverter with the control terminal, assign 18(RS) to an intelligent input terminal.

Relation code

b003 : Retry waiting time

b007 : Frequency setting to match

C102 : Reset selection

C103 : Reset frequency matching

selection

Reset frequency matching selection C103 selects whether the inverter restarts


at **0Hz** or the inverter matches the output frequency after the reset operation is complete.


Reset selection C102 selects when the alarm signal is cancelled and whether it is valid of invalid in normal operation.

The RS terminal is valid only when the contact is set to NO


If the RS terminal is in the ON state for mote than 4 seconds, a communication error is caused

Set item	Function code	Data	Description
Retry waiting time	b003	0.3-100.	Units:seconds (Reference to items of instantaneous power failure or under-voltage) After reset. time until restart is tried.
Frequency setting to match	b007	0.00-400.0	Units:Hz (Reference to items of instantaneous stop/under-voltage)
		00	On ON signal, trip cancel (examplel) On normal, this is valid (output cuts off).
Reset selection	C102	0 1	On OFF signal, trip cancel (example2) On normal, valid (output cuts off)
		02	On ON signal, trip cancel (example1) On normal, this is invalid. (only trip cancel)
Reset frequency setting	C103	, 00	0Hz start
Selection	0103	01	Frequency matching start. (example3)





(Example3) When 01 (frequency matching) is selected with reset frequency matching selection Cl 03 it is also possible to operate frequency start on power ON:



Unattended start protection (USP)

The USP function is designed as **a** fail safe lo prevent accidental starting of the Inverter if the RUN signal is ON when the power is restored to the Inverter.


Relation code

C001-C005: intelligent input terminal

Either resetting the Inverter or turning the RUN signal OFF can clear the trip.

If the trip is cancelled while the RUN signal is still ON then the inverter will restart automatically.(Example2) Assign 13(USP) lo an intelligent input terminal.

Unattended start protection is shown as follows;



UP/DOWN selection

The Inverter output frequency can be changed with the UP and DWN intelligent input terminals.

Relation code
C101 :UP/DOWN memory selection
C001-C005:Intelligent input terminal

Assign 27(UP) and 28(DWN) to two of the intelligent inputs I-5.


This function is valid only when the frequency command selection A001 is **set** lo 01 or 02. However, when 01 (control terminal) is set, this can only be used for multi-speed operation.

This function will **not** operate when the external analog frequency command or the jogging operation is used. Acceleration lime operates according to FO02. F003/F202, F203 when UP/DWN terminal is ON.

To change 1" /2nd control. assign 08(SET) to an intelligent input terminal. change with SET terminal.

II is possible for the Inverter to retain the frequency setting value from the UP/DWN terminals. Parameter Cl01 switches the memory On or OFF. It is also possible to clear the memory and return to the original set frequency. Assign 29(UDC) to an intelligent input terminal and switch it on to clear the memory.

_	Function code	į	Data	Description
1	CI01	0	0	This will not memorize the frequency command adjusted with UP/DWN . When power is turned ON again, set value is returned to the value before it was adjusted with UP/DWN .
1	Cioi	0	1	This memorizes the frequency command adjusted with UP/DWN . When power is turned ON again, set value is kept the value after it was adjusted with UP/DWN .



External trip (EXT)

This function can be used to force the **Inverter** into **a** trip situation which is switched by an external input. i.e. PLC or relay contact.


C001-C005: Intelligent input terminal

When the EXT terminal is switched ON, the inverter trips on an El2 error and the outputis switched OFF.

Assign 12(EXT) to an intelligent input terminal.


The trip will not be canceled when the terminal is turned OFF.

To cancel the trip, the reset signal must be applied or the Inverter switched OFF and ON again at the Supply.



3 Wire input function

This function is used when a momentary push start/stop control is required.




Set the operation command selection A002 to control terminal (01).

Assign all of 20 (STA). 21 (STP) and 22 (F/R) to three of the intelligent input terminals.

If all three inputs are not assigned this function will not operate.

The FW terminal and RV terminal become redundant when the 3 wire control is assigned to the intelligent input terminals.

Output from the 3 wire control terminal is as follows;



Output terminal setting

Any of the following functions can be assigned to the intelligent output terminals (11 or 12) or the alarm relay.

Both intelligent output terminals 11 and 12 and the alarm relay are all relay outputs.

All three output relays can be selected to be either NO or NC (a orb).

Relation code

C021-C022 : Intelligent output

terminal

C026 :Alarm relay output

terminal setting

Data	Description	Reference item
00	RUN:Signal during run	Signal during run
0 1	FA1:Frequency arrival type1 signal	Frequency arrival signal
02	FA2:Frequency arrival type2 signal	
03	OL:Overload advance notice signal	Overload advance notice signal
04	OD:output deviation for PID control	PID function
05	AL:Alarm signal	Protection function
06	FA3:Arrival signal for only setting frequency	Frequency arrival signal
08	IP:Instantaneous stop signal	Instantaneous stop/under-voltage
09 U\	/:Under voltage signal	
11	RNT:RUN time over	RUN time over
! 12	ONT:ON time over	Power ON time over
13	THM:Thermal caution	Electric thermal function



Output terminal a/b (NO/NC)selection

This sets the intelligent output terminal 1-12 and alar most relay output terminal contact condition to either NO or NC (a orb).

Relation code

CO31-CO32 :intelligefoutput 11-12a/b (NO/NC)

selection

D36:AlarmAlakhi outputia/b (NO/NC)


Each output is changeable individually.

Both intelligent output terminals 11 and 12 and the alarm relay are all relay outputs.

Set item	Function co	de Data		Description
Intelligent output 11-12	C031-C032	00	A contact(NO)	Contact specification
A/b(NO/NC) selection		01	B contact(NC)	AC_250V \$△max
Alarm relay output	CO36	00	A contact(NO)	Contact specification
A/b(NO/NC)selection		01	B contact(NC)	AL1-AL0:AC 250V 5Amax AL2-AL0:AC 250V 2Amax

a contact: Close with (ON), open with (OFF). b contact: Open with (ON), close with (OFF).

(1) Specification of the intelligent output terminals 11 and 12 Specification of the intelligent output terminals 11 and 12 is as follows:




Contact Specification

C031, C032 set value	Power s	supply	Output	desc	ripti	ion	State of output terminal 11 or 12 terminal
00	0 "	,		ON		Ì	Close
00 (a contact)	U "		OFF				Open
(a contact)	Of	f					Open
01	0 "	,		ON			Open
(b contact)				0	F	F	Close
	Of	f					open

	. Resistor	Inductor
•	load	· load
Maximum	AC250V, 5A	
	DC30V, 5A	DC30V, 1A
Minimum	DC1V ·	1mA

(2) Specification of the alarm relay output terminal

The specifications of the alarm relay output terminal is a changeover contact. Action is as follows



Example on using as alarm t

CO36	Power	state of inverter	State of output terminal		
set va	lue source	mverter	AL1-AL0	AL2-AL0	
00	0 "	On abnorma	Close	open	
00 (a contact)	U	On normal	open	Close	
(a contact)	Off		open	Close	
01	0"	On abnormal	open	Close	
(b contact)	U	On normal	Close	Open	
(5 contact)	Off		Open	Close	

	Contact S	pecification	Resistor load Inductor load
-	AL1-AL0	.Maximum	;' AC250V, 2A AC250V, 0.2A ! DC30V, 8A DC300V, 0.6A
		Minimum	AC100V, 10mA DC5V, 100mA
	AL2-AL0	Maximum	AC250V, 1A . AC250V, 0.2A DC30V, 1A . DC30V, 0.2A
	ALZ-ALU	Minimum	3 AC100V, 10mA DC5V, 100mA




Signal durina run (RUN)

This function is to provide an output signal when the **Inverter** is in a running condition.

C001-C005: Intelligent input terminal

Assign OO(RUN: signal during run) to an intelligent output terminal 11. 12 or the alarm relay output terminal. The signal is still outputted when the dc braking operates

Operation is as follows;



Frequency arrival signal (FA1, FA2, FA3)

When the output frequency arrives at the set frequency. an arrival signal is outputted.

Assign 01(FA1:constant speed arrival signal), 02(FA2:over setting frequency) or 06(FA3: only setting frequency) to an intelligent output terminal II. 12 or the alarm relay output terminal.

Hysteresis frequency arrival signal is the following.

When ON: ON with (1% of setting frequency-maximum frequency)(Hz) When OFF: OFF with (2% of setting frequency-maximum frequency)(Hz)

However in to set 06(FA3) case when inverter accelerate.

When ON :(1% of setting frequency - maximum frequency)(Hz)
When OFF: (2% of setting frequency + maximum frequency)(Hz)

When inverter decelerates

When ON : (1% of setting frequency + maximum frequency)(Hz) When OFF: (2% of setting frequency - maximum frequency)(Hz)

Set item	Function code	Data (Hz)	Description
Acceleration	CO42	0.0	Don't output arrival signal on acceleration.
arrival frequency/		0.01-400.0	Output arrival signal on acceleration.
Deceleration	co43	0.0	Don't output arrival signal on deceleration.
arrival frequency		0.01-400.0	Output arrival signal on deceleration.

Relation code

C021/C022: Intelligent output terminal

C042 :Acceleration arrival

frequency

C043 :Deceleration arrival


frequency



(1) Output on constant speed arrival (01:FA1)


When the **inverter** arrives at the set frequency with frequency setting (F001, A020) or multi-speed (A021-A035),

the output relay is switched.




(2) Output over setting frequency (02:FA2)

When the output is **over** the arrival frequency set in C042. CO43 on adjustable speed time. the output relay is switched.



(3) Output setting frequency (06:FA3)

The signal is switched only when the output frequency matches the arrival frequency set in C042. CO43 on adjustable speed time.



RUN time / Dower ON time over (RNT/ONT)

When **the** accumulated operation time reaches or is Over the setting time in **b034**, RUN time/power ON time **over** (RNT/ONT) output is switched.

Relation code

b034 : Warning time level
C021-C022: Intelligent output terminal
C026 : Alarm relay output terminal
d016 :Accumulation time monitor during

RUN

d017 :Power ON time monitor

Function code	Data	Description
	0.	Don't operate.
b034	19999.	Set by 10-hour unit.
	1000-6553	Set by 100 hours unit. (10000-65530 hours)

(1) Run time over (RNT)

Assign 11(RNT) to an intelligent output terminal 11. 12 (C021, C022) or the alarm relay output terminal (C026).

Set ON time level with b034.

(2) Power ON time over (ONT)

Assign 12(ONT) to an intelligent output terminal 11. 12 (C021, C022) or the alarm output terminal, (C026). Set ON time level with b034.

FM terminal

The FM control terminal can monitor the output frequency and output current. FM terminal is a PWM (Pulse Width Modulation) output.

Relation code

C027: FM selection b081: FM adjustment

(1) FM selection

Select a signal to output from the following options.


When 03(digital frequency) is set a digital frequency counter meter is required.

Use an analog meter for all other output signals.

Function code	Data	Description	Full scale value
	00	Output frequency (example 1)	0-Max. frequency(Hz)
	01	Output current (example 1)	0-200%
C027	03	Digital output frequency (example 2)	0-Max. frequency(Hz)
	04	Output voltage (example 1)	0-100%
	05	Input electric power (example 1)	0-200%
	06	Thermal load ratio (example 1)	0-100%
	07	LAD frequency (example 1)	0-Max. frequency(Hz)


(Example 1) Set value:00, 01. 04. 05. 06, 07

(Example 2) Set value: 03



Period T: constant (6.4m)

Duty t/T: change



Period T: change Duly t/T: 50%fixed

(2) FM adjustment

This function is used to calibrate a meter connected to the FM terminal.

Function code	set range	Description	
ь081	0255.	Change one by one.	

(calibration methods)

- (1) Connect meter to FM-CM1.
- (2) Adjust **b081** so that the meter is reading the same as the output frequency on your **scale** (Example) When output frequency is 60Hz, change value of **b081** so that meter is 60Hz.

AM terminal, AMI terminal

The AM terminal and the AMI terminal can monitor the output frequency or the output current.

The AM terminal has en analog output of 0-10V.

The AMI terminal has en analog output of 4-20mA.

(1) AM, AMI selection

Select a signal to output from the following options;

Relation code 7

b080: AM adjustment **C028**: AM selection

C029: AMI selection

C086: AM offset adjustment

C087: AMI adjustment

C088: AMI offset adjustment

Set item	Function code i	Data	contents	Full scale value
	<u>i_</u>	00	Output frequency	O-Max. frequency(Hz)
		01	output current	0-200%
AM selection/ AMI selection	C028/C029 -	04	output voltage	0-100%
	C020/C029 -	05	Input electric power	o-200%
		06	Thermal load ratio	0.100%
		07	LAD frequency	O-Max. frequency(Hz)

(2) AM adjustment. AMI adjustment

This function is used to calibrate a meter connected to the AM and AMI terminal.

Set item	Function c o d e	Data	Description
AM adjustment	Ь080	0255.	After offset adjustment with C086, adjust according to! memory.
AM offset Adjustment	C086	0.0-10.0	Units:V
AMI adjustment	CO87	0250.	/After offset adjustment with COBB, adjust according to/memory.
AMI offset adjustment	C088	0.0-20.0	Units:mA

External thermistor

Temperature protection of the external machine is possible by the use of a Thermistor fitted to your motor.

Wire the thermistor between control terminals TH and CM1.

Set the following function according to the thermistor specification.,

Relation code

b098: Thermistor selection b099: Thermistor error level C085: Thermistor adjustment

Set item	Function code	set value	Contents
		00	Invalid (No temperature protection by external thermistor)
Thermistor selection	ь098	01	Valid normal temperature/factor resistance element (For PTC)
		02	Valid (For NTC)
Thermistor error level	ь099	09999.	Units:OHM Set the resistance value of temperature for trip according to termistor methods.
Thermistor adjustment	CO85 !	0.0-1000.	Use this es gain adjustment.

Initialization setting

Il is possible at any time to reinitialize the Inverter parameters back to their factory default. The trip history can also be cleared at any time, however, if problems occur it will be difficult to fault find without the trip history for reference. Initialization details are as follows;


Relation code

b084: initialization selection b085: Initial data selection


Set item Function mode		Data	Description'
		00	This clears only trip history.
Initialization selection	b084	01	This only initializes setting value. Setting value becomes the state on factory forwarding.
		02	This clears trip history and initializes setting.
Initial data Selection	b085	00	Initializing setting for Japan.
		01	Initializing setting for Europe
		02	Initializing setting for America.

(Initialization methods)

After setting the above parameters, initialize as follows:



(1) Hold down the FUNC. UP and DOWN key and the" press the STR key. When the display starts to flash and rotate release all the keys.



(2) During initializing,Above display is for Japan.Other displays are below.




(3) When "d001" is displayed in the monitor, initialization is complete.

During initializing for Europe.

During initializing for America.

During initializing of trip history.



The display revolves on the left

Display selection

This function can be used to limit what the digital operator can display.

Relation code

:Display selection

-U012: User selection

Set item	Function code	Data	Description
B: 1	01	Function individual display (Display, no display by item set)(example1)	
Display selection	b037	02	User setting and b037 Only item set by user selection of UOOI-UOIZ is displayed. (Set U001-U012_first.)
User	er U001-U012	n o	No assignment.
selection	0001-0012	d001-P002	Select the code to display. (All code is an object.)

(Example1) When the Display selection (b037) is set to 02, only the programmed parameters are displayed. To set which parameters are displayed insert code groups in parameter U001-U012.

The table below shows which parameter groups can be displayed and what code is used in U001-U012.

N o	Function to restrict display	Data	I Code to be restricted display.	Note
1 2	A001	01	A005,A006,A011-A016,A101-A105, A111-A114,C081-C085,C121-C123 f	O,OI,O2 terminal
3	A002	01,03,04,05	b087	Slop key function
1	A019	00	*000 *00F	Multi appeal forestion
4	C001-C005	02,03,04,05	A028-A035	Multi-speed function
5	! A044	02	b100-B113	Control methods
6	A 0 5 1	01	A052-A061	DC control
7	A071	01	A072-A076,C044	PID function
8	A094	01	A095-A096	2 stage adjustable frequency
9	b013	02	b015-b020	Electric thermal characteristic
10	b021	01.02	h022-h023	/Overload restriction
11	b024	01,02	b025-b026	Overload restriction2
12	b095	01,02	lb090	BRD function
13	C001-C005	08	A203,A204,A220,A241-A244, A261,A262, A292,A293,b212,b213	2 nd control
14	<u>.</u>	11	HORR	Free-run stop
15	C021,C022,C026	02.06	C042-C043	Frequency arrival signal
16	A294 C001-C005	01 06	A294-A296	2nd two adjustable frequency

Stabilized factor Relation code

When the motor is hunting or unstable, this function can be adjusted to help stabilized factor stabilize the motor.

When the motor is unstable, check the allowable motor selection (H003/H203) and motor pole selection (H004/H204) with your motor. If their code data is different from your motor specification, set the right data. When R1 of usage motor is less than R1 of regular motor. raise the set value of H006/H206 gradually.

When you operate greater motor than rated capacity of inverter. lower the set value of H006/H206.

The following two functions can also assist to reduce hunting or rattling of a motor.

- (1) Lower the carrier frequency (b063).
- (2) Lower the output voltage gain (A045).

Set item	Function code	Data	Description
Output gain	A045	20100.	Units:% Lower this when hunting occurs
Carrier	b083	0.5-12.0	Units :kHz
frequency	5000	0.0 12.0	Lower this when hunting occurs.
Stabilized	H006/H206	0255.	Raise or lower when hunting occurs.
factor	HUUUIHZUU	0255.	Traise of lower when hunding occurs.

Operation selection on option error

When an add-in option is the cause of a protective trip this function can be used to switch the trip facility off and allow the Inverter to carry on in it's operation.

Relation code

P001: Option1 operation selection

on error

P002: Option 2 operation selection

on error

Set item	Function code	Data	Description
Operation selection		00	TRP: inverter trip and output alarm when option error occurs.!
	P001/P002	04	RUN: inverter ignores this and continues operation when
on optional error		01	option_error occurs.

Motor constant

Relation code

H003/H203: 1st/2nd allowable motor selection

H004/H204: 1st /2nd motor pole selection

Set each constant according to the motor you use.

In case of using several motors in parallel, set the constant values that are closest to the total capacity of the belonging motor.

Reduced torque or instability may occur while using auto torque boost function if these settings are incorrect.

Communication function

Serial communication is possible from the **Inverter** lo any external equipment using RS465 protocol. This **function** is built-in as standard and is controlled by the TM2 control terminals.

Relation code

A001: Frequency selection A002: Operation command

selection

C070: Data command C071: Communication transmission speed

C072: Communication code
C073: Communication bit
C074: Communication parity
C075: Communication stop bit

C078: Communication waiting time


(1) Communication specification

Item	Specification	Notes
Transmission speed	2400/4800/9600/19200 bps	Selection with operator
Communication methods	Half duplex communication methods	
Synchronizing methods	Direct current transmission	
Transmission code	ASCII code	
Transmission methods	Transmission from lower bit	
Communication interface	RS465	
Data bit	7/8 bit	Selection with
		operator
Parity	No parity/even/odd	Selection with
		Operator
Stop bit	1/2 bit	Selection with
		operator
Start methods	One-way start form by command of host side	l
Waiting time	10-1000[ms]	Setting with
		operator
Connect form	1:N (N = Maximum 32)	Station number is
		selected with
	1	operator.
Error check	Overrun /Fleming / BCC / Vertical / Horizontal parity	

35.7. 2.

<RS485 port specification and connection>


Use TM2 of control terminal PCB for RS485 communication function.



Abbreviatio n name	Description	
SP	Transmission and Reception + side	
SN	Transmission and reception - side	
RP.	Terminal resistance valid terminal	
SN	Terminal resistance valid	

Connect each **inverter** in parallel as shown below. It is necessary to short terminals RP and SN on the last **inverter** in the link (even if communication is to only one **inverter** the link should still be made).

By shorting between RP and SN. the terminal resistance is increased and controls the reflection of the signal.




(2) Setting'

The following settings are required to operate RS485 communication

Set item	'unction code	set value	Description
		02	Operator
	co70	03	RS485
Data command		04	Option 1
		05	Option 2
		02	/Loop-back lest
0		03	2400 bps
Communicating	co71	04	14600 bps
transmission speed		05	9600 bps
		06	19200 bps
Camanasiaatian			This assigns the station number Of the
Communication code	CO72	1 to32	inverter. This is used when you control /more than one simultaneously.
	co73	7	7 bit
Communication bit		6	8 bit
	_	00	No parity
Communication	co74	01 Even parity	
parity		0,2	Odd parity
Communication bit	C075	<u>-</u> -	1 bit
Communication bit		2	2 bit
Communication waiting time	C078	0 to 1000	Units :ms

(3) Communication protocol

The method of the communication protocol is shown below in the time diagram,



The following is indicated.

- (1):Frame transmitted from external control machines to the inverter
- (2):Frame replied from inverter to the external control machines

Frame (2) from the inverter is a reply to frame (1) from the external control machine, the active output is not operated.

The commands are shown below:

Command list

Command	Command description	Advisabilit y of all code	Notes
00	Forward / backward /stop command	1 0	
01	Setting of frequency command		
02	Setting of intelligent terminal state	8	
03	Collective reading of monitor data	××	
04	Reading of inverter state	I \times	
05	Reading of trip history	××o	
06	Reading of 1 setting item	\times	
07	Setting of 1 set item	l o	
08	Returning of each set value to initial value	0	This doesn't operate unless b084 is set to (01 or 02).
09	This checks whether set value can be Conserved to EEPROM or not.	×	
OA	This conserves set value to EEPROM	1 0	
0B	Recalculation of internal constant.	Ó	

Explanation of each command is the following.

(i) 00 command: This controls the forward, backward and stop command,

Transmission frame

Frame format

STX	Cod	le	Command	Data	ВО	СС	CR	
	l	Exp	lanation			Da	ıta	Value
						size		
STX		Con	trol code (Sta	art of TeXt)	1 byte		STX (0x02)
Code		Stat	tion number o	f inverter		2 byte		01-32, and FF(all code communication)
Comma	nd	d Transmission command		2	byte	00		
Data	Transmission data		1	byte	(Note1) Reference			
BCC		Bloc check code		2 byte		Exclusive OR of Code, Command and Data		
CD	-	Con	trol code			1 byte		CD (0×0D)
CR		(Caı	rriage Return)		1 0	yıe	CR (0x0D)

(Note1)

Data	Description	Note
0	Stop command	
1	Forward command	
2	Reverse command	

(Example) when you transmit forward command to code 01

(STX)|01|00|1|(BCC)|(CR). 02130 31130 30131133 30|0D

Reply frame

ASCIlconverter

On normal reply: (4) - (i) reference
On abnormal reply: (4) - (ii) reference

(ii) 01 command: This is to set frequency command,

Transmission frame

T

Frame format

STX C	ode Command Data BC	CCCR	
	Explanation	Data size	Value
STX	Control code (Start of TeXt)	1 byte	STX (0x02)
Code	Station number of inverter	2 byte	01-32, and FF (all code communication)
Command	Transmission command	2 byte	01
Data	Transmission data (tenth ASCII code)	6 byte	(Note2) Reference
BCC	Block check code	2 byte	Exclusive OR of Code. Command and Data
CR	Control code (Carriage Return)	1 byte	CR (0x0D)

(Note2) when you set code 01 for 5Hz

(STX)|01|01|000500|(BCC)|(CR)

ASCII conversion 02|30 31|30 31|30 30 30 35 30 30|30 35|0D

Note) the data is 100 times as big as set value.

Example) **5(Hz)** → 500 → 000500 → 30 30 30 35 30 30 ASCII

Reply frame

On normal reply: (4) - (i) Reference
On abnormal reply: (4) - (ii) reference

(iii) 02 command: This sets the state of the intelligent terminals.

Transmission frame Frame format

STX	Code	e Command	Data	BCC	CR	
Explanation Da				Data	size	Value
STX		Control code (S	tart of TeX	t) 1 by	rte	STX (0x02)
Code		Station number	of inverte	2 by	te	01-32, and FF (all cord communication)
Comma	nd	Transmission of	ommand	d 2 byte		02
Data		Transmission d	ion data 16 byte		yte	(Note3) reference
всс		Block check co	de	2 by	rte	Exclusive OR of Code. Command and Data (5) Reference
CR		Control code (Carriage Retu	rn) ʻ	1 by	te	CR (0x0D)

(Note3) Data (sixteenth) of intelligent terminal and contents (the details refer to intelligent input terminal function.)

Data (sixteenth)	Description	Data (sixteenth)	Description
000000000000001	FW: forward command	0000000000100000	STA: 3 wire start
0000000000000000	RV: reverse command	0000000000200000	STP: 3 wire holding
0000000000000004	CF1: multi-speed1(binary operation)	0000000000400000	F/R: 3 wire forward
8000000000000000	CF2: multi-speed2(binary operation)	0000000000600000	PID:PID selection (valid/invalid)
000000000000010	CF3: multi-speed3(binary operation)	0000000001000000	PIDC: PID integral reset
000000000000000000000000000000000000000	CF4: multi-speed4(binary operation)	0000000002000000	1
0000000000000040	JG: jogging(inching operation)	0000000004000000	i I
0000000000000000000	DB: external DC control	0000000006000000	UP: remote operation Accelerating speed
0000000000000100	SET: 2"" control	000000010000000	DWN: remote operation Decelerate speed
0000000000000200	2CH: two stage adjustable speed	0000000020000000	UDC: remote operation data clear
000000000000400		0000000040000000	'
0000000000000000	FRS: free-run stop	0000000060000000	i
000000000001000	EXP: external trip	0000000100000000	SF1: multi-speed(bit run)
0000000000002000	USP: unattended start protection	0000000200000000	SF2: multi-speed(bit run)
0000000000004000	CS: commercial change	0000000400000000	SF3: multi-speed(bit run)
0000000000006000	SFT: software lock (control terminal)	0000000600000000	SF4: multi-speed(bit run)
000000000010000	AT: analog input voltage/current select	0000001000000000	SF5: multi-speed(bit run)
0000000000020000		0000002000000000	SF6: multi-speed(bit run)
000000000040000	RS: reset	0000004000000000	SF7: multi-speed(bit run)
000000000000000000000000000000000000000		000000800000000	OLR: overload restriction setting

Example) When you make (forward). (multi-speedl) and (multi-speed2) active on inverter setting of code 01. the calculation of data is

(STX)[01][02][0000000000000000](BCC)[(CR)]

Reply frame

On normal reply : (4) • (i) Reference
On abnormal reply : (4) • (ii) reference

(iv) 03 command: This reads monitor data collectively.

Transmission frame

Frame format

	Lva	lanation		D =	to 0:-0	Male
					Керіау	паше
STX	Code	Command	BCC	CR	Replay	fromo

	Explanation	Data size	Value
STX	Control code/Start of TeXt)	1 byte	STX (0x02)
Code	Station number of inverter	2 byte	01-32
Command	Transmission command	2 byte	03
BCC	Block check code	2 bvte	Exclusive OR of Code, Command and Data (5) Reference
CR	Control code (Carriage Return)	1 byte	CR (0x0D)

Frame format

STX	Code	Data	всс	CR]	
Explanation				Data size	Value	
STX	Cor	Control code (Start of TeXt)		1 byte	STX (0x02)	
Code	Stat	Station number of inverter		2 byte	01.32	
Data	Data	Data		104 byte	(Note4) reference	
всс	Bloo	Block check code		2 byte	Exclusive OR of Code. Command and Data (5) Reference	
CR		itrol code rriage Retu			1 byte	CR (0x0D)

(Note4) Each monitor value

Monitor item	Units	Compe	Data	Explanation	
		-titive	size		
		rate			-
Output frequency	HZ	x100	8 byte	Tenth ASCII code	_
output current	Α	x10	8 byte	Tenth ASCII code	Ā
Revolution direction			8 byte	0: stop. 1: forward, 2:backward	Upper
PID feedback monitor	%	x100	a byte	Tenth ASCII code	
Intelligent input monitor			8 byte	'5) reference	bite-
Intelligent output monitor			8 byte	'6) reference	
Frequency converting monitor		x100	8 byte	Tenth ASCII code'	-
Output torque monitor	%	ΧI	8 byte	(00000000) padding data	
Output voltage monitor	V	x10	8 byte	Tenth ASCII code	<u> </u>
Electric power monitor	kW	x10	8 byte	Tenth ASCII code	lower
			B byte	(00000000) padding data	
RUN time monitor	h	ΧI	8 byte	Tenth ASCII code	bite
ON time monitor	h	x1	8 byte	Tenth ASCII code	(p

(Note5) Intelligent input terminal monitor

Item	Data
Forward terminal	00000001.
1 st terminal	00000002
2 nd terminal	00000004
3 rd terminal	8000000
4th terminal	00000010
5 th terminal	00000020

(Note6) Intelligent output terminal monitor

Item	Data
AL	0000001
1 ⁵¹ terminal	00000002
2 ^{no} terminal	00000004

(v) 04 command: This reads the stale of the inverter.

Transmission frame

Frame format

STX	Code	Command	всс	·CR
			ı	4

	·		
	Explanation	Data size	Value
STX	Centrol code(Start of TeXt)	1 byte	STX (0x02)
Code	Station number of inverter	2 byte	01-32
Command	Transmission command	2 byte	0 4
всс	Block check code	2 byte	Exclusive OR of Code, Command and Data (5) Reference
CR	Control code(Carriage Return)	1 byte	CR (0x0D)

""事。....

Replay frame

Frame formal

STX	Code Data BCC CR	(Note7)	
	Explanation	Data size	Value
STX	Control code(Start of TeXt)	1 byte	STX (0x02)
Code	Station number of inverter	2 byte	01-32
Data	Data on trip	8 byte	i (Note7) reference
всс	Block check code	2 byte	Exclusive OR of Code. Command and Data

The data to indicate status contents of inverter is constructed from the following three factors [A). B), C))

Data	Status A	Status B	status c	00	(reservation)	1

Inverter status A)

Code	Status
00	Initial status
01	Vdc on waiting settlement
02	On stopping
03	On running
04	0" FRS
05	On JG
06	On rea
07	On retading frequency
08	On UV On retrying
09	10
10	On TRIP
11	0" waiting reset

Control code(Carriage Return) 1 byte

Inverter status C)

Code	Status
00	4
01	stop
02	Deceleration speed
03	Constant speed
04	Acceleration speed
05	Forward
06	Reverse
07	Reverse from
	forward
80	Forward from reverse
09	Forward start
10	Reverse start

(5) Reference

CR(0x0D)

Inverter status B)

Code	status
00	On stopping
01	On running
02	On tripping

(vi) 05 command: This reads trip history data.

Transmission frame

Frame format

STX Code	Command	всс	C R
----------	---------	-----	-----

	Explanation	Data size	Value
STX	Control code(Start of TeXt)	1 byte	STX (0x02)
Cord	Station number of inverter	2 byte	01-32
Command	Transmission command	2 byte	i 05
			Exclusive OR of Code. Command and
всс	Block check code	2 byte	Data
			(5) Reference
CR	Control coode (Carriage Return)	1 byte	CR (0x0D)

Replay frame

Frame format:

STX	Co	ode	Data	всс	CR			
		Ехр	lanation				Data size	Value
STX		Control code(Start of TeXt)				1 byte	STX (0x02)	
Code		Station number of inverter			2 byte	01-32		
Data		Each monitor data on trip				440 byte	(Note8) reference	
всс	ВІ	lock check code			2 byte	Exclusive OR of Code, Command and D a t a (5) Reference		
CR		Con	trol code(C	Carriage	Return)	1 byte	CR (0x0D)

(Note8) The monitor data (trip history) on trip memorizes the last six errors with an accumulated count number (Bbyte).

Accumulated	Trip history 1		Trip	history	6	;	-	_	
count number	mp matory / .	_				_			

Monitor item	Units Magnifi	Data Notes size
Trip factor	: Cation	Rhyto
Inverter status A)		8byte 및
Inverter status B)	- : -	
Inverter status C) 'Output frequency	Hz x10	Bbyte Bbyte Tenth ASCII code
Accumulated RUN time	hour x 1	Bbyte Tenth ASCII code _
output current	A x10	Bbyte Tenth ASCII code 🤉
current voltage	v x10	, , , , , , , , , , , , , , , , , , , ,
Power source ON time	hour : xl	Bbyte Tenth ASCII code

(vii) 06 command: This reads 1 set item.

Transmission frame

Frame format

STX Co	de Command	Parameter	всс	CR		
	Explanation		Data s	ize	Value	
STX	Control code(Start of TeXt)				STX (0x02)	
Code	Station number of inverter		2 byte		01-32	
Command	Transmission command		2 byte		0 6	
Parameter	Parameter number	4 byte		(Note9)		
всс	Block check code		2 byte		Exclusive OR of Code, Command and Data (5) Reference	
CR	Control code(Ca	rri age Return) i	1 byte		CR (0x0D)	

(Note9) The range of parameter to get.

F001-, A001-, b001-, C001-, H003-, P001-

Replay frame

Frame format

On normal reply: (4) - (i) Reference,

STX Code ACK Data BCC CR

	Explanation	I Data size	Value
STX	Control code(Start of TeXt)	i 1 byte	STX (0x02)
CSotletion	number of inverter	2 byte	01-32
ACK	Control code(ACKnowledge)	1 byte	ACK (0x06)
Data	; Data (tenth ASCII code)	8 byte	(Note10)
! BCC	Block check code	2 byte	Exclusive OR of Code, Command and Data (5) Reference
CR	Control code(Carriage Return)	⊥ 1 byte	CR (0x0D)

(Note10) when data is the selected item; this transmits and receives corresponding to station number.

On abnormal reply: (4) (ii) reference

(viii) 07 command: This sets 1 set item.

Transmission frame

Frame format

STX	ode	Command	Parameter	ļ	Data	ļ	ВС	BCC CR		
	j	Explana	ation	i	Data	siz	ze	_		Value
STX	Con	trol code(Star	t of TeXt)	1	1 byte] ;	STX	(0x0	02)
Code	Sta	tion numb& c	f inverter	2	2 byte 01-32, FF(all code communication)			F(all code communication)		
Command	Tra	nsmission cor	nmand	12	2 byte 07					
Parameter	Parameter Parameter number of data			4	4 byte (Note9)					
Data of parameter (Tenth ASCII code)				3 byte			(Note10)			
BCC Block check code			1	2 byte Exclusive OR of Code, Command a		OR of Code, Command and Data ence				
CR	1	byte		. (CR ((0x0E	0)			

Reply frame

On normal reply : (4) (i) Reference
On abnormal reply : (4) - (ii) Reference

(ix) 06 command: This returns each set value to initial value.

This works in conjunction with initial selection (b064). If b064 is 00, the trip history is cleared Transmission frame

Frame format

STX	STX Co		Command	всс	CR	ı	
		Exp	lanation			Data size	Value
STX	Control code(Start of TeXt)		1 byte	STX (0x02)			
Cord		Station number of inverter		2 byte	01-32, FF(all code communication)		
Comma	nd	Transmission command		2 byte	06		
всс	Block check code		2 byte	Exclusive OR of Code, Command and Data (5) Reference			
CR		Control code(Carriage Return)		1 byte	CR (0x0D)		

Replay frame

On normal reply: (4) • (i) Reference
On abnormal reply: (4) -(ii) Reference

(x) 09 command: This checks whether it is possible to store set value to EEPROM or not

Transmission frame

Frame format

STX	Code	Command BCC CR				
	Explanation					
STX	Cor	ntrol code(Start of TeXt)	1 byte	STX (0x02)		
Code	Sta	tion number of inverter	2 byte	01-32		
Command	l Tra	nsmission command	2 byte	09		
всс	Bloc	ck check code	2 byte	Exclusive OR of Code, Command and Data (5) Reference		
CR	Cor	ntrol code(Carriage Return)	1 byte j	CR (0x0D)		

Transmission frame

Frame format

STX	Code	ACK Data BCC	CR		
				_	
		Explanation	Data size	Value	
STX		Control code(Start of TeXt)	1 byte	STX (0x02)	
i Code		Station number of inverter	2 byte	01-32	
, ACK		Control code(ACKnowledge)	1 byte	ACK (0x06)	
Data		Data	2 byte	Allowance with 01	
BCC		Block check code	2 hyda	Exclusive OR of Code. Command and Data	
ВСС		Block check code	2 byte	(5) Reference	
CR		Control code(Carriage Return)	1 byte	CR (0x0D)	

On normal reply: (4) - (i) Reference



(xi) OA command: This stores the set value to the EEPROM.

Transmission frame

Frame format

STX	Cod	е	Command	всс	CR				
Explanation D				D	ata		Value		
							size		_
STX		С	ontrol code(Si	art of Te	eXt)		1 byte		STX (0x02)
Code		S	tation number	of inve	rter		2 byte		01-32
Comma	nd	Tr	ansmission o	ommano	ŀ		2	by	yte OA
!									Exclusive OR of Code, Command and
всс	Block check code		2 byte		Data				
<u> </u>									(5) Reference
CR		С	ontrol code(C	arriage	Retur	n)	1 byte		CR (0x0D)

Replay frame

On normal reply: (4) - (i) Reference
On abnormal reply: (4) - (ii) Reference

(xii) OB command: This recalculates the internal motor constants

This function is required when the motor capacity or the number of motor poles is changed by RS485 communication.

Transmission frame

Frame format

	STX	Code	Command	всс	CR
--	-----	------	---------	-----	----

I	Explanation	Data	Value
	1	size	
STX	Control code(Start of TeXt)	1 byte	STX (0x02)
Code	Station number of inverter	2 byte	01-32
Command	! Transmission command	2 byte	0B
			Exclusive OR of Code, Command and
BCC	Block check code	2 byte	Data
			(5) Reference
CR	Control code(Carriage Return)	1 byte	CR (0x0D)

Reply frame

On normal reply: (4) - (i) Reference
On abnormal reply: (4) - (ii) Reference

(i) Affirmative reply Reply frame Frame format

STX	Code	ACK	всс	CR

	Explanation	Data	Value
		size	<u>. L</u>
STX	Control code(Start of TeXt)	1 byte	STX (0x02)
Code	Station number of inverter	2 byte	01-32
ACK	Control code(ACKnowledge)	1 byte	ACK(0x06)
ВСС	Block check code	2 byte	Exclusive OR of Code, Command and
ВСС	Block check code	Data (5) Reference	
CR	Control code(Carriage Return)	1 byte	CR (0x0D)
		-	

(ii) 01Inverter reply

Reply frame

Frame format

STX Code NAK Error code BCC C

	Explanation	Data size	i Value
STX	Control code(Start of TeXt)	1 byte	STX (0x02)
Code	Station number of inverter	2 byte	01-32
NAK	Control code (Negative ACKnowledge)	1 byte	ACK(0x06)
Error code	Error contents of Communication	2 byte	(Note11)
BCC	Block check code	2 byte	Exclusive OR of Code, Command and Data (5) Reference
CR	Control code (Carriage Return)	1 byte	CR (0x0D)


(Note11) Error code list

Error code	contents
01H	Parity error
02H	Sum check error
03H	Framing error
04H	overrun error
05H	Protocoi error
06H	ASCII code error
07H	Reception buffer overrun error
08H	Reception time out error
11H	Error for abnormal command
12H	
13H	Practice disapproval error
14H	•
15H	•
16H	Parameter abnormal error
17H	


Inverter doesn't reply on all code communication

(5) About the calculation method of BCC (the Block Check Cord)

(Example) 5Hz is set up by using 01 commands (the setting of the frequency command). (when the code of the inverter of the object is '01')



BCC is the result that transforms the Code-Data into ASCII Code and took an EXCUSIVE OR (Xor) every lbyte. In the case of the above transmission frame. BCC calculates it as follows.



(Appendix) ASCII code transformation table

! Character	data	i	ASCII code
CTV			0 20
<u>J</u> GR∧		i	<u>0 D</u>
• 0		j	30
1 1			31
2		F	32
3			33
4			3.4
5			35
6		-	36
7			37
8		i	38
9		;	39

Character data	ASCII code
. A	4 1
В	4 2
С	4 3
D	4 4
E	4 5
F	4 6

(6) Communication test mode

The communication test mode checks the communication line of RS485

(The communication test mode procedure)

- 1. Please remove the wiring of terminal unit TM2 of the control terminal unit foundation, to do the loop back check.
- Please set up the following with the operator of the inverter.
 Please set up CO71 (Communication transmission speed selection) to 02 (Loop Sack Test)
- 3. Shut the power supply of the inverter at first and please turn on the power supply once again. The check is started
- 4. When the check ends the display is as follows.

Normal :	L	_	_	
Abnormal:	L		_	_

5. Please push the reset button of the digital operator or copy unit. And, the setting of CO71 is returned to the setting of an original request.

4.4 Protection function list

4. 4. 1 Protection functio

Name	Description	Display of digital panel digital	Display of remote operator/ Copy unit ERR1***	
		operator		
	Materia	At constant Speed	E01	OC. Drive
Over-current protection	Motor is restricted and decelerates rapidly, excessive current is drawn through the inverter and there is a	On decelertion speed	E 0 2	OC. Decel
, p	risk of damage. Current protection circuit operates and the inverter output is switched off.	On acceleration appead	E03	OC. Accel
		Other	E 84	Over. C
Overload protection (note1)	When the inverter detects an overloa the internal electronic thermal overloa the inverter output is switched off.	d operates and	E05	Over. L
Braking resistor overload protection	When BRD exceeds the usage ratio of the regenerative braking resistor, the over-voltage circuit operates and the inverter output is switched off.		E 0 8	OL. BRD
Over-voltage protection	When regenerative energy from the the maximum level, the over-voltage of and the inverter output is switched off	circuit operates	E 0 7	Over. V
EEPROM error (note2)	When EEPROM in the inverter is sub- noise or unusual temperature rises output is switched off.	ect to radiated s, the inverter	E08	EEPROM ،
Under-voltage	When the incoming voltage of inver- control can't operate correctly. The circuit operates and the inverter outp off.	E09	Under. V	
CT error	When an abnormality occurs to a detector) in the inverter, the inve- switched off.	E 10	CT	
CPU error	When a mistaken action causes an err CPU, the inverter output is switched o	EII	CPU1	
External trip	When a signal is given to the EXT in terminal, the inverter output is switche (on external trip function select)	E 12	EXTERNAL	
USP error	This is the error displayed when the in- restored while still in the RUN mode. (Valid when the USP function is selec-	E 13	USP	
Ground fault protection	When power is turned ON, this detects between the inverter output and the m	s ground faults otor.	E 14	GND. Fit
Incoming over-voltage) protection	When the incoming voltage is hig specification value, this detects it for then the over-voltage circuit operates a output is switched off.	E 15	OV. SRC	
Temporary power loss protection	When an instantaneous power failure of than 15ms, the inverter output is switt the instantaneous power failure wait time and the power has not been restored it a normal power failure. However, when the operation comma with restart selection the inverter with please be careful of this.	E 16	Inst. P-F	
Abnormal temperature	When main circuit temperature raises cooling fan, the inverter output is switc	E21	OH. FIN	
Gate Allay error	Communication error between CPU a indicate	E 2 3	GA	
Open-phase protection	When an open-phase on the input sup inverter output is switched off.	F 2 4	PH. Fail	
GBT error	When an instantaneous over-current is the output the inverter output is switched the main devices.	E 30	IGBT	


Chapter 4 Explanation of function

Name	Description	Display of digital panel. digital operator	Display of remote operator/ Copy unit ERR1***
Thermistor error	When the inverter detects a high resistance on the thermistor input from the motor the inverter output is switched off.	<u>E3S</u>	ΤH
Option 1 error 0-9	These indicate the error of option 1. You can realize the details each instruction manual.	E60 - E69	OP1 0-9
Option 2 error 0-9	These indicate the error of option 2. You can realize the details by each instruction manual.	E10 - E19	OP2 0-9
During under-voltage waiting	When the incoming voltage of the inverter has dropped, the inverter cutput is switched off and the inverter walts.	U	UV. WAIT

Note1: After a trip occurs and 10 minutes pass, restart with reset operation.

Note2: When EEPROM error **E 08** occurs, confirm the setting data again.

4.4.2 Trip monitor display



Chapter 4 Explanation of function

4.4.3 Warning Monitor display

Relation code dogo : warning Monito

Warning messages will appear when the **data** set is contradicting to others. Program lamp (PRG) turns ON during the warning (until the data is changed).

Below is the description of the warnings.

	Codes	-	> Basic code
Warning	Codes frequency upper limiter A061/A261	<,: 	Pasic Code
_ -¦001/ -¦201_ -¦002/ -¦202		<u> </u>	Maximum frequency
- 002/ - 202 - 004/ - 204	Base frequency AOO:VA203	>	A004/A204
	putput frequency F001, Multi stage speed 0 A020/A220	>	7,0047/1207
<u>-</u> 003/ <u>-</u> 203 <u>-</u> 006/ <u>-</u> 206	Multi stage speed 1-15 A021~A035	>	
		>	
<u>-</u> 012/ - 212_	frequency upper limiter A062/A262	>	frequency upper limiter
·-·	Output frequency F001, Multi stage speed 0 A020/A220	<u> </u>	—_A061/A261
<u> - 016/ </u>	Multi stage speed 1-15 A021~A035	<u>; ></u>	
<u>-</u> 021/ <u>-</u> 221	frequency upper limiter A061/A261	<u> </u>	1
	Output frequency F001, Multi stage speed 0 A020/A220	<	
	requency upper limiter A061/A261	<	
<u> -</u> 032/	frequency lower limiter A062/A262	<	<u></u>
<u> - 035/ -</u> 235_	Output frequency F001, Multi stage speed 0 A020/A220	<	.
<u>-</u> 036	Multi stage speed 1-15 A021~A035	! <	
_ 037	Jogging frequency A036	<u> </u>	
[-] 085/ <u>-</u> <i>285</i>	Output frequency F001, Multi stage speed 0 A020/A220	< >	Jump frequency 1/2/3 +- Jump width —A063+-A064
l <u>-</u> ¦086	Multistage speed 1~15 A021~A035	<>	A005 - A000
·-· ·-·	requency upper limter A061/A261	>	
	requency lower limiter A062/A262	: >	
<u>-</u> 095/ <u>-</u> 295	Output frequency #10 Multi stage speed 0 A020/A220	>	Free v/f frequency 7 b112
<u>-</u> 096	Multi stage speed 1-15 A021~A035	<u>, > </u>	
	Free v/f frequency I-6 b100, b102, b104. b106, b108, b110	<u> </u>	·
	Free v/f frequency 2-6 b102. b104. b106, b108, b110	į <	Free v/f frequency 1 b100
	Free v/f frequency 1 b100	; >	Free v/f frequency 2 b102
	Free v/f frequency ^ ^ b104, b106, b108, b110	:	<
	Free v/f frequency 1,2 b100, b102	>	Free v/f frequency 3 h104
i <u>:</u> i110	1 F # 5 # / E406 E409 E440		In oquality o blot
- · · -	Free, v/f frequency 4-6 b106, b108, b110		
_ · · · -	Free v/f frequency 1-3 b100, b102, b104	; >	
_ · · · ·	Free v/f frequency 1-3 b100, b102, b104 Free v/f frequency 5, 6 b108~b110	1	
.	Free v/f frequency 1-3 b100, b102, b104	1	Free v/f frequency 4 b106
- · · · -	Free v/f frequency 1-3 b100, b102, b104 Free v/f frequency 5, 6 b108~b110	; >	Free v/f frequency 4 b106 Free v/f frequency 5 b108
	Free v/f frequency 1-3 b100, b102, b104 Free v/f frequency 5, 6 b108~b110 Free v/f frequency 1-4 b100, b102, b104, b106	; >	Free v/f frequency 4 b106 Free v/f frequency 5 b108 Free v/f frequency 6 b110
	Free v/f frequency 1-3 b100, b102, b104 Free v/f frequency 5, 6 b108~b110 Free v/f frequency I-4 b100, b102, b104, b106 Free v/f frequency 6 b110	; > ; ; >	Free v/f frequency 4 b106 Free v/f frequency 5 b108 Free v/f frequency 6 b110 Free electronic thermal frequency 1 b015
-,, -,	Free v/f frequency 1-3 b100, b102, b104 Free v/f frequency 5, 6 b108~b110 Free v/f frequency I-4 b100, b102, b104, b106 Free v/f frequency 6 b110 Free v/f frequency I-5 b100, b102, b104, b106, b106	; > ; ; >	Free v/f frequency 4 b106 Free v/f frequency 5 b108 Free v/f frequency 6 b110 Free electronic thermal
l≓l120	Free v/f frequency 1-3 b100, b102, b104 Free v/f frequency 5, 6 b108~b110 Free v/f frequency 1-4 b100, b102, b104, b106 Free v/f frequency 6 b110 Free v/f frequency 1-5 b100, b102, b104, b106, b106 Free electronic thermal frequency 2,3 b047, b019	; > ; ; >	Free v/f frequency 4 b106 Free v/f frequency 5 b108 Free v/f frequency 6 b110 Free electronic thermal frequency 1 b015 Free electronic thermal

Warning is cleared when the setting fulfils the above condition.

Data will be changed automatically to the basic code.

(Note 1) The jump frequency will be automatically re-written to the lowest jump frequency (= Jump frequency -jump width)

5.1 Precautions for Maintenance/Inspection

5.1 .1 Daily inspection

Every day before operation check the following;

- [I] Does the motor operate according to the settings?
- [2] Is there any trouble with the surroundings of the installation?
- [3] Is there any trouble with the cooling or ventilation system?
- [4] Is there any abnormal vibration or sound?
- [5] Are their any signs of over-current or discoloration?
- [6] Is their any unusual odour present?

Check the input voltage to the inverter by using a meter during running

- [1] Is the supply voltage constant?
- [2] Are all the phases of the supply balanced?

51.2 Cleaning

Make sure that the inverter is not dirty when operating. Wipe clean with a soft cloth and synthetic detergent or ethanol.

(Notes) Don't use solvents containing any of the following, acetone, benzene, toluene, alcohol etc. as they can cause melting of the inverter surface, peeling of paint.

Never clean the display part of the digital operator with detergent or alcohol.

5.1.3 Reaular inspection

Inspections should be regularly carried out on the parts that can't be inspected while the inverter is running.

- [1] Is there any trouble with the cooling system? - Cleaning of air filter etc.
- [2] Check that all screw terminals and fixings are tight as they may loosen due to vibration of temperature change etc.
- [3] Is there any corrosion, damage to insulators?
- [4] Measurement of insulation resistance.
- [5] Check of cooling fan, smoothing capacitor, relay and exchange if necessary.

\$

5.2 Daily inspection and regular inspection

	Inspection		on	-				
Inspection tion Parts Inspection		Inspection Item		cycle		Inspection methods	Decision standard	Meter
			Uany	1	2	1		1
	Surrounding	Check temperature of surrounding, humidity, dust.	0			Refer to 2.1 Installing.	Temperature range is between -10 and 40 degrees. No dew present and humidity is below 90%.	Thermomete r. hygrometer, recorder
Whole	Whole equipment	is there abnormal vibration, abnormal sound?	0			By watching, hearing.	Na trouble.	
	Power voltage	Is main circuit voltage normal?	0			Measurement of inverter terminal R, S, T phase voltage	Within atternating voltage allowable change.	Tester, digital multi- meter
	₩hole	(1)Megger check Between circuit terminal and earth terminal (2)Are all screws terminals tight? (3)Is there any sign of over-voltage? (4)cleaning		0 0		(1)After you remove connector J81 from inside the inverter Take out the wiring of input/output of inverter main circuit terminal and control terminal, measure beween parts shortened terminal R,S,T,U, V,W,P,PO,N,RB and earth terminal with megger. (2)Incremental clamping. (3)Watch.	(1)To be over 5M ohm. (2)(3) No abnormality .	DC50DV class megger
	Connection conductor/ electric line	(1)is there werp in conductor? (2)is there any damage of coating of wires?		0	_	(1)(2) By watching	(1)(2) No abnormality	
	Terminals	is there any damage?	1 =	Q		By watching.	No abnormality.	
Main circuit	iverter parts Converter arts	Resistance check Between each Terminal.			0	Take out connect of inverter, measure terminal between R,S,T and P,N, between U,V,W and P,N with tester x	Refer to check method of 5.5 inverter, converter parts.	Analog form
	Smoothing capacitor	(1)Is there any liquid? (2)Does relief valve come out? Is there any swell? (3)Measure of allowable	00	0		(1).(2) By watching. (3)Measure with capacity measure.	(1),(2) No abnormality (3) Over 80% of rated capacity.	Capacity mater
	Relay	static-electricity. (1)Is there abnormal sound in operation? (2)is there damage to the contacts?	_	0 0		(†)By hearing (2)By watching	(1) No abnormality (2) No abnormality	
	Resistor	(1)Is there any crack, discoloration of resistance insulator. (2)Confirm existance of breaking of wire.		0		(1)By watching cementing resistance. Curl type resistance. Take out connection to other side, measure it with tester.	(1)No abnormality Error to be within 10% of Display resistance.	Tester Digital multi- meter
Control circuit Protec- tion circuit	Operation check	(1)Confirm balance of each output phase voltage with inverter single operation. (2)Operate sequence protection moving test. And no abnormality.	† -	0	_	(1)Measure inverter output terminal U.V.W phase voltage. (2)Short or open protection circuit output of inverter.	(1)Phase voltage balance 200v/400v class is within 4V/8V. (2)On sequence, to operate abnormality.	Digital multi- meter, rectification type voltmeter
Cooling system	Cooling fan	(1) is there abnormal vibration, abnormal sound? (2) is there toosening of	Õ	0	_	(1)Revolve by hands in the state of tone-on idle. (2) By watching.	(1)Revolving smooth. (2)No abnormality.	
	Display	connecting parts? (1)Is the LED lamp illuninated?			_	(1)Lamp indicates lamp on operator.	(1)Canfirm light.	
Display	Meter	(2) Cleaning. Is direction value . Normal?	0	0	_	(2) Cleaning with cloth. Confirm indication value of board meter.	Satisfy normal value, control value.	Voltage meter, current
Motor	Whale	(1)is there abnormal signal, abnormal sound? (2)is there any abnormal odour?	0		-	(1)By hearing, feeling, watching. (2)Abnormal adour from overheat, damage etc. Confirmation.	(1)(2) No abnormality.	meter
	Inslated resistance	(1)Megger check (terminal collection - earth terminal)		_	0	Remove connection to U,V and W and disconnect motor wiring.	(1) To be over 5M ohm.	DC 500V Megger

(Notes) Life time of the capacitors depends on the ambient temperature

5.3 Meaaer test


When executing a Megger test on the inverter remove all wires to R, S, T, PD. P, N, RB, U, V and W.

Do not use a megger or buzzer on the control circuit only use a digital multi-meter.

(Megger Voltage 500V DC)

Execute megger test of main circuit after the J61 connector has been removed. Short terminals of R, S, T, PD. P, N, RB, U, V and W.

After the Megger test is complete, reconnect the J61 connector as before.



5.4 Withstand Voltage test

Never perform a withstand voltage test on the inverter.

The inverter main circuit uses semiconductors. Semiconductors can deteriorate when a withstand voltage test is performed.

5.5 The method to check Inverter. converter Dart

A test is possible to check quality.


(Preparation)

- [1] Take out the power lines (R. S and T) connected to the inverter, the motor connection lines (U, V and W) and the regenerative control resistance (P and RB).
- [2] Prepare tester. (Using range of 1 ohm resistance measure range.) (How to check)
 - It is possible to check the quality of the charging state of the terminals R. S. T. U, V, W, R8, P and N of the inverter and the pole of the tester by measuring the charging state.
- (Notel) Before you measure the voltage between P and N with DC current range. confirm that the smoothing capacitor is discharged fully. execute checks.
- (Note2) Almost infinite value is indicated on no conducting.


With the effect of the smoothing capacitor, the inverter conducts instantly and an infinite value isn't indicated. Ohm-number 10 ohms is indicated on conducting.

The values indicated will not be exactly the same for each terminal. however they will be very close together. If there is a significant difference a problem may exist.

		Pole of	f tester	14
		0	lө	Measure value
		(Red)	(Black)	value
	D1	R	PD	No-conduct
Ì		PD	R	Conduct I
	D2	S	PO	No-conduct
		PO	S	Conduct
L	D3	Ŧ	PD	No-conduct
Converter		PD	Т	Conduct
onv	04	R	N	Conduct
ن		N	R	No-conduct
	D5	S	N	Conduct
		N	S	No-conduct
	D6	T	N	Conduct
		N	Т	No-conduct
	TR1	ับ	Р	No-conduct
		Р	υ	Conduct
	TR2	V	Р	No-conduct
		Р	V	Conduct
	TR3	W	Р	No-conduct
nverter		Р	W	Conduct
nve	TR4	U	N	Conduct
_		N	U	No-conduct
	TR5	٧	N	Conduct
		N	V	No-conduct
	TR6	W	N	Conduct
		N	w	No-conduct
_	TR7	RB	Р	No-conduct
BR part		Р	RB	Conduct
<u>چ</u>		R8	N	No-conduct
"		N	RB	No-conduct



5.6 Capacitor Life Curve



(Note1)

Ambient temperature means the surrounding temperature of the inverter. In case the inverter is installed in a cabinet, ambient temperature is the temperature of the internal air of the cabinet.

(Note2)

DC bus capacitors are recommended to be replaced every 5 years. And if the inverter is used in a worse condition, this recommended replacing period is reduced.

£ 25 €

6.1Standard specification list

	•					200V	class		· -		Ţ			400	/ cises			
Invert	er Model		L300P	L300P-	1.300P	L300P-	L300P.	L300P-	L300P-	L300P-	L300P-	L300P-	L300P-	L300P	L300P-	L300P-	L300P-	L300P
D	ction struc	·	110LF	150LF	165LF	2201.F	300JF	370LF	450LF	550LF	110HF	150HF	185HF	2201	300HF	3701-₹	450HF	550HF
(note		The state	İ				•			IP20(NEMA1)							
Max	Applicade	Motor 4P	11	15	18.5	22	30	37	45	55	11	15	18.5	22	30	37	45	55
	(note2) 1 input						 	ļ <u></u>	 10	 	<u> </u>		102			ļ.,		
	ebno	200√/ 400√	15.2	20.0	25.2	29.4	39.1	48.4	58.5	72.7	15.2	20.0	25.6	29.7	39.4	48.4	58.8	72.7
voltaç	pe(kVA)	240V/ 480V	18.2	24.1	30.3	35.3	46.9	58.1	70.2	87.2	182	24.1	30.7	35.7	47.3	58.1	70.1	87.2
Ratec	f input alte ye	mating	Three-phase 200-240V (+-10%) 50Hz/60Hz Three-phase 380-480V (+-10%) 50Hz/60Hz								•							
	output vo	tage	Three-pha	ese 200-240	X (This con	responds to	receiving v	oltage.)			Three-p	hase 380-48	10V (This co	masponds t	o receiving v	oltage.)	•	
Rates	output au	ment (A)	44	58	73	85	113	140	169	210	22	29	37	43	57	70	85	105
·	ol system		5 Ine-ways	modulation	PWMsys	tern.												
(note	if frequenc 4)	cy mange	0.1-400Hz		·													
	ency accu		Digital con	Trimend +/-0	01% for Ma	x frequenc	y, analog fr	equency +/-(0.2%(25+-10	DC)								
POWe POWe	Mency reso		Digital set	ting: 0.01Hz	analog set	ting Max. In	equency /40	00										
	gevifrequen potensibo	cy	V/f option	variable, V/	control. (co	instant torqu	ue, reduced	torque)										
_	oad curren	rt mente	120% for (60 seconds	150% for 0	.5second												
	eration/ eration tim	•	0.01-3,600	Diseconds (s	traight or S-	Сигуе оп а	cceleration,	deceleration	s optionals	setting indivi	dually), 2" a	djustable se	tting is possi	bie.				
	Regeners Control (short dura (note5)	tve	BRD circuit built-in (Discharge resistance is required.) Regenerative unit is required. (Discharge resistance is required.) Regenerative						ative unit is :	required.								
美旨	DC Braker	19		g and decei power, time				operates un	der operabo	n setting fred	quency. Or is	nverter open	žes vith est	emai input				
Ī		Operator	Setting by		⊘ квуз						-							
		Volume	Setting wit	h potention	eter on the	digital open	etor (Buiti-in	as standard	(Analog se	tang)								
	Freq. Jency	Extens	DC 0 to 5	V5 to +5V.	0 to 10V, -1	0 to +10V (input impedi	ance 10k oh	m). 4-20mA	(input impe	dance 100 i	ohm)						
-		Signal External	DC 0 to 5V, -5 to +5V, 0 to 10V, -10 to +10V (input impedance 10k ohm), 4-20mA (input impedance 100 ohm) Setting with RS485 communication															
- }-		port	<u> </u>									_						
ŝ		Operator External		(forward ch														
60	Run/St op	10 004	Forward F	tun/Ston (1:	connect), f	everse con	nmand s im	possible on	assigning of	terminal (se	ection of 1s	10 B possi	bis), input of	3 wires is p	ocesible.			
<u> </u>		Externel port	Setting wit	th RS485.										·				
F	intelligent termna/	nput	Reverse of USP funct 3 wine dire	tion (USP), d action select	tV), multi-sp commercial con (F/R), P	change (C: ID selection	S),software i valid/invalid	ock (SFT), a I (PID), PID I	inalog input	voltage / cur aset (PIDC),	rent/select remote con	(AT), reset a atrox.up functi	werter (RS),	3 жге гил	n stop (FRS), (STA),3 wire i down funco	keep (STP)	(EXT),	
	Thermsto	rinout	1 termenai								, , , , , , ,	<u> </u>						
	termina: Intelligent	0.40.4	1		mark) =====	1c contact	or desired series	- مامحد	- follows:									
- 1	(aumuna) Harandarii						, output rela; constant sp		is raiows; itting frequer	ncy, PID ove	r-devation)							
	intelligent output terr						pulse line o											
	y monitor											electric pov						
Other	function		Starting fre	squency, Ca											t.Analog met ip retry, Redu			
Came	r frequenc	у	Overload r 0.5-12 kHz					.										
	stron functi	on	Over-curre	ant over-voi	tage, under	votage e	ectronic the	mál level, a	bnormal tro	uble, ground	d faut cume	nt on startin	g, instantane	stop, (USP error, o	pen-phase	ertor, contro	nesisto
Stupus	Freque temper /Preser temper (note6)	asture Vastion		CT entor, exc degrees (not				RH (installe	id with no de	w condens:	stion)			-				
Usage	Vibratio	rı (nate?)		0.6G), 10-56														
	Using r	kace				doors (insta	wed away fo	om comosim	e gesses, d	st)(note8)								
Paunto				14 version		for apph of	المراجع ورفعهم	no meioto-	Manager and a	Annie I	nitrometic -	marter D C	montes F1	r Hain S	ter, higher ha			
Option	e			LCR filter					OPO OTREVE	CONTRACTOR OF THE	, and macing	research, D.C.	. restutt, EM	n, Maliti IE	vor,ing⊓erhe	i inuni¢		
Remo	te operato						m), ICS3(3n	1)										
chec	netic mees	(kg)	5	5	12	12	12	20	30	30	5		12	12	12	20	30	3(

(note1) Protective system bases on JME1030.

(note2) Applicable motor indicates HITACHI three-phase motor. When you use other motor, set so that the motor current doesn't exceed the rated current of the inverter.

(note3) Output voltage will reduce when the power voltage is reduced. (Except when AVR function is selected.)

(note4) When you operate motor over 50/80Hz, inquire about the allowable maximevolution time of motor etc. from motor manufacturer.

(notes) Braising resistance soft installed in the inverter. When the inverter requires a high regenerative torque, use optional braising resistance and regenerative braising unit.


(note6) Protective temperature is temperature during transportation.

(note7) This besies on the test methods of JIS (0911(1984).


(notes) When the inverter is used in a place with dust, we recommend the optional varnish coating specification. Before it is required.

6.2 Dimension


L300P-110,150LF/HF




L300P-185-300LF/HF



L300P-370LF/HF



L300P-450,550LF/HF







Phone: (604) 7098600 Fax: (604) **872-8560** Toll free phone: Toll free fax: 1 (877) 539-2542 1 (800) 539-2542

Hitachi 0 Series Variable Frequency Drive Software

Date: \$2.3E2009-7.2526174	Company:	
VFD MODEL 12 2 3 4 4 4 4 4 4	Contact: 2007	· · ·
Serial Number: 5	Phone: ALL	Faxition
VFD:Taggard Example 12-12	Project: \$100 N	

NOTE: Only the software parameters different from the "Initial Value" are noted.

BRICODELLA	各位VALUE 经	SETIVALUE
FILE DESCRIPTION OF THE PERSON	Monitor mode	na
F2200000000000000000000000000000000000	Set frequency	
经现场规划	F	
F5 MALES STATES	NOTE 1	
F612/图域基础	NOTE 2	
F7在战争经济。14	NOTE 2	
68 高級 (12)	11	
F-9 C - 10 C - 2	0	
E10	72	
	NOTE 3	
ETH SHOP AND AND AND AND AND AND AND AND AND AND	A0	
C0.00000000000000000000000000000000000	1	
CINESSE	10	
G242240	7	

DISPLAY SINITIAL STATES

G1 10	
G23460000000000007	
G3 5 5 5 5 11	
G4945 6 3 0 0	

G20	2	
G2(1)	3	

DISPLAYE LCODE		SETVALUE
A0 SYCORES		
A1I2社内有效思想	NOTE 4	
A2包含的	4	
ASTERNATIONS	0.0	
A4LESS SALES		
A5也是新国家	0	
A613 STEED	0	
A76KELETES		
AS ELECTRON		
A9		
A10家医表现家教徒		
A11直接的建設		
A12505 FACT		
A13年日本		
A14LTZERE		
A1570ESETY		
A162 CAR		
	0	
A18 BASS		
A19 MACANA		
A20 20 20 20 20 20 20 20 20 20 20 20 20 2		
A24	10	
A927	1	
A28	100	
λ 2 4)	0	
A95,	0	
A26News	0	
A27/	0	
A28	0	
	0	
A30	150	
A312415	150	<u> </u>

NOTE	1:18	for LFU	models.	26 for	HFU	& MFU	models.

NOTE 2: 10 sec. for LFU models, 15 sec. for HFU & MFU models.

NOTE 3: 230 for LFU models, 460 for HFU models, 575 for MFU models

NOTE 4: Output kW rating of the VFD.

NOTE 5: DO NOT CHANGE. Factory use only.

DISPLAY	REMINITIALS	新兴大学的设计
W CODE	A VALUE LA	SETVALUE
A32 12 44 12 12 12 12 12 12 12 12 12 12 12 12 12	0	
A33 Kilon Epu	0	
A34 TELESTICAL	0	
A35WAGEARU	0	
A36以及2000	0	
A374	NOTE 3	
A38 (SEE 12)	5	
A39 2 Karaj	100	
A401211234	100	
A4.180	1	
A42 25 4 7 1	1	
A43 (2) (2)	0	

A47.78522	1.0	
A48157477	0	
A49 (31.02)	2	
A50 (2007)	1	
A518EE	0.0	
A5223 1222	1	
A53	0	

A55	0	
A56	1	
A574	0	
A58	1	

A62 60	
A63 7 60	
A649032425284 0	

A68 8 2 2 2 2 10.50	

STATE OF THE STATE OF	NOTE 5	
HOURSTANDEN TANK	NOTE 5	
ASTE ALL SE	NOTE 5	<u> </u>
A82 17 17 18	1.0	
A83 X 12 2 2 2	10.0	
A84.	0	
A85	1.0	





Operation manual - <NB497X>

CANADA

Phone: (604) 7094600 Fax: (604) 872-8560 Toll free phone: 1 (677) 539-2542 Toll free fax: 1 (600) 539-2542

Hitachi J100 Series Variable Frequency Drive Software Programming (DOP)

Date: St. 1	Company:	
VFD MODEL	Contact:	
Serial Number:	Phone:	Face
VFD Tag	Project:	<u> </u>

NOTE: Only the software parameters different from the "Initial Value" are noted.

Monitor Mode

MOINTO IN	MOINTOI MODE		
Displayo	display	Initial C	Set Value
第四种	ACC1	0010.00\$	
	DEC1	0010.008	
102	F-SET-M	Remote	
20	F/R-SW	Remote	
40 S	RPM 4P	00000RPM	
MD Vis	/Hz01.0	0.00	
	IfA	Im000.0%	na
	PN-V	000V	na
्ट	V Boost Code	<11>	
1.40	V-Gain	100%	
	M-ADJ	72	

Function Mode

Initial	Function Mode			
E001913 CONTROL			inia K	
E015-987; +Fmax 000.0Hz E502-987; Fmin 000.5Hz E33-987; H-LIM-F 000.0Hz E143-988; L-LIM-F 000.0Hz E155; Speed-1 005.0Hz E156; Speed-2 020.0Hz E306; Speed-3 040.0Hz E208; Speed-4 000.0Hz E208; Speed-5 000.0Hz E208; Speed-6 000.0Hz E309; Speed-6 000.0Hz E309; Speed-6 000.0Hz E309; Speed-7 000.0Hz E309; Speed-7 000.0Hz E309; Speed-7 000.0Hz E309; Speed-7 000.0Hz E309; Speed-7 000.0Hz E309; Speed-7 000.0Hz E309; Speed-8 000.5Hz E309; Speed-7 000.0Hz E309; Speed-8 000.0S E319; V-DCB 010 E319; Speed-8 000.0S E319; Speed-9 000.0S E319;	E200) 5 5	CONTROL	VF	
E502 Fmin 000.5Hz E503 Fmin 000.0Hz E503 Fmin 000.0Hz E504 Fmin 000.0Hz E505 Speed-1 005.0Hz E505 Speed-1 005.0Hz E505 Speed-2 020.0Hz E505 Speed-3 040.0Hz E505 Speed-3 040.0Hz E506 Speed-4 000.0Hz E506 Speed-6 000.0Hz E506 Speed-6 000.0Hz E506 Speed-6 000.0Hz E506 Speed-6 000.0Hz E506 Speed-7 000.0Hz E506 Speed-7 000.0Hz E506 Speed-7 000.0Hz E506 Speed-7 000.0Hz E506 Speed-7 000.0Hz E506 Speed-7 000.0Hz E506 Speed-7 000.0Hz E506 Speed-7 000.0Hz E506 Speed-7 000.0Hz E506 Speed-7 000.0Hz E506 Speed-7 000.0Hz E506 Speed-8 000.5Hz E506 Speed-8 000.5Hz E506 Speed-8 000.0Hz E507 Speed-8 000.0Hz E507 Speed-8 000.0Hz E508 Speed-8 000.0Hz			000.0Hz	
Color			000.5Hz	
Speed-1	F203	H-LIM-F	000.0Hz	
Speed-2 O20.0Hz	EDAY.	L-LIM-F	000.0Hz	
\$\frac{\text{Speed-3}}{\text{Speed-4}} \text{O40.0Hz} \\ \text{Speed-4} \text{O00.0Hz} \\ \text{Speed-5} \text{O00.0Hz} \\ \text{Speed-6} \text{O00.0Hz} \\ \text{Speed-6} \text{O00.0Hz} \\ \text{Speed-7} \\ \text{Speed-7} \text{O00.0Hz} \\ \text{Speed-7} \\ \text{Speed-7} \\ \text{O00.0Hz} \\ \text{Speed-7} \\ \text{Speed-7} \\ \text{O00.0Hz} \\ \text{Speed-7} \\ \text{Speed-7} \\ \text{O00.0Hz} \\ \text{Speed-7} \\ \text{Speed-7} \\ \text{O00.0Hz} \\ \text{Speed-7} \\ \text{Speed-7} \\ \text{O00.0Hz} \\ \text{Speed-7} \\ \text{Speed-7} \\ \text{Speed-7} \\ \text{O00.0Hz} \\ \text{Speed-7} \\ \text{Speed-7} \\ \text{O00.0Hz} \\ \text{Speed-7} \\ \text{Speed-7} \\ \text{Speed-7} \\ \text{Speed-7} \\ \text{Speed-7} \\ \text{Speed-7} \\ \text{Speed-7} \\ \text{Speed-7} \\ \text{Speed-7} \\ \text{Speed-7} \\ \text{Speed-7} \\ \text{Speed-7} \\ \text{Speed-7} \\ \text{Speed-7} \\ \text{Speed-7} \\ \text{Speed-7} \\ \text{Speed-7} \\ \text{Speed-7} \\ \text{Speed-7} \\ Speed-	(1)(5) Market	Speed-1	005.0Hz	
Speed-4	印度	Speed-2	020.0Hz	
Speed-5	E20/4	Speed-3	040.0Hz	
Speed-6	E438	Speed-4	000.0Hz	
Speed-7	8(13)	Speed-5	000.0Hz	
### F-DCB 000.5Hz ####################################	(i) €	Speed-6		
ESB V-DCB 010 [24 T-DCB 000.0S [25 M E-therm 100% [25 M E-therm 100% [25 M E-therm 100% [25 M E-therm 100% [25 M E-therm 100% [27 M E-therm 100% [27 M E-therm 100% [27 M E-therm 100% [28 M E-therm 100% [28 M E-therm 100% [29 M E-therm 100% [20 M E-therm	PANI	Speed-7	000.0Hz	
T-DCB 000.0S E35				
### ### ##############################			*	
### ACCline Linear #### DECline Linear ###################################				
E37 DECline Linear E38 DECLINE E-START 000.0Hz E39 F-START 000.0Hz E39 F-END L SWITCH1 DCB OFF SWITCH1 FM ANA SWITCH1 fmax 120 SWITCH1 FWER ALM SWITCH1 DOP FWD SWITCH1 FWD ON				
F-START 000.0Hz F-START 000.0Hz F-END L SWITCH1 DCB OFF SWITCH1 FM ANA SWITCH1 fmax 120 SWITCH1 PWER ALM SWITCH1 DOP FWD SWITCH1 FWD ON			1	
F-END				
SWITCH1 DCB			000.0Hz	
SWITCH1 FM ANA SWITCH1 fmax 120 SWITCH1 PWER ALM SWITCH1 DOP FWD SWITCH1 FWD ON	EXID TABLE		<u> </u>	
SWITCH1 fmax	P320			
SWITCH1 PWER ALM SWITCH1 DOP FWD SWITCH1 FWD ON	2			
SWITCH1 DOP FWD SWITCH1 FWD ON	3.0			
SWITCH1 FWD ON	30		·	
	1. 1. 1			ļ
SWITCH1 REV ON	200			ļ
Mark Control of the C	All similar			ļ
SWITCH! OLMT ON		ISMITCHT OLMT	I ON	

Function Mode

Display	是是美国	(initial)	1
Code	Display	e Value V	Set Value
F-211137-0	SWITCH2 DB	LVL	
	SWITCH2 STOP	ON	
100	SWITCH2 Ethm	000	
	SWITCH2 SLOK	OFF	
	SWITCH2 AIN	5V	
F-22 700 S	SWITCH3 SOFT	FREE	_
	SWITCH3 FARV	2	
	SWITCH3 TRIP	OFF	
DECKE STATE	SWITCH3 DEBG	OFF	
	SWITCH3 TCNT	CNT	
F-23 6562	SWITCH4 MON	FM	
F24	SWITCH5 RUN	1 01	
	SWITCH5 AVR	ON	
	SWITCH5 LAD	ON	ļ
	SWITCH5 RVS	ON	
25	LM.CONS	150%01.0	ļ
5-26 K-10		001.03	
F-28	BRD-%ED	05.0%	
	SPD-ARV	ACC100%	
P-30	CARRIER	16kHz	
F31 424	V-SET	NOTE 1	i
F-32	DEC-V	NOTE 1	
533	JUMP-F1	000.0Hz	
	JUMP-F2	000.0Hz	
F-35	JUMP-F3	000.0Hz	
F-36	JMP-WID	0.5Hz	
F-387	Olalarm	150%	
	IN-TM 1	CF1	
	IN-TM 2	USP	
	IN-TM 3	2CH	
TANK THE	IN-TM 4	RS	<u> </u>
	IN-TM 5	REV	
	IN-TM O/C-1	NO	
	IN-TM O/C-2	NC.	
	IN-TM O/C-3	NO.	-
	IN-TM O/C-4	NO	
7.5	IN-TM O/C-5	NO AD	_
A 16 10 11	OOI-IM I	AR	
I SAME SALES FOR EX	TOO IS IM OVER	NO	
	OUT-TM O/C-A SAMP-F	NC 08	
FE40	LOAMPT	. 40	

NOTE 1: 230 for LFU models, 460 for HFU models, 575 for MFU models. (Some exception may apply to older models) NOTE 2: BOLD values can be changed.



Technologies Inc.

VFD SALES AND ENGINEERING 275 West 4th Avenue Vancouver, BC V5Y 1G8 **CANADA**

Operation manual - <NB501X> Logic board: 1499 or lower

Phone: (604) 872-8155 Fax:

(604) 872-8560

Toll free phone: Toll free fax:

(877) 539-2542 (800) 539-2542

Hitachi J300 Series Variable Frequency Drive Software Programming (OPE)

Date: New York	Company: 3	
VED MODEL	Contact:	
Serial Number:	Phone:	Fax:
VFD Tag	Projecting	

NOTE: Only the software parameters different from the "Initial Value" are noted.

DISPLAY	INITIAL VALUE	SETVALUE
F2	0	
F4	F	
F5	02	_
F6	30.0	
F7	30.0	
F8	11	
F9	03	
F10	72	
F11	NOTE 1	

F14	JAU	na
•		

d0	Output Frequency Monitor
d1	Motor Revolution Speed Monitor
d2	Output Current Monitor
d3	Frequency converted value
d10	Trip Monitor
d11	Trip History Monitor

DISPLAY	INITIAL S	SETVALUE
A0	0	
A1	NOTE 2	
A2	4	
A3	2.00	
A4	0.50	
A5	0	
A6	0	
A7	0	
A8	0	
A9	0	
A10	NOTE 3	
A11	NOTE 5	
A12	0	
A13	Ō	
A14	0	

A23 A24	100	I	
A24	1		
A 2 6	lo lo		
A26 A27	0		
721			
A34	0		

A38	NOTE 4	
A39	0	
A40	0	

NOTE 1: 230 for LFU models, 460 for HFU & MFU models.

NOTE 2: Output kW rating of the VFD.

NOTE 3: DO NOT ADJUST. Factory use only.

NOTE 4: 1.5 for VFDs with DBU, 0.0 for VFDs without DBU.

NOTE 5: For European models only.

DISPLAY.	NITIALS VALUE	SETWALUE
A44	0	
A48	1	

_ 1	
. ĮV	
0	
INOTE 5	T
0	
	NOTE 5

A62 6)
A63 6	

A65_	[o	
A80	(NOTE3	
A81	NOTE 3	

C0	18	
C0 C1 C2 C3 C4 C5 C6	16	
C2	5	
C3	11	
C4	9	
C5	13	
C6	1	
C7	0	

C10	0_	
C11	1	
C20	(00	
C21	04	



Operation manual - < NB506X> Logic board: 1876 or higher

Phone: (604) 872-8155 Fax: (604) 872-8560 Toll free phone: (677) 539-2542 Toll free fax: (600) 539-2542

Hitachi 0 Series Variable Frequency Drive Software Programming (OPE)

Date:	Company: R	
VED MODEL	Contact:752	
Serial Number:	Phone: 524	Fax: Leal-3
VED Tag Walls Solve Solve	Project: Pas	

NOTE: Only the software parameters different from the "Initial Value" are noted.

DISPLAY FINITIAL	DISPLAY	DISPLAY
DISPLAY INITIAL SET. VALUE	DISPLAY MINITIAL SETVALUE	DISPLAY INITIAL SETVALUE
52.3.3.4.2. 0	AO O	A44 3451263 0
FARETRIN F	A1版企业 NOTE 2	
	A21 4	A472 1
6 30	A317 2 2	A48E2EEE 1
30	A4 0.5	A49 5 1 1 0
58 20 445 11	A538168855 O	
E9 4.1.2.4.2.3	A6 2 4 0 0	A54 1
72	A7800 222 0	
NOTE 1	ABT 0	A581478464 6
A0 na	A9 STEED 0	A59 2 2 0
	A102 NOTE 3	
70.000 18	A10-250-8	A6112/AFE 1
16	A(2) 6 0	A6213 60
CP. 2 5	XIBO E DIO	A6312 200 60
C3 20 20 11	A74 4 0	AB4 120
Q 2 3 4 5 9		
G50 0000 13	AZ3- 100	A30 NOTE 3
Samuel 1	AZA 5 1	AND NOTE 3
(C) (C) (C) (C) (C) (C) (C) (C) (C) (C)	A25 4	
	A26 - 0	ASSESSED 0
0	A 7 7 8 8 8 8 0	<u> </u>
G0 : 1		A50576.500 1
	AXA CONTRACTOR	ASPER AL I
(20) A 0		A92 (34 A) 0
621 5 4	A38 NOTE 4	-
	A395 0	APAR DE 0
Output Frequency Monitor	AAOXAAR O	A951200000 0
Motor Revolution Speed Mon		A96944 0
2 Output Current Monitor		A97/2 A37 0
Frequency converted value		A98 3 4 5 0
B(i) Trip Monitor		A99 2 0
Trip History Monitor		

NOTE 1: 230 for LFU models, 460 for HFU models, 575 for MFU models.

NOTE 2: Output kW rating of the VFD.

NOTE 3: DO NOT ADJUST. Factory use only.

NOTE 4: 1.5 for VFDs with DBU, 0.0 for VFDs without DBU.



Operation manual - <NB501X> Logic board: 1499 or lower

Phoi (604) 872-8155 Fax: (604) 872-8560

Toll free phone: (877) 539-2542 Toll free fax: (800) 539-2542

Hitachi J300 Series Variable Frequency Drive Software Programming (DOP)

Date: WEST PARTY	Company:	
VFD MODEL	Contact: Will Land	
Serial Number:	Phone:	Fax:455
VFD.Tag: 2000	Project: 12 Control & State &	

NOTE: Only the software parameters different from the "Initial Value" are noted.

Monitor Mode

Coasi	Display	Initial Value	Set Value
No.	ACC1	0030.005	
	DEC1	0030.00S	
	F-SET-SELECT	TRM	
	F/R-SELECT	TRM	
(A)	RPM 4P	0RPM	
NO.	/Hz01.0	0.00	
	lm 0.0	0.0%	
ुन्न	Torque	0%	
X 5	V-boost code	<11>	
	V-Gain	100%	
	Jogging	1.0Hz	
图形	ADJ	072	
医	TRM	LLLLLLLL	

NOTE 1: 230 for LFU models, 460 for HFU & MFU models.

A CONTRACTOR OF THE PARTY OF TH

NOTE 2: Output kW rating of the VFD. NOTE 3 Varies depending on model. NOTE 4: BOLD values can be changed

100	Display	Initial Value	Set Value
	F-BASE	0060Hz	
12010年	F-MAX	0060Hz	
1202 E.R.	Fmin	0.50Hz	
203/2	AVR AC	NOTE 1	
31.157			
	AVR DEC	OFF	
HALL ADMI	CONTROL	VC	
\$15%	AUX AUTO	NOR	
	AUX DATA	NOR	
	AUX K	NOTE 2	
10	AUX P	4P	
-1	AUX R1	NOTE 3	
	AUX R2	NOTE 3	
133	AUX L	NOTE 3	
4.00	AUX M	NOTE 3	
. 12	AUX J	NOTE 3	
	AUX Kp	002.00	
	AUX Ti	00100ms	
1	AUX KPP	001.00	
ED6 2	ACC1	0030.00s	
1.1	ACC2	0015.00s	
1.	ACC LINE	L	
342	ACC GAIN	02	
107/	DEC1	0030.00s	1
李章	DEC2	0015.00s	
	DEC LINE	L	1
	DEC GAIN	02	
E08		0000.0Hz	
	Fsp TIME	00.0s	
	PARAM	REM	
-	RUN KIND	SPD	
-1/	RUN MODE	NOR	
	1.101110000	1000	l

322			
Code	Display	anital Value	Set Value
E41126	SPD 1	0000.00Hz	
2 E	SPD 2	0000.00Hz	
	SPD 3	0000.00Hz	
1223	SPD 4	0000.00Hz	
	SPD 5	0000.00Hz	
	SPD 6	0000.00Hz	
A	SPD 7	0000.00Hz	
FI 12	PRC1 F	2H00.00Hz	
	PRC1 TF	OFF	
· 5	PRC1 T	0000.0s	
3	PRC1 A/D	S1F	
	PRC1 TERM	NOR	
	PRC1 NEXT	1	
E 13	PRC2 F	0000.00Hz	
	PRC2 TF	OFF	
X 4	PRC2 T	0000.0s	
3.8	PRC2 A/D	S1F	
	PRC2 TERM	NOR	
11303	PRC2 NEXT	1	
F-14%	PRC3 F	00 <u>00.00Hz</u>	
生活一等	PRC3 TF	OFF	
本語意	PRC3 T	0000.0s	
	PRC3 A/D	S1F	
	PRC3 TERM	NOR	
新教教	PRC3 NEXT	1	
医疫	PRC4 F	0000.00Hz	
1.6	PRC4 TF	OFF	ļ
	PRC4 T	0000.0s	
14	PRC4 A/D	S1F	
1 4 3	PRC4 TERM	NOR	
	PRC4 NEXT	1 1	

Function Mode

€,

COMPANDO	HAND STREET, SERVICE AND	THE WAS TREETED	
(CODD:	Dis	olay	Set Value
医16到	PRC5 F	0000.00Hz	
Carrier S	PRC5 TF	OFF	
112.1	PRC5 T	0000.0s	
T	PRC5 A/D	S1F	
	PRC5 TERM	NOR	
连进设	PRC5 NEXT	1	
E2175 @	PRC6 F	0000.00Hz	
続後	PRC6 TF	OFF	
	PRC6 T PRC6 A/D	0000.0s	
		S1F	
20 (20)	PRC6 TERM	NOR	
	PRC6 NEXT	1	
	PRC7 F	0000.00Hz	
	PRC7 TF	OFF	
3	PRC7 T	0000.0s	
	PRC7 A/D	S1F	
图的	PRC7 TERM	NOR	
7	PRC7 NEXT	1	
1974	PRC8 F	0000.00Hz	
	PRC8 TF	OFF	
	PRC8 T	0000.0s	
Sec. 15	PRC8 A/D	S1F	
	PRC8 TERM	NOR	
	PRC8 NEXT	1	-
		OFF	l —
≓×01.	DCB SW		
	DCB KIND	LVL	
2 8 1	DCB F	0000.5Hz	ļ
表演之	DCB V-STA	00	
6 15 18	DCB V-STP	00	ļ
	DCB T-STA	000.0s	
	DCB T-STP	000.08	
	DCB STOP-T	0.00s	ļ
	BRD-%ED	001.5%	
F-227-2	IPS TIME	1.0s	
1.	IPS WAIT	001.0s	
Sec. 31	IPS POWR	ALM	
4	IPS TRIP	OFF	ļ <u>.</u>
D-XI	E-THM CHAR	SUB	
	E-THM LEVEL	100%	ļ
	E-THM A1	NOTE 3	
	E-THM F1	NOTE 3	ļ
1 - 1	E-THM A2	NOTE 3	1
	E-THM F2	NOTE 3	 -
	E-THM A3	NOTE 3	
	E-THM F3	NOTE 3	
E24	OLOAD LEVEL	125%	
E 12.7	OLOAD CONST	01.0	
	OLOAD ACC	ON	
	S-LOCK	MD1	
D 26	LIMIT L	0000.0Hz	<u></u>
1000	LIMIT H	0000.0Hz	
127.9	JUMP F1	0000.0Hz	
3 70	JUMP F2	0000.0Hz	·}
100	JUMP F3	0000.0Hz	1
7. 2	JUMP W	0.5Hz	
日28月	STOP-SW	ON	
2974	F/R SW	FRE	
	F/R PREV	OFF	
3 44 .	F/R RVS	6	
E330)		120Hz	
ASSESSED VALUE			1

Code Display	Set Value
F-310 IN ANA	100
IN EXS 0000.0	lacksquare
	0%
IN EXAS	0%
IN LEVEL	Hz
IN F-SAMP	8
F-32 ARV PTN C	ST
R STORES)Hz
)Hz 0%
36-52-30	0%
E-3492 IN-TM1	RS
F-3472 IN-TM1 IN-TM2 IN-TM3	AT
IN-TM3	JG
SASSA IN-TIME	RS
	H1
EVANCE III.	ISP
18 23 33	EV EV
IN-TMO/C-1	NO
	NO
RESEARCH IN-TMO/C-3	NO
	NO
	*A1
	UN
OUT-TM O/C-A OUT-TM O/C-1	NC NO
E-RESCRIP	NO
F36 CARRIER 16.0	
	A-F
E38E3 INIT TCNT C	TN
1673-18527	OFF
INIT DOPE F	ON ON
E3973 OP P 01024pu	
3/35233	SR
17 27	OFF
OR POS	IN
OR P 00000pt	
OR FC 0005.	_
OR TURN F	WD
	00s
PO EGRP	FB
	001
3	001
PO FFWG 000 PO G 000.50m	3.00 ad/a
	EM
TRQ FWD 1	50%
TRQ REV 15	50%
F (3) PID IN-SEL	IN
PID LVL 000.0	
PID P PID I 0	1.0s
	00.0
1) 5 6 1	MD0
536 COM BAU 00600	
COM NUMBER	01
COM LENGTH	8
COM PAR-SEL1	ON
COM PAR-SEL2	EVN
COM STOPBIT	2
123 1334	STP
OP-ERR2	STP



Operation manual - <NB506X> Logic board: 1878 or higher

Phone (604) 872-8155 Fax: (604) 872-8560 Toll free phone (877) 539-2542 Toll free fax: (800) 539-2542

Hitachi J300 Series Variable Frequency Drive Software Programming (DOP)

Date: Marie Table	Company:	
VED MODEL	Contact: Land Land	
Serial Number:	Phone:	Fax:
VED/Tag: ************************************	Project.	

NOTE: Only the software parameters different from the "Initial Value" are noted.

Code	ins tur La Display	Initial Value	Set (
原 藥	ACC1	0030.00S	
	DEC1	0030.00\$	
AN 29	F-SET-SELECT	TRM	
201	F/R-SELECT	TRM	
	RPM 4P	0RPM	
	/Hz01.0	0.00	
	lm 0.0	0.0%	na
NO.	Torque	0%	na
	V-boost code	<11>	
器OM	V-boost F	10.0%	
	V-Gain	100%	
阿斯斯	Jogging	1.0Hz	
100 A	ADJ	172	
	TRM	LLLLLLL	

NOTE 1: 230 for LFU models, 460 for HFU models, 575 for MFU models.

NOTE 2: Output kW rating of the VFD.

NOTE 3: Value varies depending on models.

NOTE 4: BOLD values can be changed.

NOTE 5: This software parameter list applies to J300 manuals, NB506X, XA,

XB, & XC.

NOTE 6: This software parameter list applies to logic board number #1878 or

higher.

	建工业务信息		r sat
Code	Display	(Initial Value	· Valve
度00	F-BASE	0060Hz	
E01	F-MAX	006 0 Hz	
第02	Fmin	0.50Hz	
F-03	AVR AC	NOTE 1	
والمساوات	AVR DEC	OFF	
E04	CONTROL	VC	
F-05	AUX AUTO	NOR	
4. 4	AUX DATA	NOR	
Q	AUX K	NOTE 2	
2.36	AUX P	4P	
	AUX R1	NOTE 3	
346	AUX R2	NOTE 3	
	AUX L	NOTE 3	
	AUX M	NOTE 3	
S 34	AUX J	NOTE 3	
	AUX Kp	002.00	
	AUX Ti	00100ms	
	AUX KPP	001.00	
E:06	ACC1	0030.00s	
	ACC2	0015.00s	
18	ACC LINE	L	
	ACC GAIN	02	

A 1. 17. 60	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	24 加速的	LES ALE
Corio	and Splay	opicy/ichigh	Vaiuo
	DEC1	0030.00s	
£ 1	DEC2	0015.00s	
1 6	DEC LINE		
	DEC GAIN	02	
F08	Fsp F	0000.0Hz	
	Fsp TIME	00.0s	
1-1-1	PARAM	REM	
E 10 K	RUN MODE	NOR	
	RUN FRS	ZST	
長11課	SPD 1	0000.00Hz	
	SPD 2	0000.00Hz	
200	SPD 3	0000.00Hz	
10.5	SPD 4	0000.00Hz	
	SPD 5	0000.00Hz	
	SPD 6	0000.00Hz	
	SPD 7	0000.00Hz	
MATERIAL SERVICES	DCB SW	OFF	
	DCB KIND	LVL	
	DCB F	0000.5Hz	
143	DCB V-STA	00	
	DCB V-STP	00	
	DCB T-STA	000.0s	
100	DCB T-STP	000.0S	
	DCB STOP-T	0.00s	

Code	Display	Initial Value	Set Value
E-215/4	BRD-%ED	001.5%	
F 22	IPS TIME	1.0s	
	IPS TIME IPS WAIT IPS POWR	001.0s	
100	IPS POWR	ALM	
THE PERSON NAMED IN	IIFO INIF	OFF	
F-23 (5)	E-THM CHAR E-THM LEVEL	SUB	
	E-THM LEVEL	100%	
42 32 4 1	[- I I II II I I I I I I I I I I I I I	8.5A	
	E-THM F1	0000Hz	
管的時	E-THM F1 E-THM A2	8.5A	
100	E-THM F2	5Hz	
	E-THM A3 E-THM F3	13. <mark>0Hz</mark>	
亚结5]	E-THM F3	73Hz	
F-24549	OLOAD LEVEL OLOAD CONST	125%	
经验到	OLOAD CONST	01.0	
3380	OLOAD ACC	ON	
E225年第	S-LOCK	MD1	
F-269%	LIMIT L	0000.0Hz	
	LIMIT L LIMIT H	0000.0Hz	
F-27-56	JUMP F1	0000.0Hz	
角期	JUMP F1 JUMP F2	0000.0Hz	i
	JUMP F3 JUMP W	0000.0Hz	
34.5	JUMP W	0.5Hz	
E-281949	ISTOP-SW	ON	
E 29 F)	F/R SW	FRE	
學學们	F/R SW F/R PREV	OFF	
经取得	F/R RV\$	6	
	F-MAX-L	120Hz	
F:3193	IN ANA	10V	
	IN EXS IN EXE IN EX%S	0000.0Hz	
	IN EXE	0000.0Hz	
79 Sec. 1	IN EX%S	000%	
	IN EX%E	100%	
27 6	IN LEVEL	0Hz	
	IN F-SAMP	8	
F 32	ARV PTN	CST	
	ARV ACC	0.0Hz	
	ARV DEC	0.0Hz	
33	OV-TRQ V	100%	
	OV-TRO R	100%	
		RS]
433	IN-TM1 IN-TM2 IN-TM3	AT	
	IN-TM3	JG	
	IN-TM4	FRS	
四 原 3	IN-TM5	CH1	
	IN-TM6	USP	
美工 名	IN-TM7	CF1	
	IN-TM8	REV	
	IN-TMO/C-1	NO	
	IN-TMO/C-2	NO	
	IN-TMO/C-3	NO	
		NO	

		HEREST SECTIONS	ALSet 2
经验			#26F
E COCOR		Minital Value	FABINAT
	OUT-TM1	FA1	
4.0	OUT-TM2	RUN	
146	OUT-TM O/C-A	NC NC	-
2.0	OUT-TM2 OUT-TM O/C-A OUT-TM O/C-1 OUT-TM O/C-2	NO	
8250 Ed	001-IM 0/C-2	NO	
	CARRIER	16.0kHz	
	MONITOR	A-F;	
	INIT TONT INIT DEBG	CNT	
	INIT DEBG	OFF	
16.4	INIT DOPE INIT RESET	FWD	
E-00****	INIT KESET		
F-39%	OP MODE	01024pulse	
医器 图	OP MODE OP RO-TO	ASR	
EMCE	OP RO-10	O.F.F.	
I AV	OR POS		
	OR P	00000pulse	
100	ORFC	0005.0Hz	
<u> </u>	OR TURN	FWD	<u> </u>
1000	OR L	00005pulse	
100	OR TW	0.00s	
151	PO EGRP	FB	
100	PO EGR-N PO EGR-D	00001	
	PO EGR-D PO FFWG	00001	
	PO FFWG	00.00	
E To An	PO G	000.50rad/s	,
F#38	TRQ LIMIT	REM	
	TRQ FWD	150%	
SEA STA	TRQ REV	150%	
F-437		IN	
	PID LVL	000.00%	
THE CARLES WA	PID P	1.0	
	PID I	01.0s	
	PID D PID MODE	0.00.0	
		MD0	
F45	COM BAU	00600bps	
	COM NUMBER	01	
V/a	COM LENGTH	8	
72.	COM PAR-SEL1	ON	
14	COM PAR-SEL2	EVN	
	COM STOPBIT	2	
野	OP-ERR1	STP	
	OP-ERR2	STP	
[2]8	RELAY RYA	RUN	
	RELAY RYB	CST	
	RFLAY BYC	OTQ	



Operation manual - <NB506X> Logic board: 1878 or higher

Phone:

(604) 872-8155 (604) 872-8560 Toll free phone: Toll free fax: (877) 539-2542 (800) 539-2542

Hitachi J300 Series Variable Frequency Drive Software Programming (HOP)

Date: The Care Care Care	Company: 43	
VFD MODEL TO TAKE THE	Contact:注意	
Serial Number:	Phone: 宋上海	Fax: 2000
VFD Tag: 好海、快迎公司	Project:	

Monitor Mode

	Factory	Set		Factory	Set		Factory	Set
FS	0.00Hz		Torque	NOTE 1		WARN	NOTE 2	I
AC1	30.00s		V-Boost	11		ERR1	NOTE 2	
AC1 DC1	30.00s		V-Boost F	10.0%		ERR2	NOTE 2	
RPM	4P		V-Gaiл	100%		ERR3	NOTE 2	
/Hz	1.0	1	Jogging	1.00Hz	1	Count	NOTE 2	
lm	NOTE 1		ADJ	172				
	NOTE 1		TERM	NOTE 1	T			

t Layer	d Layer	3rd Layer	4th Layer	Factory	Set	1st Layer	d Layer	d Layer	4th Layer	Factory	Set
Command			1 F-SET	0: TRM		3 Function	tun	SPD	1 1S	0.00Hz	
		ļ	2 F/R	0: TRM					2 2S	0.00Hz	
			3 PARM	0: REM		¬.			3 3S	0.00Hz	
nitial			1 TCNT	0: CNT					4 4S	0.00Hz	
			2 DEBG	0: OFF					5 5S	0.00Hz	
			3 DOPE	0: FWD	1				6 6S	0.00Hz	
		1	4 RESET	0: ON		_			7 7S	0.00Hz	
unction	ontrol	1 V/f	1 F-BASE	60Hz			Iraking	DCB	1 SW	0: ÖFF	
		1	2 F-MAX	60Hz		_			2 KIND	1: LVL	
		1	3 Fmin	0.50Hz					3 F	0.5Hz	
		1	4 A-AC	NOTE 3		_			4 V-STA	0	_
]	5 A-DEC	0: OFF	-				5 V-STP	lo lo	
		1	6 MODE	0: VC					6 T-STA	0.0s	
		2 Motor	1 AUTO	0: NOR	T T				7 T-STP	0.0s	
		1	2 DATA	0: NOR					8 STOP-T	0.00s	
		1	3 K	NOTE 3	1			BRD	1 %ED	0	
			4 P	1: 4P				Ethermal	1 CHAR	1: SUB	
			5 R1	NOTE 3	T I	-		2010111101	2 LEVEL	100%	+
			6 R2	NOTE 3	<u> </u>				3 A1	NOTE 3	+-
			7 L	NOTE 3					4 F1	0Hz	+
			8 M	NOTE 3					5 A2	NOTE 3	+
			9 J	NOTE 3	<u> </u>	_			6 F2	5Hz	+
		1	а Кр	NOTE 3					7 A3	NOTE 3	+
			b Ti	NOTE 3		┪			8 F3	73Hz	+-
			с Крр	NOTE 3				OLoad	1 LEVEL	125%	+
		3 Carrier	1 Cari-f	NOTE 3				CLUSO	2 CONST	1237	→
	Acc/Dec	1 Accel	1 A1	30.00s		-		•	3 ACC	1: ON	+
	1000000	1 / 1000	2 A2	15.00s		-		Freq.	1 LIML	10.0Hz	 -
		l .	3 LINE	0: L	+	⊣		rieq.	2 LIMH	0.0Hz	+
			4 GAIN	2	-	⊣			3 F1	0.0Hz	
		2 Decel	1 D1	30.00s	-				4 F2	0.0Hz	_
		12 0000.	2 D2	15.00s	+	_			5 F3	0.0Hz	
			3 LINE	0: L	+	⊣			6 WIDTH	0.5Hz	_
			4 GAIN	2	+		1	IPS	1 TIME	1.0s	+
	Run	1 Freq.	1 F	0,0Hz	 -	⊣	1	""	2 WAIT	1.0s	
	NUIT	T. EQ.	2 TIME	0.0s	+	\dashv	1				+
		2 Pattern	1 MODE	0: NOR	+	⊣			3 POWR 4 TRIP	0: ALM 1: OFF	+-
		2 Fallern	2 FRS	1: ZST				Ц	Ja IRIP	II. OFF	

1st Layer	2nd Layer	3rd Layer	4th Layer	Factory	Set	1st Layer	2nd Layer	d Layer	4th Layer	Factory	Set
3 Function	5 Protect	5 Others	1 MAXF	0: 120Hz		4 Option	1 Op Error		1 OP1	1: \$TP	
		į	2 SLOCK	1: MD1					2 OP2	1: STP	
			3 STOP	1: ON			2 Select		1 ENÇ-P	1024pis	
			4 F/R	2: FRE					2 MODE	0: ASR	
			5 PREV	0: OFF					3 R0-T0	0: OFF	
	l l		6 RVS	6			3 Orient		1 POS	0: IN	
	6 Terminal	1 Analog	1 V	1: 10					2 P	0pts	
	1	1	2 EXS	0.0Hz	1	_			3 FC	5.0Hz	
			3 EXE	0.0Hz	1				4 TURN	0: FWD	
		4	4 EX%S	О	1	7			5 LIMIT	5pls	
	1		5 EX%E	1 .	1	_			6 TW	0.00s	
		1	6 LEVEL	0: 0Hz		_	4 Position		1 EGRP	0: FB	
		į	7 F-SAMP	8	1				2 EGR-N	1	
	l .	2 Signal	1 PTN	0: CST	1				3 EGR-D	1	
	1	J	2 ACC	0.0Hz					4 FFWD	0.00	
			3 DEC	0.0Hz	<u> </u>		1		5 G	0.50rad	
		1	4 V	100%	1	_	5 Torque		1 LIMIT	0: REM	ľ
		1	5 R1	100%	T	1			2 FWD	150%	_1
	1	3 Terminal	1 1-1	18: RS	1				3 REV	150%	
	1		2 1-2	16: AT			6 PID		1 I-SEL	0: IN	
			3 1-3	5: JG	1	_	1		2 LVL	0.00%	
	1	1	4 1-4	11: FRS					3 P	1.0	
	1	1	5 I-5	9: CH1		7			4 l	1.0s	1
			61-6	13: USP	"I				5 D	0.0	.]
	ı		7 1-7	1: CF1					6 MODE	0: MD0	
		i	8 1-8	0: REV		-1	7 Com.		1 BAU	1: 600bps	
		3	9 I-OC1	0: NO		7			2 NUMBER	1	
			a I-OC2	0: NO		7			3 LENGTH	0:8	
		ì	b I-OC3	0: NO					4 PAR-1	1: ON	}
		1	c I-OC4	0: NO					5 PAR-2	0: EVN	
	ļ	1	d O-1	0: FA1	1	_			6 STOPBIT	0: 2	
			e O-2	1: RUN	1	7	8 RELAY		1 RYA	3: RUN	
	l		f O-OCA	1: NC					2 RYB	0: CST	
			g O-OC1	0: NO	1	7			3 RYC	4: OTQ	
l	1	ı	h O-OC2	0: NO							
i		4 Monitor	1 SEL	0: A-F	1	_					

NOTE 1

Value depends on the operation condition.

Data will be available when there are Warnings or Errors. NOTE 2

NOTE 3 Value depends on VFD model.

ķ



Operation manual - <NB541XB>

Phone: (604) 709-8600 Toll free phone: 1 (877) 539-2542 Fax: (604) 872-8560 Toll free fax: 1 (800) 539-2542

Hitachi L100 Series Variable Frequency Drive Software Programming (OPE)

Date PLane English	Company:	
VED MODEL: 图学出版	Contact: 33	
Serial Number:	Phone: Coa	Fax:
YFD Tag: 在中国的	Přőječt: 🎎	

NOTE: Only the software parameters different from the "Initial Value" are noted.


SPLAY	INITIAL	SET,	DISPLAY	INITIAL	FOSET
SPLAY	VALUE	VALUE	CODE	VALUE	VALUEL
	0.0	<u></u> _	A38認識別新	1.0	
被重要	10.0		A3915	00	
10000	10.0				
WEST	00		A41000000	0	
			A427111111	11	
學學學	01		A43	10.0	
C-822	01		A44	00	
知智能的			A452551012	100	
J. 11	60.0				
			A515网络音光	00	
THE STATE OF	0		A52章后望是	0.5	
	0		A53272421	0.0	
XXX			A542222141	0	
STATE OF	0		A55127 (712)	0.0	
学生的	100				
	01		A61聚态 PST	0.0	
四天沙	8		A62	0.0	
			A63]智慧观点	0.0	
377	0.0		A84官员、安徽	0.5	-
O-VALLY	0.0		A65	0.0	
A DE LA SE	0.0		A66	0.5	
	0.0		AGZ	0.0	
) of the	0.0		A68	0.5	
の心臓をな	0.0				
ル・地震	0.0		A7.1	00	
BA	0.0		A72	1.0	
	0.0		A73	1.0	
	0.0		A7.41	0.0	·
AS 187	0.0		A75	1.00	
THE STATE OF	0.0		A76	00	
ALC: N	0.0				
11000	0.0		A81 27 PM	02	
***	0.0		A822 450 25	NOTE 1	
- 513	0.0				
			A92 75 12	15.0	· · · · · ·
			A93世紀後	15.0	
			A94EXE	00	
			A95) A	0.0	
			A967 EV 51	0.0	<u> </u>
			A975052A	00	
			A98Marker	00	
E 1: 230) for LFU & N	NFU models. 46	0 for HFU models	s .	
		NFU models. 46	60 for HFU models	S .	

DISPLAY	NITAL	SET
HG.CODE		MAVALUES
b01清洁	00	
b02基整数数	1.0	
603四数23	1.0	L
LAG CONTRACTOR	NOTE 0	_
b12 医高级流		
513.55 A	01	,
b2100000	01	
b22 00000	NOTE 3	
b23-17-15	1.0	
		<u> </u>
53100	01	
53265-2220	NOTE 4	
b81局基础	80	
582 5 GZ	0.5	
b83 地名	5.0	
b84 12 18 18 18 18 18 18 18 18 18 18 18 18 18	00	
585	02	
686 3 3 3 3	1.0	_
ь87 4 С. Т.	00	_
b88	00	
589	01	
C0)!	00	
C02	01	
G08:	16	_
C04	13 '	
G05	18	
CIPERIN	00	
C12/2007	00	
C13.	00	
C14LAS	01	
C/5	00	
C21	01	
022	00	
G23178-2-12	00	<u> </u>
024	00	
C3(1)	00	
C32	00	_
COOPERSON.	01	<u> </u>
C414	NOTE 2	
C422 C33	0.0	
C43 35 40 4	0.0	

NOTE 3: 125% of rated output current of the VFD.

NOTE 4: Only for 055 & 075xFU models. 58% of rated output current of the VFD.

C410	NOTE 2	
C423000	0.0	
C43 4 4 4	0.0	
C44 EN E	3.0	





Phone: (604) 709-8600 Fax: (604) 872-8560 Toll free phone: Toll free fax:

1 (877) 539-2542 1 (800) 539-2542

Hitachi L 100 Series Variable Frequency Drive Software Programming (DOP)

Date: 28	Company:	
VFD MODEL: 《설문문문	Contact: Calland	
Serial Number:	Phone:	Fax:
VED Tag	Project:	

NOTE: Only the software parameters different from the

Mon	itor	М	lod	le
-----	------	---	-----	----

Poh.	N. Park	建型型型	
Code	Display 4	initial Value	Set Value :
100	F\$000.0	0.0Hz	
	ACC1	0010.00\$	
	DEC1	0010.008	
	F-SET-SELECT	TRM	
<u> </u>	F/R-SELECT	TRM	
WG 4	/Hz01.0	0.00	
<u> </u>	Im 0.0A	0.0%	na
Me.	V-boost code	<11>	
化可托	V-boost F	10.0%	
6 6	V-Gain	100%	
MZ.	Jogging	1.0Hz	
	Jog Mode	0	
	ADJ	80	
	PANEL	d01	
经银币	TRM	LLLLLLLL	па

NOTE 1: 230 for LFU & NFU, 460 for HFU.

NOTE 2; Rated output current.

NOTE 3: 125% of rated output current. NOTE 4: BOLD values can be changed.

"Initial	Value" are noted	,	
Functio	n Mode		
		APE SES	WATER CO.
医氯磺	Display	initial Value	7. 产业市
	F-BASE		Set Value
		060Hz	
F-01		060Hz	
F-02/3		0.50Hz	
	AVR AC	NOTE 2	
	AVR MODE	DOFF	
F-04815	CONTROL	VC	
(00) (00)	ACC1	0010.08	
中的	ACC CHG	TM	
10.19	ACC 2	0015.0S	
	ACC 2 ACC CHFr	000.0Hz	
	ACC LINE	٦	
F07/31	DEC 1	0010.0S	
	DEC 2	0015.0\$	
	DEC CHFr	000.0Hz	
100	DEC LINE	L	
	RUN FRS	- ZST	
	SPD 1	000.0Hz	
	SPD 2	000.0Hz	
	SPD 3	000.0Hz	
新	SPD 4	000.0Hz	
	SPD 5	000.0Hz	
	SPD 6	000.0Hz	
	SPD 7	000.0Hz	
	SPD 8		
		000.0Hz	
7	SPD 9	000.0Hz	
	SPD 10	000.0Hz	
; •	SPD 11	000.0Hz	
j	SPD 12	000.0Hz	1
٤.	SPD 13	000.0Hz	
	ISPD 14	000.0Hz	
	SPD 14 SPD15	000.0Hz	i —
52017	DCB SW	OFF	
75	DCB F	0000.5Hz	
,62)	DCB WAIT	0.0s	
	DCB V	000	
15.5	DCB T	00.05	
7(2)	IPS UVTIME	01.0s	
於	IPS WAIT	001.0s	
*****	IPS POWR	ALM	
	E-THM LVL	NOTE 2	
24	OLOAD LVL	NOTE 3	<u> </u>
		01.0	
32	OLOAD CONST OLOAD MODE	ON	
26	S-LOCK	MD1	

PAGE 1		1490年1863	CONTRACT OF
Code	Display 4.	Initial Value	Set Value
E26.3	LIMIT L	000.0Hz	
E-17-77	LIMIT H	000.0Hz	
77 5	JUMP F1	000.0Hz	
1	JUMP F2	000.0Hz	
阿爾爾	JUMP F3	000.0Hz	
海 粉	JUMP W1	00.5Hz	
	JUMP W2	00.5Hz	
	JUMP W3	00.5Hz	
F28	STOP-SW	ON	
刻.	IN EXS	000.0Hz	
	IN EXE	000.0Hz	
	IN EX%S	000%	
	IN EX%E	100%	
	IN LEVEL	0Hz	
26.7	IN F-SAMP	8	
F3217	ARV ACC	000.0Hz	
	ARV DEC	000.0Hz	
F33 (2)	OV Load	NOTE 2	
	OV PID	003.0%	
	IN-TM1	FW	
1199	IN-TM2	· RV	
1.0	IN-TM3	CF1	
	IN-TM4	CF2	
	IN-TM5	RS	
	IN-TM O/C-1	NO	
	IN-TM O/C-2	NO	
	IN-TM O/C-3	NO	
	IN-TM O/C-4	NC	
	IN-TM O/C-4 IN-TM O/C-5 OUT-TM1	NO	
F\$577	OUT-TM1	FA1	
1	OUT-TM2	RUN	
	OUT-TM O/C-A	NC	
18.00	OUT-TM O/C-1	NO	
1	OUT-TM O/C-2	NO	
E3632	CARRIER	5.0kHz	<u> </u>
F-37.50	MONITOR	A-F	
FQ:	INIT SEL	USA	l
R. 10	INIT DEBG	OFF	
	INIT DOPE	FWD	-
		TRP	
48,5	PID SW	OFF	
1.136	PID P	1.0	
1. 32	PID I	001.0s	
	PID D	0.000	
	PID CONV	01.00	
	PID INPT	CUR	<u> </u>



Phone: (604) 709-8600 Fax:

(604) 872-8560

Toll free phone: Toll free fax:

1 (877) 539-2542

Hitachi SJ100 Series Variable Frequency Drive Software Programme

1 (800) 539-2542

Date: File	CARREL OF	Comp	any: 233

Date: FIG. SERVER	Company:	
VFD MODEL:	Contact: **** 2.	
Serial Number:	Phone:	Faction
VFD Tag:	Project: 試證	

NOTE: Only the software parameters different from the "Initial Value" are noted.

				1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 -	(Carrier and
DISPLAY	INITIAL	VALUE S	DISPLAY	WINITIAL	SETC
版CODE	VALUE	VALUE N	CODE	②VALUE G	建VALUE 的
F015/	0.0		A61 3331 331	0.0	
F02 (\$44)	10.0		A62	0.0	1
F2021154	10.0		A63 (44393)	0.0	
F031257-13	10.0		A64 220 TEA	0.5	
203.≁∽	10.0		A65 WHITE	0.0	
E0403	00		A66 1525 284	0.5	
			A67.000900	0.0	
A011	01		A68 LOADEN	0.5	
A02:-	01				·
A03 × 46	60.0		A71 NET 352	00	
A203 ED.	60.0	_	A725-1464	1.0	
A04904	60.0	· ·	A73NE SECT	1.0	
A204 (40)	60.0	· · · · · ·	A74235(1)	0.0	
			A75 E374	1.00	
Ata 🕬	0	1	A76	00	(— — — I
A12 in place	0	i		-	
A13 Pre	0	· · · · · ·	A81 \$22 \$22	02	
A14954*70#	100	T	A821314715		
A15 70420	01				,
A16 495	8		A92 (5)	15.0	Γ'
2114	<u> </u>		A292 英文金		
A2001A44	0.0	1	A93號號2		
A21399339	0.0	·	A293161335		
A22 59	0.0		A94 140 271 7		1
A23 🐠 🐣	0.0	 	A294 # 9137	00	1
A24 - 4.3	0.0		A951801816	+	
A25 to h . 63	0.0		A295371(7)		
A26 # 125	0.0 .	<u> </u>	A96 (70 C) 18	0.0	
A27 - ASSAULT	0.0		A296 1134	0.0	i
A28 9-55	0.0		A97.	00	
A29 495	0.0	i -	A98 COLUMN	00	
A30 PL36	0.0		1		
A31: 2005	0.0	1	ì		
A32			501	00	l
A33 4433	0.0		602	1.0	
834 · WIE	0.0		b03	1.0	I
A35 ∹= €	0.0		1		
			b12	NOTE 2	
A38 @- 879	1,0		b212	NOTE 2	1
A390 4442	00		613.5	01	1
			b213	01	
A41 EXCES		1			
A241 ************************************	00	L	b21度30000000		
A42 /48	11		b22.	NOTE 3	
A242 X	11		b23 13 11 1	1.0	L
A43 · 454	10.0				
A243 7887	10.0		631 SEE	01	
A44 'A53	00				
A244 4443			b8122	80	
A45 = 450		1	b82 10 342	0.5	
			b83	+	
A51 1965	00	T	b848 5 4 5 1		
A52 200		T	b85		
A53 2272		1	b86 300 A		1
A. A.		1	5874000		1
A55 × 144		1	588 KANAZES	00	1
			b89¥[ve==0		1

690 PAR 1

b91

b92.500052

00

00

00

1,			,		
DISPLAY	INITIAL	SET	PDISPLAY/	INITIAL	P ISET
CO10FED DE	00		H0124 (1832)	00	
C02 :: 22 - 23	01		H023 2028	- 00	
C03/b23%	16		H202	00	
C047546323	13		H0313328732	NOTE 5	
C0572-3312	09		H203 874343	NOTE 5	
C06 14 (2)	18		H04525255	4	
			H204 \$200	4	f .
C115 MELS	00		H0586-74219	20	
C12#38/88	00		H20550000	20	
C13 12 22 6	00		H06数系统	100	
C146031652	01		H206 E2874	100	
C151/ex15/21	00		**		
C16以线线	00		H20长年64	NOTE 4	
			H220	NOTE 4	
C21	01		H21	NOTE 4	
C22 7 7 7 7	00		H221	NOTE 4	
C23 緊發經濟	00		H227475333	NOTE 4	ļ
C24Y和深级级	05		H222 123 1	NOTE 4	
			H23 数数据53	NOTE 4	
C31223233	00		H223 新数本数	NOTE 4	<u> </u>
C3275532	00		H24124735	NOTE 4	
C33 [14.12.0]	01		H224 IF\$\$7339	NOTE 4	
C416英数赛	NOTE 2		H30147747		na
C42 (4)	0.0		H230 538 355	NOTE 6	na
C43.5% 美型			H31\272.32		na
C44 P45 模型	3.0	<u> </u>	H23113327	NOTE 6	na
			H3221137	NOTE 6	na
C81127.183	NOTE 4		H2325357		na
C82	NOTE 4		H33 C	NOTE 8	па
			H233 52 82 8		na
C9114		na	H347		na
C92		na	H234	NOTE 6	na
C93	NOTE 6	na			
Cay Market		na			
C95	NOTE 6	na			

NOTE 1: NOTE 2:	230 for LFU & NFU, 460 for HFU. Rated current of the VFD.
NOTE 3:	125% of rated current of the
NOTE 4:	Value varies on models.
NOTE 5:	Rated kW capacity of the VFD.
NOTE 8:	DO NOT CHANGE. Factory use only.



Operation manual - <NB582X>

Phone: Fax: (604) 709-8600 (604) 872-8560 Toll free phone: Toll free fax: 1 (877) 539-2542 1 (800) 539-2542

Hitachi SJ100 Series Variable Frequency Drive Software Programming (DOP)

Dete: Market	Company	
VFD MODEL:	Contact: 4	
Serial Number:	Phone:	Fax: 90000
VFD Tag	Project: 234	

NOTE: Only the software parameters different from the "Initial Value" are noted.

Monitor Mode Function Mo

101110	r Mode		G. 52 - 10 G G G
	\$55.7 En	Initial	
Code	ជីខិ½ Display	Value i⊀	¥ Value v
Carrier L	FS000.0	0.0H2	
	ACC1	0010.0\$	
蹇衤	ACC2	0015.0S	
4	2ACC	0010.0S	
*	2ACC2	0015.08	
3 34	DEC1	0010.08	
*	DEC2	0015.0S	
1:03	2DEC	0010.08	
	2DEC2	0015.08	
	F-SET-SFLECT	TRM	
為為	F/R-SELECT	TRM	
2000年度	/Hz01.0	0.00	
M	(m 0.0A	0.0%	na
9	V-boost code	<11>	
3	2V-boost code	<11>	
42	V-boost F	10.0%	
1875	2V-boost F	10.0%	
	V-Gain	100%	
16.	Jogging	1.00Hz	
1 ±	Jog Mode	0	-
d P	ADJ-O	100	
ŏ	ADJ-OI	100	
22	ADJ	80	
š.,	PANEL	d01	
	TRM	LLLLLLLL	na
總器	RUN	000000H	
X	ERR1	NOTE 1	
建岩	ERROR COUNT	11012	
	ERR2	NOTE 1	
3	ERR3	NOTE 1	
£	PN-V		NOTE 2
3.	BRO ON	0%	
1	E-Thermal	0%	
	IO F780		NOTE 2
1	CO D001		NOTE 2
1.75		B3C02119	
F 2 2 2 2	10		
f	CO	B3B02120	
50 60 m	040000000000000		NOTE 2
, °	1400000000000000	00	NOTE 2

	Function Mode						
ode	Display	Value	Set Value	Code	Rolling Co.	No.	Set Value
-0015	F-BASE	060Hz		F-115	SPD FS	000.0Hz	
	2F-BASE	060Hz			SPD 2FS	000.0Hz	
01%	F-MAX	060Hz		1	SPD 1	000.0Hz	
	2F-MAX	060Hz		130	SPD 2	000.0Hz	
	Fmin	0.50Hz		1189	SPD 3	000.0Hz	
	AVR AC	NOTE 3			SPD 4	000.0Hz	
- 40	AVR MODE	DOFF		ITTIES	SPD 5	000.0Hz	
043	CONTROL	VC		144	SPD 6	000.0Hz	
	2CONTROL	VC		130	SPD 7	000.0Hz	
្រកទ	AUX AUTO	NOR		15.3	SPD 8	000.0Hz	
	AUX DATA	NOR		鐵鐵	SPD 9	000.0Hz	
33	2AUX DATA	NOR		100	SPD 10	000.0Hz	•
经过	AUX K	NOTE 4		130	SPD 11	000.0Hz	
	2AUX K	NOTE 4		操程	SPD 10 SPD 11 SPD 12	000.0Hz	
	AUX P	4P			SPD 13	000.0Hz	
经上	2AUX P	4P			SPD 14	000.0Hz	•
VS.	AUX R1	NOTE 5				000.0Hz	· · · ·
沙豆	2AUX R1	NOTE 5			0.00.0141	OFF	
4	AUX R2	NOTE 5		200	DC8 F	00.5Hz	
71	2AUX R2	NOTE 5	-		DCB WAIT	0.0s	
	AUX L	NOTE 5		180	DCB V	000	
挪	2AUX I	NOTE 5	-		DCB T	00.08	
2	AUX IO	NOTE 5			BRD-%ED	0.00%	
93	AUX IO 2AUX IO AUX J 2AUX J	NOTE 5		5-22 s	IPS UVTIME	01.0s	
	AUX J	NOTE 5			IPS WAIT	001.0s	
子多	2AUX J	NOTE 5			IPS POWR	ALM	
188	AUX Kp	20		F-23%	E-THM CHAR	CRT	
***	2AUX Kp	20			2E-THM CHAR	CRT	1
1	AUX KCD	100%		松	E-THM LVL	NOTE 6	
	2AUX KCD	100%			2E-THM LVL	NOTE 6	
Desi	ACC1	0010.08			OLOAD LVL	NOTE 7	
3	2ACC1	0010.0\$		18	OLOAD CONST	01.0	
	ACC CHG	TM			OLOAD MODE	ON	
40.00	2ACC CHG	TM			S-LOCK	MD1	
i, E.	ACC 2	0015.03			LIMIT L	000.0Hz	
1	2ACC 2	0015.05			LIMIT H	000.0Hz	
3.5	ACC CHFr	000.0Hz		3274	JUMP F1	000.0Hz	
	2ACC CHFr	000.0Hz			JUMP F2	000.0Hz	
	ACC LINE	L			JUMP F3	000.0Hz	
07.90		0010.05	1		JUMP W1	00.5Hz	1
*	2DEC 1	0010.05		建一场	JUMP W2	00.5Hz	
46	DEC 2	0015.08			JUMP W3	00.5Hz	
	2DEC 2	0015.08		F-28質	STOP-SW	ON	
		000.0Hz			IN EXS	000.0Hz	
	2DEC CHFr	000.0Hz			IN EXE	000.0Hz	
C.UL	DECLINE	1 1	-		IN EX%S	000%	
109	RUN FRS RUN STP	ZST			IN EX%E	100%	
	RUN STP	DEC		1	IN LEVEL	OHz	
	j	, ,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,		120000	IN F-SAMP	8	1

	Display	Unitial A	明治规
Code	事成 Display 添加		Set:Value
22	ARV ACC	000.0Hz	
	ARV DEC	000.0Hz	
	OV Load	NOTE 6	
	OV PID	003.0%	
34.9	IN-TM1	FW	
1	IN-TM2	RV	
	IN-TM3	AT	
	IN-TM4	USP	
	IN-TM5	2CH	
100	IN-TM6	RS	
- 30	IN-TM O/C-1	NO	
	IN-1 M O/C-2	NO	
	IN-TM O/C-3	NO	
	IN-TM O/C-4	NC	
3.1	IN-TM O/C-5	NO	
	IN-TM O/C-6	NO	
35.3	OUT-TM1	FA1	
Co.	OUT-TM2	RUN	
	OUT-TM RY	AL	İ
	OUT-TM O/C-RY	NC	
	OUT-TM O/C-1	NO	
	OUT-TM O/C-2	NO	
	CARRIER	5.0kHz	
37/A	MONITOR	A-F	
3857	INIT SEL	USA	
100	INIT DEBG	OFF	
	INIT SEL INIT DEBG INIT DOPE	FWD	
	INIT MODE	TRP	
Alan P	INIT MODE INIT FAN-CTL	OFF	
	PID SW	OFF	
4	PID P	1.0	
27	PID I	001.0s	
	PID D	0.00.0	
	PID CONV	01.00	
	PID INPT	CUR	
= (2)	V-Boost MODE	0	
	2V-Boost MODE	0	
	V-Boost code	11	
	2V-Boost code	11	
	V-Boost F	10.0%	
1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	2V-Boost F	10.0%	
	1		

NOTE 1: Error information

NOTE 2: DO NOT CHANGE. Factory use only.

NOTE 3: 230V for LFU & NFU models, 460V for HFU models.

NOTE 4: Rated kW capacity of the unit.

NOTE 5: Value varies on models

NOTE 6: Rated output current.

NOTE 7: 125% of the rated current.
NOTE 8: BOLD values can be changed.



Phone:

(604) 709-8600

Toll free phone:

1 (877) 539-2542

Fax:

(604) 872-8560

Toll free fax:

1 (800) 539-2542

Hitachi L300 Plus Series Variable Frequency Drive Software Programming (OPE)

Date: Wife	Company:	
VFD MODEL: 图 2000	Contact:	
Serial Number: 11 1		
VFD Tag:	Project:	

NOTE: Only the software parameters different from the "Initial Value" are noted.

DISPLAY	INITIAL N	SET !
CODE	VALUE	VALUE
F001	0.00Hz	
F002	30.0s	
F202	30.0s	
F003資金源	30.0s	
F203	30.0s	
F004聚聚熟	00	
A001	01	
A002党建筑	01	
A003	60Hz	
A203度認識	60Hz	
A004	60Hz	
A204	60Hz	
A005	00	
A006	00	
A011		
A012	.00Hz	
A013	0.0%	
A014	100.0%	
A015	01	
A016	8	<u></u>
<u>;</u>		
A019	00	
A020	0.00Hz	
A021算量。	0.00Hz	
A022	0.00Hz	
A023	0.00Hz	ļ
A024	0.00Hz	
A025	0.00Hz	
A026	0.00Hz	ļ
A027	0.00Hz	
A028	0.00Hz	
A029	0.00Hz	
A03 0支票	0.00Hz	 _
A031	0.00Hz	
A032章 表现	0.00Hz	
A033階級	0.00Hz	
A034器線	0.00Hz	
A035智慧論	0.00Hz	

DISPLAY	KINITIAL	SET.
総CODE協	総VALUE	WVALUE
A038		
A039	00	
A041	00	_
A241計算記	00	
A0421数量品	1.0	
A242	1.0	
A0431	5.0	
A243	5.0	
A044 3	00	
A244 字 家和	00	
A045是建設	100	
A051	00	
A052	0.50Hz	
A053	0.0s	
A054	0%	
A055	0.0s	
A056	01	
A057	0%	
A058	0.0s	
A059 :	3.0kHz	
A061	0.00Hz	
A261	0.00Hz	
A062	0.00Hz	
A262	0.00Hz	
A063	0.00Hz	
A064	0.50Hz	
A065	0.00Hz	
A066	0.50Hz	
A067	0.00Hz	
A068	0.50Hz	
A069國際開	0.00Hz	

DISPLAY	INITIAL	SET S
CODE	AVALUE	VALUE
A070a 5 24	0.0s	" '
A071	00	
A072	1.0	
A073	1.0s	
A074	0.00s	
A075复数	1.00%	
A076	00	
A0818822	02	
A082	NOTE 1	
A092	15.00s	
A2921	15.00s	
A093	15.00s	
A293	15.00s	
A094	00	
A294	00	
A095	0.00Hz	
A295	0.00Hz	
A096	0.00Hz	
A296).	0.00Hz	
A09/A	00	
A098	00	
A1015 * 12	0.00Hz	· .
A102	0.00Hz	
A103	20%	
A104	100%	
A105E	01	
Atlanta	0.00Hz	
A112 E	0.00Hz	
XXX38808	-100%	
A11(4)	100%	
AVEIL E	02	
A THE PARTY OF THE		

DISPLAY	INITIAL VALUE	SET VALUE
b001 % 数率	00	
b002	1.0s	
b003號	1.0s	
b004	00	_
b005閱题。	00	
b006編纂	00	
b007@	0.00Hz	

b012問題影	NOTE 2	
b212學學。	NOTE 2	
b0135	01	
b213	01	
b015	0Hz	
b016等还能:	0.0A	
b017 5 000000000000000000000000000000000000	0Hz	
b018 開報	0.0A	
b019第8年	0Hz	
b020 接近 了	0.0A	
b021	01	
b022表现。	NOTE 3	
b0231	1.00s	
b024-超過	01	
b025 经数 管	NOTE 3	
b026 编译:	1.00s	,

b031 d 数字	01	
b034 🗱 🚶	0hr	
b035	00	
b036	06	
ს037点键 注	00	

b081	150	
5082 (基)	0.50Hz	
b083 编版	3.0kHz	
b084	00	
b085	02	
b086	1.0	
b087	00	
b088 🎉 🚱	00	

DISPLAY/	NITIAL VALUE	SET
C001层冷凝体	18	
C002掛短線	16	
C003斯勒塔	13	
C004章 為提	02	
C005際線等	01	

C0112次设	00	
C012	00	
C013EP线线	01	
C0143 ASS	00	
C015緊急	00	
C019数字数	00	

C021是學文法	01	
C022逐凝	00	
C026	05	
C027语证学	00	
C028连续	00	
C02958	00	

C031學學學	00	
C032	00	
C036端海湖	01	

C040	01	
C041采证器	NOTE 2	
C042是398	0.00Hz	
C043[新葉基	0.00Hz	Ι
C04492	3.0Hz	

C061 23 3	6 0 %	
C070	02	
C07/15/20	04	
C072	1	
C073	7	
C074	00	1
C075	1	
C078	0ms	1

DISPLAY	MINITALY	SET
於CODE總	数VALUE约	経VALUE時
C081情级设置	NOTE 6	
C082	NOTE 6	
C08372	NOTE 6	
C085	105	
C086资度到	0.0V	
C08745533	50	
C088	NOTE 6	

C91型配置	00	
C10174 & 1	00	
C102)	00	
C103号基础	00	
C121時深鏡	NOTE 6	na
C122	NOTE 6	na
C123高速	NOTE 6	na

H003些建設	NOTE 5	
H203	NOTE 5	
H004	4	
H204	4	
出006变态器	100	
H206 5	100	I -

P001	00	<u> </u>
P002E05	00	l
世001建設等	no	
U002	no	
U003 器超速	no	
U004	по	
U005	no	
山006厘压变型	no	
0007歲營營	no	
世008建設	no	
U009K	no	
U010	no	,
DOM BACK	no	
D012	ПO	

: NOTE 1: 230 for LFU 8 NFU, 460 for HFU.

: NOTE 2: Rated current of the VFD.

NOTE3: 125% of rated current of the VFD.

NOTE 4: Value varies on model*.

NOTE 5: RatedkW capacity Of the VFD.

NOTE 6: DO NOT CHANGE. Factory use only.

NOTE 7: 360 for LFU, 720 for HFU

